



CENTRAL AIR CONDITIONER WITH ELECTRONIC CONTROL

SPLIT SYSTEM
SERIES CD DCI



INSTALLATION INSTRUCTION

Getting started...

REQUIRED TOOLS LIST

- | | | |
|--|------------------------------------|--------------------|
| 1. Screw driver | 8. Gas leak detector | 15. Torque wrench |
| 2. Electric drill,
hole core drill (60 mm) | 9. Measuring tape | 18 N m (1.8 kgf.m) |
| 3. Hexagonal wrench | 10. Thermometer | 45 N m (4.5 kgf.m) |
| 4. Spanner | 11. Megameter | 65 N m (6.5 kgf.m) |
| 5. Pipe cutter | 12. Multimeter | 75 N m (7.5 kgf.m) |
| 6. Reamer | 13. Vacuum pump | 85 N m (8.5 kgf.m) |
| 7. Knife | 14. Gauge manifold
(for R-410A) | |

ATTENTION

- Selection of the units location.
Select a location which is rigid and strong enough to support or hold the unit, and select a location for easy maintenance.
- Do not release refrigerant during piping work for installation, reinstallation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.
- Installation work. It may need two people to carry out the installation work.
- Do not install this appliance in a laundry room or other location where water may drip from the ceiling, etc.

SAFETY PRECAUTIONS

Read the following 'SAFETY PRECAUTIONS' carefully before installation. Electrical work must be installed by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model to be installed.

The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.

Carry out test running to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

The items to be followed are classified by the symbols:



WARNING
This indication shows the possibility of causing death or serious injury.



Symbol with background white denotes item that is **PROHIBITED** from doing.







WARNING

- Use qualified installer and follow careful this instructions, otherwise it will cause electrical shock, water leakage, or aesthetic problem.
- Install at a strong and firm location which is able to withstand the set's weight. If the strength is not enough or installation is not properly done, the set will drop and cause injury.
- For electrical work, follow the local national wiring standard, regulation and this installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough it will cause electrical shock or fire.
- Use the specified cable and connecting tightly for indoor/outdoor connection. Connect tightly and clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat-up or fire at the connection.
- Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause heat-up at connection point of terminal, fire or electrical shock.
- Before obtaining access to terminals, all supply circuits must be disconnected.
- When carrying out piping connection, take care not to let air substance other than the specified refrigerant go into refrigeration cycle, otherwise, it will cause lower capacity, abnormal high pressure in the refrigeration cycle, explosion or injury.
- Do not damage or use unspecified power supply cord. Otherwise, it will cause fire or electrical shock.
- Do not modify the length of the power supply cord or use of the extension cord, and do not share the single outlet with other electrical appliances. Otherwise, it will cause fire or electrical shock.
- This equipment must be earthed. It may cause electrical shock if grounding is not perfect.
- Do not install the unit at place where leakage of flammable gas may occur. In case of leaks and accumulates at surrounding of the unit, it may cause fire.
- Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.
- If supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Contents:

Installation/Service Tooling	3
Attached Accessories	
General information	4
General precautions	5
Drainage installation	
Indoor unit	6
Access to the unit	
Unit installation	
Outdoor unit	7
Unit dimensions	
Several outdoor installation	
Disposal of outdoor unit	

Pipes connections	8
Cutting and flaring	
Pipe insulation	
Pipe connections to unit	
Evacuation of pipes and indoor unit	
Electrical connections	9
Display Control Unit	11
Additional options	12
Check list before operation	15
Care and maintenance	
Air volume/static pressure table	
Air filter access	16

Installation/Service Tooling for R410A	Changes
Gauge manifold 	As the working pressure is high, it is impossible to measure the working pressure using conventional gauges. In order to prevent any other refrigerant from being charged, the port diameters have been changed.
Charge hose 	In order to increase pressure resisting strength, hose materials and port sizes have been changed (to 1/2 UNF 20 threads per inch). When purchasing a charge hose, be sure to confirm the port size.
Electronic scale for refrigerant charging 	As working pressure is high and gasification speed is fast, it is difficult to read the indicated value by means of charging cylinder, as air bubbles occur.
Torque wrench (nominal dia. 1/2, 5/8) 	The size of opposing flare nuts have been increased. Incidentally, a common wrench is used for nominal diameters 1/4 and 3/8.
Flare tool (clutch type) 	By increasing the clamp bar's receiving hole size, strength of spring in the tool has been improved.
Gauge for projection adjustment	Used when flare is made by conventional flare tool.
Vacuum pump adapter & check valve	Connected to a conventional vacuum pump. It is necessary to use an adapter to prevent vacuum pump oil from flowing back into the charge hose. The charge hose connecting part has two ports -- one for conventional refrigerant (7/16 UNF 20 threads per inch) and one for R410A. If the vacuum pump oil (mineral) mixes with R410A a sludge may occur and damage the equipment.
Gas leakage detector 	Exclusive for HFC refrigerant.











Incidentally, the "refrigerant cylinder" comes with the refrigerant designation (R410A) and protector coating in the U.S.'s ARI specified rose colour (ARI colour code: PMS 507). Also, the "charge port and packing for refrigerant cylinder" requires 1/2 UNF 20 threads per inch corresponding to the charge hose's port size.

CAUTION R410A Air Conditioner Installation

THIS AIR CONDITIONER ADOPTS THE NEW HFC REFRIGERANT (R410A) WHICH DOES NOT DESTROY OZONE LAYER. R410A refrigerant is apt to be affected by impurities such as water, oxidizing membrane, and oils because the working pressure of R410A refrigerant is approx. 1.6 times of refrigerant R22. Accompanied with the adoption of the new refrigerant, the refrigeration machine oil has also been changed. Therefore, during installation work, be sure that water, dust, former refrigerant, or refrigeration machine oil does not enter into the new type refrigerant R410A air conditioner circuit. To prevent mixing of refrigerant or refrigerating machine oil, the sizes of connecting sections of charging port on main unit and installation tools are different from those used for the conventional refrigerant units. Accordingly, special tools are required for the new refrigerant (R410A) units. For connecting pipes, use new and clean piping materials with high pressure fittings made for R410A only.

Moreover, do not use the existing piping because there are some problems with pressure fittings and possible impurities in existing piping.

ATTACHED ACCESSORIES

Description	Amount	Name
	1	Technician's installation manual
	1	Instruction manual for remote control
	1	Instruction manual for unit display
	1	Remote control including batteries
	1	Remote control bracket
	1	Central control display
	4	Rubber mounting pads
	4	Tie - Wraps
	4each	Dibbles - Screws - Washers
	1	Drain elbow

Do not vent R410A into atmosphere. R410a is a fluorinated greenhouse gas, covered by Kyoto Protocol, with a global warming potential (GWP) = 1725.

Changes in the product and components

In air conditioners using R410A, in order to prevent any other refrigerant from being accidentally charged, the service port diameter size of the outdoor unit control valve (3 way valve) has been changed. (1/2 UNF 20 threads per inch).

In order to increase the pressure resisting strength of the refrigerant piping, flare processing diameter and opposing flare nuts sizes have been changed. (for copper pipes with nominal dimensions 1/2 and 5/8).


In case of pipes welding please make sure to use dry Nitrogen inside the pipes.

Use copper tube of spcial thickness for R410A: 1/4"-1/2" 0.8 mm
5/8"-3/4" 1 mm
7/8" 1.1 mm


USE
Installation instructions
Operation instructions for remote
Operation instructions
Operating the air-conditioner
Hanging the remote control on the wall
Operating and main working display
Padding of the outdoor unit
Tightening the indoor and the outdoor units electrical cables
Installing bracket for remote control and central control display
Connecting drain hose to outdoor

GENERAL INFORMATION

Indoor Unit



Outdoor Unit




MAXIMUM PIPES LENGTH & HEIGHT

NOMINAL CAPACITY	TUBES O.D	LENGTH (A)	HEIGHT (B)
14.0kW	3/8" - 3/4"	70m	30m


EXTERNAL STATIC PRESSURE

NOMINAL CAPACITY	NOMINAL	MIN - MAX
14.0kW	140 Pa	140 - 200 Pa



The indoor unit can be installed also below the outdoor unit.

GENERAL PRECAUTIONS




Always use the support of a large radius cylinder for bending the tubes using pipe bending tools.




Do not leave nuts of gas tube uncovered.




Do not untie gas tubes after installation.




Avoid placing the indoor unit near water or oily mist.



Avoid pipes bending and keep pipes as short as possible.




Oil trap for units up to 5kW.
In case the outdoor unit is under the indoor unit no trap is required.



For assuring a correct operation of the draining system, pay attention to the following points:

- Draining tubes should be slanted down at an angle of at least 2° . Up slanting should be avoided to prevent liquid back-flow.
- Use always 19 mm diameter tube for draining.
- Making of a water trap (Siphon) will prevent bad odors and assure proper drainage.




Tighten electrical circuits cables.

UNIT LOCATION

While selecting a place for the indoor unit:

- Allow max. air flow to the desired space
- Allow max return air flow
- Ensure adequate drainage of condensed water
- Ensure noise reduction near bedrooms
- Leave a minimum 250 mm free space in front of the filter
- Allow a free service access to electrical box.
- Allow easy access to the base of the indoor unit while providing enough space from the ceiling
- Use serrated rubber under the unit and flexible joints to avoid resonance vibrations


UNIT DIMENSION




CLEARANCE AROUND THE UNIT

SERVICE ACCESS FROM THE BOTTOM OF THE UNIT

* For right units, switch between both dimensions.



UNIT INSTALLATION




- Insert 4 M10 or 3/8" threads rods into the ceiling.
- Introduce the rods through the slots of unit suspension brackets.
- Position the shock absorbers, add washers and screw the nuts until the unit is firmly supported.
- In case of a gap between the unit and the ceiling, put a rubber or a neoprene sheet.

IMPORTANT! The unit must be perfectly levelled.


OUTDOOR UNIT

UNIT DIMENSIONS



NOMINAL CAPACITY	A	B	C	D	E	F
14.0 kW	1250	900	705	97	340	357


CLEARANCES AROUND THE UNIT




SEVERAL OUTDOORS INSTALLATION

When installing several outdoors units please take into account the air flow around the units and follow the minimum distance suggestions as shown in the diagrams below.


Row Installation



Back to Back Front to Front



Front to Back




DISPOSAL OF OUTDOOR UNIT DRAIN WATER

In case of using a drain elbow, the unit should be placed on a stand at least 3 cm high.

Install the hose with a downward to allow smooth flow of draining water.


Use 16mm I.D. tube for drainage.



PIPES CONNECTIONS


CUTTING AND FLARING THE PIPES

1. Please use the pipe cutter for cutting the pipes.
2. Remove all burrs by using reamer. Gas leakage might happen if burrs are not removed!
Turn pipe edge down to avoid metal powder from entering down the pipes.
3. After inserting the flare nut into the copper pipes, please make a flare.



PIPE INSULATION

1. Please carry out insulation at pipe connection portion as mentioned in Indoor/ Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.
2. If drain hose or connecting pipes is in the room (where dew may form). Please increase the insulation by using POLY-E FOAM with thickness of 9 mm or more.




PIPES CONNECTIONS TO THE UNIT

Connecting to the indoor unit

1. Align the center of the pipes and finger tight the flare nut.
2. Use the torque wrench to tighten the nut firmly.

Connecting to the outdoor unit

1. Align the center of the pipes to the valves.
2. Use the torque wrench to tighten the valves firmly according to table:




Torque(N.m)	1/4	3/8	1/2	5/8	3/4
Flare Nuts	13-18	40-45	60-65	70-75	80-85
Valve Cap	13-20	13-20	18-25	18-25	40-50
Service Port Cap	11-13	11-13	11-13	11-13	11-13

EVACUATION OF PIPES AND INDOOR UNIT

After connection the unions of the indoor and outdoor units, evacuate the air from the tubes and from the indoor unit as the follow

1. Connect the charging hoses with a push pin to the low and high sides of the charging set and the service port of the suction and liquid valves. Be sure to connect the end of the charging hose with the push pin to the service port.
2. Connect the center hose of the charging set to a vacuum pump.
3. Turn on the power switch of the vacuum pump and make sure that the needle in the gauge moves from OMPa (0cm Hg) to - 0.1 MPa (-76cm Hg). Let the pump run for fifteen minutes.
4. Close the valves of both the low and high sides of the charging set and turn off the vacuum pump. Note that the needle in the gauge should not move after approximately five minutes.
5. Disconnect the charging hose from the vacuum pump and from the service ports of the suction and liquid valves.
6. Tighten the service port caps from both valves, and open them using a hexagonal Allen wrench.
7. Remove the valve caps from both valves, and open them using a hexagonal Allen wrench.
8. Remount valve caps onto both of the valves.
9. Check for gas leaks from the four unions and from the valve caps. Test with electronic leak detector or with a sponge immersed in soapy water for bubbles.



Sample



NOTE: For additional charge of various tubing lengths, refer to outdoor unit table.

ELECTRICAL CONNECTIONS

ELECTRICAL SPECIFICATIONS

POWER SUPPLY

230V / 50Hz / 1 PH



Electrical wiring and connections should be made by qualified electricians in accordance with local electrical codes and regulation. The air conditioner units must be grounded.

The air conditioner units must be connected to an adequate power outlet from a separate branch circuit protected by a time delay circuit breaker, as specified on unit's nameplate. Voltage should not vary beyond $\pm 10\%$ of the rated voltage.


For all power supply connections to the outdoor unit, also for the connecting cable between indoor and outdoor unit, only HO5RN-F (60245 IEC 57) cable is to use. For the optional power supply on the indoor unit at least HO5VV-F (60227 IEC 53) is to use

1. Prepare the multiple wire cable ends for connection.
2. Take away the Indoor/outdoor cover and open the terminals, take away the cable clamp screw and turn over the cable clamp.
3. Connect the cable ends to the terminals of the indoor and outdoor units.
4. Connect the other end of the twin wire cable to the outdoor unit twin wire terminal.
5. Secure the multiple wire power cable with the cable clamps.
6. The cable between controller and indoor unit shall be fixed accordingly to local electrical requirements.

NOMINAL CAPACITY	CIRCUIT BREAKER	POWER SUPPLY CABLE	POWER SUPPLY SIDE
14.0 kW	32A	3x6mm ²	TO OUTDOOR UNIT




1PH Units Power supply to outdoor and indoor units



1. Indoor Unit
2. Power Supply Cable
3. Main Power Breaker
4. Outdoor Unit
5. Interconnecting Cable (2x0.75 mm²)**
6. Wireless Remote Control
7. Display Unit

1PH Units Power supply to outdoor unit



8. Display Connector
 9. Control Cable **
 10. Sensor Wire with Connector
 11. Room Temperature Sensor
 12. Power Interconnecting Cable (3x1.5 mm²)**
 13. Power Breaker (*by installer)
- } Optional

* The Power Breaker must be of type that disconnect all poles with 3 mm contact opening.

** Use shielded cable and connect the shield to earth point for indoor unit only.

ELECTRICAL CONNECTION

Room Thermostat Installation Instructions (Optional)


Before starting the connection verify that the unit is disconnected from mainpower supply!!

Supplied components list:

#	Item	QTY
1	Thermostat box	1
2	Shielded cable	1
3	Screws	2
4	Plugs	2
5	Extension cable with connector	1

Choosing location of installation:

- Away from air drafts
- Away from direct sun light rays
- Average height – 1.5 meters above floor.
- Away from any heat source



1. Install the thermostat box on the wall according the above location preferences. See figure 1.
2. Connect the shielded cable supplied to the thermostat box into points 3 and 9 (non polarity).
3. Disconnect the existing "RM" sensor from the indoor unit main controller. **Note:** In cases that the thermostat kit is a factory option, no need to perform this action.
4. Connect the other end of the cable to the the indoor unit main controller using the "RM" extension cable.
5. Connect the grounding fork terminal into the grounding terminal point. Check electrical scheme.
6. **Connect Earth at indoor unit only.**
7. In the indoor unit main controller, move the dip switch #2 to OFF position (DCI units only).

DISPLAY CONTROL UNIT

LOCATION CRITERIA

It is recommended to install the Display Control Unit close to a ceiling in a central and neutral zone at typical conditions. In addition, the aesthetic aspect should be considered. The Display Control Unit is connected to the main control board on the air conditioner (the indoor unit) by a communication cable. The cable is connected to the Display Control Unit by a quick-connector. (8 pin plug)

INSTALLATION OF DISPLAY CONTROL UNIT ON WALL

Drill a 12 mm diameter hole on the wall, for routing the communication cable

Open the unit cover, drill 3 holes in the wall to match the holes in the Display Control Unit, install the inserts and fasten the unit to the wall with 3 screws.

The Display Control Unit is provided of a special communication cable, 7 meters long, terminated by a plug, connected in the housing itself to a distribution box, which enables the control of the air conditioner from several different rooms, each one from its own Display Control Unit.

Connect the quick connector to the appropriate socket on the main control board in the indoor unit electrical box.




WARNING

The plug should not be cut off the communication cable if the cable length is insufficient. In such case, a 5-meter extension cable may be added.


CONSIDERATIONS IN LOCATING THE REMOTE CONTROL UNIT

- Locate the Remote Control Unit in such a way that when mounted on its support on the wall, it will be in line sight with the Display Control Unit (at less than 8 m).
- It is recommended to establish the final location of the Remote Control Unit only after the first operation, assuring proper transmission and reception between the Remote Control Unit and the Display Control Unit.



COLOR CHART

Conn. Point	Wire Color
1	Gold
2	Green
3	Black
4	Brown
5	Purple
6	Yellow
7	Orange
8	Red



Connection of several Displays in parallel units

- Main Control Board on Indoor Unit.
- Distribution Board, Cat N. 402729
- Communication cable Cat. N. 404020
- Display Control Unit Cat. N. 438778

ADDITIONAL OPTIONS FOR 4-6HP (10-14kW) DCI UNITS ONLY

1. FEATURES SETUP

1.1. DISPLAY BOARD GENERAL DESCRIPTION


The display board serves as interface between the installer/technician and the A/C unit.

Buttons description:

Up & Down - used to scroll between options (up and down)


Select - used to select an option

Escape - Will go up one level in the menu



1.2. SET-UP

There are 2 types of current limitation for the maximum current drawn by the outdoor unit, one is to set maximum limit to the current and the other is to set power shedding limit. For both actions follow the below described procedure.



1. Scroll down the "Down" button until setup is displayed (Set) and then press the "Select" button.
2. Scroll down the "Down" button to choose the option required and press the "Select" button.

Mode (Cl/Ht/Sb)		
Technician Test (tt)		
	-	Technician Test Cool (ttC)
	-	Technician Test Heat (ttH)
Diagnostics (dla)		
	-	Outdoor Unit (Odu)
	-	Indoor Unit (Idu)
Set Up (Set)		
	-	Indoor Unit Supply (IdSU)
	-	Max Current Limit (CurL)
	-	Power Shedding (PSC)

1.2.1 Maximum Current Limit

The maximum operating current of the unit can be selected by the table in order to reduce/increase the circuit breaker value. This operation will affect the maximum capacity of the unit.

The default values are: indoor unit supplied from outdoor unit ("OUT") and the current is 30A for 12.5kW unit and 25A for 10.0 kW unit.

Enter the Set Up menu by Scrolling down to "Set" and set the indoor unit supply (IdSU) parameter to either "Out" for external power supply for Indoor unit (via Outdoor unit) or "In" for supplying the indoor unit from separate internal circuit breaker.

Escape one time and scroll to "CURL".

Enter the value corresponding the max current as per the table.

Display	Max. Current setting	Circuit breaker
30_A	30A	32A
27_A	27A	30A/32A
23_A	23A	25A
18_A	18A	20A
14_A	14A	16A

1.2.2 Power Shedding Current Limit

The maximum operating current of the unit can be limited by setting the unit into power shedding mode which will control the unit up to pre-defined current percentage (out the max current). This operation will reduce the maximum capacity of the unit.

ADDITIONAL OPTIONS FOR 4-6HP (10-14kW) DCI UNITS ONLY

Activation of this feature is described in the next paragraph of "Dry Contacts".

The upper limit of the power consumption (Current) can be setup by the display board according to the table.

In order for this feature to become active you must shorten the "PWS" dry contact (see below procedure).

Enter the Set Up menu by Scrolling down to "Set" and set the power shedding control ("PSC") parameter according to the table.

Display	Max. Current setting
50%	% of Max Current
60%	
70%	
80%	

1.3 FEATURE SET UP WITH DRY CONTACTS (INPUT)

The input dry contacts are used for controlling.


An external circuitry which may include a switch or a relay should be used for closing the internal circuit to indicate that some change is required.

A wire of up to 1.5mm² is recommended to be used.

Note: NO external power should be used in this case!


1.3.1 Night Mode quiet operation (Cool mode)

When "Night" dry contact is shorted, the unit will enter to a special mode and reduce the compressor and outdoor fans speed to allow quiet operation.




1.3.2 Stand-By

When "SB" dry contact is shorted, the unit will stop and go to stand by mode.



1.3.3 Power Shedding

When "PWS" dry contact is shorted, the unit will limit its maximum power consumption according to a pre defined value. This value can be changed via the display board (see above procedure).




ADDITIONAL OPTIONS FOR 4-6HP (10-14kW) DCI UNITS ONLY

1.4 FEATURE SET UP WITH DRY CONTACTS (OUTPUT)

1.4.1 Alarm

The alarm dry contacts is used to indicate a problem or any malfunction of the system.

An internal relay is used to close an external circuit which may include an external power supply. The external circuit should include some kind of a load (lightening bulb, LED, etc).



When "Alarm" dry contact is open, alarm output will be activated when there is any ODU fault or protection.

Alarm output will turn off as soon as the fault is cleared.

Output specifications: Voltage – Max 24VAC/DC

Current – Max 3.0Amp

A wire of up to 1.5mm² is recommended to be used.

1.5 ACCESSORIES SET UP

1.5.1 BASE HEATER (BH)

Base Heater is an heating element designed to melt any ice that is accumulated on the outdoor unit base during heating operation.

The unit will automatically detect the heater and operate unique operation logic to ensure operation only at freeze time.

Output specifications: Voltage – Max 240VAC

Current – Max 1.0Amp

A wire of up to 1.5mm² is recommended to be used



1.5.2 CRANCK CASE HEATER (CCH)

Crank Case Heater is an heating element designed to heat-up the compressor oil crank case during heating operation.

The unit will automatically detect the heater and operate unique operation logic to ensure operation only at freeze time.

Output specifications: Voltage – Max 240VAC

Current – Max 1.0Amp

A wire of up to 1.5mm² is recommended to be used



Note: Heaters should be orderderd and provided safety approved by the manufacturer

Check list before operation

CHECK THE DRAINAGE

Pour water into the drain tray-styrofoam.
Ensure that water flows out from drain hose of the indoor unit.

EVALUATION OF THE PERFORMANCE

Operate the unit at cooling mode and high fan speed for fifteen minutes or more.

Measure the temperature of the intake and discharge air.
Ensure the difference between the intake temperature and the discharge is more than 8 °C.

CHECK ITEMS

- | | |
|--|---|
| <input type="checkbox"/> Is there any gas leakage at flare nut connections? | <input type="checkbox"/> Is the indoor unit properly mounted to the ceiling? |
| <input type="checkbox"/> Has the heat insulation been carried out at flare nut connection? | <input type="checkbox"/> Is the power supply voltage complied with rated value? |
| <input type="checkbox"/> Is the connecting cable being fixed to terminal board firmly? | <input type="checkbox"/> Is there any abnormal sound? |
| <input type="checkbox"/> Is the connecting cable being clamped firmly? | <input type="checkbox"/> Is the cooling operation normal? |
| <input type="checkbox"/> Is the drainage OK?
(Refer to "Check the drainage" section) | <input type="checkbox"/> Is the thermostat operation normal? |
| <input type="checkbox"/> Is the earth wire connection properly done? | <input type="checkbox"/> Is the remote control's LCD operation normal? |

CARE AND MAINTENANCE



Caution!

Before any maintenance operation the unit should be disconnected from mains.

DISPLAY CLEANING

- Clean the unit with a dry, soft cloth
- Don't use warm water or solvents, in order to avoid damage to the external surfaces.

BEFORE OPERATING SEASON

- Make sure that no object obstacles return and exiting air flow, in both internal and external units.
- Make sure that the air conditioner is properly connected to mains.
- Remember that power is supplied to the external unit through the internal unit.

PROTECTION FOR THE ELECTRONIC SYSTEM

- The distance between remote control unit and any electrical appliance should be at least 1 m.

AIR VOLUME / STATIC PRESSURE


Static pr. (Pa)	80	90	100	110	120	130	140	150	160	170	180	190	200
Air Volume	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr	M ³ /Hr
High							3265	3170	3075	2993	2910	2835	2760
Med					3070	2978	2885	2835	2785	2670	2555		
Low	2430	2368	2305	2228	2150								

Non working range area

AIR FILTER ACCESS

Turn off two screws and release a air filter support.

Pull down the air filter for further treatment.



Caution!

The Air Conditioner should not be activated without air filters mounted in place!