

REMOTE CONTROL MANUAL



CONTENT

PRECAUTIONS1-2

USING THE REMOTE CONTROL UNIT3

OPERATION4-8



**Thank you for
purchasing our
Room Air Conditioner.**

Before using your air-conditioner, please read this operating instruction carefully and keep it for future reference.

PRECAUTIONS

DISPLAY

Information are displayed when the remote control unit is switched on.

Operation Mode



Automatic Heating Cooling

Fan only Dehumidification (dry)

Displayed when data transmitted Or remote control unit lock



Shows the type of timer Clock (hours and minutes)

Displayed when the timer on is set and activated

Displayed when the timer off is set and activated

Displayed in Sleep Mode Operation



Display in Fresh air mode operation

Display in ionizer & E.S.F mode operation

Set temperature or room temperature

Displayed when the temperature is the room temperature

Indicate that the air conditioner is operating in I FEEL mode



Automatic horizontal air flow oscillation switched on

Automatic supply air flap oscillation switched on

Fan speed indication

Automatic fan speed

Strong speed

Low speed

Medium speed

High speed

ON/OFF OPERATION BUTTON

This button turns the air conditioner ON and OFF.

MODE SELECTOR BUTTON

Press this button to modify the air conditioner mode.

(automatic) ★

When this setting is selected, the air conditioner calculates the difference between the thermostat setting and the room temperature and automatically switches to the "cool" or "heat" mode.

(heating)

The air conditioner makes the room warmer.

dehumidification (dry)

The air conditioner reduces the humidity in the room.

(cooling)

The air conditioner makes the room cooler.

(fan)

The air conditioner circulate the air.

★ **COOL / DRY / HEAT / FAN Models**


IONIZER & E.S.F AND FRESH-AIR BUTTON

Push button to select Ionizer & E.S.F and Fresh air function.

I FEEL TEMPERATURE SENSING AND ROOM TEMPERATURE DISPLAY BUTTON

Push this button to activate the temperature control in the remote control until and show the actual room temperature around the remote control.


TRANSMITTER





When you press the buttons of the remote control unit, the  mark appears on the display to transmit the setting changes to the receiver in the air conditioner.

SENSOR

A temperature sensor inside the remote control unit detects the room temperature.

FAN SPEED SELECTOR BUTTON

 Fan speed is automatically selected by the microcomputer.

- | | |
|---|--|
|  Low speed. |  Strong speed |
|  Medium speed. |  High speed. |

TEMPERATURE SETTING BUTTONS

- (**cooler**) Press this button to decrease the set temperature.

+ (**warmer**) Press this button to increase the set temperature.

SET BUTTON

Push this button to select the functions:

- set the present time
- set the ON-OFF timer

For detail see "HOW TO SET THE PRESENT TIME" and "SETTING THE TIMER".

TIMER BUTTON (timer setting)

Push the TIMER on the display starts the timer ON and OFF setting procedure. For detail see "SETTING THE TIMER".



TIMER AND PRESENT TIME SETTING BUTTONS

Pushing + or - buttons the setting of the time and timer can be activated. For detail see "HOW TO SET THE PRESENT TIME" and "SETTING THE TIMER".

TIMER RESET

Push the CLEAR button to cancel all timer setting.

LOCKING THE REMOTE CONTROL

Pushing this button freezes the last operation setting. When  is activated the remote control will not be able to control the air conditioner. To release the lock status push  again.


HORIZONTAL SWING BUTTON

Push button to activate the horizontal Air Flow to auto swing.

VERTICAL SWING BUTTON

Push button to activate the supply air flap to auto swing.

SLEEP BUTTON

For details, see "Sleep mode". When you press this button in the COOL, HEAT or DRY mode, the mark  appears on the display and the microcomputer in the remote control unit will adjust the set temperature to save energy.

USING THE REMOTE CONTROL UNIT

HOW TO INSTALL BATTERIES

- Remove the lid in the rear part of the remote control unit.
- Insert two AAA alkaline batteries of 1,5 V-DC. Make sure the batteries point in the direction marked in the battery compartment.
- The batteries last about six months. Depending on how much you use the remote control unit. Remove the batteries if you do not use the remote control unit for more than one month. Press the +, -, SET and CLEAR buttons together after batteries replacement. (This operation allows you to reset correctly all the programs. The remote control unit is to be set up again).
Replace the batteries when the remote control unit lamp fails to light, or when the air conditioner does not receive the remote control unit signals.
- The batteries of the remote control contain polluted substances exhausted batteries must be disposed according to the laws in force.

OPERATION WITH THE REMOTE CONTROL UNIT



Check that the circuit breaker on the power panel is turned ON and the STANDBY lamp is light up. When using the remote control unit, always point the unit transmitter head directly at the air conditioner receiver.

HOW TO TURN ON THE AIR CONDITIONER


Press the ON/OFF button to turn the air conditioner on. The indicator OPERATION will light up, indicating the unit is in operation.

TEMPERATURE SENSOR SELECTOR

- Under normal conditions the room temperature is detected and checked by the temperature sensor placed in the air conditioner.
- Press the remote control I FEEL button to activate the temperature sensor placed in the remote control. This function is designed to provide a personalised environment by transmitting the temperature control command from the location next to you. Therefore, in using this function, the remote control should always be aimed, without obstruction, at the air conditioner.

NOTE

The remote control unit sends the temperature signal to the air conditioner regularly at two minute intervals. If the signal from he remote control unit stops for more than five minutes due to some troubles, the air conditioner will switch to the temperature ensor which is built into the indoor unit and controls the room temperature. In these cases, the temperature around the remote control unit may differ from the temperature detected in the air conditioner position.



REMOTE CONTROL UNIT DISPLAY


OPERATION


HOW TO SET THE PRESENT TIME

1. Press the SET button for five seconds. The time indication alone flashes.
2. Press the + or - buttons until the present time is displayed.
3. Press the SET button to stop the indication flashing.

COOLING



Verify that the unit is connected to the main power and the STANDBY lamp is light up.

1. Set the MODE selector to COOL .
2. Press the ON/OFF button and switch the air conditioner ON.
3. Press the TEMP. buttons to set the desired temperature (the temperature range is between 30°C max. and 16°C min.).




23°C

THE DISPLAY SHOWS THE
SELECTED TEMPERATURE.



4. Press the FAN SPEED button to select the fan speed.
5. Press Button  to activate the supply air flap to auto swing
Press button  to activate the horizontal air flow to auto swing. Press the two button again, the flap stops immediately.

HEATING

1. Set the MODE selector to HEAT .
2. Press the ON/OFF button and switch the air conditioner ON.
3. Press the TEMP. buttons to set the desired temperature (the temperature range is between 30 °C max. and 16 °C min.).

23°C

THE DISPLAY SHOWS THE
SELECTED TEMPERATURE.

4. Press the FAN SPEED button to select the fan speed.
5. Press Button  to activate the supply air flap to auto swing
Press button  to activate the horizontal air flow to auto swing. Press the two button again, the flap stops immediately.

NOTE

For several minutes after the start of heating operation, the indoor fan will not run until the indoor heat exchanger coil has warmed up sufficiently. This is because the COLD DRAFT PREVENTION SYSTEM is operating.

• DEFROSTING OF HEAT EXCHANGE OUT DOOR UNIT "STANDBY"


When the outdoor temperature is low, frost or ice may appear on the heat exchanger coil, reducing the heating performance. When this happens, a microcomputer defrosting system operates. At the same time, the fan in the indoor unit stops and the OPERATION lamp is flashing until defrosting is completed. Heating operation restarts after several minutes. (This interval will vary slightly depending on the room and outdoor temperature).

• HEATING PERFORMANCE

A heat pump conditioner heats a room by taking heat from outside air. The heating efficiency will fall off when the outdoor temperature is very low. If enough heat is not obtained with this air conditioner, use another heating appliance in conjunction with it.

OPERATION

AUTOMATIC OPERATION


1. Set the MODE selector to AUTO .
2. Press the ON/OFF button and switch the air conditioner ON.
3. Press the TEMP. buttons to set the desired temperature (the temperature range is between 30 °C max. and 16 °C min.).


23°C

THE DISPLAY SHOWS THE SELECTED TEMPERATURE.

When this setting is selected, the air conditioner calculates the difference between the thermostat setting and the room temperature and automatically switches to the COOL or HEAT mode as appropriate.

4. Switch the FAN SPEED selector button to the setting you want.

Example of operation diagram in the  (Auto) mode with the set room temperature at 23°C.




NOTE

The air conditioner changes the operation mode (from cool to heat), if one of the following conditions occurs:

- **ZONE A:** changes if the difference between the room temperature and the temperature set on the remote control unit is at least 3°C..
- **ZONE B:** changes if the difference between the room temperature and the temperature set on the remote control unit is at least 1°C, one hour after the compressor stop.
- **ZONE C:** never changes if the difference between the room temperature and the temperature set on the remote control unit is no more than 1°C.

DEHUMIDIFYING (DRY)

1. Set the MODE selector switch to "DRY" .
2. Press the ON/OFF button and switch the air conditioner ON.
3. Press the TEMP. buttons to set the desired temperature (the temperature range is between 30 °C max. and 16 °C min.).

23°C


THE DISPLAY SHOWS THE SELECTED TEMPERATURE.

NOTE

- Use DRY operation when you want to reduce the humidity in the room.
- Once the room temperature reaches the set level, the unit repeats the cycle of turning on and off automatically.
- During DRY operation, the fan speed is automatically set to low or stops to prevent overcooling.
- Dry operation is not possible if the indoor temperature is 15 °C or less.

FAN ONLY

If you want to make air circulate without any temperature control, follow these steps:

1. Set the MODE selector switch to "FAN" .
2. Press the ON/OFF button and switch the air conditioner ON.

OPERATION

ADJUSTING THE FAN SPEED

• AUTOMATIC

Simply set the FAN SPEED selector to the **AUTO** position. A microcomputer automatically controls the fan speed when the AUTO mode is selected. When the air conditioner starts operating, the difference between the room temperature and the set temperature is detected by the microcomputer which then automatically switches the fan speed to the most suitable level.

NOTE

In FAN Only mode the fan speed is adjusted automatically as in cooling mode.

WHEN DIFFERENCE BETWEEN ROOM TEMPERATURE AND SET TEMPERATURE IS		FAN SPEED
Cooling and dehumidifying modes:	2 °C and over	High
	Between 2 and 1 °C	Medium
	Below 1 °C	Low
Heating mode:	2 °C and over	High
	Below 2 °C	Medium

The above mentioned data make reference to the conditioner operating when the sensor on the remote control unit is ON. If the sensor on the indoor unit is being used then actual operation will slightly differ from that described in the above tables.

• MANUAL

If you want to manually adjust speed just set the FAN SPEED selector as desired.

Each time the button is pressed, the fan speed is changed in sequence:

(Lo) → (Med) → (Hi) → (Strong) → (AUTO)

- 1) Strong fan will only operation cooling & heating mode.
- 2) Strong fan option is selectable via switch.

SLEEP MODE

The SLEEP mode enables you to save energy.

1. Set the MODE selector to cool, dry or heat.
2. Press the SLEEP button.
3. The mark appears on the display. Press the SLEEP button again to release the SLEEP function.


What does the SLEEP mode mean?

In this mode, the air conditioner will cool or heat the room to the set temperature, and then the thermostat will make the unit pause. After about 1 hour, the air conditioner will automatically reset the set temperature as follows (also refer to graphs).


OPERATING MODE	SET TEMPERATURE CHANGE
Heating	Lowered by 1 °C
Cooling and Dehumidifying	Raised by 1 °C

When the room temperature reaches the new set value, the thermostat will cause the unit to pause. After about 1 hour the temperature will be raised by 1 °C in cooling, or lowered by 1 °C in heating. This enables you to save energy without sacrificing your comfort.

COOLING AND DEHUMIDIFYING



HEATING



OPERATION



IONIZER/FRESH AIR OPERATION (OPTIONAL)

Pressing the Ionizer / Fresh air button will cycle in the following manner:

Fresh air (continual) & Ionizer → Fresh air (continual) → Ionizer → off

Fresh air option is selectable via switch. The function will be kept when mode is switched over (E.S.F works together with Ionizer.)

I FEEL/ROOM TEMP FUNCTION OPERATION


Press button I FEEL/ROOM to activate the I FEEL function. Thermometer sign will appear on the LCD operation display . Select suitable temperature setting. Make sure that the remote control unit is aimed at the air conditioner, with the I FEEL sensor in front. Prevent the I FEEL sensor from being affected by heat sources such as lamps, heaters, direct sun, etc. or from being directly affected by the air conditioner air flow. These may cause the sensor to transmit the wrong temperature data, thereby disturbing the performance of the I FEEL function. By pressing on ROOM temperature, the measured room temperature sign will be displayed . To cancel the ROOM Temperature display press on one of the following:

- Press again on ROOM Temperature button.
- Change of MODE button.

NOTE

Room temperature range is between 6 and 36 in 1 increments. Display should show "HI" or "LO" to represent temperature that is above 36 or below 6.

LOCK FUNCTION

By pressing LOCK button, the remote control will lock the last operation program. All the function buttons will be inoperative, including START/STOP button. By pressing LOCK button again the remote control will be released from its locked position. When lock mode is functioning, the transmission sign  will be on.

SETTING THE TIMER

There are four timers that can be selected on the remote control. Two daily timers (designated as T1, T2), and two optional weekend timers (designated as WKT1, WKT2). Each timer can be selected by pressing TIMER button.

The daily timers T1 and T2 can be set for ON and OFF separately for two different time periods. Timer setting will not change until new setting is input.

The weekend timers WKT1 and WKT2 can be set for ON and OFF separately for two different time periods and they are effective two days only. These timers will be effective on the day of setting and on the day after only.

At 24:00 on the second day, the WK timer will not be effective anymore and the daily timer will be effective again.

WKT1 - effective on the setting day


WKT2 - effective one day after the setting day.

NOTE:

1. During the weekend timer operation, the daily timers will be disabled.
2. The WK timers must be reactivated before every weekend.

A) HOW TO SET THE ON TIME

1. Press the TIMER button to select the desired timer.
2. Press the SET button till the ON sign blinks.
3. Press the + or - (HOUR) button until the desired value is displayed.
4. Press the SET button to activate the timer.



OPERATION

B) HOW TO SET THE OFF TIME

1. Press the TIMER button to select the desired timer.
2. Press the SET button till the OFF sign blinks.
3. Press the + or - (HOUR) button until the desired value is displayed.
4. Press the SET button to activate the timer.



C) HOW TO SET A PROGRAM FOR DAILY ON/OFF OPERATION

1. Press the TIMER button to select the desired timer.
2. Press the SET button till the ON sign blinks.
3. Press the + or - (HOUR) button until the desired value is displayed.
4. Press the SET button again, the OFF sign blinks.
5. Press the + or - (HOUR) button until the desired value is displayed.
6. Press the SET button to activate the timer.



D) HOW TO CLEAR THE TIMER


1. Press the TIMER button to select the timer.
2. Press the CLEAR button if you want that every timer operation will be cleared.




NOTE

If the procedure to set the timer is not completed, by pushing the SET button, within 15 seconds the timer operation will be cancelled and the last set-up is restored.

ADJUSTING THE AIR FLOW DIRECTION

Press  button to activate the supply air flap to auto swing. If you push again the flap stops immediately.

Press  button to activate the horizontal air flap to auto swing. If you push again the flap stops immediately.



Set vertical vanes to the front position during COOLING/DRY operation if humidity is high.

If the vertical vanes are set to the left-most or right-most position, condensation will form around the air outlet and drip off.



Do not move the flap with your hands when the air conditioner is running.

NOTES

The flap automatically closes when the unit is off.

During the heating operation, the fan speed will be very low and the flap will be in the horizontal position until the air being blown out of the unit begins to warm. Once the air warms up, the flap position and fan speed change to the settings specified with the remote control.



Use the FLAP button on the remote control to adjust the position of the flap. If you move the flap by hand, the factual flap position and the flap position on the remote control may no longer match. If this should happen, shut off the unit, wait for the flap to close, and then turn on the unit again; the flap position will now be normal again.

Do not have the flap pointed down during cooling operation. Condensation may begin to form around the air vent and drip down.