



Service Manual

WNG LED/LCD DCI Inverter Series

| Indoor Units | Outdoor Units |
|--------------|---------------|
| WNG 50 DCI | DCI 50 |
| WNG 60 DCI | DCI 60 |
| WNG 72 DCI | DCI 72 |
| | DCI 72 Z |
| WNG 80 DCI | DCI 80 |



REFRIGERANT

R410A

HEAT PUMP

APRIL 2007

LIST OF EFFECTIVE PAGES

Note: Changes in the pages are indicated by a “Revision#” in the footer of each effected page (when none indicates no changes in the relevant page). All pages in the following list represent effected/ non effected pages divided by chapters.

Dates of issue for original and changed pages are:

Original 0September 2006

Total number of pages in this publication is 107 consisting of the following:

| Page No. | Revision No. # | | Page No. | Revision No. # | | Page No. | Revision No. # |
|-------------|-------------------|--|-------------|-------------------|--|-------------|-------------------|
|-------------|-------------------|--|-------------|-------------------|--|-------------|-------------------|

| | |
|------------------|---|
| Title | 3 |
| A | 3 |
| i..... | 3 |
| 1-1 - 1-4 | 3 |
| 2-1 - 2-4 | 3 |
| 3-1 | 3 |
| 4-1 - 4-3 | 3 |
| 5-1 - 5-17 | 3 |
| 6-1 - 6-3 | 3 |
| 7-1 | 3 |
| 8-1-8-3 | 3 |
| 9-1-9-2 | 3 |
| 10-1-10-2 | 3 |
| 11-1..... | 3 |
| 12-1-12-23 | 3 |
| 13-1-13-18 | 3 |
| 14-1-14-12 | 3 |
| 15-1-15-10 | 3 |
| Appendix -A..... | 3 |

- Zero in this column indicates an original page.

*Due to constant improvements please note that the data on this service manual can be modified with out notice.

**Photos are not contractual

Table of Contents

| | | |
|-----|---|------|
| 1. | INTRODUCTION | 1-1 |
| 2. | PRODUCT DATA SHEET | 2-1 |
| 3. | RATING CONDITIONS | 3-1 |
| 4. | OUTLINE DIMENSIONS | 4-1 |
| 5. | PERFORMANCE DATA & PRESSURE CURVES | 5-1 |
| 6. | SOUND LEVEL CHARACTERISTICS | 6-1 |
| 7. | ELECTRICAL DATA..... | 7-1 |
| 8. | WIRING DIAGRAMS | 8-1 |
| 9. | REFRIGERATION DIAGRAMS | 9-1 |
| 10. | ELECTRICAL CONNECTIONS..... | 10-1 |
| 11. | TUBING CONNECTIONS..... | 11-1 |
| 12. | CONTROL SYSTEM | 12-1 |
| 13. | TROUBLESHOOTING | 13-1 |
| 14. | EXPLODED VIEWS AND SPARE PARTS LISTS..... | 14-1 |
| 15. | APPENDIX A | 15-1 |

1. INTRODUCTION

1.1 General

The new **WNG DCI INVERTER** split wall mounted range has expanded, comprising the following RC (heat pump) models:

- **WNG50**
- **WNG60**
- **WNG72**
- **WNG80**

The indoor **WNG** units are available as LED or LCD display types, featuring esthetic design, compact dimensions, and low noise operation.

1.2 Main Features

The **WNG DCI** series benefits from the most advanced technological innovations, namely:

- DC inverter technology.
- R410A.
- High COP.
- Pre-Charged units up to the max' allowing tubing distance.
- Networking system connectivity.
- A dry contact for clock or power shedding functions (configurable).
- Base heater connection.
- Cooling operation at outdoor temperature down to -10°C.
- Heating operation at outdoor temperature down to -15°C.
- Supports Indoor Air Quality features, such as – Ionizer and Active Electrostatic Filter.
- Indoor large diameter cross flow fan, allowing low noise level operation.
- Bended indoor coil with treated aluminum fins and coating for improved efficiency.
- Easy access to the interconnecting tubing and wiring connections, so that removing the front grill or casing is not necessary.
- Refrigerant pipes can be connected to the indoor unit from 5 different optional directions.
- Automatic treated air sweep.
- Low indoor and outdoor noise levels.
- Easy installation and service.

1.3 Indoor Unit

The indoor unit is wall mounted, and can be easily fitted to many types of residential and commercial applications.

Indoor Unit features:

| Feature | WNG 50 | WNG60 | WNG72/80 |
|-----------------------------|---|-------|----------|
| Display | LCD or LED | | LCD |
| Ionizer | YES | | |
| ESF | YES | | |
| Fresh air | YES | NO | |
| Indoor fan motor | Variable speed (PG) | | |
| Horizontal motorized louver | YES | | |
| Vertical motorized louver | YES | | |
| Heating element | NO | | |
| M2L Cable port | YES | | |
| Dry contact | Presence detector or (jumper selected) power shedding | | |

1.4 Filtration

The **WNG DCI INV** series presents several types of air filters:

- Easily accessible, and re-usable pre-filters (mesh)
- Pre-charged electrostatic filter (disposable)
- Active carbon filter (disposable)
- ESF. Active Electro Static re-usable filter (optional)

1.5 Ionizer (Optional)

A special design Ionizer protected by unique patents integrated into the indoor unit, generating negative ions to the room providing comfort and upgraded indoor air quality.

1.6 Control

The microprocessor indoor controller, and an infrared remote control, supplied as standard, provides complete operating function and programming.

Remote controllers: RC-2/3/4/5/7, RC-4i-1, RCW, µBMS.

Networking system Airconet version 4.2 and up, MIU SW version H8 and up.

1.7 Outdoor Unit

The WNG DCI INV outdoor units can be installed as floor or wall mounted units by using a wall supporting bracket. The metal sheets are protected from corrosion paint work allowing long life resistance. All outdoor units are pre-charged. For further information please refer to the Product Data Sheet, Chapter 2.

Outdoor Unit Feature

| Feature | DCI 50 | DCI 60 | DCI 72/72Z/80 |
|----------------|----------------------------|--------|---------------|
| Display | 3 LED's | | |
| Base Heater | Optional | | |
| Outdoor Fan | Variable speed DC Inverter | | |
| M2L cable Port | No | Yes | |
| Night | No | Yes | |
| STBY | No | Yes | |
| Power Shedding | No | Yes | |
| Alarm | No | Yes | |

1.8 Tubing Connections

Flare type interconnecting tubing to be produced on site.
For further details please refer to the Installation Manual, Appendix A.

1.9 Accessories





| Item | Description |
|----------------|---|
| MIU (WNG) | MODBUS interface unit |
| RS485 Adapter | To be used as an interface with RCW or μ BMS remote controllers |
| Base Heater | |
| M2L cable Port | |

1.10 Inbox Documentation

Each unit is supplied with its own installation and operation manuals.

1.11 Matching Table

1.11.1 R410A

| OUTDOOR UNITS | | | INDOOR UNITS | | | |
|--|-------------------|-------------------|--|-----------|---|-----------|
| | | |  | |  | |
|  | MODEL | REFR ^o | WNG50 DCI | WNG60 DCI | WNG72 DCI | WNG80 DCI |
| | DCI 50 | R410A | ✓ | | | |
| | DCI 60 | R410A | | ✓ | | |
| | DCI 72 DCI 72Z | R410A | | | ✓ | |
|  | DCI 80 | R410A | | | | ✓ |

2. PRODUCT DATA SHEET

2.1 WNG50 DCI

| | | | | | |
|--|-------------------------------------|--|-----------------------|------------------------------|---------------------|
| Model Indoor Unit | | | | WNG 50 | |
| Model Outdoor Unit | | | | DCI 50 | |
| Installation Method of Pipe | | | | Flared | |
| Characteristics | | | Units | Cooling | Heating |
| Capacity ⁽¹⁾ | | | Btu/hr | 17060(5120-20470) | 20470(5120-25930) |
| | | | kW | 5.00(1.50-6.00) | 6.00(1.50-7.60) |
| Power input ⁽¹⁾ | | | kW | 1.46(0.50-2.00) | 1.66(0.45-2.20) |
| EER (Cooling) or COP(Heating) ⁽¹⁾ | | | W/W | 3.42 | 3.61 |
| Energy efficiency class | | | | A | A |
| Power supply | | | V/Ph/Hz | 220-240V/Single/50Hz | |
| Rated current | | | A | 6.6 | 7.5 |
| Starting current | | | A | 10.5 | |
| Circuit breaker rating | | | A | 20 | |
| INDOOR | Fan type & quantity | | | Crossflow x 1 | |
| | Fan speeds | | | 1200/1050/900 | |
| | Air flow ⁽²⁾ | | H/M/L | RPM | 850/760/620 |
| | External static pressure | | Min-Max | Pa | 0 |
| | Sound power level ⁽³⁾ | | H/M/L | dB(A) | 55/51/47 |
| | Sound pressure level ⁽⁴⁾ | | H/M/L | dB(A) | 43/39/34 |
| | Moisture removal | | | l/hr | 2 |
| | Condensate drain tube I.D | | | mm | 16 |
| | Dimensions | | WxHxD | mm | 1060x295x210 |
| | Weight | | | kg | 15 |
| | Package dimensions | | WxHxD | mm | 1125x360x280 |
| | Packaged weight | | | kg | 18 |
| | Units per pallet | | | units | 16 units per pallet |
| | Stacking height | | | units | 8 levels |
| OUTDOOR | Refrigerant control | | | EEV | |
| | Compressor type,model | | | Scroll,Panasonic 5CS130XCC03 | |
| | Fan type & quantity | | | Propeller(direct) x 1 | |
| | Fan speeds | | H/L | RPM | 920 |
| | Air flow | | H/L | m3/hr | 2160 |
| | Sound power level | | H/L | dB(A) | 63 |
| | Sound pressure level ⁽⁴⁾ | | H/L | dB(A) | 53 |
| | Dimensions | | WxHxD | mm | 795x610x290 |
| | Weight | | | kg | 39 |
| | Package dimensions | | WxHxD | mm | 945x655x395 |
| | Packaged weight | | | kg | 43 |
| | Units per pallet | | | Units | 9 units per pallet |
| | Stacking height | | | units | 3 levels |
| | Refrigerant type | | | R410A | |
| | Refrigerant chargeless distance | | | kg/m | 1.50/7.5 |
| | Additional charge per 1 meter | | | g/m | No need |
| | Connections between units | | Liquid line | ln.(mm) | 1/4"(6.35) |
| | | | Suction line | ln.(mm) | 1/2"(12.7) |
| | | | Max.tubing length | m. | Max.30 |
| | | | Max.height difference | m. | Max. 10 |
| Operation control type | | | | Remote control | |
| Heating elements | | | kW | | |
| Others | | | | | |

(1) Rating conditions in accordance with ISO 5151 and ISO 13253 (for ducted units) and EN 14511.

(2) Airflow in ducted units; at nominal external static pressure.

(3) Sound power in ducted units is measured at air discharge.

(4) Sound pressure level measured at 1 meter distance from unit.

2.2 WNG60 DCI

| | | | | | | | |
|--|-------------------------------------|-----------------------|---------|-----------------------|---------------------|------------------------------|--|
| Model Indoor Unit | | | | WNG-60 | | | |
| Model Outdoor Unit | | | | DCI60 | | | |
| Installation Method of Pipe | | | | Flared | | | |
| Characteristics | | | Units | Cooling | Heating | | |
| Capacity ⁽¹⁾ | | | Btu/hr | 20470(5120-22860) | 22180(5120-26950) | | |
| | | | kW | 6.00(1.50-6.70) | 6.50(1.80-7.90) | | |
| Power input ⁽¹⁾ | | | kW | 1.99(0.50-2.20) | 1.90(0.45-2.30) | | |
| EER (Cooling) or COP(Heating) ⁽¹⁾ | | | W/W | 3.02 | 3.42 | | |
| Energy efficiency class | | | | B | B | | |
| Power supply | | | V/Ph/Hz | 220-240V/Single/50Hz | | | |
| Rated current | | | A | 8.9 | 8.6 | | |
| Starting current | | | A | 10.5 | | | |
| Circuit breaker rating | | | A | 20 | | | |
| INDOOR | Fan type & quantity | | | | Crossflow x 1 | | |
| | Fan speeds | | H/M/L | RPM | 1250/1100/1000 | | |
| | Air flow ⁽²⁾ | | H/M/L | m3/hr | 900/760/620 | | |
| | External static pressure | | Min-Max | Pa | 0 | | |
| | Sound power level ⁽³⁾ | | H/M/L | dB(A) | 56/53/48 | | |
| | Sound pressure level ⁽⁴⁾ | | H/M/L | dB(A) | 45/40/34 | | |
| | Moisture removal | | | l/hr | 2 | | |
| | Condensate drain tube I.D | | | mm | 16 | | |
| | Dimensions | | WxHxD | mm | 1060x295x210 | | |
| | Weight | | | kg | 15 | | |
| | Package dimensions | | WxHxD | mm | 1125x360x280 | | |
| | Packaged weight | | | kg | 18 | | |
| | Units per pallet | | | units | 16 units per pallet | | |
| | Stacking height | | | units | 8 levels | | |
| | OUTDOOR | Refrigerant control | | | | EEV | |
| | | Compressor type,model | | | | Scroll,Panasonic 5CS130XCC03 | |
| Fan type & quantity | | | | Propeller(direct) x 1 | | | |
| Fan speeds | | H/L | RPM | 820 | | | |
| Air flow | | H/L | m3/hr | 2860 | | | |
| Sound power level | | H/L | dB(A) | 65 | | | |
| Sound pressure level ⁽⁴⁾ | | H/L | dB(A) | 55 | | | |
| Dimensions | | WxHxD | mm | 846x690x302 | | | |
| Weight | | | kg | 46 | | | |
| Package dimensions | | WxHxD | mm | 990x770x430 | | | |
| Packaged weight | | | kg | 50 | | | |
| Units per pallet | | | Units | 9 units per pallet | | | |
| Stacking height | | | units | 3 levels | | | |
| Refrigerant type | | | | R410A | | | |
| Refrigerant chargeless distance | | | kg/m | 1.65/7.5 | | | |
| Additional charge per 1 meter | | | g/m | No need | | | |
| Connections between units | | Liquid line | ln.(mm) | 1/4"(6.35) | | | |
| | | Suction line | ln.(mm) | 1/2"(12.7) | | | |
| | | Max.tubing length | m. | Max.30 | | | |
| | | Max.height difference | m. | Max. 10 | | | |
| Operation control type | | | | Remote control | | | |
| Heating elements | | | kW | | | | |
| Others | | | | | | | |

(1) Rating conditions in accordance with ISO 5151 and ISO 13253 (for ducted units) and EN 14511.

(2) Airflow in ducted units; at nominal external static pressure.

(3) Sound power in ducted units is measured at air discharge.

(4) Sound pressure level measured at 1 meter distance from unit.

2.3 WNG72 DCI

| | | | | | | |
|--|-------------------------------------|---------|-----------------------|-------------------------------|-------------------|--|
| Model Indoor Unit | | | | WNG-DCI 72 | | |
| Model Outdoor Unit | | | | GC-DCI 72 | | |
| Installation Method of Pipe | | | | Flared | | |
| Characteristics | | | Units | Cooling | Heating | |
| Capacity ⁽¹⁾ | | | Btu/hr | 23188(5100~25575) | 25916(5100~30000) | |
| | | | kW | 6.8(1.5-7.5) | 7.6(1.5~8.8) | |
| Power input ⁽¹⁾ | | | kW | 2.25(0.5-2.8) | 2.35(0.45~3.0) | |
| EER (Cooling) or COP(Heating) ⁽¹⁾ | | | W/W | 3.01 | 3.23 | |
| Energy efficiency class | | | | B | C | |
| Power supply | | | V/Ph/Hz | 220-240V/Single/50Hz | | |
| Rated current | | | A | 9.8 | 10.3 | |
| Starting current | | | A | 15 | | |
| Circuit breaker rating | | | A | 20 | | |
| INDOOR | Fan type & quantity | | | Crossflow x 1 | | |
| | Fan speeds | H/M/L | RPM | 1300/1150/1000 | 1350/1200/1050 | |
| | Air flow ⁽²⁾ | H/M/L | m3/hr | 950/800/650 | 1000/850/700 | |
| | External static pressure | Min-Max | Pa | 0 | | |
| | Sound power level ⁽³⁾ | H/M/L | dB(A) | 60/54/47 | | |
| | Sound pressure level ⁽⁴⁾ | H/M/L | dB(A) | 47/41/34 | | |
| | Moisture removal | | l/hr | 2.5 | | |
| | Condensate drain tube I.D | | mm | 16 | | |
| | Dimensions | WxHxD | mm | 1060x295x210 | | |
| | Weight | | kg | 15 | | |
| | Package dimensions | WxHxD | mm | 1115x350x260 | | |
| | Packaged weight | | kg | 18 | | |
| | Units per pallet | | units | 16 | | |
| | Stacking height | | units | 8 levels | | |
| OUTDOOR | Refrigerant control | | | EEV | | |
| | Compressor type,model | | | Two Rotary,Mitsubishi TNB220F | | |
| | Fan type & quantity | | | Propeller(direct) x 1 | | |
| | Fan speeds | H/L | RPM | 850 | | |
| | Air flow | H/L | m3/hr | 3600 | | |
| | Sound power level | H/L | dB(A) | 66 | | |
| | Sound pressure level ⁽⁴⁾ | H/L | dB(A) | 56 | | |
| | Dimensions | WxHxD | mm | 950x835x412 | | |
| | Weight | | kg | 65.5 | | |
| | Package dimensions | WxHxD | mm | 1080x910x477 | | |
| | Packaged weight | | kg | 73 | | |
| | Units per pallet | | Units | 2 | | |
| | Stacking height | | units | 2 levels | | |
| | Refrigerant type | | | R410A | | |
| | Refrigerant chargeless distance | | kg/m | 2.4kg/30m | | |
| | Additional charge per 1 meter | | g/m | No Need | | |
| | Connections between units | | Liquid line | In.(mm) | 3/8"(9.53) | |
| | | | Suction line | In.(mm) | 5/8"(15.88) | |
| | | | Max.tubing length | m. | Max.30 | |
| | | | Max.height difference | m. | Max.15 | |
| Operation control type | | | | Remote control | | |
| Heating elements (Option) | | | kW | | | |
| Others | | | | | | |

(1) Rating conditions in accordance with ISO 5151 and ISO 13253 (for ducted units) and EN 14511.

(2) Airflow in ducted units; at nominal external static pressure.

(3) Sound power in ducted units is measured at air discharge.

(4) Sound pressure level measured at 1 meter distance from unit.

2.4 WNG72Z DCI

| Model Indoor Unit | | | | WNG 72 DCI | |
|--|-------------------------------------|-----------------------|---|-------------------|-------------------|
| Model Outdoor Unit | | | | DCI 72 Z R410A | |
| Installation Method of Pipe | | | | Flared | |
| Characteristics | | | Units | Cooling | Heating |
| Capacity ⁽⁴⁾ | | | Btu/hr | 23200(5120-25590) | 24050(5120-30030) |
| | | | kW | 6.80(1.50-7.50) | 7.05(1.50-8.80) |
| Power input ⁽⁴⁾ | | | kW | 2.25(0.5-2.8) | 2.19(0.45-3.0) |
| EER (Cooling) or COP(Heating) ⁽⁴⁾ | | | W/W | 3.01 | 3.23 |
| Energy efficiency class | | | | B | C |
| Power supply | | | V | 220-240 | |
| | | | Ph | Single | |
| | | | Hz | 50 | |
| Rated current | | | A | 10.0 | 10.3 |
| Power factor | | | | 0.97 | 0.97 |
| Prated (IDU) | | | W | 60 | |
| Prated (IDU+ODU) | | | W | 3000 | |
| Starting current | | | A | 15 | |
| Circuit breaker rating | | | A | 20 | |
| INDOOR | Fan type & quantity | | | Crossflow x 1 | |
| | Fan speeds | | H/M/L | RPM | 1350/1150/1000 |
| | Air flow ⁽¹⁾ | | H/M/L | m3/hr | 960/800/670 |
| | External static pressure | | Min | Pa | 0 |
| | Sound power level ⁽²⁾ | | H/M/L | dB(A) | 60/56/51 |
| | Sound pressure level ⁽³⁾ | | H/M/L | dB(A) | 47/43/38 |
| | Moisture removal | | | l/hr | 2.5 |
| | Condensate drain tube I.D | | | mm | 16 |
| | Dimensions | | WxHxD | mm | 1060x295x210 |
| | Net Weight | | | kg | 15 |
| | Package dimensions | | WxHxD | mm | 1125x360x280 |
| | Packaged weight | | | kg | 18 |
| | Units per pallet | | | units | 16 |
| | Stacking height | | | units | 8 levels |
| | OUTDOOR | Refrigerant control | | | EEV |
| Compressor type,model | | | Two Rotary,Sanyo(Sheny) C-7RVN153H0W | | |
| Fan type & quantity | | | Propeller(direct) x 1 | | |
| Fan speeds | | H | RPM | 850 | |
| Air flow | | H | m3/hr | 3600 | |
| Sound power level | | H | dB(A) | 66 | |
| Sound pressure level ⁽³⁾ | | H | dB(A) | 56 | |
| Dimensions | | WxHxD | mm | 950x835x412 | |
| Net Weight | | | kg | 64.5 | |
| Package dimensions | | WxHxD | mm | 1080x910x477 | |
| Packaged weight | | | kg | 72 | |
| Units per pallet | | | Units | 4 | |
| Stacking height | | | units | 2 levels | |
| Refrigerant type | | | R410A | | |
| Standard charge | | kg(7.5m) | 2.3kg | | |
| Additional charge | | | 7.5m≤Length≤20m:+0g; 20m≤Length≤30m:+300g | | |
| Connections between units | | Liquid line | In.(mm) | 3/8"(9.53) | |
| | | Suction line | In.(mm) | 5/8"(15.88) | |
| | | Max.tubing length | m. | 30 | |
| | | Max.height difference | m. | 15 | |
| Operation control type | | | | Remote control | |
| Heating elements(Optional) | | | kW | | |
| Others | | | | | |

(1) Rating conditions in accordance with ISO 5151 and ISO 13253 (for ducted units) and EN 14511.

(2) Airflow in ducted units; at nominal external static pressure.

(3) Sound power in ducted units is measured at air discharge.

(4) Sound pressure level measured at 1 meter distance from unit.

2.5 WNG80 DCI

| | | | | |
|--|-------------------------------------|--|----------------------|------------------------------------|
| Model Indoor Unit | | | WNG- 80 | |
| Model Outdoor Unit | | | DCI 80 | |
| Installation Method of Pipe | | | Flared | |
| Characteristics | | Units | Cooling | Heating |
| Capacity ⁽¹⁾ | Btu/hr | | 26620(5100~30035) | 29010 (5100~32420) |
| | kW | | 7.8 (1.50~8.8) | 8.5 (1.5~9.5) |
| Power input ⁽¹⁾ | kW | | 2.59 (0.50~3.1) | 2.65 (0.5~3.2) |
| EER (Cooling) or COP(Heating) ⁽¹⁾ | W/W | | 3.01 | 3.21 |
| Energy efficiency class | | | B | C |
| Power supply | V/Ph/Hz | | 220-240V/Single/50Hz | |
| Rated current | A | | 11.3 | 11.5 |
| Starting current | A | | 15 | |
| Circuit breaker rating | A | | 20 | |
| INDOOR | Fan type & quantity | | Crossflow x 1 | |
| | Fan speeds | H/M/L | RPM | 1350/1150/1000 1350/1200/1050 |
| | Air flow ⁽²⁾ | H/M/L | m3/hr | 1250/1050/900 1250/1100/950 |
| | External static pressure | Min-Max | Pa | N/A |
| | Sound power level ⁽³⁾ | H/M/L | dB(A) | 66/61/57 |
| | Sound pressure level ⁽⁴⁾ | H/M/L | dB(A) | 51/48/44 |
| | Moisture removal | | l/hr | 3 |
| | Condensate drain tube I.D | | mm | 16 |
| | Dimensions | WxHxD | mm | 1200x340x236 |
| | Weight | | kg | 18.5 |
| | Package dimensions | WxHxD | mm | 1305x430x325 |
| | Packaged weight | | kg | 24 |
| | Units per pallet | | units | 12 units per pallet |
| | Stacking height | | units | 6 levels |
| | OUTDOOR | Refrigerant control | | EEV |
| Compressor type, model | | Twin Rotary DC Inverter Mitsubishi TNB220F | | |
| Fan type & quantity | | Propeller(direct) x 1 | | |
| Fan speeds | | H/L | RPM | 850 |
| Air flow | | H/L | m3/hr | 3600 |
| Sound power level ⁽³⁾ | | H/L | dB(A) | 66 |
| Sound pressure level ⁽⁴⁾ | | H/L | dB(A) | 56 |
| Dimensions | | WxHxD | mm | 950x412x835 |
| Weight | | | kg | 66 |
| Package dimensions | | WxHxD | mm | 1080x477x910 |
| Packaged weight | | | kg | 73.5 |
| Units per pallet | | | Units | 2 units per pallet |
| Stacking height | | | units | 3 levels |
| Refrigerant type | | | | R410A |
| Refrigerant chargeless distance | | | kg/m | 2.75/30 |
| Additional charge per 1 meter | | | g/m | No need |
| Connections between units | | Liquid line | In.(mm) | 3/8”(9.53) |
| | | Suction line | In.(mm) | 5/8”(15.88) |
| | | Max. tubing length | m. | Max.30 |
| | | Max. height difference | m. | Max. 15 |
| Operation control type | | | Remote control | |
| Heating elements | | kW | | |
| Others | | | | |

(1) Rating conditions in accordance with ISO 5151 and ISO 13253 (for ducted units) and EN 14511.

(2) Airflow in ducted units; at nominal external static pressure.

(3) Sound power in ducted units is measured at air discharge.

(4) Sound pressure level measured at 1 meter distance from unit.

3. RATING CONDITIONS

Rating conditions in accordance with ISO 5151 and ISO 13253 (for ducted units).

Cooling:

Indoor: 27°C DB 19°C WB

Outdoor: 35°C DB

Heating:

Indoor: 20°C DB

Outdoor: 7°C DB 6°C WB


3.1 Operating Limits

3.1.1 R410A


| | | Indoor | Outdoor |
|---------|-------------|-----------------|-------------------|
| Cooling | Upper limit | 32°C DB 23°C WB | 46°C DB |
| | Lower limit | 21°C DB 15°C WB | -10°C DB |
| Heating | Upper limit | 27°C DB | 24°C DB 18°C WB |
| | Lower limit | 10°C DB | -15°C DB -16°C WB |
| Voltage | | 198 – 264 V | |



4. OUTLINE DIMENSIONS

4.1 Indoor Unit: WNG 50/60/72 DCI




4.2 Outdoor Unit: DCI 50





4.5 Outdoor Unit: DCI 72 / 72 Z / 80



5. PERFORMANCE DATA

5.1 WNG50 DCI / DCI 50

5.1.1 Cooling Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| OD COIL ENTERING AIR DB TEMPERATURE [°C] | DATA | ID COIL ENTERING AIR DB/WB TEMPERATURE [°C] | | | | |
|--|------|---|-------|-------------|-------|-------|
| | | 22/15 | 24/17 | 27/19 | 29/21 | 32/23 |
| -10 - 20 (protection range) | TC | 80 - 110 % of nominal | | | | |
| | SC | 80 - 105 % of nominal | | | | |
| | PI | 25 - 50 % of nominal | | | | |
| 25 | TC | 4.93 | 5.22 | 5.51 | 5.80 | 6.09 |
| | SC | 4.10 | 4.16 | 4.22 | 4.28 | 4.34 |
| | PI | 1.10 | 1.13 | 1.15 | 1.18 | 1.20 |
| 30 | TC | 4.67 | 4.96 | 5.25 | 5.54 | 5.83 |
| | SC | 3.94 | 4.00 | 4.06 | 4.12 | 4.18 |
| | PI | 1.26 | 1.28 | 1.31 | 1.33 | 1.36 |
| 35 | TC | 4.42 | 4.71 | 5.00 | 5.29 | 5.58 |
| | SC | 3.78 | 3.84 | 3.90 | 3.96 | 4.02 |
| | PI | 1.41 | 1.44 | 1.46 | 1.48 | 1.51 |
| 40 | TC | 4.17 | 4.46 | 4.75 | 5.04 | 5.53 |
| | SC | 3.62 | 3.68 | 3.74 | 3.80 | 3.86 |
| | PI | 1.56 | 1.59 | 1.61 | 1.64 | 1.66 |
| 46 | TC | 3.86 | 4.15 | 4.44 | 4.73 | 5.02 |
| | SC | 3.43 | 3.49 | 3.55 | 3.61 | 3.67 |
| | PI | 1.75 | 1.77 | 1.80 | 1.82 | 1.85 |

LEGEND

- TC – Total Cooling Capacity, kW
- SC – Sensible Capacity, kW
- PI – Power Input, kW
- WB – Wet Bulb Temp., (°C)
- DB – Dry Bulb Temp., (°C)
- ID – Indoor
- OD – Outdoor

5.1.2 Capacity Correction Factors




5.1.3 Heating Capacity (kW) - Run Mode)**230[V] : Indoor Fan at High Speed.**

| | | ID COIL ENTERING AIR DB TEMPERATURE [°C] | | |
|---|------|--|-------------|------|
| OD COIL ENTERING AIR DB/WB TEMPERATURE [°C] | DATA | 15 | 20 | 25 |
| -15/-16 | TC | 2.73 | 2.34 | 1.94 |
| | PI | 1.16 | 1.24 | 1.33 |
| -10/-12 | TC | 3.60 | 3.21 | 2.82 |
| | PI | 1.31 | 1.40 | 1.48 |
| -7/-8 | TC | 4.26 | 3.87 | 3.47 |
| | PI | 1.43 | 1.51 | 1.59 |
| -1/-2 | TC | 4.59 | 4.19 | 3.80 |
| | PI | 1.48 | 1.57 | 1.65 |
| 2/1 | TC | 4.81 | 4.41 | 4.02 |
| | PI | 1.52 | 1.60 | 1.69 |
| 7/6 | TC | 6.39 | 6.00 | 5.61 |
| | PI | 1.58 | 1.66 | 1.74 |
| 10/9 | TC | 6.72 | 6.33 | 5.94 |
| | PI | 1.61 | 1.69 | 1.77 |
| 15/12 | TC | 7.06 | 6.66 | 6.27 |
| | PI | 1.64 | 1.72 | 1.80 |
| 15-24 (Protection Range) | TC | 85 - 105 % of nominal | | |
| | PI | 80 - 120 % of nominal | | |

LEGEND

TC – Total Heating Capacity, kW
 PI – Power Input, kW
 WB – Wet Bulb Temp., (°C)
 DB – Dry Bulb Temp., (°C)
 ID – Indoor
 OD – Outdoor

5.1.4 Capacity Correction Factors

5.2 WNG60 DCI / DCI 60

5.2.1 Cooling Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| | | ID COIL ENTERING AIR DB/WB TEMPERATURE [°C] | | | | |
|--|------|---|-------|-------------|-------|-------|
| OD COIL ENTERING AIR DB TEMPERATURE [°C] | DATA | 22/15 | 24/17 | 27/19 | 29/21 | 32/23 |
| -10 - 20 (protection range) | TC | 80 - 110 % of nominal | | | | |
| | SC | 80 - 105 % of nominal | | | | |
| | PI | 25 - 50 % of nominal | | | | |
| 25 | TC | 5.91 | 6.26 | 6.61 | 6.95 | 7.30 |
| | SC | 4.64 | 4.71 | 4.78 | 4.85 | 4.92 |
| | PI | 1.50 | 1.54 | 1.57 | 1.61 | 1.64 |
| 30 | TC | 5.61 | 5.96 | 6.30 | 6.65 | 7.00 |
| | SC | 4.46 | 4.53 | 4.60 | 4.67 | 4.74 |
| | PI | 1.71 | 1.75 | 1.78 | 1.81 | 1.85 |
| 35 | TC | 5.30 | 5.65 | 6.00 | 6.35 | 6.70 |
| | SC | 4.28 | 4.35 | 4.42 | 4.49 | 4.56 |
| | PI | 1.92 | 1.96 | 1.99 | 2.02 | 2.06 |
| 40 (Protection Range) | TC | 5.00 | 5.35 | 5.70 | 6.05 | 6.39 |
| | SC | 4.10 | 4.17 | 4.24 | 4.31 | 4.38 |
| | PI | 2.13 | 2.17 | 2.20 | 2.23 | 2.27 |
| 46 (Protection Range) | TC | 4.64 | 4.99 | 5.33 | 5.68 | 6.03 |
| | SC | 3.88 | 3.95 | 4.02 | 4.09 | 4.16 |
| | PI | 2.38 | 2.42 | 2.45 | 2.48 | 2.52 |

LEGEND

- TC – Total Cooling Capacity, kW
- SC – Sensible Capacity, kW
- PI – Power Input, kW
- WB – Wet Bulb Temp., (°C)
- DB – Dry Bulb Temp., (°C)
- ID – Indoor
- OD – Outdoor

5.2.2 Capacity Correction Factors



5.2.3 Heating Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| | | ID COIL ENTERING AIR DB TEMPERATURE [°C] | | |
|---|------|--|------|------|
| OD COIL ENTERING AIR DB/WB TEMPERATURE [°C] | DATA | 15 | 20 | 25 |
| -15/-16 | TC | 2.96 | 2.53 | 2.11 |
| | PI | 1.33 | 1.42 | 1.52 |
| -10/-12 | TC | 3.90 | 3.48 | 3.05 |
| | PI | 1.50 | 1.60 | 1.69 |
| -7/-8 | TC | 4.61 | 4.19 | 3.76 |
| | PI | 1.63 | 1.73 | 1.82 |
| -1/-2 | TC | 4.97 | 4.54 | 4.12 |
| | PI | 1.70 | 1.79 | 1.82 |
| 2/1 | TC | 5.21 | 4.78 | 4.35 |
| | PI | 1.74 | 1.84 | 1.93 |
| 7/6 | TC | 6.93 | 6.50 | 6.07 |
| | PI | 1.81 | 1.90 | 2.00 |
| 10/9 | TC | 7.28 | 6.86 | 6.43 |
| | PI | 1.84 | 1.93 | 2.03 |
| 15/12 | TC | 7.64 | 7.22 | 6.79 |
| | PI | 1.87 | 1.97 | 2.06 |
| 15-24 (Protection Range) | TC | 85 - 105 % of nominal | | |
| | PI | 80 - 120 % of nominal | | |

LEGEND

- TC – Total Heating Capacity, kW
- PI – Power Input, kW
- WB – Wet Bulb Temp., (°C)
- DB – Dry Bulb Temp., (°C)
- ID – Indoor
- OD – Outdoor

5.2.4 Capacity Correction Factors



5.3 WNG72 DCI / DCI 72

5.3.1 Cooling Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| | | ID COIL ENTERING AIR DB/WB TEMPERATURE [°C] | | | | |
|--|------|---|-------|-------|-------|-------|
| OD COIL ENTERING AIR DB TEMPERATURE [°C] | DATA | 22/15 | 24/17 | 27/19 | 29/21 | 32/23 |
| -10 - 20 (protection range) | TC | 80 - 110 % of nominal | | | | |
| | SC | 80 - 105 % of nominal | | | | |
| | PI | 25 - 50 % of nominal | | | | |
| 25 | TC | 6.70 | 7.09 | 7.49 | 7.88 | 8.28 |
| | SC | 5.04 | 5.12 | 5.19 | 5.27 | 5.34 |
| | PI | 1.70 | 1.74 | 1.78 | 1.82 | 1.85 |
| 30 | TC | 6.35 | 6.75 | 7.14 | 7.54 | 7.93 |
| | SC | 4.85 | 4.92 | 5.00 | 5.07 | 5.15 |
| | PI | 1.94 | 1.98 | 2.01 | 2.05 | 2.09 |
| 35 | TC | 6.01 | 6.41 | 6.80 | 7.19 | 7.59 |
| | SC | 4.65 | 4.73 | 4.80 | 4.87 | 4.95 |
| | PI | 2.17 | 2.21 | 2.25 | 2.29 | 2.33 |
| 40 (Protection Range) | TC | 5.67 | 6.06 | 6.46 | 6.85 | 7.25 |
| | SC | 4.45 | 4.53 | 4.60 | 4.68 | 4.75 |
| | PI | 2.41 | 2.45 | 2.49 | 2.52 | 2.56 |
| 46 (Protection Range) | TC | 5.26 | 5.65 | 6.04 | 6.44 | 6.83 |
| | SC | 4.22 | 4.29 | 4.37 | 4.44 | 4.52 |
| | PI | 2.69 | 2.73 | 2.77 | 2.81 | 2.85 |

LEGEND

- TC – Total Cooling Capacity, kW
- SC – Sensible Capacity, kW
- PI – Power Input, kW
- WB – Wet Bulb Temp., (°C)
- DB – Dry Bulb Temp., (°C)
- ID – Indoor
- OD – Outdoor

5.3.2 Capacity Correction Factors



5.3.3 Heating Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| | | ID COIL ENTERING AIR DB TEMPERATURE [°C] | | |
|---|------|--|------|------|
| | | 15 | 20 | 25 |
| OD COIL ENTERING AIR DB/WB TEMPERATURE [°C] | DATA | | | |
| | | | | |
| -15/-16 | TC | 3.46 | 2.96 | 2.46 |
| | PI | 1.64 | 1.76 | 1.88 |
| -10/-12 | TC | 4.57 | 4.07 | 3.57 |
| | PI | 1.86 | 1.98 | 2.09 |
| -7/-8 | TC | 5.40 | 4.90 | 4.40 |
| | PI | 2.02 | 2.14 | 2.25 |
| -1/-2 | TC | 5.81 | 5.31 | 4.81 |
| | PI | 2.10 | 2.22 | 2.33 |
| 2/1 | TC | 6.09 | 5.59 | 5.09 |
| | PI | 2.15 | 2.27 | 2.39 |
| 7/6 | TC | 8.10 | 7.60 | 7.10 |
| | PI | 2.23 | 2.35 | 2.47 |
| 10/9 | TC | 8.52 | 8.02 | 7.52 |
| | PI | 2.28 | 2.39 | 2.51 |
| 15/12 | TC | 8.94 | 8.44 | 7.94 |
| | PI | 2.32 | 2.44 | 2.55 |
| 15-24 (Protection Range) | TC | 85 - 105 % of nominal | | |
| | PI | 80 - 120 % of nominal | | |

LEGEND

- TC – Total Heating Capacity, kW
- PI – Power Input, kW
- WB – Wet Bulb Temp., (°C)
- DB – Dry Bulb Temp., (°C)
- ID – Indoor
- OD – Outdoor

5.3.4 Capacity Correction Factors



5.4 WNG72 DCI / DCI 72Z

5.4.1 Cooling Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| | | ID COIL ENTERING AIR DB/WB TEMPERATURE [°C] | | | | |
|--|------|---|-------|-------|-------|-------|
| OD COIL ENTERING AIR DB TEMPERATURE [°C] | DATA | 22/15 | 24/17 | 27/19 | 29/21 | 32/23 |
| -10 - 20 (protection range) | TC | 80 - 110 % of nominal | | | | |
| | SC | 80 - 105 % of nominal | | | | |
| | PI | 25 - 50 % of nominal | | | | |
| 25 | TC | 6.70 | 7.09 | 7.49 | 7.88 | 8.28 |
| | SC | 5.04 | 5.12 | 5.19 | 5.27 | 5.34 |
| | PI | 1.70 | 1.74 | 1.78 | 1.82 | 1.85 |
| 30 | TC | 6.35 | 6.75 | 7.14 | 7.54 | 7.93 |
| | SC | 4.85 | 4.92 | 5.00 | 5.07 | 5.15 |
| | PI | 1.94 | 1.98 | 2.01 | 2.05 | 2.09 |
| 35 | TC | 6.01 | 6.41 | 6.80 | 7.19 | 7.59 |
| | SC | 4.65 | 4.73 | 4.80 | 4.87 | 4.95 |
| | PI | 2.17 | 2.21 | 2.25 | 2.29 | 2.33 |
| 40 (Protection Range) | TC | 5.67 | 6.06 | 6.46 | 6.85 | 7.25 |
| | SC | 4.45 | 4.53 | 4.60 | 4.68 | 4.75 |
| | PI | 2.41 | 2.45 | 2.49 | 2.52 | 2.56 |
| 46 (Protection Range) | TC | 5.26 | 5.65 | 6.04 | 6.44 | 6.83 |
| | SC | 4.22 | 4.29 | 4.37 | 4.44 | 4.52 |
| | PI | 2.69 | 2.73 | 2.77 | 2.81 | 2.85 |

LEGEND

- TC – Total Cooling Capacity, kW
- SC – Sensible Capacity, kW
- PI – Power Input, kW
- WB – Wet Bulb Temp., (°C)
- DB – Dry Bulb Temp., (°C)
- ID – Indoor
- OD – Outdoor

5.4.2 Capacity Correction Factors



5.4.3 Heating Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| | | ID COIL ENTERING AIR DB TEMPERATURE [°C] | | |
|---|------|--|------|------|
| | | 15 | 20 | 25 |
| OD COIL ENTERING AIR DB/WB TEMPERATURE [°C] | DATA | | | |
| | | | | |
| -15/-16 | TC | 3.21 | 2.75 | 2.28 |
| | PI | 1.53 | 1.64 | 1.75 |
| -10/-12 | TC | 4.23 | 3.77 | 3.31 |
| | PI | 1.73 | 1.84 | 1.95 |
| -7/-8 | TC | 5.00 | 4.54 | 4.08 |
| | PI | 1.88 | 1.99 | 2.10 |
| -1/-2 | TC | 5.39 | 4.93 | 4.47 |
| | PI | 1.96 | 2.07 | 2.17 |
| 2/1 | TC | 5.65 | 5.18 | 4.72 |
| | PI | 2.01 | 2.12 | 2.22 |
| 7/6 | TC | 7.51 | 7.05 | 6.59 |
| | PI | 2.08 | 2.19 | 2.30 |
| 10/9 | TC | 7.90 | 7.44 | 6.98 |
| | PI | 2.12 | 2.23 | 2.34 |
| 15/12 | TC | 8.28 | 7.83 | 7.37 |
| | PI | 2.16 | 2.27 | 2.38 |
| 15-24 (Protection Range) | TC | 85 - 105 % of nominal | | |
| | PI | 80 - 120 % of nominal | | |

LEGEND

- TC – Total Heating Capacity, kW
- PI – Power Input, kW
- WB – Wet Bulb Temp., (°C)
- DB – Dry Bulb Temp., (°C)
- ID – Indoor
- OD – Outdoor

5.4.4 Capacity Correction Factors



5.5 WNG80 DCI / DCI 80

5.5.1 Cooling Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| | | ID COIL ENTERING AIR DB/WB TEMPERATURE [°C] | | | | |
|--|------|---|-------|-------------|-------|-------|
| OD COIL ENTERING AIR DB TEMPERATURE [°C] | DATA | 22/15 | 24/17 | 27/19 | 29/21 | 32/23 |
| -10 - 20 (protection range) | TC | 80 - 110 % of nominal | | | | |
| | SC | 80 - 105 % of nominal | | | | |
| | PI | 25 - 50 % of nominal | | | | |
| 25 | TC | 7.68 | 8.14 | 8.59 | 9.04 | 9.49 |
| | SC | 6.41 | 6.51 | 6.60 | 6.70 | 6.79 |
| | PI | 1.96 | 2.00 | 2.05 | 2.09 | 2.13 |
| 30 | TC | 7.29 | 7.74 | 8.19 | 8.65 | 9.10 |
| | SC | 6.16 | 6.25 | 6.35 | 6.45 | 6.54 |
| | PI | 2.23 | 2.27 | 2.32 | 2.36 | 2.41 |
| 35 | TC | 6.90 | 7.35 | 7.80 | 8.25 | 8.70 |
| | SC | 5.91 | 6.00 | 6.10 | 6.20 | 6.29 |
| | PI | 2.50 | 2.55 | 2.59 | 2.63 | 2.68 |
| 40 (Protection Range) | TC | 6.50 | 6.95 | 7.41 | 7.86 | 8.31 |
| | SC | 5.66 | 5.75 | 5.85 | 5.95 | 6.04 |
| | PI | 2.77 | 2.82 | 2.86 | 2.91 | 2.95 |
| 46 (Protection Range) | TC | 6.03 | 6.48 | 6.93 | 7.39 | 7.84 |
| | SC | 5.36 | 5.45 | 5.55 | 5.64 | 5.74 |
| | PI | 3.10 | 3.14 | 3.19 | 3.23 | 3.28 |

LEGEND

- TC – Total Cooling Capacity, kW
- SC – Sensible Capacity, kW
- PI – Power Input, kW
- WB – Wet Bulb Temp., (°C)
- DB – Dry Bulb Temp., (°C)
- ID – Indoor
- OD – Outdoor

5.5.2 Capacity Correction Factors



5.5.3 Heating Capacity (kW) - Run Mode


230[V] : Indoor Fan at High Speed.

| OD COIL ENTERING AIR DB/WB TEMPERATURE [°C] | DATA | ID COIL ENTERING AIR DB TEMPERATURE [°C] | | |
|---|------|--|------|------|
| | | 15 | 20 | 25 |
| -15/-16 | TC | 3.87 | 3.31 | 2.75 |
| | PI | 1.85 | 1.99 | 2.12 |
| -10/-12 | TC | 5.11 | 4.55 | 3.99 |
| | PI | 2.09 | 2.23 | 2.36 |
| -7/-8 | TC | 6.03 | 5.48 | 4.92 |
| | PI | 2.28 | 2.41 | 2.54 |
| -1/-2 | TC | 6.50 | 5.94 | 5.38 |
| | PI | 2.37 | 2.50 | 2.63 |
| 2/1 | TC | 6.81 | 6.25 | 5.69 |
| | PI | 2.43 | 2.56 | 2.69 |
| 7/6 | TC | 9.06 | 8.50 | 7.94 |
| | PI | 2.52 | 2.65 | 2.78 |
| 10/9 | TC | 9.53 | 8.97 | 8.41 |
| | PI | 2.57 | 2.70 | 2.83 |
| 15/12 | TC | 10.00 | 9.44 | 8.88 |
| | PI | 2.61 | 2.75 | 2.88 |
| 15-24 (Protection Range) | TC | 85 - 105 % of nominal | | |
| | PI | 80 - 120 % of nominal | | |

LEGEND


TC – Total Heating Capacity, kW
 PI – Power Input, kW
 WB – Wet Bulb Temp., (°C)
 DB – Dry Bulb Temp., (°C)
 ID – Indoor
 OD – Outdoor

5.5.4 Capacity Correction Factors




5.6 Capacity Correction Factor Due to Tubing Length

5.6.1 WNG 50/60/72/80 DCI: Cooling





5.6.2 Heating





5.7 Pressure Curves



5.7.1. Model: WNG50 DCI / DCI 50 Cooling — Test Mode





5.7.2. Heating — Test Mode





5.7.3 Model: WNG60 DCI / DCI 60 Cooling — Test Mode.





5.7.4 Heating — Test Mode




5.7.5 Model: WNG72 DCI / DCI 72 Cooling — Test Mode.





5.7.6 Heating — Test Mode





5.7.7 Model: WNG72 DCI / DCI 72Z Cooling — Test Mode.





5.7.8 Heating — Test Mode



5.7.9 Model: WNG80 DCI / DCI 80 Cooling — Test Mode.



5.7.10 Heating — Test Mode



6. SOUND LEVEL CHARACTERISTICS

6.1 Sound Pressure Level





Figure 1

| FAN SPEED | LINE |
|-----------|------|
| HI | —▲— |
| ME | —○— |
| LO | —□— |

6.2 Sound Pressure Level Spectrum (Measured as Figure 1)



6.3 Outdoor units









Figure 2

6.4 Sound Pressure Level Spectrum (Measured as Figure 2)



Sound Pressure Level Spectrum (Measured as Figure 2)**DCI 72Z Cooling****DCI 72Z Heating****DCI 72/80 Cooling****DCI 72/80 Heating**

7. ELECTRICAL DATA

7.1 Single Phase Unit

| Model | WNG50 | WNG60 | WNG72/80 |
|----------------------------------|-------------------------|-------|------------|
| Power Supply | 1 PH ,220-240VAC ,50HZ | | |
| Connected to | To indoor | | To outdoor |
| Maximum Current | 13.5A | 15A | 15.7A |
| Inrush Current ^{\(a)} | 45 A | | <35A |
| Starting Current ^{\(b)} | 13.5 A | 15A | 15.7A |
| Circuit Breaker | 20 A | | |
| Power Supply | 3 X 2.5 mm ² | | |
| Interconnecting cable | 4 X 2.5 mm ² | | |

(a) Inrush current is the current when power is up (charging the DC capacitors at outdoor unit controller).


(b) Starting current is the current at compressor start up.

NOTE


Power wiring cord should comply with local laws and electrical regulations requirements.

8. WIRING DIAGRAMS


8.1 Indoor Unit: WNG 50_60 DCI




8.2 Outdoor Unit: DCI 50_60 DCI



8.4 Outdoor Units: DCI 72Z




INDOOR UNIT



Note: The dashed part is optional


OUTDOOR UNIT




9. REFRIGERATION DIAGRAMS

9.1 Heat Pump Models



9.1.1 WNG 50_60 / DCI 50_60 Cooling Mode



9.1.2 WNG 50_60 / DCI 50_60 Heating Mode




9.1.3 WNG 72/80, DCI 72/72 Z/80



10. ELECTRICAL CONNECTIONS

10.1 WNG 50, WNG 60 DCI



1. Indoor unit terminal

2. Ground wire.

3. Indoor coil.

4. Power cable in the indoor side.


5. Multiple wire cable.

6. Cable clamp.

7. Outdoor unit wire terminal.

A. OUTDOOR B. INDOOR

10.2 WNG 72, WNG 80 DCI



1. Indoor unit terminal

2. Ground wire.

3. Indoor coil.

4. Multiple wire cable.



5. Cable clamp.

6. Outdoor unit wire terminal.

7. Power cable in the outdoor side
(only for outdoor unit power supply)

A. OUTDOOR B. INDOOR

11. TUBING CONNECTIONS



| TUBE (Inch) | 1/4" | 3/8" | 1/2" | 5/8" | 3/4" |
|------------------|-------|-------|-------|-------|-------|
| TORQUE (Nm) | | | | | |
| Flare Nuts | 11-13 | 40-45 | 60-65 | 70-75 | 80-85 |
| Valve Cap | 13-20 | 13-20 | 18-25 | 18-25 | 40-50 |
| Service Port Cap | 11-13 | 11-13 | 11-13 | 11-13 | 11-13 |

1. Valve Protection Cap-end
2. Refrigerant Valve Port (use Allen wrench to open/close)
3. Valve Protection Cap
4. Refrigerant Valve
5. Service Port Cap
6. Flare Nut
7. Unit Back Side
8. Copper Tube

12. CONTROL SYSTEM

12.1 General Functions and Operating Rules

The DCI software is fully parametric.

All the model dependent parameters are shown in Blue color and with Italic style [*parameter*].

The parameters values are given in the last section of this control logic chapter of the service manual.

12.1.1 System Operation Concept

The control function is divided between indoor and outdoor unit controllers. Indoor unit is the system 'Master', requesting the outdoor unit for cooling/heating capacity supply. The outdoor unit is the system 'Slave' and it must supply the required capacity unless it enters into a protection mode avoiding it from supplying the requested capacity.

The capacity request is transferred via indoor to outdoor communication, and is represented by a parameter called 'NLOAD'. NLOAD is an integer number with values between 0 and 127, and it represents the heat or cool load felt by the indoor unit.

12.1.2 Compressor Frequency Control

12.1.2.1 NLOAD setting

The NLOAD setting is done by the indoor unit controller, based on a PI control scheme.

The actual NLOAD to be sent to the outdoor unit controller is based on the preliminary LOAD calculation, the indoor fan speed, and the power shedding function.

NLOAD limits as a function of indoor fan speed:

Indoor Fan Speed Maximum NLOAD Cooling Maximum NLOAD Heating

| Indoor Fan Speed | Maxium NLOAD Cooling | Maxium NLOAD Heating |
|------------------|----------------------|----------------------|
| Low | <i>MaxNLOADIF1C</i> | <i>MaxNLOADIF1H</i> |
| Medium | <i>MaxNLOADIF2C</i> | <i>MaxNLOADIF2H</i> |
| High | <i>MaxNLOADIF3C</i> | <i>MaxNLOADIF3H</i> |
| Turbo | <i>MaxNLOADIF4C</i> | <i>MaxNLOADIF4H</i> |
| Auto | <i>MaxNLOADIF5C</i> | <i>MaxNLOADIF5H</i> |

NLOAD limits as a function of power shedding:

| Mode | Power Shedding OFF | Power Shedding ON |
|----------------|--------------------|-------------------|
| Cooling | No limit | Nominal Cooling |
| Heating | No limit | Nominal heating |

12.1.3 Target Frequency Setting

12.1.3.1 Target Frequency Setting for DCI 50/60/72Z

The compressor target frequency is a function of the NLOAD number sent from the indoor controller and the outdoor air temperature.

Basic Target Frequency Setting:

| NLOAD | Target Frequency |
|--------------|--|
| 127 | <i>Maximum Frequency</i> |
| 10<NLOAD<127 | Interpolated value between minimum and maximum frequency |
| 10 | Minimum frequency |
| 0 | Compressor is stopped |

Target frequency limits as a function of outdoor air temperature (OAT):

| OAT Range | Cooling Mode limits | Heating Mode limits |
|---------------|----------------------|-----------------------|
| OAT < 6 | <i>MaxFreqAsOATC</i> | No limit |
| 6 ≤ OAT < 15 | | <i>MaxFreqAsOAT1H</i> |
| 15 ≤ OAT < 28 | | <i>MaxFreqAsOAT2H</i> |
| 28 ≤ OAT | No limit | |

12.1.3.2 Target Frequency Setting for DCI 72/80

The compressor Target Speed is calculated according to the following formula:

$$Target\ Speed_{load} = \max \left[MinSpeed, MaxSpeed \cdot \frac{ODUNload}{127} \right]$$

MiniSpeed, *MaxSpeed* are defined as following:

When the unit is in the cool mode, *MiniSpeedC* = 15Hz, *MaxSpeed* = 75Hz

When the unit is in the heat mode, *MiniSpeedH* = 20Hz, *MaxSpeed* = 95Hz

ODU NLOAD is caculated according to the IDU NLoad:

$$ODU\ NLOAD = \min \left\{ \frac{3 * IDUNLOAD}{ODUCode}, 127 \right\}$$


| OAT | ODUCodeC | ODUCodeH | IDUNLOAD |
|-----|----------|----------|---------------------------------|
| ≤-5 | 3 | 3 | Refer to sect. <u>112.1.2.1</u> |
| ≤-5 | 3.8 | 3 | |

12.1.4 Frequency Changes Control

When the unit is running normally , the compressor frequency change rate is 1 Hz/sec.

12.1.5 Compressor Starting Control

12.1.5.1 Compressor starting control for DCI50/60/72Zzz



12.1.5.2 Compressor starting control for DCI72/80

Step 1

Whenever the compressor starts up, after it has been off for more than 45 minutes, the compressor frequency cannot go below *Step1RPS* for 3 continuous minutes (*this rule comes to ensure oil return to the compressor*).

Step 2

The compressor speed cannot go above *Step2RPS* once after each compressor start up for 3 continuous minutes (*this rule comes to prevent oil exit from the compressor after its start up*).

Step 3

The speed cannot go higher than *Step3RPS* unless it was operating for more than 1 continuous minutes between *Step3RPS – 5* and *Step3RPS*.

After passing above *Step3RPS*, this rule is re-applied when passing below *Step3RPS-5*.

12.1.6 Minimum On and Off Time

3 minutes

12.1.7 Indoor Fan Control

8 Indoor fan speeds are determined for each model. 4 speeds for cool/dry/fan modes and 4 speeds for heat mode.

When user sets the indoor fan speed to a fixed speed (Low/ Medium/ High), unit will operate constantly at set speed.

When Auto Fan is selected, indoor unit controller can operate in all speeds. The actual speed is set according to the cool/heat load.

12.1.7.1 Turbo Speed

The Turbo speed is activated during the first 30 minutes of unit operation when auto fan speed is selected and under the following conditions:

Difference between set point and actual room temperature is bigger then 3 degrees.

Room temperature > 22 for cooling, or < 25 for heating.

12.1.8 Outdoor Fan Control

12.1.8.1 Outdoor Fan Control for DCI50/60

7 outdoor fan speeds are determined for each model. 3 speeds for cool and dry modes, and 3 speeds for heat mode, and a very low speed.


Outdoor fan speed is a function of compressor frequency and outdoor air temperature (OAT).

4 routines for fan control are determined. The control routine selection depends on operation mode, compressor speed, outdoor air temperature (OAT) and heat sink temperature (HST).

| Routine | Conditions |
|----------|---|
| A | Heating with OAT < 15°C or Cooling with OAT > 20°C, or Faulty OAT |
| B | Cooling with 20°C > OAT > 7°C |
| C | Cooling with 7°C > OAT |
| D | Heating with OAT > 15°C |

| Compressor Target Frequency | OFAN Speed | | | |
|--|-------------|-------------|-------------|-------------|
| | Routin A | Routin B | Routin C | Routin D |
| Freq=0 | OFF | OFF | OFF | OFF |
| $10 \leq \text{Freq} < \text{OFLowFreq}$ | Low | Low | VL | Low |
| $\text{OFLowFreq} \leq \text{Freq} < \text{OFMedFreq}$ | Medium | Low | VL | Low |
| $\text{OFMedFreq} \leq \text{Freq}$ | High | Low | Low | Medium |

When compressor is switched to OFF and the heat sink temperature is above 55 degrees, the outdoor fan will remain ON in low speed for up to 3 minutes.



12.1.8.2 Outdoor Fan Control for DCI72/72Z/80

OFAN operates between any speed *OFMinRPM* to *OFMaxRPM*.

The fan speed is also related to protections and OMT value.

* For DCI 72Z, in heating mode the OFAN speed is related to OCT.

12.1.9 EEV (Electronic Expansion Vavle) Control

12.1.9.1 EEV Control for DCI50/60

EEV opening is defined as $\text{EEV} = \text{EEVOL} + \text{EEVCV}$

EEVOL is the initial EEV opening as a function of the compressor frequency, operation mode, unit model and capacity.

EEVCV is a correction value for the EEV opening that is based on the compressor temperature.

During the first 5 minutes of compressor operation $\text{EEVCV} = 0$.

Once the first 5 minutes are over, the correction value is calculated as follow: $\text{EEVCV}(n) = \text{EEVCV}(n-1) + \text{EEVCTT}$

EEVCTT is the correction based on the compressor temperature. A target compressor temperature is set depending on frequency and outdoor air temperature, and the actual compressor temperature is compared to the target temperature to set the required correction to the EEV opening.

12.1.9.2 EEV Control for DCI72/72Z/80

The target EEV value is the sum of open loop value (OL) and a result of the accumulative correction values (CV).

$$EEV = EEV_{OL} + \sum EEV_{CV}$$

The EEV initial value(OL) is defined as follow:

$$EEV_{OL} = EEV_{BaseOpenLoop} + EEV_{OpenLoopCpctyCrct} + EEV_{TubeCompnst}$$

| Basic EEV open loop | | Open Loop correction | EEV tube Length compensation |
|---------------------|-------|----------------------|------------------------------|
| Mode | 72/80 | 72/80 | 72/80 |
| COOL | 220 | 25 | 0 |
| HEAT | 170 | 30 | 0 |

*For DCI72Z

The initial EEV_{OL} is defined in accordance to the compressor frequency

EEV_{CV} is a correction value for the EEV opening that is based on the compressor temperature, During the first 6 minutes after SB the correction is not calculated. After that the correction value is updated every 30 seconds.

12.1.10 RV(Reversing Valve) Control

Reversing valve is on in heat mode.


Switching of RV state is done only after compressor is off for over 3 minutes.

12.1.11 Ioniser Control

Ioniser is on when unit is on ,AND indoor fan is on ,AND Ioniser power switch (on Ioniser) is on.

12.1.12 Base Heater Control

The base heater will be working only when RV is "ON" according to the following graph:



When OAT is faulty the base heater will be "ON" continuously in HEAT mode.

12.2 Fan Mode

In high/ medium/ low indoor fan user setting, unit will operate fan in selected speed.

In AutoFan user setting, fan speed will be adjusted automatically according to the difference between actual room temperature and user set point temperature.

12.3 Cool Mode

NLOAD is calculated according to the difference between actual room temperature and user set point temperature by PI control.

In high/ medium/ low indoor fan user setting, unit will operate fan in selected speed.

In AutoFan user setting, fan speed will be adjusted automatically according to the calculated NLOAD.

12.4 Heat Mode

NLOAD is calculated according to the difference between actual room temperature and user set point temperature by PI control.

In high/ medium/ low indoor fan user setting, unit will operate fan in selected speed.

In AutoFan user setting, fan speed will be adjusted automatically according to the calculated NLOAD.

12.4.1 Temperature Compensation


In wall mounted, ducted, and cassette models, 3 degrees are reduced from room temperature reading (except when in I-Feel mode), to compensate for temperature difference between high and low areas in the heated room, and for coil heat radiation on room thermistor.

The temperature compensation can be enabled/disabled by shortening of J2 on the indoor unit Controller

| Model | J2 Shorted | J2 Opened |
|---------------|-----------------------|-----------------------|
| Wall mounted | Compensation Disabled | Compensation Enabled |
| Cassette | Compensation Enabled | Compensation Disabled |
| Ducted | Compensation Enabled | Compensation Disabled |
| Floor/Ceiling | Compensation Disabled | Compensation Enabled |

12.4.2 Indoor Fan Control in Heating Mode

Indoor fan speed depends on the indoor coil temperature:



12.5 Auto Cool/Heat Mode

When in auto cool heat mode unit will automatically select between cool and heat mode according to the difference between actual room temperature and user set point temperature (.T). Unit will switch from cool to heat when compressor is off for 3 minutes, and $.T < -3$.

Unit will switch from heat to cool when compressor is off for 5 minutes, and $.T < -3$.

12.6 Dry Mode

As long as room temperature is higher than the set point, indoor fan will work in low speed and compressor will work between 0 and *MaxNLOADIF1C* Hz.

When the room temperature is lower than the set point, compressor will be switched OFF and indoor fan will cycle 3 minutes OFF, 1 minute ON.

12.7 Protections

There are 5 protection codes.

Normal (Norm) – unit operate normally.

Stop Rise (SR) – compressor frequency can not be raised but does not have to be decreased.

HzDown1 (D1) – Compressor frequency is reduced by 2 to 5 Hz per minute.

HzDown2 (D2) – Compressor frequency is reduced by 5 to 10 Hz per minute.

Stop Compressor (SC) – Compressor is stopped.

12.7.1 Indoor Coil Defrost Protection

| ICT | ICT Trend | | | | |
|---------------------|-----------------|------------|-----------|------------|------|
| | Fast Increasing | Increasing | No Change | Decreasing | Fast |
| $ICT < -2$ | SC | SC | SC | SC | SC |
| $-2 \leq ICT < 0$ | D1 | D1 | D2 | D2 | D2 |
| $0 \leq ICT < 2$ | SR | SR | D1 | D2 | D2 |
| $2 \leq ICT < 4$ | SR | SR | SR | D1 | D2 |
| $4 \leq ICT < 6$ | Norm | Norm | SR | SR | D1 |
| $6 \leq ICT \leq 8$ | Norm | Norm | Norm | SR | SR |
| $ICT > 8$ | | | Norm | | |

12.7.2 Indoor Coil Overheating Protection

12.7.2.1 Indoor Coil Overheating Protection For 50/60/72Z

| ICT | ICT Trend | | | | |
|-----------------------|-----------------|------------|-----------|------------|-----------------|
| | Fast Decreasing | Decreasing | No Change | Increasing | Fast Increasing |
| $ICT > 62$ | SC | SC | SC | SC | SC |
| $60 \leq ICT < 62$ | D1 | D1 | D2 | D2 | D2 |
| $55 \leq ICT < 60$ | SR | SR | D1 | D2 | D2 |
| $52 \leq ICT < 55$ | SR | SR | SR | D1 | D2 |
| $48 \leq ICT < 52$ | Norm | Norm | SR | SR | D1 |
| $45 \leq ICT \leq 48$ | Norm | Norm | Norm | SR | SR |
| $ICT < 45$ | | | Norm | | |


12.7.2.2 Indoor Coil Overheating Protection For 72/80

| ICT | ICT Trend | | | | |
|------------------------------|-----------|------|--------|----|----|
| | <-2 | -2 | -1,0,1 | 2 | >2 |
| ICT >62 | SC | SC | SC | SC | SC |
| $60 \leq \text{ICT} < 62$ | D1 | D1 | D2 | D2 | D2 |
| $58 \leq \text{ICT} < 60$ | SR | SR | D1 | D2 | D2 |
| $56 \leq \text{ICT} < 58$ | SR | SR | SR | D1 | D2 |
| $54 \leq \text{ICT} < 56$ | Norm | Norm | SR | SR | D1 |
| $52 \leq \text{ICT} \leq 54$ | Norm | Norm | Norm | SR | SR |
| ICT <52 | Norm | | | | |

12.7.3 Compressor Overheating Protection

12.7.3.1 Compressor Overheating Protection for DCI50/60/72Z

Compressor temperature can be in one of 5 control zones (4 in protection, and 1 normal), according to the following chart.




| Control Status | Compressor Temperature Increases | Else |
|-----------------|----------------------------------|-----------|
| P1 | Normal | Stop Rise |
| P2 | HzDown 1 | Stop Rise |
| P3 | HzDown 2 | HzDown 1 |
| Stop Compressor | Stop Compressor | |

12.7.3.2 Compressor Overheating Protection for DCI72/80

| CTT | | CTT Trend | | | | |
|-----------------------|-----------------------|-----------------|------------|-----------|------------|-----------------|
| Cool | Heat | Fast Decreasing | Decreasing | No Change | Increasing | Fast Increasing |
| $CTT > 105$ | $CTT > 105$ | SC | SC | SC | SC | SC |
| $100 \leq CTT < 105$ | $100 \leq CTT < 105$ | D1 | D1 | D2 | D2 | D2 |
| $98 \leq CTT < 100$ | $95 \leq CTT < 100$ | SR | SR | D1 | D2 | D2 |
| $93 \leq CTT < 100$ | $85 \leq CTT < 95$ | SR | SR | SR | D1 | D1 |
| $90 \leq CTT \leq 93$ | $80 \leq CTT \leq 85$ | Norm | Norm | Norm | SR | SR |
| $CTT < 90$ | $CTT < 80$ | Norm | | | | |

12.7.4 Compressor Over Current Protection Only For DCI50/60/72Z



12.7.5 Heat Sink Overheating Protection

12.7.5.1 Heat Sink Overheating Protection For DCI50/60/72Z

| HST | HST Trend | | | | |
|-----------------------|-----------------|------------|-----------|------------|-----------------|
| | Fast Decreasing | Decreasing | No Change | Increasing | Fast Increasing |
| $HST \geq 90$ | SC | SC | SC | SC | SC |
| $85 \leq HST < 90$ | D1 | D1 | D2 | D2 | D2 |
| $82 \leq HST < 85$ | SR | SR | D1 | D2 | D2 |
| $80 \leq HST < 82$ | SR | SR | SR | D1 | D1 |
| $78 \leq HST \leq 80$ | Norm | Norm | Norm | SR | SR |
| $HST < 78$ | Norm | | | | |

12.7.5.2 Heat Sink Overheating Protection For DCI72/80

| HST | Delta HST | | | | |
|-----------------------|-----------|------|--------|----|----|
| | <-2 | -2 | -1,0,1 | 2 | >2 |
| $HST \geq 81$ | SC | SC | SC | SC | SC |
| $79 \leq HST < 81$ | D1 | D1 | D2 | D2 | D2 |
| $75 \leq HST < 79$ | SR | SR | D1 | D2 | D2 |
| $73 \leq HST < 75$ | SR | SR | SR | D1 | D1 |
| $71 \leq HST \leq 73$ | Norm | Norm | Norm | SR | SR |
| $HST < 71$ | Norm | | | | |

12.7.6 System Over Power Protection Only For DCI72/80

| Power | | Delta PWR | | | | |
|---------------------------|---------------------------|-----------|-----------|------|----------|--------|
| | | < -2000 | [-2000,0) | 0 | (0,2000] | > 2000 |
| PWR1 | PWR2 | | | | | |
| $PWR \geq 3500$ | $PWR \geq 2900$ | SC | SC | SC | SC | SC |
| $3300 \leq PWR < 3500$ | $2750 \leq PWR < 2900$ | D1 | D1 | D2 | D2 | D2 |
| $3100 \leq PWR < 3300$ | $2600 \leq PWR < 2750$ | SR | SR | D1 | D2 | D2 |
| $3000 \leq PWR < 3100$ | $2450 \leq PWR < 2600$ | SR | SR | SR | D1 | D1 |
| $2950 \leq PWR \leq 3000$ | $2300 \leq PWR \leq 2450$ | Norm | Norm | Norm | SR | SR |
| $PWR < 2950$ | $PWR < 2300$ | Norm | | | | |

There are two sets of OVRPWR values, the selection of the values are set according to the state of the Power-Shed input.

Power-Shed input open Set values 1

Power-Shed input sort Set values 2

12.7.7 Outdoor Coil Deicing Protection

12.7.7.1 Outdoor coil Deicing Protection For DCI50/60/72Z

► Entering Deicing Conditions

Deicing operation will start when either one of the following conditions exist:

Case 1: $OCT < OAT - 8$ AND $TLD > DI$

Case 2: $OCT < OAT - 12$ AND $TLD > 30$ minutes.

Case 3: OCT is Invalid AND $TLD > DI$

Case 4: Unit is just switched to STBY AND $OCT < OAT - 8$

Case 5: $NLOAD = 0$ AND $OCT < OAT - 8$

Case 6: $OCT < -19$ AND $TLD > 60$ minutes

All this condition will exist during 10 seconds

OCT – Outdoor Coil Temperature

OAT – Outdoor Air Temperature


TLD – Time from Last Deicing

DI – Deicing Interval (Time Interval Between Two Deicing)

Deicing interval time when compressor is first started in heat mode, is 10 minutes if $OCT < -2$, and is 40 minutes in other cases.

Deicing interval time is changed (increased/ decreased in 10 minutes steps) as a function of deicing time. If deicing time is shorter then former deicing time, the deicing interval time will be increased. If deicing time is longer then former deicing time, the deicing interval time will be decreased.

► Deicing Operation Procedure



T1=60 secondes; T2=36 secondes; T3=6 secondes

12.7.7.2 Outdoor coil Deicing Protection For DCI72/80

► Entering Deicing Conditions

Deicing operation will start when either one of the following conditions exist:

Case 1: $OCT < OAT - 8$ AND $TLD > DI$

Case 2: $OCT < OAT - 12$ AND $TLD > 30$ minutes.

Case 3: OCT is Invalid AND $TLD > DI$

Case 4: Unit is just switched to STBY AND $OCT < OAT - 8$

Case 5: $NLOAD = 0$ AND $OCT < OAT - 8$

Case 6: OAT is invalid AND $OCT < 8$ AND $TLD > DI$ AND Compressor ON Time > 15 minutes

All this condition will exist during 400 seconds

OCT – Outdoor Coil Temperature

OAT – Outdoor Air Temperature


TLD – Time from Last Deicing

DI – Deicing Interval (Time Interval between Two Deicing)

Deicing interval time when compressor is first started in heat mode, is 10 minutes if $OCT < -2$, and is 40 minutes in other cases.

Deicing interval time is changed (increased/ decreased in 10 minutes steps) as a function of deicing time. If deicing time is shorter then former deicing time, the deicing interval time will be increased. If deicing time is longer then former deicing time, the deicing interval time will be decreased.

► Deicing Operation Procedure



T1=50 secondes;T2=36 secondes;T3=6 secondes

12.7.8 Condensate Water Over Flow Protection



Each of the pins P1, P2, P3 can have two options:

1 – When it is shorted with P4


0 – When it is not shorted to P4

► Water Level Protection-1 level

| P1 | P2 | P3 | Level |
|------------|------------|----|----------|
| Don't care | Don't care | 1 | Normal |
| Don't care | Don't care | 0 | Overflow |

(*) 1- Pin P1, P2, or P3 is connected to P4.

0- Pin P1, P2 or P3 is not connected to P4.



12.8 Indoor Unit Dry Contact

Indoor unit Dry contact has two alternative functions that are selected by J9.

| | Function | Contact=open | Contact=short |
|----------|------------------------------|--------------|---------------|
| J9=open | Presence Detector Connection | No limit | Force to STBY |
| J9=short | Power Shedding Function | No limit | Limit NLOAD |

12.9 Operating the Unit from Mode Button

Forced operation allows to start, stop and operate in Cooling or Heating, in pre-set temperature according to the following table:

| Forced operation Mode | Pre-set Temperature |
|-----------------------|---------------------|
| Cooling | 20°C |
| Heating | 28°C |

12.10 On Unit Controls and Indicators

12.10.1 Indoor Unit controller Controls and Indications for All Models Except for Floor/Ceiling model

During OFF, Fan, Cool, Heat, Dry, and Auto modes (for operation in other modes, see at the relevant spec paragraph):

| | |
|-----------------------------|--|
| STAND BY INDICATOR | 1. Lights up when the Air Conditioner is connected to power and ready to receive the R/C commands |
| OPERATION INDICATOR | <ol style="list-style-type: none"> 1. Lights up during operation. 2. Blinks for 300 msec., to announce that a R/C infrared signal has been received and stored. 3. Blinks continuously during protections (according to the relevant spec section). |
| TIMER INDICATOR | Lights up during Timer and Sleep operation. |
| FILTER INDICATOR | Lights up when Air Filter needs to be cleaned. |
| COOLING INDICATOR | Lights up when system is switched to Cool Mode by using the Mode Switch <u>on the unit</u> . |
| HEATING INDICATOR | Lights up when system is switched Heat Mode by using the Mode Switch <u>on the unit</u> . |
| Mode SWITCH (COOL/HEAT/OFF) | <p>Every short pressing , the next operation mode is selected, in this order : SB → Cool Mode → Heat Mode → SB → ...</p> <p>In long pressing system enters diagnostic mode.</p> |
| RESET / FILTER SWITCH | <p>For short pressing:</p> <p>When Filter LED is on - turn off the FILTER INDICATOR after a clean filter has been reinstalled.</p> <p>When Filter LED is off – enable/disable the buzzer announcer, if selected.</p> <p>In long pressing system enters set up mode (if in SB).</p> |

12.10.2 Outdoor Unit controller Indications

Unit has three LED's.

SB LED is ON when power is ON (230 VAC, even when no communication).

STATUS LED is ON when COMP is ON, and Blinks according to diagnostics mode definitions when either fault or protection occurs.

FAULT LED Blinks according to diagnostics mode definitions when either fault or protection occurs.

12.11 Test Mode

12.11.1 Entering Test Mode

System can enter Test mode in two ways:

Automatically when the following conditions exists for 30 minutes continuously:

Mode = Cool, Set point = 16, Room temperature = $27(+1/-2)$, Outdoor temperature = $35(+2/-1)$

Or

Mode = Heat, Set point = 30, Room temperature = 20 ± 1 , Outdoor temperature = $7\pm(+1/-2)$

Manually when entering diagnostics with the following settings:

Mode = Cool, Set point = 16

Mode = Heat, Set point = 30

12.11.2 Unit Operation in Test Mode

In test mode, the unit will operate in fixed settings according to the indoor fan speed setting:

| Indoor FAN Speed Setting | Unit Setting |
|--------------------------|--------------------------|
| Low | Minimum Capacity Setting |
| Turbo | Nominal Capacity Setting |
| Auto | Maximum Capacity Setting |

During test mode, protections are disabled, except for stop compressor status.

12.12 SW Parameters

12.12.1 Indoor Units SW Parameters

Model dependent parametes - KN

| | A (KN-60) | B (KN-72) | C (KN-80) |
|--------------|--------------|--------------|--------------|
| Cap .Group | 3 | 4 | 4 |
| NomLoadC | 81 | 61 | 67 |
| NomLoadH | 77 | 59 | 67 |
| MaxNLOADIF1C | 55 | 44 | 85 |
| MaxNLOADIF2C | 70 | 50 | 102 |
| MaxNLOADIF3C | 127 | 120 | 120 |
| MaxNLOADIF4C | 127 | 127 | 127 |
| MaxNLOADIF5C | 127 | 127 | 127 |
| MinRTC | 20 | 20 | 20 |
| MaxNLOADRTC | 127 | 127 | 127 |
| MaxNLOADIF1H | 127 | 127 | 127 |
| MaxNLOADIF2H | 127 | 127 | 127 |
| MaxNLOADIF3H | 127 | 127 | 127 |
| MaxNLOADIF4H | 127 | 127 | 127 |
| MaxNLOADIF5H | 127 | 127 | 127 |
| MaxNLOADRTH | 127 | 127 | 127 |
| MaxRTH | 27 | 27 | 27 |
| MaxNLOADPSC | 81 | 61 | 67 |
| MaxNLOADPSH | 77 | 59 | 67 |

Model dependent parameters - DNG

| Unit | A (DNG50) | B (DNG60) | C (DNG72) | D (DNG80) |
|--------------|--------------|--------------|--------------|--------------|
| Cap .Group | 3 | 3 | 4 | 4 |
| NomLoadC | 62 | 77 | 57 | 60 |
| NomLoadH | 74 | 80 | 55 | 63 |
| ICTSTSpeed | 22 | 22 | 22 | 22 |
| ICTVLSpeed | 28 | 28 | 28 | 28 |
| ICTLSpeed | 30 | 30 | 30 | 30 |
| ICTHSpeed | 32 | 32 | 32 | 32 |
| ICTTSpeed | 40 | 40 | 40 | 40 |
| MaxNLOADIF1C | 50 | 50 | 63 | 78 |
| MaxNLOADIF2C | 63 | 63 | 85 | 100 |
| MaxNLOADIF3C | 120 | 120 | 115 | 127 |
| MaxNLOADIF4C | 127 | 127 | 127 | 127 |
| MaxNLOADIF5C | 127 | 127 | 127 | 127 |
| MinRTC | 20 | 20 | 20 | 20 |
| MaxNLOADRTC | 127 | 127 | 127 | 127 |
| MaxNLOADIF1H | 127 | 127 | 127 | 127 |
| MaxNLOADIF2H | 127 | 127 | 127 | 127 |
| MaxNLOADIF3H | 127 | 127 | 127 | 127 |
| MaxNLOADIF4H | 127 | 127 | 127 | 127 |
| MaxNLOADIF5H | 127 | 127 | 127 | 127 |
| MaxNLOADRTH | 127 | 127 | 127 | 127 |
| MaxRTH | 27 | 27 | 27 | 27 |
| MaxNLOADPSC | 62 | 77 | 57 | 60 |
| MaxNLOADPSH | 74 | 80 | 55 | 63 |

Model dependent parameters - WNG

| Parameter name | (WNG) Wall Mounted Models | | | | | |
|---|---------------------------|------|------|------|------|------|
| | 25 | 35 | 50 | 60 | 72 | 80 |
| NLOAD limits as a function of selected indoor fan speed | | | | | | |
| MaxNLOADIF1C | 40 | 40 | 45 | 50 | 53 | 68 |
| MaxNLOADIF2C | 53 | 53 | 62 | 85 | 75 | 90 |
| MaxNLOADIF3C | 120 | 120 | 120 | 120 | 105 | 120 |
| MaxNLOADIF4C | 127 | 127 | 127 | 127 | 127 | 127 |
| MaxNLOADIF5C | 127 | 127 | 127 | 127 | 127 | 127 |
| Indoor Fan speeds | | | | | | |
| IFVLOWC | 700 | 700 | 700 | 800 | 850 | 850 |
| IFLOWC | 800 | 800 | 900 | 1000 | 1000 | 1000 |
| IFMEDC | 900 | 950 | 1050 | 1100 | 1150 | 1150 |
| IFHIGHC | 1050 | 1100 | 1200 | 1250 | 1350 | 1300 |
| IFTURBOC | 1150 | 1200 | 1250 | 1300 | 1400 | 1350 |
| IFVLOWH | 700 | 700 | 700 | 800 | 900 | 900 |
| IFLOWH | 800 | 850 | 900 | 950 | 1050 | 1050 |
| IFMEDH | 950 | 1000 | 1100 | 1150 | 1200 | 1200 |
| IFHIGHH | 1100 | 1150 | 1250 | 1250 | 1350 | 1300 |
| IFTURBOH | 1200 | 1250 | 1300 | 1300 | 1400 | 1350 |

Model dependent parameters - PXD

| Unit | A (PXD50) | B (PXD60) | C (PXD72) | D (PXD80) |
|--------------|--------------|--------------|--------------|--------------|
| Cap .Group | 3 | 3 | 4 | 4 |
| NomLoadC | 68 | 80 | 60 | 63 |
| NomLoadH | 77 | 82 | 60 | 67 |
| MaxNLOADIF1C | 40 | 50 | 127 | 127 |
| MaxNLOADIF2C | 60 | 85 | 127 | 127 |
| MaxNLOADIF3C | 90 | 127 | 127 | 127 |
| MaxNLOADIF4C | 90 | 127 | 127 | 127 |
| MaxNLOADIF5C | 90 | 127 | 127 | 127 |
| MinRTC | 20 | 20 | 20 | 20 |
| MaxNLOADRTC | 127 | 127 | 127 | 127 |
| MaxNLOADIF1H | 127 | 127 | 127 | 127 |
| MaxNLOADIF2H | 127 | 127 | 127 | 127 |
| MaxNLOADIF3H | 127 | 127 | 127 | 127 |
| MaxNLOADIF4H | 127 | 127 | 127 | 127 |
| MaxNLOADIF5H | 127 | 127 | 127 | 127 |
| MaxNLOADRTH | 127 | 127 | 127 | 127 |
| MaxRTH | 27 | 27 | 27 | 27 |
| MaxNLOADPSC | 68 | 80 | 60 | 63 |
| MaxNLOADPSH | 77 | 82 | 60 | 67 |

12.12.2 Outdoor Units SW Parameters:**Model dependent parameters for DCI50/60**

| # | Name | Single DCI-50 | Single DCI 60 |
|----|-------------------|---------------|---------------|
| 1 | MinFreqC | 20 | 20 |
| 2 | MaxFreqC | 85 | 95 |
| 3 | MinFreqH | 20 | 26 |
| 4 | MaxFreqH | 95 | 94 |
| 5 | NormAccel | 1 | 1 |
| 6 | NormDecel | 1 | 1 |
| 7 | Step1Freq | 60 | 60 |
| 8 | Step2Freq | 70 | 70 |
| 9 | Step3Freq | 90 | 90 |
| 10 | OFVL | 20 | 20 |
| 11 | OFLOWC | 60 | 55 |
| 12 | OFMEDC | 76 | 70 |
| 13 | OFMAXC | 92 | 79 |
| 14 | OFLOWH | 60 | 55 |
| 15 | OFMEDH | 83 | 70 |
| 16 | OFMAXH | 100 | 79 |
| 17 | OFANTESTMODEC | 92 | 83 |
| 18 | OFANTESTMODEH | 100 | 83 |
| 19 | OFDeITestMode | 28 | 28 |
| 20 | CTTOH1 | 94 | 94 |
| 21 | CTTOH2 | 98 | 98 |
| 22 | CTTOH3 | 102 | 102 |
| 23 | CTTOH4 | 105 | 105 |
| 24 | CCROC1 | 10 | 11.4 |
| 25 | CCROC2 | 10.5 | 11.8 |
| 26 | CCROC3 | 10.8 | 12.2 |
| 27 | CCROC4 | 11.2 | 12.6 |
| 28 | DEICT1 | 60 | 60 |
| 29 | DEICT2 | 36 | 36 |
| 30 | DEICT3 | 6 | 6 |
| 31 | ProtFreqLimit | 60 | 60 |
| 32 | EEVDecierOpen | 100 | 180 |
| 33 | OptimDeicFreq | 90 | 90 |
| 34 | EEVMinOperOpenC | 50 | 80 |
| 35 | EEVMaxOperOpenC | 380 | 380 |
| 36 | EEVMinOperOpenH | 50 | 60 |
| 37 | EEVMaxOperOpenH | 380 | 300 |
| 38 | EEVNormRate | 33 | 33 |
| 39 | EEVHighRate | 12 | 12 |
| 40 | EEVMaxOpen | 500 | 500 |
| 41 | OFLowFreqC | 40 | 35 |
| 42 | OFMedFreqC | 70 | 55 |
| 43 | OFLowFreqH | 40 | 40 |
| 44 | OFMedFreqH | 86 | 60 |
| 45 | HeaterDisableFlag | 0 | 0 |
| 46 | DeiceFreqChRV | 0 | 0 |
| 47 | OATRefC | 35 | 35 |
| 48 | SUCT Enable | 0 | 0 |
| 49 | HST Enable | 1 | 1 |
| 50 | OAT Enable | 1 | 1 |
| 51 | OATRefH | 7 | 7 |
| 52 | MinTargCTTC | 30 | 30 |
| 53 | MaxTargCTTC | 95 | 90 |
| 54 | MinTargCTTH | 40 | 45 |
| 55 | MaxTargCTTH | 95 | 90 |
| 56 | DST | 8 | 8 |
| 57 | DSTF | 12 | 12 |
| 58 | OATLimitC | 28 | 28 |
| 59 | OATLimit1H | 6 | 6 |
| 60 | OATLimit2H | 15 | 15 |
| 61 | MaxFreqAsOATC | 64 | 85 |
| 62 | MaxFreqAsOAT1H | 85 | 80 |
| 63 | MaxFreqAsOAT2H | 60 | 60 |

Model dependent parameters for DCI72Z

| No. | Name | Single DCI-72Z |
|-----|-------------------|-------------------|
| 1 | MinFreqC | 15 |
| 2 | MaxFreqC | 70 |
| 3 | MinFreqH | 15 |
| 4 | MaxFreqH | 90 |
| 7 | Step1Freq | 35 |
| 8 | Step2Freq | 55 |
| 9 | Step3Freq | 90 |
| 10 | OFMinRPM | 8 |
| 11 | OFMaxRPM | 90 |
| 12 | NightRPM | 65 |
| 13 | OFNNoiseMaxRPM | 78 |
| 14 | CTTOH1 | 90 |
| 15 | CTTOH2 | 95 |
| 16 | CTTOH3 | 100 |
| 17 | CTTOH4 | 105 |
| 18 | CCROC1 | 12.5 |
| 19 | CCROC2 | 13.3 |
| 20 | CCROC3 | 14.1 |
| 21 | CCROC4 | 14.9 |
| 22 | ProtFreqLimit | 60 |
| 23 | EEVMinOperOpenC | 50 |
| 24 | EEVMaxOperOpenC | 480 |
| 25 | EEVMinOperOpenH | 50 |
| 26 | EEVMaxOperOpenH | 480 |
| 27 | HeaterDisableFlag | 0 |
| 28 | HST Enable | 1 |
| 29 | OATLimitC | 24 |
| 30 | OATLimit1H | 6 |
| 31 | OATLimit2H | 15 |
| 32 | MaxFreqAsOATC | 60 |
| 33 | MaxFreqAsOAT1H | 85 |
| 34 | MaxFreqAsOAT2H | 75 |
| 35 | NormAccel | 1 |
| 36 | NormDecel | 1 |

Model dependent parameters for DCI72/80

| Compressor Parameters | Value |
|------------------------------|--------------|
| <i>MinOFFTime</i> | 3 |
| <i>MinOnTime</i> | 3 |
| <i>MaxCTT1</i> | 90 |
| <i>MaxCTT2</i> | 90 |
| <i>MinSpeedAsCTT1</i> | 26 |
| <i>MinSpeedAsCTT2</i> | 26 |
| <i>MaxSpeedC</i> | 75 |
| <i>MaxSpeedH</i> | 95 |
| <i>Step1RPS</i> | 40 |
| <i>Step2RPS</i> | 60 |
| <i>Step3RPS</i> | 75 |
| <i>NormAcc (sec/RPS)</i> | 1 |
| <i>NormDec (sec/RPS)</i> | 1 |
| <i>Down1(Sec/RPS)</i> | 12 |
| <i>Down2 (Sec/RPS)</i> | 7 |
| <i>DeiceAcc (Sec/RPS)</i> | 0.2 |
| <i>DeiceDec (Sec/RPS)</i> | 0.5 |

| EEV Parameters | Value |
|-----------------------------|--------------|
| <i>NormEEVRate</i> | 30 |
| <i>EEVCompOFFOpen</i> | 200 |
| <i>EEVCompOFFTime</i> | 60 |
| <i>EEVMaxOpen</i> | 500 |
| <i>EEVMinOperOpenC</i> | 60 |
| <i>EEVMaxOperOpenC</i> | 500 |
| <i>EEVMinOperOpenH</i> | 70 |
| <i>EEVMaxOperOpenH</i> | 500 |
| <i>EEVMinOperOpenHInIDU</i> | 60 |
| <i>EEVMaxOperOpenHInIDU</i> | 140 |
| <i>EEVIDUOFFOpen</i> | 130 |
| <i>EEVMoveSteps</i> | 20 |
| <i>EEVTConstC</i> | 30 |
| <i>EEVTConstH</i> | 30 |
| <i>BlncTimTrnsStC</i> | 1 |
| <i>BlncTimStdyStC</i> | 1 |
| <i>BlncTimTrnsStH</i> | 1 |
| <i>BlncTimStdyStH</i> | 1 |
| <i>CompOffTimToTrnsSt</i> | 20 |

13. TROUBLESHOOTING

13.1 Troubleshooting for DCI50/60/72Z

WARNING!!!

When Power Up – the whole outdoor unit controller, including the wiring, is under HIGH VOLTAGE!!!

Never open the Outdoor unit before turning off the Power!!!

When turned off, the system is still charged (400V)!!!

It takes about 3 Min. to discharge the system.

Touching the controller before discharging may cause an electrical shock!!!

13.1.1 Single Split System failures and Corrective Actions

| No | Symptom | Probable Cause | Corrective Action |
|----|---|--|---|
| 1 | Power supply indicator (Red LED) does not light up. | No power supply | Check power supply. If power supply is OK, check display and display wiring. if OK, replace controller. |
| 2 | Unit does not respond to remote control message | Remote control message not reached the indoor unit | Check remote control batteries, if batteries are OK, check display and display wiring, if OK, replace display PCB. If still not OK replace controller. |
| 3 | Unit responds to remote control message but Operate indicator (Green LED) does not light up | Problem with display PCB | Replace display PCB. If still not OK replace controller. |
| 4 | Indoor fan does not start (louvers are opened and Green LED does light up) | Unit in heat mode and coil is still not warm. | Change to cool mode and check. |
| | | Problem with PCB or capacitor | Change to high speed and Check power supply to motor is higher than 130VAC (for triack controlled motor) or higher than 220VAC for fixed speed motors, if OK replace capacitor, if not OK replace controller. |
| 5 | Indoor fan works when unit is OFF, and indoor fan speed is not changed by remote control command. | PCB problem | Replace controller |
| 6 | Compressor does not start | Electronics control problem or protection | Perform diagnostics and follow the actions described. |
| 7 | Compressor stops during operation and Green LED remains on | Electronic control or power supply problem | Perform diagnostics and follow the actions described. |
| 8 | Compressor is on but outdoor fan does not work | Problem with outdoor electronics or outdoor fan | Check outdoor fan motor according to the procedure below, if not OK replace controller. |

| No | Symptom | Probable Cause | Corrective Action |
|----|---|---|---|
| 9 | Unit works in wrong mode (cool instead of heat or heat instead of cool) | Electronics or power connection to RV | Check RV power connections, if OK, check RV operation with direct 230VAC power supply, if OK, replace outdoor controller. |
| 10 | All components are operating properly but no cooling or no heating | Refrigerant leak | Check refrigeration system. |
| 11 | Compressor is over heated and unit does not generate capacity | EEV problem | Check EEV. |
| 12 | Units goes into protections and compressor is stopped with no clear reason | Control problem or refrigeration system problem | Perform diagnostics , and follow the actions described. |
| 13 | Compressor motor is generating noise and no suction occurs | Phase order to compressor is wrong | Check compressor phase order. |
| 14 | Water leakage from indoor unit | Indoor unit drainage tube is blocked | Check and open drainage tube. |
| 15 | Freezing of outdoor unit in heat mode and outdoor unit base is blocked with ice | | Connect base heater. |
| 16 | Unit operates with wrong fan speeds or wrong frequency | Wrong jumper settings | Perform diagnostics, and check if units is operating by EEPROM parameters. |

13.1.2 Checking the refrigeration system

Checking system pressures and other thermodynamic measures should be done when system is in Test Mode (in Test mode, system operates in fixed settings). The performance curves given in this manual are given for unit performance in test mode when high indoor fan speed is selected.

Entering test mode:

Set unit to Cool/16 degrees/High indoor fan speed, or Heat/30 degrees/High indoor fan speed, and enter diagnostics.

13.1.3 Judgment by Indoor/Outdoor Unit Diagnostics

Enter diagnostics mode - press for five seconds Mode button in any operation mode. Acknowledgment is by 3 short beeps and lights of COOL and HEAT LED's. Then, every short pressing of Mode button will scroll between Indoor and Outdoor unit diagnostic modes by the acknowledgment of 3 short beeps and lighting of COOL and HEAT LED's.

During the Outdoor unit diagnostics all four Indoor LED's (STBY, Operate, Filter and Timer) are blinking. When Indoor diagnostics is displayed, all four LED's (STBY, Operate, Filter and Timer) are ON.

When system enters diagnostics mode, only one fault code is shown. Order of priority is from the lower to the higher number. Diagnostics is continuously ON as long as power is ON. The current system operation mode will not be changed.

If no fault occurred in the system, no fault code will be displayed during normal operation mode. The last fault code will be displayed even if the system has recovered from that fault. The last fault will be deleted from the EEPROM after the system has exit diagnostics mode.

In diagnostics mode, system fault / status will be indicated by blinking of Heat & Cool LEDs.

The coding method will be as follows:

Heat LED will blink 5 times in 5 seconds, and then will be shut off for the next 5 seconds. Cool LED will blink during the same 5 seconds according to the following Indoor / Outdoor unit tables:

Note: 0 – OFF, 1-ON

13.1.4 Indoor Unit Diagnostics

| No | Problem | 5 | 4 | 3 | 2 | 1 |
|-----|---------------------------|---|---|---|---|---|
| 1 | RT-1 is disconnected | 0 | 0 | 0 | 0 | 1 |
| 2 | RT-1 is shorted | 0 | 0 | 0 | 1 | 0 |
| 3 | RT-2 is disconnected | 0 | 0 | 0 | 1 | 1 |
| 4 | RT-2 is shorted | 0 | 0 | 1 | 0 | 0 |
| 5 | Reserved | 0 | 0 | 1 | 0 | 1 |
| 7 | Communication mismatch | 0 | 0 | 1 | 1 | 1 |
| 8 | No Communication | 0 | 1 | 0 | 0 | 0 |
| 9 | No Encoder | 0 | 1 | 0 | 0 | 1 |
| 10 | Reserved | 0 | 1 | 0 | 1 | 0 |
| 11 | Outdoor Unit Fault | 0 | 1 | 0 | 1 | 1 |
| ... | Reserved | | | | | |
| 17 | Defrost protection | 1 | 0 | 0 | 0 | 1 |
| 18 | Deicing Protection | 1 | 0 | 0 | 1 | 0 |
| 19 | Outdoor Unit Protection | 1 | 0 | 0 | 1 | 1 |
| 20 | Indoor Coil HP Protection | 1 | 0 | 1 | 0 | 0 |
| 21 | Overflow Protection | 1 | 0 | 1 | 0 | 1 |
| 22 | Reserved | | | | | |
| 24 | EEPROM Not Updated | 1 | 1 | 0 | 0 | 0 |
| 25 | Bad EEPROM | 1 | 1 | 0 | 0 | 1 |
| 26 | Bad Communication | 1 | 1 | 0 | 1 | 0 |
| 27 | Using EEPROM data | 1 | 1 | 0 | 1 | 1 |
| 28 | Model A | 1 | 1 | 1 | 0 | 0 |
| 29 | Model B | 1 | 1 | 1 | 0 | 1 |
| 30 | Model C | 1 | 1 | 1 | 1 | 0 |
| 31 | Model D | 1 | 1 | 1 | 1 | 1 |

13.1.4.1 Indoor Unit Diagnostics and Corrective Actions

| No. | Fault | Probable Cause | Corrective Action |
|-----|---|---|--|
| 1 | Sensor failures of all types | | Check sensor connections or replace sensor |
| 2 | Communication mismatch | Indoor and Outdoor controllers are with different versions | Replace Indoor controller |
| 3 | No Communication | Communication or grounding wiring is not good. | Check Indoor to Outdoor wiring and grounding |
| 4 | No Encoder | Indoor electronics or motor | Check motor wiring, if ok, replace motor, if still not ok, replace Indoor controller. |
| 5 | Outdoor Unit Fault | Outdoor controller problem | Switch to Outdoor diagnostics. |
| 6 | EEPROM Not Updated | System is using ROM parameters and not EEPROM parameters | No action, unless special parameters are required for unit operation. |
| 7 | Bad EEPROM | | No action, unless special parameters are required for unit operation. |
| 8 | Bad Communication | Communication quality is low reliability | Check Indoor to Outdoor wiring and grounding |
| 9 | Using EEPROM data | No problem. System is using EEPROM parameters | |
| 10 | The power supply indicator (red led) doesn't light up. | There is no correct voltage between the line and neutral terminals on main P.C.B. | <p>-If the voltage is low repair power supply.</p> <p>-If there is no voltage repair general wiring.</p> <p>-If there is correct voltage replace main or display P.C.B'S</p> |
| 11 | The operating indicator (green led) does not light up | The remote control batteries are discharged | -Replace batteries of the remote control |
| 12 | The operating indicator (green led) does not light up when starting from unit.. | Check main P.C.B and display P.C.B. | -Replace P.C.B if necessary. |
| 13 | The indoor fan does not function correctly. | Check the voltage between indoor fan terminals on the main P.C.B | - If there is voltage replace capacitor or motor. |

| No. | Fault | Probable Cause | Corrective Action |
|-----|---|---|--|
| 14 | The outdoor fan does not function correctly. | <p>Check the voltage between indoor fan terminals on the main P.C.B.</p> <p>There is voltage between outdoor fan terminals on the outdoor unit.</p> <p>There is no voltage between outdoor fan terminals on the outdoor unit.</p> | <p>- If there is no voltage replace main P.C.B</p> <p>- Replace capacitor or motor.</p> <p>- Check and repair electrical wiring between indoor and outdoor units.</p> |
| 15 | The compressor does not start up. | <p>Check voltage on compressor terminals on the outdoor unit. (with ampmeter)</p> <p>Check if there is correct voltage between compressor terminals on the outdoor unit.</p> | <p>-If no voltage replace main P.C.B.</p> <p>- If low voltage repair power supply.</p> <p>-If the voltage correct replace capacitor or compressor.</p> <p>-If there is no voltage repair electrical wiring between indoor and outdoor units.</p> |
| 16 | The refrigeration system does not function correctly. | Check for leaks or restrictions, with ampmeter, pressure guage or surface thermometer. | - Repair refrigeration system and charge refrigerant if necessary. |
| 17 | No cooling or heating only indoor fan works. | Outdoor fan motor faulty or other fault caused, compressor overload protection cut out. | <p>-Replace P.C.B.</p> <p>- Outdoor fan blocked remove obstructions.</p> |
| 18 | Only indoor fan and compressor working. | Outdoor fan blocked. | - Remove obstructions. |
| 19 | Only indoor fan working. | <p>-Run capacitor of outdoor fan motor faulty.</p> <p>-Windings of outdoor fan are shorted.</p> | <p>- Replace capacitor.</p> <p>-Replace motor.</p> |

| No. | Fault | Probable Cause | Corrective Action |
|-----|--|---|---|
| 20 | No cooling or heating takes place, indoor and outdoor fans working. | <ul style="list-style-type: none"> - Overload safety device on compressor is cut out (low voltage or high temperature) - Compressor run capacitor faulty. - Compressor windings are shorted. | <ul style="list-style-type: none"> - Check for proper voltage, switch off power and try again after one hour. - Replace compressor capacitor. - Replace compressor. |
| 21 | No air supply at indoor unit, compressor operates. | <ul style="list-style-type: none"> -Indoor fan motor is blocked or turns slowly. -indoor fan run capacitor faulty. - motor windings are shorted. | <ul style="list-style-type: none"> - Check voltage, repair wiring if necessary. -Check fan wheel if it is tight enough on motor shaft, tighten if necessary. -Replace indoor fan motor. |
| 22 | Partial, limited air supply at indoor indoor unit. | Lack of refrigerant (will accompanied by whisteling noise) cause ice formation on indoor unit coil in cooling mode. | -Charge the unit after localizing leak. |
| 23 | Water accumulates and overflow from indoor unit section. | Drain tube or spout of drain pan clogged. | -Disassemble plastic drain tube from spout of indoor unit drain pan. |
| 24 | Water dripping from outdoor unit base. (in heating mode) | Water drain outlet is clogged. | -Open outdoor unit cover clean out water outlet ,clean the base inside throughly. |
| 25 | Freeze-up of outdoor coil in heating mode, poor heating effect in room, indoor fan operates. | <ul style="list-style-type: none"> -Faulty outdoor thermistor. -Faulty control cable. - Outdoor temperature is too low (below -2°C) -Outdoor unit air outlet is blocked. | <ul style="list-style-type: none"> -Replace thermistor. - Repair control cable. - Shut unit off, outdoor temp. is below design conditions and cannot function properly. -Remove obstructions. |

13.1.5 Outdoor Unit Diagnositis

| No | Problem | 5 | 4 | 3 | 2 | 1 |
|----|--|---|---|---|---|---|
| 1 | OCT is disconnected | 0 | 0 | 0 | 0 | 1 |
| 2 | OCT is shorted | 0 | 0 | 0 | 1 | 0 |
| 3 | CTT is disconnected | 0 | 0 | 0 | 1 | 1 |
| 4 | CTT is shorted | 0 | 0 | 1 | 0 | 0 |
| 5 | HST is disconnected (when enabled) | 0 | 0 | 1 | 0 | 1 |
| 6 | HST is shorted (when enabled) | 0 | 0 | 1 | 1 | 0 |
| 7 | OAT is disconnected (when enabled) | 0 | 0 | 1 | 1 | 1 |
| 8 | OAT is shorted (when enabled) | 0 | 1 | 0 | 0 | 0 |
| 9 | TSUC is disconnected (when enabled) | 0 | 1 | 0 | 0 | 1 |
| 10 | TSUC is shorted (when enabled) | 0 | 1 | 0 | 1 | 0 |
| 11 | IPM Fault | 0 | 1 | 0 | 1 | 1 |
| 12 | Bad EEPROM | 0 | 1 | 1 | 0 | 0 |
| 13 | DC under voltage | 0 | 1 | 1 | 0 | 1 |
| 14 | DC over voltage | 0 | 1 | 1 | 1 | 0 |
| 15 | AC under voltage | 0 | 1 | 1 | 1 | 1 |
| 16 | Indoor / Outdoor unit Communication mismatch | 1 | 0 | 0 | 0 | 0 |
| 17 | No Communication | 1 | 0 | 0 | 0 | 1 |
| 18 | Reserved | 1 | 0 | 0 | 1 | 0 |
| 20 | Heat sink Over Heating | 1 | 0 | 1 | 0 | 0 |
| 21 | Deicing | 1 | 0 | 1 | 0 | 1 |
| 22 | Compressor Over Heating | 1 | 0 | 1 | 1 | 0 |
| 23 | Compressor Over Current | 1 | 0 | 1 | 1 | 1 |
| 24 | No OFAN Feedback | 1 | 1 | 0 | 0 | 0 |
| 25 | OFAN locked | 1 | 1 | 0 | 0 | 1 |
| 26 | Compressor Lock | 1 | 1 | 0 | 1 | 0 |
| 27 | Bad Communication | 1 | 1 | 0 | 1 | 1 |

13.1.5.1 Outdoor Unit Diagnostics and Corrective Actions

| No | Fault | Probable Cause | Corrective Action |
|----|--|--|---|
| 1 | Sensors failures of all types | | Check sensors connections or replace sensors. |
| 2 | IPM Fault | Electronics HW problem | Check all wiring and jumper settings, if OK, replace electronics. |
| 3 | Bad EEPROM | | No action, unless special parameters are required for unit operation. |
| 4 | DC under/over Voltage | Electronics HW problem | Check outdoor unit power supply voltage |
| 5 | AC under Voltage | | Check outdoor unit power supply voltage |
| 6 | Indoor / Outdoor unit Communication mismatch | Indoor and Outdoor controllers are with different versions | Replace Indoor controller |
| 7 | No Communication | Communication or grounding wiring is not good. | Check Indoor to Outdoor wiring and grounding |
| 8 | Compressor Lock | | Switch unit to STBY and restart |
| 9 | Bad Communication | Communication quality is low reliability | Check Indoor to Outdoor wiring and grounding |

13.1.6 Judgment by MegaTool

MegaTool is a special tool to monitor the system states.

Using MegaTool requires:

A computer with RS232C port.

A connection wire for MegaTool.

A special MegaTool software.

Use MegaTool according to following procedure:

Setup MegaTool software: copy the software to the computer.

Connect RS232C port in computer with MegaTool port in Indoor/Outdoor unit controller by the connection wire.

Run the software and choose the COM port, you can monitor the A/C system state

In monitor tab

13.1.7 Simple procedures for checking the Main Parts

13.1.7.1 Checking Mains Voltage.

Confirm that the Mains voltage is between 198 and 264 VAC. If Mains voltage is out of this range, abnormal operation of the system is expected. If in range check the Power (Circuit) Breaker and look for broken or loosed cable lugs or wiring mistake(s).

13.1.7.2 Checking Power Input.

If Indoor unit power LED is unlighted, power down the system and check the fuse of the Indoor unit. If the fuse is OK replace the Indoor unit controller. If the fuse has blown, replace the fuse and power up again.

Checking Power Input procedure for the Outdoor unit is the same as with the Indoor unit.

13.1.7.3 Checking the Outdoor Fan Motor.

Enter Test Mode (where the OFAN speed is high)

Check the voltage between lead wires according to the normal value as following:

Between red wire and black wire: 310VDC +/- 20V

Between orange wire and black wire: 15VDC +/- 1V

Between yellow wire and black wire: 2-6VDC

13.1.7.4 Checking the Compressor.

The compressor is brushless permanence magnetic DC motor. Three coil resistance is same. Check the resistance between three poles. The normal value should be below 0.5 ohm (TBD).

13.1.7.5 Checking the Reverse Valve (RV).

Running in heating mode, check the voltage between two pins of reverse valve connector, normal voltage is 220VAC.

13.1.7.6 Checking the electrical expansion valve (EEV).

The EEV has two parts, drive part and valve. The drive part is a step motor; it is ringed on the valve. Check the drive voltage (12VDC). When Outdoor unit is power on, EEV shall run and have click and vibration.

13.1.8 Precaution, Advise and Notice Items

13.1.8.1 High voltage in Outdoor unit controller.

Whole controller, including the wires that are connected to the Outdoor unit controller may have the potential hazard voltage when power is on. Touching the Outdoor unit controller may cause an electrical shock.

Advise: Don't touch the naked lead wire and don't insert finger, conductor or anything else into the controller when power is on.

13.1.9 Charged Capacitors

Three large-capacity electrolytic capacitors are used in the Outdoor unit controller. Therefore, charging voltage (380VDC) remains after power down. Discharging takes about four minutes after power is off. Touching the Outdoor unit controller before discharging may cause an electrical shock.

13.1.10 Additional advises

When disassemble the controller or the front panel, turn off the power supply.

When connecting or disconnecting the connectors on the PCB, hold the whole housing, don't pull the wire.

There are sharp fringes and sting on shell. Use gloves when disassemble the A/C units.

13.2 Troubleshooting for DCI72/80

WARNING!!!

When Power Up – the whole outdoor unit controller, including the wiring, is under
HIGH VOLTAGE!!!

Never open the Outdoor unit before turning off the Power!!!

When turned off, the system is still charged (400V)!!!

It takes about 1 Min. to discharge the system.

Touching the controller before discharging may cause an electrical shock!!!

13.2.1 General System Failures and Corrective Actions

| No | Symptom | Probable Cause | Corrective Action |
|----|--|--|--|
| 1 | Indoor unit power supply indicator (Red LED) does not light up. | No power supply | Check power supply. If OK, check display and display wiring. if OK, replace controller |
| 2 | Indoor unit does not respond to remote control message | Remote control message not reached the indoor unit | Check remote control batteries, if OK, check display and display wiring, if OK, replace display PCB. If still not OK replace controller |
| 3 | Indoor unit responds to remote control message but Operate indicator (Green LED) does not light up | Problem with display PCB | Replace display PCB. If still not OK replace controller |
| 4 | Indoor fan does not start (louvers are opened and Green LED is ON) | Unit in heat mode and coil is still not warm | Change to cool mode |
| | | Outdoor unit is in opposite mode | Change operation mode |
| | | Problem with controller or capacitor | Change to high speed and Check power supply to motor is higher than 130VAC (for triack controlled motor) or higher than 220VAC for fixed speed motors, if OK replace capacitor, if not OK replace controller |
| 5 | Indoor fan works when unit is OFF, and indoor fan speed is not changed by remote control command. | Controller problem | Replace controller |
| 6 | Water leakage from indoor unit | Indoor unit drainage tube is blocked | Check and open drainage tube |

| No | Symptom | Probable Cause | Corrective Action |
|----|---|---|---|
| 7 | Outdoor unit display board and leds are off | No power supply | Check the connections and the wiring on the main terminal - Repair if needed. |
| | | PFC Chock coil | Check the PFC Chock coil |
| | | Burnt fuse | Check 20A fuse on the Filter |
| 8 | Compressor operates but no capacity | EEV problem | Check EEV |
| | | Refrigerant leakage | Check refrigeration system |
| | | Indoor coil block | Clean filters and/or remove block |
| | | Outdoor coil block | Remove block and/or avoid air by-pass |
| 9 | Compressor is over heated and unit does not generate capacity | EEV problem | Check EEV |
| | | Refrigerant leakage | Check refrigeration system) |
| | | Indoor coil block | Clean filters and/or remove block |
| | | Outdoor coil block | Remove block and/or avoid air by-pass |
| 10 | Compressor stops during operation | Electronic control | Check diagnostics |
| | | Refrigerant leakage | Check refrigeration system |
| 11 | Unit is not operating | Communication problems | Check diagnostics |
| 12 | Compressor does not start | Electronics control problem or protection | |
| 13 | Unit works in wrong mode (cool instead of heat or heat instead of cool) | Electronics or RV problem | Check RV |
| 14 | All components are operating properly but no cooling or no heating | Refrigerant leak | Check refrigeration system |
| 15 | Compressor motor is generating noise and no suction occurs | Phase order to compressor is wrong | Check compressor phase order |
| 16 | Freezing of outdoor unit in heat mode and outdoor unit base is blocked with ice | | Connect base heater |
| 17 | The unit stop suddenly during operation | EMC interference to the A/C unit | Check for EMC problems |
| 18 | Indoor unit(s) Indicator(s) leds may flicker | | |

| No | Symptom | Probable Cause | Corrective Action |
|----|--|--|------------------------|
| 21 | Other home appliances operation is faulty such as noise appears in the television picture, or the picture is distorted or static occurs in the radio sound | EMC interference by the A/C unit | Check for EMC problems |
| 22 | All others | Specific problems of indoor or outdoor units | Check diagnostics |

13.2.2 Checking the refrigeration system

Checking system pressures and other thermodynamic measures should be done when system is in technician Mode where the system operates as in fixed settings. The performance curves given in this manual are given for unit performance in Technician mode when high indoor fan speed is selected.

13.2.3 Diagnostics

13.2.3.1 Outdoor unit diagnostics

If any fault exists in the system, it will be shown according to the following coding method. If no fault exists in the system, no fault code will be displayed during normal operation mode, and the status led will be on while the compressor is enabled.

Two LEDs display the system diagnostics on real time as follows:

STATUS LED is blinking 5 times in 5 seconds, and shut off for the next 5 seconds.

FAULT LED will blink during the same 5 seconds according to the following table:

| No | Problem | 5 | 4 | 3 | 2 | 1 |
|----|---|---|---|---|---|---|
| 1 | OCT bad | 0 | 0 | 0 | 0 | 1 |
| 2 | CTT bad | 0 | 0 | 0 | 1 | 0 |
| 3 | HST bad | 0 | 0 | 0 | 1 | 1 |
| 4 | OAT bad | 0 | 0 | 1 | 0 | 0 |
| 5 | OMT bad | 0 | 0 | 1 | 0 | 1 |
| 6 | RGT bad | 0 | 0 | 1 | 1 | 0 |
| 7 | OFAN/Compressor Feedback Loss | 0 | 0 | 1 | 1 | 1 |
| 8 | OFAN- IPM fault | 0 | 1 | 0 | 0 | 0 |
| 9 | OFAN Lock | 0 | 1 | 0 | 0 | 1 |
| 10 | OFAN- Vospd exceeded | 0 | 1 | 0 | 1 | 0 |
| 11 | Compressor- IPM Fault | 0 | 1 | 0 | 1 | 1 |
| 12 | Compressor Lock | 0 | 1 | 1 | 0 | 0 |
| 13 | Compressor- Vospd exceeded | 0 | 1 | 1 | 0 | 1 |
| 14 | Compressor- Foldback | 0 | 1 | 1 | 1 | 0 |
| 15 | DC under voltage | 0 | 1 | 1 | 1 | 1 |
| 16 | DC over voltage | 1 | 0 | 0 | 0 | 0 |
| 17 | AC under voltage | 1 | 0 | 0 | 0 | 1 |
| 18 | No communication A | 1 | 0 | 0 | 1 | 0 |
| 19 | reserved | 1 | 0 | 0 | 1 | 1 |
| 20 | reserved | 1 | 0 | 1 | 0 | 0 |
| 21 | reserved | 1 | 0 | 1 | 0 | 1 |
| 22 | Compressor- Illegal Speed | 1 | 0 | 1 | 1 | 0 |
| 23 | System Configuration Changed | 1 | 0 | 1 | 1 | 1 |
| 24 | System Configuration Problem | 1 | 1 | 0 | 0 | 0 |
| 25 | Heat sink Over Heating Fault/Protection | 1 | 1 | 0 | 0 | 1 |
| 26 | Deicing Protection | 1 | 1 | 0 | 1 | 0 |
| 27 | Compressor Over Heating Protection | 1 | 1 | 0 | 1 | 1 |
| 28 | System over power Protection | 1 | 1 | 1 | 0 | 0 |
| 29 | Bad EEPROM | 1 | 1 | 1 | 0 | 1 |
| 30 | Not Configured | 1 | 1 | 1 | 1 | 0 |
| 31 | Bad Communication | 1 | 1 | 1 | 1 | 1 |

Notes:

1 - ON, 0 - OFF

Whenever this table is updated, the installation test procedure, and the alarm output function should be updated.

Only one code is shown.

Order of priority is 1-32. Diagnostics is continuously ON as long as power is on.

Heat Sink Over Heating Protection, Compressor Over Heating Protection, and System Over Power Protection are declared only whenever in 'Stop-Compressor' status.

All faults, except the thermistor faults, will remain at least 10 seconds. This rule comes to serve the monitoring utilities, in a case the fault is released quickly it will be still shown under the monitoring utilities.

Thermistor faults are reported only when they are enabled.

When the outdoor unit is in fault (not protection), an in-fault signal is sent to the indoor. When all the outdoor unit faults are cleared, 'no-fault' signal is sent to the indoor.

13.2.3.2 Outdoor fault corrective actions

| No | Fault Name | Probable Cause | Corrective Action |
|----|-------------------------------|--|--|
| 1 | OCT bad | Thermistor not connected or damaged | Check Thermistor |
| 2 | CTT bad | | |
| 3 | HST bad | | |
| 4 | OAT bad | | |
| 5 | TSUC bad | | |
| 6 | RGT bad | | |
| 7 | OFAN/Compressor Feedback Loss | OFAN halls or wires bad. Compressor wire cable bad or IPM bad or compressor bad | Check OFAN motor and compressor |
| 8 | OFAN - IPM fault | Over current / Over temperature of OFAN IPM | Check no obstruction to controller air opening Check OFAN motor Check motor type matches motor jumpers in controller |
| 9 | OFAN Lock | Fan does not rotate | Check OFAN motor |
| 10 | OFAN- Vospd exceeded | Exceeds speed high limit | Check motor type matches motor jumpers in controller Make necessary arrangements in unit installation location to avoid back wind Avoid EMC problems |
| 11 | Compressor- IPM Fault | Over current / Over temperature of compressor IPM | Check no obstruction to controller air opening Check Compressor |
| 12 | Compressor Lock | Compressor does not rotate | Check Compressor |
| 13 | Compressor- Vospd exceeded | Exceeds speed limit | Try again and replace controller if still have the problem |
| 14 | Compressor- Foldback | High pressure / Current reduces compressor speed | Check Compressor |
| 15 | DC under voltage | DC voltage is lower than limit | Replace controller |
| 16 | DC over voltage | DC voltage exceeds its high limit | Check if input voltage higher than limit (270VAC), if not and the problem persist, replace controller. If voltage is high, shut off the power and recommend the customer to fix the power supply |
| 17 | AC under voltage | AC input voltage is lower than limit | Check if input voltage lower than limit (170VAC), if not and the problem persist, replace controller. If voltage is low, recommend the customer to fix the power supply |

| No | Fault Name | Probable Cause | Corrective Action |
|----|--|---|--|
| 18 | No communication A | No signals in line A | Check communication |
| 19 | Compressor- Illegal Speed | Exceeds speed low limit | See # 13 |
| 20 | System Configuration Changed | Communication lines changed from last operation | No problem just an announcement |
| 21 | System Configuration Problem | Miss-match between the IDUs connected to port A,B,C or D, or the total capacity code of IDUs is higher than the ODU maximum capacity code | Change configuration if needed. |
| 22 | Heat sink Over Heating Fault/ Protection | Compressor stopped due to heatsink protection | Check that the airflow around the ODU is free and the fan is running free. Check fan motor (0) |
| 23 | Deicing Protection | During deicing procedure | No action required |
| 24 | Compressor Over Heating Protection | Compressor stopped due to over heat protection | Check if gas is missing in the system |
| 25 | System over power Protection | Compressor stopped due to over power protection | No action required |
| 26 | Bad EEPROM | EEPROM not operating | Power reset. (Replace Controller just in case you need EEPROM). |
| 27 | Not Configured | Cannot start the control | Power reset. Replace Controller if didn't help |
| 28 | Bad Communication | Bad communication lines | See # 18-21 |

13.2.4 Fault Code for Indoor unit

Pressing Mode button for long will activate diagnostic mode by the acknowledgment of 3 short beeps and lighting of COOL and HEAT LED's.

Entering diagnostics in STBY mode allows only viewing of status (fault-display).

In diagnostic mode, system problems / information will be indicated by blinking of Heat & Cool LED's.

The coding method will be as follows:

Heat led will blink 5 times in 5 seconds, and then will be shut off for the next 5 seconds. Cool Led will blink during the same 5 seconds according to the following table:

| No | Fault Name | 5 | 4 | 3 | 2 | 1 |
|-----|---------------------------|---|---|---|---|---|
| 1 | RT-1 is disconnected | 0 | 0 | 0 | 0 | 1 |
| 2 | RT-1 is shorted | 0 | 0 | 0 | 1 | 0 |
| 3 | RT-2 is disconnected | 0 | 0 | 0 | 1 | 1 |
| 4 | RT-2 is shorted | 0 | 0 | 1 | 0 | 0 |
| ... | Reserved | 0 | 0 | 1 | 0 | 1 |
| 7 | Communication mismatch | 0 | 0 | 1 | 1 | 1 |
| 8 | No Communication | 0 | 1 | 0 | 0 | 0 |
| 9 | No Encoder | 0 | 1 | 0 | 0 | 1 |
| 10 | Reserved | 0 | 1 | 0 | 1 | 0 |
| 11 | Outdoor Unit Fault | 0 | 1 | 0 | 1 | 1 |
| ... | Reserved | | | | | |
| 17 | Defrost protection | 1 | 0 | 0 | 0 | 1 |
| 18 | Deicing Protection | 1 | 0 | 0 | 1 | 0 |
| 19 | Outdoor Unit Protection | 1 | 0 | 0 | 1 | 1 |
| 20 | Indoor Coil HP Protection | 1 | 0 | 1 | 0 | 0 |
| 21 | Overflow Protection | 1 | 0 | 1 | 0 | 1 |
| ... | Reserved | | | | | |
| 24 | EEPROM Not Updated | 1 | 1 | 0 | 0 | 0 |
| 25 | Bad EEPROM | 1 | 1 | 0 | 0 | 1 |
| 26 | Bad Communication | 1 | 1 | 0 | 1 | 0 |
| 27 | Using EEPROM data | 1 | 1 | 0 | 1 | 1 |
| 28 | Model A | 1 | 1 | 1 | 0 | 0 |
| 29 | Model B | 1 | 1 | 1 | 0 | 1 |
| 30 | Model C | 1 | 1 | 1 | 1 | 0 |
| 31 | Model D | 1 | 1 | 1 | 1 | 1 |

1 - ON, 0 - OFF

Only one code is shown. Order of priority is lower to the higher number. Diagnostics is continuously ON as long power is on.

13.2.4.1 Indoor unit diagnostics and corrective actions

| No. | Fault | Probable Cause | Corrective Action |
|-------|------------------------|--|---|
| 1-4 | Sensor failures | Sensors not connected or damaged | Check sensor connections or replace sensor |
| 7 | Communication mismatch | Indoor and Outdoor controllers are with different versions | Replace Indoor controller |
| 8 | No Communication | Communication or grounding wiring is not good | Check Indoor to Outdoor wiring and grounding |
| 9 | No Encoder | Indoor electronics or motor | Check motor wiring, if ok, replace motor, if still not ok, replace Indoor controller. |
| 11 | Outdoor Unit Fault | Outdoor controller problem | Switch to Outdoor diagnostics. |
| 17-21 | Protections | Indication | No action |
| 24 | EEPROM Not Updated | System is using ROM parameters and not EEPROM parameters | No action, unless special parameters are required for unit operation. |
| 25 | Bad EEPROM | | No action, unless special parameters are required for unit operation. |
| 26 | Bad Communication | Communication quality is low reliability | Check Indoor to Outdoor wiring and grounding |
| 27 | Using EEPROM data | No problem | |
| 28-31 | IDU model | | |

13.2.5 Procedures for checking Main Parts**13.2.5.1 Checking Mains Voltage**

Confirm that the Mains voltage is between 198 and 264 VAC. If Mains voltage is out of this range, abnormal operation of the system is expected. If in range check the Power (Circuit) Breaker and look for broken or loosed cable lugs or wiring mistake(s).

13.2.5.2 Checking Main fuse

Check 20A fuse on the Filter Board - If burnt – check the compressor, fan or any other peripheral that can cause a short. In case of a problematic peripheral - replace it.

In case no problematic peripheral, check the resistance on the DC bank (B+ & B- on the Power board), if it is less than 30Ω, replace the controller. Otherwise replace the burnt fuse. In case of frequent burning fuse, replace the controller.

13.2.5.3 Checking PFC Chock coil

Check PFC chock connection – repair if needed.

Dis-connect the chock from the controller wire extensions, check if the 2 wires of the chock are shorted. If shorted (OK) check between each wire and the metal box. If shorted replace chock, if not (OK), open the controller top cover and check if the wire extensions are connected well and if shorted. If not shorted, replace wires, if shorted (OK) than might be a controller problem – replace controller.

13.2.5.4 Checking the Outdoor Fan Motor

Check FAN-Power and FAN-Halls connections - Repair if needed.

Rotate the fan slowly by hand. If the fan does not rotate easily, check whether something is obstructing the fan, or if the fan itself is coming into contact with the outer case, preventing it from rotating. Correct if necessary - otherwise, the fan motor bearings have seized. Replace the motor.

If the fan rotates easily, use a current probe ("Clamp") to assure AC current on each phase and it is less than 1A.

In case there is no current, check the resistance between the three poles. Assure the three coil resistances are almost the same.

The normal value should be between 10 Ω to 20 Ω .

Change to Stand-by or Power OFF and re-start - If the fault is still active - replace controller.

13.2.5.5 Checking the Compressor

Check Compressor connections - Repair if needed.

Use a current probe ("Clamp") to assure that there is an AC current on each phase – no more than 15A.

In case there is no current, check the resistance between the three poles. Assure the three coil resistances are almost the same (between 0.8 Ω to 1.5 Ω).

Change to Stand-by or Power OFF and re-start - If the fault is still "Active" - replace controller.

13.2.5.6 Checking the Reverse Valve (RV)

The RV has two parts, Solenoid and valve.

Solenoid - Running in heating mode, check the voltage between two pins of reverse valve connector, normal voltage is 230VAC. if no power supply to RV, Check RV operation with direct 230VAC power supply, if OK, replace outdoor controller.

Valve - if RV solenoid is OK (as above) but still no heating operation while compressor is On, replace the valve.

13.2.5.7 Checking the electrical expansion valve (EEV)

The EEV has two parts, drive and valve.

When Outdoor unit is powered on, EEV shall run and have click and vibration.

For assuring the problem is of the EEV parts, perform the installation test and if fails and no other indications in the diagnostics, than the problem is with the EEV (one or more).

Drive - a step motor; ringed on the valve. Check the drive voltage, should be 12VDC.

Valve – if drive is OK (as above) but still the indoor unit perform no conditioning replace the valve (no need to take out the refrigerant, just pump down and shut off the main valves).

13.2.5.8 Checking the thermistors

Check Thermistor connections and wiring - Repair if needed.

Check Thermistor resistance – between 0°C and 40°C should be between 35K Ω and 5K Ω .

13.2.5.9 Checking the communication

Change to Stand-by or Power OFF and re-start - If the fault is still "Active" check Indoor to Outdoor.

Communication wiring and grounding connections (should be less than 2.0 Ω) - Repair if needed.

If IDU failure – replace IDU controller that does not respond.

If ODU failure – replace ODU.

13.2.5.10 Checking for electromagnetic interference (EMC problems)

EMC troubles to the A/C unit

Locations most susceptible to noise :

1. Locations near broadcast stations where there are strong electromagnetic waves.
2. Locations near amateur radio (short wave) stations.
3. Locations near electronic sewing machines and arc-welding machines.

Trouble :

Either of the following trouble may occur:

1. The unit may stop suddenly during operation.
2. Indicator lamps may flicker

Correction :

The fundamental concept is to make the system less susceptible to noise (insulate for noise or distance from the noise source):

1. Use shielded wires.
2. Move unit away from the noise source.

13.2.5.11 EMC troubles to near by home appliances

Locations most susceptible to noise :

1. A television or radio is located near the A/C and A/C wiring.
2. The antenna cable for a television or radio is located close to the A/C and A/C wiring.
3. Locations where television and radio signals are weak.

Trouble :

1. Noise appears in the television picture, or the picture is distorted.
2. Static occurs in the radio sound.

Correction

1. Select a separate power source.
2. Keep the A/C and A/C wiring at least 1 meter away from wireless devices and antenna cables.
3. Change the wireless device's antenna to a high sensitivity antenna.
4. Change the antenna cable to a BS coaxial cable.
5. Use a noise filter (for the wireless device).
6. Use a signal booster.

13.2.6 Precaution, Advise and Notice Items

13.2.6.1 High voltage in Outdoor unit controller

Whole controller, including the wires, connected to the Outdoor unit controller may have the potential hazard voltage when power is on. Touching the Outdoor unit controller may cause an electrical shock.

Advise: Don't touch the naked lead wire and don't insert finger, conductor or anything else into the controller when power is on.

13.2.6.2 Charged Capacitors

Three large-capacity electrolytic capacitors are used in the Outdoor unit controller. Therefore, charging voltage (380VDC) remains after power down. Discharging takes about one minute after turned off. Touching the Outdoor unit controller before discharging may cause an electrical shock. When open the Outdoor unit controller cover, don't touch the soldering pin by hand or by any conductive material.

13.2.6.3 Advise:

Open the Outdoor unit controller cover only after one minute from power off.

Measure the electrolytic capacitors voltage before farther checking controller.


Additional advises

When disassemble the controller or the front panel, turn off the power supply.

When connecting or disconnecting the connectors on the PCB, hold the whole housing, don't pull the wire, there are sharp fringes and sting on shell. Use gloves when disassemble the A/C units.

14. EXPLODED VIEWS AND SPARE PARTS LISTS


14.1 Indoor Unit: WNG 50 / WNG 60 DCI



14.2 Indoor Unit: WNG 50/60 DCI

| Item No. | Part No. | Description | Qty |
|----------|-----------|--|-----|
| 1A | 452917400 | Grill A/WNG18 | 1 |
| 1B | 452952800 | Grill B/WNG18 | 1 |
| 1C | 452952900 | Grill C/WNG18 | 1 |
| 2A | 453080400 | Display Board Assy.906-257-00 | 1 |
| 3 | 452919800 | Filter | 2 |
| 4 | 4518113 | Fiber Filter Assy. (Optional) | 1 |
| 5 | 453054000 | Frame assy./WNG18 | 1 |
| 6A | 4526946 | Display Lens Assy(LCD) | 1 |
| 6B | 4527144 | Display Cover Assy | 1 |
| 7 | 452919600 | Screw cover | 3 |
| 8 | 433133 | IONIZER DISPLAY 906-191-07 (Optional) | 1 |
| 8A | 452919700 | Cover/Ionizer (Optional) | 1 |
| 9 | 453134600 | Evaporator Assy. | 1 |
| 10 | 4518664 | Drain hose | 1 |
| 11 | 452917300 | Air outlet | 1 |
| 12 | 453050200 | STEP MOTOR A | 1 |
| 13 | 452918700 | Support/horizontal louver | 2 |
| 14 | 452917500 | Horizontal flap A | 1 |
| 14 | 452917600 | Horizontal flap B | 1 |
| 16 | 452918500 | Linkage A | 1 |
| | 452918600 | Linkage B | 1 |
| 17 | 452930700 | Vertical flap A | 12 |
| | 452918200 | Vertical flap B | 2 |
| 18 | 452918300 | Tie/vertical flap A | 1 |
| | 452918400 | Vertical flap stator B | 2 |
| | 452953000 | Vertical flap stator C | 1 |
| 19 | 4518662 | Bearing assy fan | 1 |
| 20 | 453024900 | Impeller fan | 1 |
| 21 | 453053800 | Base assy./WNG18 | 1 |
| 22 | 4518657 | TUBE LOCK | 1 |
| 23 | 452920100 | Mount bracket/WNG-18 20 | 1 |
| 24 | 452919400 | Joint/Unit housing | 1 |
| 25 | 453024500 | PG Motor | 1 |
| 26 | 4518651 | Cover Side Motor | 1 |
| 27 | 452918800 | Cover/motor | 1 |
| 28 | 453042500 | Remote controller/RC4-I-1 EHK P/N 974-710-00 | 1 |
| 29 | 453050300 | STEP MOTOR B | 1 |
| 30 | 453057900 | Gear BOX ASSY | 1 |
| 31 | 453109300 | Wire UL100726AWG/Ionizer | 1 |
| 32 | 433134 | IONIZER POWER 906-191-01 (Optional) | 1 |
| 33 | 4517022 | Plug | 1 |
| 34 | 4524967 | IONIZER WIRE A (Optional) | 1 |
| 35 | 453030600 | Indoor DC Inverter Controller(ENGLISH)916-513-00 | 1 |
| 36 | 4524963 | Electrostatic Filter (Optional) | 1 |
| 37 | 452919500 | Cover/terminal | 1 |


14.3 Outdoor Unit: ONG3-50 DCI



14.4 Outdoor Unit: ONG3-50 DCI

| ItemNo. | Part No. | Description | Qty |
|---------|----------|--|-----|
| 1 | 433218 | Front panel A | 1 |
| 2 | 4526340 | Air inlet ring-420 | 1 |
| 3 | 433223 | Painting insulation plate | 1 |
| 4 | 4526476 | Axial fan OD=401 | 1 |
| 5 | 4526475 | DC motor for DCI 50 | 1 |
| 6 | 4526457 | Motor support | 1 |
| 7 | 4527363 | Base painting Assy. | 1 |
| 8 | 4526459 | Partition | 1 |
| 9 | 4526203 | Outdoor DC inverter controller (English) | 1 |
| 10 | 4524595 | Gas valve (R410A) | 1 |
| 11 | 4524176 | Liquid valve (R410A) | 1 |
| 12 | 4526224 | EMI fliter board 901-098-00 | 1 |
| 13 | 4526396 | Chock Assy. 167-021-01 | 1 |
| 14 | 4526223 | AC-IN connected wire | 1 |
| 14 | 4526968 | Earthing wire for DCI | 1 |
| 16 | 4526222 | Fuse connecting wire | 1 |
| 17 | 4526300 | Therminal sheet | 1 |
| 18 | 4526220 | Fuse stand JEF-511B(EHK P/N:140-038-00) | 1 |
| 19 | 4526533 | Fuse 65TS(20A,230)140-031-00 | 1 |
| 20 | 204107 | Cable clip nylon | 1 |
| 21 | 4519188 | 4 poles terminal block | 1 |
| 22 | 433229 | Value cover | 1 |
| 23 | 4522509 | 4-Way valve coil | 1 |
| 24 | 4527327 | 4-way valve welding Assy. | 1 |
| 25 | 4518952 | 4-way valve | 1 |
| 26 | 4526221 | Compressor wire | 1 |
| 27 | 4523446 | DC Inverter compressor Assy. 5CS130XCC03 | 1 |
| 28 | 4526775 | Compressor top thermistor(CTT) | 1 |
| 29 | 4526774 | Outside air thermistor(OAT) | 1 |
| 30 | 4526776 | Outside coil thermistor(OCT) | 1 |
| 31 | 4526969 | Suction coil thermistor(SUCT) | 1 |
| 32 | 4526214 | Electronic expansion valve ZDPF(L)-1.6C-01-RK forR410A | 1 |
| 33 | 4526216 | EEV COIL QA(L)12-HR-01A-RK | 1 |
| 34 | 4519606 | Right side panel | 1 |
| 35 | 433228 | Back side net | 1 |
| 36 | 4526459 | Condenser soldering assy | 1 |
| 37 | 4526298 | Bridge | 1 |
| 38 | 4519614 | Painting top cover | 1 |
| 39 | 4526480 | Gasket for axial fan | 1 |
| 40 | 4519300 | Nut M5 L | 1 |
| 41 | 433225 | Handle | 1 |
| 42 | 4519607 | Left side panel painting plate | 1 |


14.5 Outdoor Unit: DCI 60



14.6 Outdoor Unit: DCI 60

| Item No. | Part No. | Description | Qty |
|----------|-----------|---|-----|
| 1 | 4517144 | FAN COVER PP+UV | 1 |
| 2 | 452795700 | PAINTED LEFT CABINET ASSY | 1 |
| 3 | 4521642 | Painted Right Cabinet and Isolation Assy. | 1 |
| 4 | 4523141 | M10 Hexagon locked nut M10 | 1 |
| 5 | 4526841 | cusion for fan | 1 |
| 6 | 4526510 | FAN D=460mm (3 blade) | 1 |
| 7 | 453026500 | DC Motor SIC-71FW-F170-2 | 1 |
| 8 | 453036400 | Motor Support | 1 |
| 9 | 453238900 | Sensor/OAT | 1 |
| 10 | 4526775 | Compressor top thermistor(CTT) | 1 |
| 11 | 4526776 | Outdoor coil thermistor(OCT) | 1 |
| 12 | 453035800 | Partition Plate | 1 |
| 13 | 453036100 | Base Plate Paint Assy. | 1 |
| 14 | 4526221 | Compressor wire | 1 |
| 14 | 453041900 | Liquid Accumulator | 1 |
| 16 | 452882900 | Condenser and distributor welding assy. | 1 |
| 17 | 4523446 | Scroll DC compressor assy. 5CS130XCC03 | 1 |
| 18 | 453034000 | 4-way Valve System Assy. | 1 |
| 19 | 4522509 | 4-Way valve coil | 1 |
| 20 | 4516766 | PAINTED VALVE PLATE ASSY | 1 |
| 21 | 4526301 | High pressure stop valve R410a | 1 |
| 22 | 4524595 | 1/2" Gas Valve for ONG R410A | 1 |
| 23 | 4526214 | Electronic expansion valve ZDPF(L)-1.6C-01-RK for R410A | 1 |
| 24 | 4526216 | EEV COIL QA(L)12-MD-02 | 1 |
| 25 | 4518952 | 4-W valve SHF-7H for R410A | 1 |
| 26 | 4525938 | PAINTED RIGHT-BACK CABINET ASSY | 1 |
| 27 | 4523145 | R.lifter | 1 |
| 28 | 4517028 | PAINTED LEFT-BACK GRILL | 1 |
| 29 | 4516758 | SMALL HANDLE | 1 |
| 30 | 452841100 | Earth wire | 3 |
| 31 | 453238800 | Ground Wire | 1 |
| 32 | 453238700 | Wire UL1007 16AWG/COM | 1 |
| 33 | 4519188 | 4 poles terminal block | 1 |
| 34 | 453238600 | Wire 1014 16#/Power Input | 1 |
| 35 | 204107 | Cable clip Nylon | 1 |
| 36 | 453048500 | DCI 2.8kW EMI Filter Board 901-107-00 | 1 |
| 37 | 453052900 | Therminal Plate Assy. | 1 |
| 38 | 4526585 | connect for motor bucket | 1 |
| 39 | 453030500 | Outdoor DCI Controller/2.8kW(English) 906-105-00 | 1 |
| 40 | 4516788 | PAINTED TOP COVER ASSY | 1 |


14.7 Indoor Unit: WNG 72 DCI



14.8 Indoor Unit: WNG72 DCI

| Item No. | Part No. | Description | Qty. |
|----------|-----------|--|------|
| 1 | 452917400 | Grille | 1 |
| 2 | 452919800 | Air Filter | 1 |
| 3 | 4518113 | Active Carbon(Cold Catalyst) Filter | 1 |
| 4 | 465720009 | Frame Assy | 1 |
| 5 | 452919600 | Screw Cover | 1 |
| 6 | 453260400 | Evaporator Assy | 1 |
| 7 | 4522754 | Draining Hose | 1 |
| 8 | 453053900 | Air Outlet Assy | 1 |
| 9 | 452917500 | Flap | 1 |
| 9 | 452917600 | Flap | 1 |
| 10 | 452930700 | Vert. Louver | 1 |
| 10 | 452918200 | Vert. Louver | 1 |
| 11 | 4518662 | Bearing Assy | 1 |
| 12 | 453024900 | Cross Flow Fan | 1 |
| 13 | 453053800 | Base Assy | 1 |
| 14 | 452920100 | Installation Plate | 1 |
| 14 | 452919400 | Tube Bracket | 1 |
| 16 | 453206800 | Motor | 1 |
| 17 | 452918800 | Motor Cover | 1 |
| 18 | 453050200 | Step Motor | 1 |
| 18 | 453050300 | Step Motor | 1 |
| 19 | | Power Wire | 1 |
| 20 | 4519147 | Cable locker | 1 |
| 21 | 453080400 | Display | 1 |
| 22 | 452919100 | Sensor | 1 |
| 23 | 453207000 | Control Box Assy | 1 |
| 24 | 438082 | Thermistor indoor coil | 1 |
| 25 | 4519813 | Thermistor Room | 1 |
| 26 | 452919500 | Terminal Cover | 1 |
| 27 | 4524963 | Electrostatic Filter/ Filter Frame (Optional) | 1 |
| 29 | 453042500 | Remote control | 1 |
| 30 | 4518651 | Motor Side Cover | 1 |
| 31 | 4526946 | LCD Display Lens Assy | 1 |
| 32 | 453057900 | Gear Box Assy | 1 |
| 33 | 452918700 | Louver Support | 1 |
| 35 | 4518657 | Tube Lock | 1 |
| 37 | 4524967 | Ionizer Cable (Optional) | 1 |
| 38 | 433134 | Ionizer Power(Optional) | 1 |
| 39 | 433133 | Ionizer Cover/Ionizer Unit(Optional) | 1 |


14.9 Indoor Unit: WNG 80 DCI



14.10 Indoor Unit: WNG 80 DCI

| Item No. | Part No. | Description | Qty |
|----------|-----------|----------------------------------|-----|
| 1 | 4525902 | GRILLE ASSY | 1 |
| 2 | 4523299 | FILTER | 1 |
| 3 | 4523303 | SHAFT LOCKER | 2 |
| 4 | 4518113 | AIR FILTER ASSY | 1 |
| 5 | 4525610 | FRAME ASSY | 1 |
| 6 | 4523301 | SCREW COVER | 3 |
| 7 | 4523302 | FIX LOCKER | 4 |
| 8 | 462350007 | EVAPORATOR ASSY WNG80 R410A | 1 |
| 9 | 4525112 | DISPLAY ASSY. 901-255-30 | 1 |
| 10 | 4525612 | AIR OUTLET ASSY | 1 |
| 11 | 4524962 | TEP MOTOR B | 2 |
| 12 | 4524965 | STEP MOTOR WIRE A | 1 |
| 13 | 4518664 | DRAIN HOSE | 1 |
| 14 | 4516204 | BEARING ASSY.,FAN | 1 |
| 14 | 4524954 | CROSS FAN | 1 |
| 16 | 4525611 | REAR PANEL ASSY | 1 |
| 17 | 433133 | IONIZER DISPLAY | 1 |
| 18 | 4523306 | IONIZER COVER(NO IONIZER) | 1 |
| | 4523307 | IONIZER WIRE COVER(WITH IONIZER) | 1 |
| 19 | 4524967 | IONIZER WIRE A | 1 |
| 20 | 4523372 | WNG-30 INSTALLATION PLATE | 1 |
| 21 | 4523309 | TUBE OUTLET | 1 |
| 22 | 4525111 | REMOTE CONTROL BOX 974-700-00 | 1 |
| 23 | 433134 | IONIZER POWER | 1 |
| 24 | 453109300 | IONIZER CABLE B | 1 |
| 25 | 4523311 | MOTOR HOUSING | 1 |
| 26 | 4524953 | FAN MOTOR | 1 |
| 27 | 4523313 | MOTOR WATER BREAKER | 1 |
| 28 | 4523312 | MOTOR COVER | 1 |
| 29 | 4524661 | FIX PLATE | 1 |
| 30 | 4524961 | STEP MOTOR A | 1 |
| 31 | 4524966 | STEP MOTOR WIRE B | 1 |
| 32 | 4523308 | WATER BREAKER COVER | 1 |
| 33 | 4525113 | POWER CORD CABLE(optional) | 1 |
| 34 | 438082 | THERMISTOR INDOOR COIL BACK | 1 |
| 35 | 4519813 | THERMISTOR ROOM BLACK | 1 |
| 36 | 4525831 | WIRE TUBE | 1 |
| 37 | 453161200 | CONTROL BOX 916-514-00 | 1 |
| 38 | 4516263 | SENSOR BASE | 1 |
| 39 | 4524963 | ESF (optional) | 1 |
| 40 | 4523304 | WIRING COVER | 1 |
| 41 | 4523300 | FILTER R | 1 |


14.11 Outdoor Unit: DCI 72/80



14.12 Outdoor Unit: DCI 72/80

| Item No. | Part No. | Description | Qty |
|----------|-----------|------------------------------------|-----|
| 1 | 465100000 | Outlet Grille | 1 |
| 2 | 4523652 | Painted Left Cabinet Assy. | 1 |
| 3 | 452960400 | Outdoor Fan | 1 |
| 4 | 466130001 | Motor | 1 |
| 5 | 452888500 | Motor Support | 1 |
| 6 | 452809900 | Base Plate Painting Assy. | 1 |
| 7 | 452809700 | Partition Plate | 1 |
| 8 | 4526774 | Outdoor air thermistor(OAT) | 1 |
| 9 | 452966200 | Compressor Top Thermistor(CTT) | 1 |
| 10 | 452677601 | Outdoor Coil Thermistor(OCT) | 1 |
| 11 | 4526514 | Hight press valve(R410A) | 1 |
| 12 | 4526513 | Low Press Valve R410A | 1 |
| 13 | 453170000 | Controller/DCI80 | 1 |
| 14 | 467420003 | Terminal Block | 1 |
| 14 | 204107 | Cable clip Nylon | 2 |
| 16 | 4526968 | Earthing wire with magnetic ring | 1 |
| 17 | 4526214 | Electronic expansion valve | 1 |
| 18 | 4526216 | EEV Coil | 1 |
| 19 | 452963000 | Insulation PVC/Compressor | 1 |
| 20 | 4510677 | Comp. screw | 1 |
| 21 | 452956600 | Compressor Cable | 1 |
| 22 | 452803300 | Compressor Assy. TNB220FLBM1 | 1 |
| 23 | 4522602 | Valve Cover | 1 |
| 24 | 4523654 | Painted Right Back Cabinet Assy. | 1 |
| 25 | 461600002 | 4-Way Valve Assy. | 1 |
| 26 | 452956700 | 4-way Valve Coil | 1 |
| 27 | 4526522 | Four-Way Valve R410A | 1 |
| 28 | 4523653 | Painted Right Cabinet Assy. | 1 |
| 29 | 462300002 | Condenser Assy. | 1 |
| 30 | 4523657 | Painted Top Cover Assy. | 1 |
| 31 | 4523758 | Nut M8 left | 1 |
| 32 | 4522600 | Left Handle | 1 |
| 33 | 453175500 | Guard Net Painting Assy. | 1 |
| 34 | 4522601 | Right Handle | 1 |
| 35 | 453256100 | Support Assy./Gas-Liquid Separator | 1 |
| 36 | 467300005 | Display Board Assy Optional | 1 |
| 37 | 452783600 | Oil Separator Assy. | 1 |
| 38 | 4526080 | Valve plate paint assy | 1 |
| 39 | 453256000 | Choke Assy. | 1 |
| 40 | 453083800 | OAT Support/OAT | 1 |
| 41 | 452956500 | Suction Thermistor(SUCT) | 1 |
| 42 | 452783200 | Liquid-gas Separator | 1 |

14.13 Outdoor Unit: DCI 72 Z



14.13 Outdoor Unit: DCI 72 Z

| No. | Item | Description | Quan. |
|-----|------------|---|-------|
| 1 | 465100000 | Grill/ DCI Trio | 1 |
| 2 | 4523652 | PAINTED LEFT CABINET ASSY | 1 |
| 3 | 4523758 | Nut M8 left | 1 |
| 4 | 452960400 | Outdoor Fan | 1 |
| 5 | 461600023 | 4-Way Valve Assy. | 1 |
| 6 | 4522509 | 4-way Valve Coil | 1 |
| 7 | 4526522 | FOUR-WAY VALVE R410A | 1 |
| 8 | 466130002R | DC Motor 70W 8P | 1 |
| 9 | 4522601 | Right Handle | 1 |
| 10 | 4523653 | PAINTED RIGHT CABINET ASSY | 1 |
| 11 | 4526775 | Compressor Top Thermistor(CTT) | 1 |
| 12 | 452956500 | OMT Thermistor(OMT) | 1 |
| 13 | 452677601 | Outdoor Coil Thermistor(OCT) | 1 |
| 14 | 452809900 | Base Plate Painting Assy. | 1 |
| 15 | 460080000R | Compressor Assy./ C-7RVN153H0W SANYO ShenYang) | 1 |
| 16 | 452783600 | Oil Separator Assy. | 1 |
| 17 | 452783200 | Liquid-gas Separator | 1 |
| 18 | 453256100 | Support Painting Support Assy./Gas-Liquid Separator | 1 |
| 19 | 4526080 | Valve plate paint assy | 1 |
| 20 | 4526513 | LOW PRESS VALVE (R410A) | 1 |
| 21 | 4526514 | Hight press valve(R410A) | 1 |
| 22 | 4523654 | PAINTED RIGHT BACK CABINET ASSY | 1 |
| 23 | 4522602 | Valve Cover | 1 |
| 24 | 4518950 | Filter Drier BFK-053S | 1 |
| 26 | 204107 | Cable clip Nylon | 2 |
| 27 | 467420003 | 7 Poles Terminal Block | 1 |
| 28 | 464280001 | Terminal Plate/ DCI 72Z | 1 |
| 29 | 4526215 | Electronic expansion valve ZDPF(L)-1.6C-01-RK for R410A | 1 |
| 30 | 4526216 | EEV COIL QA(L)12-MD-02 | 1 |
| 31 | 462300002 | Condenser Assy. | 1 |
| 32 | 453175500 | Guard Net Painting Assy. | 1 |
| 33 | 453083800 | Support/OAT | 1 |
| 34 | 4526396 | Choke Assy.167-021-01 | 1 |
| 35 | 464730006 | Partition Plate Assy./DCI 72Z | 1 |
| 36 | 467300082R | Controller/Outdoor Unit DCI 3.0KW(English) 906A-361-00 | 1 |
| 37 | 452888500 | Motor Support | 1 |
| 38 | 464250044 | Connect Plate/Controller DCI 72Z | 1 |
| 39 | 452841100 | Earth wire | 3 |
| 39 | 4516540 | Earth wire | 2 |
| 40 | 453238900 | Sensor/OAT | 1 |
| 41 | 4523657 | PAINTED TOP COVER ASSY | 1 |
| 42 | 4522600 | Left Handle | 1 |
| 43 | 467300114R | DCI 3.0KW EMI Fillter Board 901A-574-00 | 1 |

APPENDIX A

INSTALLATION AND OPERATION MANUAL



INSTALLATION & OPERATING MANUAL WNG 50/60 DCI



INSTALLATION & OPERATING MANUAL WNG 72/80 DCI

CLIMATISEUR SPLIT MURAL

FRANÇAIS

AIR CONDITIONER SPLIT WALL MOUNTED

ENGLISH

KLIMAGERÄT IN SPLIT BAUWEISE


DEUTSCH

CLIMATIZADOR SPLIT MURAL

ESPAÑOL

CONDIZIONATORE D'ARIA A PARETE SPLIT

ITALIANO



DCINVERTER

MANUEL D'UTILISATION ET DE PROGRAMMATION
PROGRAMMING AND OPERATING MANUAL
BEDIENUNGS UND PROGRAMMIERUNGS HANDBUCH
MANUAL DE UTILIZACIÓN Y DE PROGRAMACIÓN
MANUALE DI UTILIZZO E DI PROGRAMMAZIONE

CONTENTS

| | |
|--|----|
| INTRODUCTION | 1 |
| SYSTEM DESCRIPTION | 2 |
| MODES OF OPERATION, FUNCTIONS AND FEATURES | 3 |
| ON-UNIT INDICATORS AND CONTROLS | 5 |
| ● On-unit Operation | 5 |
| PROTECTION MODES | 6 |
| CARE AND MAINTENANCE | 7 |
| OPERATING TIPS | 8 |
| PRECAUTIONS | 9 |
| BEFORE CALLING FOR SERVICE | 10 |
| EXCEPTION FOR MULTI SPLIT TYPE | 11 |

*PLEASE READ THESE
INSTRUCTIONS **BEFORE**
OPERATING THE AIR
CONDITIONER*

INTRODUCTION

Dear customer:

The DC Inverter air conditioner you have purchased is one of the most advanced units of its kind. The DC Inverter air conditioner is a variable capacity air conditioner which uses high efficiency DC motors for the compressor and the outdoor fan. Unlike other models, it can adjust its capacity according to the user setting and the environmental condition, thus saving up to 30% of the seasonal power consumption, while keeping maximum comfort level. This modern unit is also equipped with an ionizer (optional) and an Electrostatic filter (optional) to maximize your indoor air quality.

Detailed instruction as to the DC Inverter air conditioner (including Single & Multi Split type) functions and way of operation are provided in the following pages.

This Split Air Conditioner is designed for versatile application:



- Cooling.



- Dehumidifying.




- Heating.



- Air Filtration.



- Ventilation



OPERATING TEMPERATURE RANGE:

-15°C ~ 46°C

IMPORTANT NOTICE:

● This air conditioner must be grounded to protect against electrical shock.

● Installation of the air conditioner must be performed by an experienced air conditioning installer, observing good refrigeration practice.

● Electrical connections and power cord replacement should only be made by authorized electricians and in accordance with electrical regulations and local codes. The appliance must be positioned so that the plug is accessible.


● Failure to comply with the manufacturer's installation and operation instructions could affect the performance of the air conditioner and the validity of the warranty.

Test Mode

Test Mode is set only for performance testing purposes, and not for user operation. Test mode can be initiated by either one of the following conditions:










- 1) Operating the unit with the following remote control settings and temperature conditions:
Cool Mode, SPT=16°C and RAT=27±1°C,
OAT=35±1°C for 30 minutes;
Heat Mode, SPT=30°C and RAT=20±1°C,
OAT=7±1°C for 30 minutes.
- 2) Entering Diagnostics with Cool/SPT=16°C or Heat/SPT=30°C.






SYSTEM DESCRIPTION




※ Not connected in multi split applications

MODES OF OPERATION, FUNCTIONS AND FEATURES

| | | |
|---|------------------|---|
|  | COOL | Cools, dehumidifies and filters the room air. Maintains desired room temperature. |
|  | HEAT | Heats and filters the room air. Maintains the desired room temperature. |
|  | AUTO | Automatically select between cool and heat operation modes, according to the requested room temperature and the actual room conditions. |
|  | DRY | Dehumidifies and softly cools the room. In DRY Mode, the air conditioner operates at an increased dehumidifying power. This function is recommended to be used when temperature is rather low but the humidity is high. |
|  | FAN | Recirculates and filters the room air. Maintains constant air movement in the room. |
|  | AUTO FAN | The air conditioner automatically selects the FAN speed in accordance to the requested room temperature and the actual room temperature. During the first 30 minutes of unit operation after being turned ON, the unit operates at high fan speed to maximize the cooling/heating effect. As the room air approaches to the desired temperature, the fan switches to a lower speed for quieter operation. |
| | HOT KEEP | In HEATING, when unit is started, the indoor fan will not be turned on until the indoor coil reaches adequate temperature. This HOT KEEP feature prevents uncomfortable cold air drafts. |
|  | I FEEL | Switches the temperature sensing point to the place where the remote control (optional) is located. (Generally the temperature sensor is located behind the intake grille of the air conditioner). This function is designed to provide a personalized environment by transmitting the temperature control command from the location next to you. The communication between the Remote Control and the unit is done by infra-red signal. Therefore, in using this function, the Remote Control should always be aimed, without obstructions, at the air conditioner. |
|  | TIMER | Real time control and display, automatically turns the air conditioner ON and OFF according to the time of day setting, ensuring comfort conditions before returning home, without wasting electricity. It turns the air conditioner off automatically when sleeping. |
|  | SLEEP | Designed to create comfortable sleeping conditions. When in COOLING mode, the temperature rises one degree centigrade after each consecutive hour, up to three hours, from the start of the mode. The temperature rise prevents the feeling of over-cooling while sleeping (when your body is at rest). In HEATING mode the reverse occurs; the air conditioner lowers its temperature one degree every hour, up to three hours, from the start of the mode. When in SLEEP mode, the air conditioner will be automatically turned off after operated for seven hours. The result is a more comfortable and invigorating sleep, which leaves you feeling fresh and energetic in the morning. |
| | AUTO FLAP | The air flap (louvers) is automatically positioned for the most suitable blow-out angle, when COOL, HEAT, DRY or FAN modes are selected. When the air conditioner is turned off, the flap will close automatically for an aesthetic appearance. |

| | | |
|---|--|---|
|  | VERTICAL AIR SWING | Automatic swing of supply air in vertical direction. The flap moves automatically in upward and downward direction to spread the conditioned air evenly throughout the room. |
|  | AIR DIRECTION POSITIONING | Automatic swing of Horizontal air flow in Horizontal direction. The flap move automatically in right and left direction to spread the conditioned air evenly throughout the room. |
|  | ROOM TEMPERATURE | Measures and displays room temperature. |
|  | FILTER INDICATION | Filter indicator on the indoor unit display is turned on when the filter requires cleaning. After cleaning and reinstalling the filter, It should be reset. |
|  | BUZZER | A soft buzzer will sound from the indoor unit display to indicate that a command sent by the remote control has been accepted and stored in the unit's memory. This feature may be easily cancelled by the user from the display panel. |
| | ON UNIT OPERATION | The air conditioner can be turned ON for COOLING or HEATING or be turned OFF directly by "MODE" key without the use of the remote control. |
| | 3-MIN DELAYED RUN | The compressor is protected by a three-minute delayed restart. |
| | MEMORY | The microprocessor retains the last data entry whether or not the unit is plugged in. Therefore, when the unit restarts after a power failure, it will resume operating in the same mode as before the power was disrupted. |
| | LOCK | Freezes the last operation setting on the remote control. When LOCK is activated, the remote control will not be able to control the air-conditioner. |
| | ILLUMINATED KEYPAD AND LCD DISPLAY (optional) | By pressing any button in dark environment, the keypad and the LCD display will be illuminated. |
| | ELECTROSTATIC FILTER (optional) | They are capable of capturing small particles down to 0.1 microns, Such as atmospheric and house hold dust, coal dust, insecticide dust, mites, pollen, pet dander, tobacco smoke particles, cooking smoke and grease, mold fungi, bacteria, viruses and more. |
| | IONIZER (optional) | Ionizer makes the air more fresh and more comfortable. Slide switch (H) to the ON position to activate the ionizer. The blue light indicator (G) on the unit will light up indicating the ionizer in operation. To cancel the operation set slide switch to OFF position. Important Notice: When the air-conditioner is turned OFF or if the indoor fan stops operation, the IONIZER stops automatically. |

ON-UNIT INDICATORS AND CONTROLS



If the air-conditioner can not be operated by the Remote Control unit, it can be turned on for cooling or heating, or completely turned off, by pressing MODE button (M) on the air-conditioner. The MODE button will change the operating status of the unit between - COOLING - HEATING -STAND BY positions. Every time MODE button (M) is pressed, (J) or (L) will light up respectively, to indicate in which mode the air-conditioner operates.

- A. Stand-by Operation indicator
Lights up in red when connected to power.
- B. ESF/ Ionizer/Fresh air indicator
Lights up during the ESF or Ionizer or Fresh air operation. (optional)
- C. LCD operation display
- D. Timer indicator
Lights up during timer and sleep operation.
- E. Filter indicator
Lights up when air filter requires cleaning.
- F. Signal receiver
Receive signals from the remote control.
- G. Ionizer indicator
Lights up during ionizer operation
- H. Ionizer on/off switch
Used to switch the ionizer on/off.
- I. Electrostatic filter operation button
Used to switch the Electrostatic filter on or off
- J. Cooling indicator
Lights up only when Mode (M) is pressed.
- K. Reset button
 - Press to turn off the filter indicator and to reset the filter function, after the cleaned filter has been reinstalled.
 - Press to cancel the buzzer announcer.
- L. Heating indicator
Lights up only when Mode (M) is pressed.
- M. Unit mode button
Used to switch the unit off or to turn it on for cooling or heating without the remote control.
- N. Electrostatic filter safety button
Turn off the Electrostatic filter when you open the grille.

PROTECTION MODES

Your air conditioner includes several automatic protection modes which enables you to use it virtually at any time and in any season, regardless of the outdoor temperature. Some of the protection modes are listed below:

| Mode | Operation conditions | Protection from | Controlled remedy |
|---------|------------------------------------|---------------------------|--|
| Cooling | Low outdoor temperature | Indoor coil Freezes up | Stops outdoor fan and compressor when approaching freezing conditions Resumes operation automatically Operating indicator (A) blinks. |
| | High outdoor temperature | Outdoor coil overheating | Stops compressor when approaching overheating conditions. Resumes operation automatically. Operating indicator (A) blinks. |
| Heating | Low outdoor temperature | Outdoor coil ice build up | Reverses operation from heating to cooling for short periods to de-ice outdoor coil. Operating indicator (A) blinks. |
| | High Indoor or outdoor temperature | Indoor coil overheating | Stops outdoor fan and compressor when approaching high indoor coil temperature. Resumes operation automatically. Operating indicator (A) blinks. |


Note: When switching the unit to OFF after heating operation, the unit may perform outdoor coil deicing operation. In such a case, the compressor will continue to run for some time after the unit has switched to OFF, and the indoor unit louvers are closed. This feature is a part of the normal unit operation.

CARE AND MAINTENANCE

Before performing any maintenance procedure, make sure to disconnect the air conditioner from the power.

CLEANING THE AIR FILTER

- Your air conditioner is provided with a filter cleaning indicator. When the filter indicator (E) lights up, the filters should be removed for cleaning.
- To remove the air filters, lift up the panel, push the air filters up slightly to unlock them, pull out the filters. Clean the filters by washing in warm soapy water and dry thoroughly, align and fit the filters in place, close the panel by pushing it in the center to lock it in place.
- Reset button (K) to turn off filter indicator (E).




CLEANING THE ELECTROSTATIC FILTER

The electronic filter should be removed from the unit and cleaning once three month. The procedure is shown as following:

- 1 open the front panel
- 2 push the hook on the filter and pull out the electrostatic filter (Fig ①)
- 3 wash the filter with the warm soapy water and dry thoroughly
- 4 push the electrostatic filter into the right position
- 5 close the front panel

Note: the above procedure is used for cleaning the electrostatic filter.




PURIFICATION FILTER REPLACEMENT

The air purifying filter should be removed from the unit and replaced once a year, shown as following:

- 1 pulling out the filter. (Fig ②)
- 2 replacing and securing the filter in its frame.
- 3 sliding the filter back in its place.

Note: The above procedure is used for replacing the active carbon filter (when supplied).

DO NOT OPERATE THE UNIT WITHOUT FILTERS!



CLEANING THE AIR CONDITIONER

- Wipe the unit with a soft dry cloth or clean it using a vacuum cleaner
- Do not use hot water or volatile materials which could damage the surface of the air conditioner.

AT THE BEGINNING OF THE SEASON

- Make sure there are no obstacles blocking the flow of inlet or outlet air, in both indoor and outdoor units.
- Make sure the power is properly connected.

PROTECT THE ELECTRONIC SYSTEM

- Indoor unit and remote control must be at least 1 meter away from a TV, radio or any other home electronic appliance.
- Protect the inner unit from direct sun or lighting.

OPERATING TIPS

- Set a suitable room temperature; excessively low room temperature is not good for your health and wastes electricity. Avoid frequent setting of the temperature.
- During cooling, avoid direct sun. Keep curtains and blinds closed. Close doors and windows to keep the cool air in the room.
- Avoid generating heat or using of heating appliances while the air conditioner in cooling mode.
- Make sure that the air flap is positioned properly: horizontal flow in cooling and downward vertical flow for heating.
- Keep the room temperature uniform by adjusting the left/right vertical air blades.
- Position the air flap and the left/right air blades in such a manner as to prevent your body from being exposed directly to air drafts.
- During prolonged operation, ventilate the room occasionally by opening a window from time to time.
- In a power failure, the microprocessor memory is retained. When restarted, operation will be resumed in the last mode of operation. However, if the timer was used, the unit will be turned off by the timer only if the remote control is aimed at the unit. Otherwise the power failure will cause the timer data to be erased from the microprocessor memory.
- After turning on, allow more than 3 minutes for cooling, heating or dry operation to start.
- When COOL or DRY modes are used, make sure that the room's relative humidity is below 78%. If the unit is used for a prolonged period of time in high humidity, moisture may form on the air outlet and drip down.
- Remote control signals may not be received if the indoor unit controls cover is exposed to direct sunlight or strong light. In such a case, block the sunlight or dim the lighting.
- The remote control is operative in a range of 8 meters. If you are out of range, the remote control may have difficulties in transmitting signals.

PRECAUTIONS


- Use the proper electrical fuse.
Do not pull out the power cord unless the unit is turned off.



- Do not start or stop operation by disconnecting the power cord.




- Do not obstruct or block the air inlet or air outlet of the air conditioner.



- Do not insert any objects in the air outlet of the indoor or outdoor units.



- Do not splash water on air conditioner.



IF NOISE IS HEARD
There may be hissing sound during operation or just after shut down. This is caused by the refrigerant that is circulating inside the unit

There may be a cracking sound at starting and stopping of the unit's operation. This is caused by heat expansion or contraction of plastics.

BEFORE CALLING FOR SERVICE

Before calling for service, please check the following common malfunctions and correct as needed.

| Problem | Cause | Remedy |
|--|---|---|
| ● Unit does not operate. Stand-by indicator does not light up. | <input type="checkbox"/> Unit not connected to power <input type="checkbox"/> Power failure | ■ Plug in the power cord ■ Check main fuse |
| ● Unit does not operate. Stand-by indicator lights. | <input type="checkbox"/> Remote control malfunctions <input type="checkbox"/> The remote control is locked. | ■ Check remote control batteries. ■ Try to operate from a closer distance. ■ Start from on-unit controls. ■ Unlock the remote control. |
| ● Unit does not respond properly to remote control command. | <input type="checkbox"/> IR signal does not reach unit. <input type="checkbox"/> Distance between remote control and unit too large or aimed at from improper angle. <input type="checkbox"/> IR receiver on-unit exposed to strong light source. | ■ Check for obstruction between unit and remote control, Clear if needed. ■ Get closer to unit. ■ Dim lights, fluorescents especially |
| ● Air does not blow out from indoor unit. | <input type="checkbox"/> De-icing protection mode is activated. | ■ Normal operation in HEATING mode. |
| ● COOLING, DRY or HEATING does not start immediately. | <input type="checkbox"/> 3-min. Compressor delayed start | ■ Normal operation for these modes. |
| ● Unit functions but does not perform sufficiently. | <input type="checkbox"/> Improper temperature setting. <input type="checkbox"/> Unit capacity insufficient for load or room size. | ■ Reset temperature. ■ Consult your dealer |
| ● Filter indicator lights up | <input type="checkbox"/> Air Filter needs cleaning | ■ Clean filter, reinstall and reset indicator |

EXCEPTION FOR MULTI-SPLIT TYPE

In multi split applications where more than a single indoor unit is connected to the same outdoor unit, it may happen that the requested operation mode can not be operated. The reason for that is that the system is currently operating in a different mode. The system operation mode can be either cooling or heating and is set by the outdoor unit controls, based on indoor and outdoor unit settings. The rules for the mode settings may be different from one application to another. In most applications the system operation mode will not be changed as long as there is an operating indoor unit requesting the active mode. The operation mode in such application will be set by the first indoor unit that is turned ON from Stand By.

The following table shows the indoor unit operation modes that can be operated per active system mode:

| | | System Active Mode | |
|--------------------------------------|----------------|--------------------|------------------|
| | | Cooling | Heating |
| Requested indoor unit operation mode | Cooling | v | X |
| | Heating | X | v |
| | Dry | v | X |
| | Auto Cool/Heat | v (cooling only) | v (heating only) |
| | Ventilation | v | X |

(v - enabled indoor unit operation mode, X - disabled indoor unit operation mode)

Indoor unit operation when the requested mode is disabled is as following:


- Louver opens;
- Green (OPER) LED blinks once in two seconds;
- Indoor fan is forced off;



CONTENTS

| | |
|---|---|
| Remote Control | 1 |
| Operation procedure | 2 |
| • Turning on the Air Conditioner | 2 |
| • Ventilating Operation | 2 |
| • Cooling Operation | 2 |
| • Cooling Operation with Auto Fan Mode | 2 |
| • Heating Operation | 2 |
| • Heating Operation With Auto Fan Mode | 2 |
| • Auto Cooling / Heating Operation | 3 |
| • Dry Operation | 3 |
| • Selecting The Temperature | 3 |
| • I FEEL/ROOM Temp Function | 3 |
| • Sleep Function | 3 |
| • Timer Operation | 4 |
| • Timer Operating Modes | 5 |
| • Air Flow velocity and Direction Adjustments | 8 |
| • Turning off the Air Conditioner | 8 |
| • Current Clock Time Set | 8 |
| • Lock Function | 8 |
| • Ionizer/ E.S.F Operation | 8 |

REMOTE CONTROL



- ❶ START / STOP button
- ❷ Operation mode selection button
 - AUTO
 - COOLING
 - HEATING
 - FAN
 - DRY
- ❸ I FEEL temperature sensing and Room temperature display button
- ❹ FAN SPEED control button
- ❺ Set point temperature UP and DOWN button
- ❻ SLEEP button
- ❼ Vertical swing button
- ❽ Horizontal swing button
- ❾ Ionizer & E.S.F and Fresh-Air button
- ❿ TIME SET button
- ⓫ TIMER button
- ⓬ Clear button
- ⓭ LCD operation display
- ⓮ RM sensor
- ⓯ Infrared signal transmitter
- ⓰ LOCK Button
- ⓱ Transmission sign
- ⓲ TIMER UP button
- ⓳ TIMER DOWN button

OPERATION PROCEDURE



TURNING ON THE AIR CONDITIONER

Press the START/STOP button (1) to turn on the air conditioner. After connecting to the power supply, The indicator (A) on the air conditioner light up, indicating that the air conditioner is in the standby status. Please note that LCD operation display (13) will always show the last mode of operation and the previous function used. If you want to change the control settings, proceed according to the following instructions. Otherwise, the air conditioner will start and operate in the same mode and functions prior to being turned off.



VENTILATING OPERATION

Select the ventilating mode by pressing MODE button (2). Switch to the desired fan speed by pressing FAN speed button (4).



COOLING OPERATION

Select the COOLING mode by pressing MODE button (2). Switch to the desired FAN SPEED or to AUTO FAN by pressing button (4). Select suitable temperature setting. By selecting the COOLING mode, the air flap will move automatically to horizontal air delivery position, optimal for cooling.



COOLING OPERATION WITH AUTO FAN MODE

This operation starts with the highest air flow in order to quickly lower the room temperature. It will then automatically switch to the low air flow to quietly maintain the selected temperature.



HEATING OPERATION

Select the HEATING mode by pressing MODE button (2). Switch to the desired FAN SPEED or to AUTO FAN by pressing FAN button (4). Select suitable temperature setting. By selecting the HEATING mode, the air flap will move automatically to vertical air delivery position, optimal for heating. The HOT KEEP function is provided. The fan will be turned off when the indoor coil temperature is not sufficiently hot to prevent uncomfortable cold air drafts. In some models the HOT KEEP function is operating in AUTO FAN mode only.



HEATING OPERATION WITH AUTO FAN MODE

This operation starts with the highest air flow in order to quickly raise the room temperature. It will then automatically switch to a lower air flow to quietly maintain the selected temperature.



AUTO COOLING/HEATING OPERATION

Select the AUTO mode by pressing MODE button (2). Switch to the desired FAN SPEED or to AUTO FAN by pressing button (4). Select suitable temperature setting. The air flap will automatically move to either horizontal air delivery for cooling or to vertical air delivery for heating. At start, the air conditioner will select its mode of operation according to the room temperature and the temperature setting.



DRY OPERATION

Select the DRY mode by pressing MODE button (2). Select the suitable temperature setting. While in DRY mode, the air conditioner will operate at low fan speed, regardless of the fan setting on the LCD operation display. Fan might terminate operation from time to time to prevent from over cooling. By selecting the mode, the air flap will move automatically to optimal horizontal air delivery position.



SELECTING THE TEMPERATURE

Press TEMP button (5) to change the temperature setting in the LCD operation display (13). The temperature setting is shown in degrees centigrade.



I FEEL/ROOM TEMP FUNCTION OPERATION

Press button (3) to activate the I FEEL function. Thermometer sign will appear on the LCD operation display (13). Select suitable temperature setting. Make sure that the remote control unit is aimed at the air conditioner, with the I FEEL sensor (14) in front. Prevent the I FEEL sensor from being affected by heat sources such as lamps, heaters, direct sun, etc. or from being directly affected by the air conditioner air flow. These may cause the sensor to transmit the Wrong temperature data, thereby disturbing the performance of the I FEEL function. By pressing on ROOM temperature, the measured room temperature and the room temperature sign will be displayed.

To cancel the ROOM Temperature display press on one of the following:

- Press again on ROOM temperature button (3).
- Change of MODE button (2)

Note: Room temperature range is between 6°C and 36°C in 1°C increments.

Display should show "HI" or "LO" to represent temperature that is above 36°C or below 6°C.



SLEEP FUNCTION

Press the SLEEP button (6) to select the SLEEP function.

The sleep icon light while the sleep OFF time icon and the time which is 7 hours after current time blink as default. The default setting can be changed from 3 hr. to 12 hr. by pressing up and down buttons HOUR+(11) and HOUR-(12) respectively. (The sleep timer will display the default time or the setting time plus the current time initially in the display).

For example: current time is 23:00 and the sleep mode is set, the sleep mode OFF time will be 6:00. If the sleep off time is set to 10 hr, the sleep mode OFF time will be 9:00. All other timers will temporarily be suspended during the activation of the sleep timer.

The other timers will resume operation at the end of the SLEEP time.

To cancel the SLEEP function press one of the following:

- START/STOP button (1)
- SLEEP button (6)

NOTE: In some models the SLEEP icon lights only and the OFF time is set for seven hours as default.

TIMER OPERATION

There are four timers that can be selected on the remote control. Two daily timers (designated as T1, T2), and two optional weekend timers (designated as WKT1, WKT2). Each timer can be selected by pressing TIMER button (11). To set each timer use time adjust up and down buttons Hour+(18) and Hour-(19) respectively. SET button (10) to enable the timer and/or CLEAR button (12) to disable the timer.

Indicator (E) on the air conditioner will light up during timer operation.

NOTE: After a power failure the timer operation is cancelled, timer indicator (E) on the air conditioner will blink, the unit will be automatically turned to stand-by mode and indicator (A) lights. To resume the timer operation, follow the instructions below.

A. DAILY TIMER

The daily timers T1 and T2 can be set for ON and OFF separately for two different time periods. Once the timer is set it will resume operation when initiated.

B. WEEKEND TIMER (OPTIONAL)

The weekend timers WKT1 and WKT2 can be set for ON and OFF separately for two different time periods for two days only.

It will be effective on the day of setting and on the day after only.

At 24:00 on the second day, the WK timer will not be effective anymore and the daily timer will resume its effectiveness.

WkT1-effective on the setting day





WKT2-effective one day after the setting day.

NOTE:

1. During the weekend timer operation, the daily timers will be disabled.
2. The WK timers must be reactivated before every weekend.

C. SELECTING A TIMER

Press the TIMER button (11) to select a timer. Each time the TIMER button (11) is pressed, one of the four following timer icons will appear on the LCD display.

| | | | |
|---|---|---|---|
| <p>Press TIMER button to select daily timer T1.</p> | <p>Press TIMER button to select daily timer T2.</p> | <p>Press TIMER button to select weekend timer WKT1</p> | <p>Press TIMER button to select weekend timer WKT2</p> |
| <p>1</p>  | <p>2</p>  | <p>3</p>  | <p>4</p>  |
| <p>Icon 1 of Timer T1 will blink</p> | <p>Icon 2 of Timer T2 will blink</p> | <p>Icons 1 and WK will blink</p> | <p>Icons 2 and WK will blink</p> |

TIMER OPERATING MODES

SETTING THE **ON** TIMER

Undertake the following steps after selecting a timer-T1,T2 or WKT1,WKT2,to set a timer for the start time of operation.

EXAMPLE:
Turning the air conditioner **ON** at 10:30.

1 Press the **SET** button.



The **ON** icon & **ON** time digits will blink.

2 Set the hours and minutes.



1. Set the **ON** time at 10:30
2. Press the (**HOURL**+) up button to advance the time, and press the (**HOURL**-) down button to retract.

3 Press the **SET** button



1. The **ON** time is activated at 10:30 (the time **ON** icon will light)
2. Time **OFF** icon & **OFF** time digits will blink.

4 Press the **CLEAR** button.



Timer **OFF** is cleared.

SETTING THE **OFF** TIMER

Undertake the following steps after selecting a timer-T1,T2 or WKT1,WKT2,to set a timer for the stop time of operation.

EXAMPLE:
Turning the air conditioner **OFF** at 18:30.

1 Press the **SET** button.



The **ON** icon & **ON** time digits will blink.

2 Press the **CLEAR** button.



1. The **ON** time is cleared.
2. **OFF** time icon & **OFF** time digits will blink.

3 Set the hours and minutes.



1. Set the **OFF** time at 18:30
2. Press the (**HOURL**+) up button to advance the time, and press the (**HOURL**-) down button to retract.

4 Press the **SET** button



OFF time is activated at 18:30 (the (timer **OFF** icon will light)

NOTES:

1. The default setting for the timers are 7:00 and 18:00 for **ON** and **OFF**, respectively.
2. The timer mode will display always the last **ON** and **OFF** settings on the LCD display

SETTING THE **ON** AND **OFF** TIMERS

Undertake the following steps after selecting a timer-T1,T2 or WKT1,WKT2,to set a timer for the start and stop time of operation.

EXAMPLE:
Turning the air conditioner ON at 10:30 and OFF at 18:30.

Press the SET button.

Set the hours and minutes.

Press the SET button

Set the hours and minutes.

Press the SET button.



The ON icon & ON time digits will blink



1. Set the ON time at 10:30
2. Press the (HOUR+) up button to advance the time, and press the (HOUR-) down button retract.



1. The ON time is activated at 10:30 (the time ON icon will light)
2. Timer OFF icon & OFF time digits will blink.



1. Set the OFF time at 18:30
2. Press the (HOUR+) up button to advance the time, and press the (HOUR-) down button retract.



OFF time is activated at 18:30 (the timer OFF icon will light)

TO CHANGE THE TIME SETTING

EXAMPLE:
To change the ON time setting from 10:30 to 9:20 (while preserving the OFF time setting)

Press the TIMER button. until the selected timer icon blinks.

Press the SET button to enter edit mode

Change the setting time to 9:20 by pressing on HOUR-.

Press the SET button to save the new setting.

Press the SET button to confirm the previous timer OFF setting



Note that the corresponding formerly set timer digits will display without blinking.



ON icon & ON time digits blink



ON icon & ON time digits blink



ON icon & ON time digits light while OFF icon & OFF time digits blink.



ON & OFF icons and time digits of the consequent timer light

TO CANCEL THE TIMER SETTING FOR A PARTICULAR TIMER

To cancel the ON time while keeping the OFF time setting.

Press **TIMER** button
to select a timer.



The selected timer icon blinks & the corresponding previous timer ON, OFF settings light.

Press **SET** button.



ON icon & ON time digits blink.

Press **CLEAR** button.



ON time is cleared, OFF icon & OFF time digits blink.

Press **SET** button



Confirm the new setting.

TO CANCEL THE **ON** & **OFF** TIME SETTINGS

Press **TIMER** button
to select a timer.



The selected timer icon blinks & the corresponding previous time ON, OFF settings light.

Press **CLEAR** button.



All settings of the selected timer are cleared.

NOTES:

1. The default settings for the timers are 7:00 and 18:00, for ON and OFF respectively.
2. The timer mode will always display the last ON and OFF settings on the LCD display.
3. Pressing CLEAR button (12) for 5 seconds will cancel all timer settings and clear timer display.



AIR FLOW VELOCITY AND DIRECTION ADJUSTMENT

Press button (7) to activate the supply air flap to auto swing;
Press button (8) to activate the Horizontal Air Flow to auto swing.
Press the two button again, you will cancel auto swing function.
To change the AIR FLOW velocity, press the button.
Each time the button is pressed, the fan speed is changed in sequence:

(Lo) → (Med) → (Hi) → (Strong) → (AUTO).

To change the AIR FLOW blowing direction vertically, press the button.

Each time the button is pressed, the mode of the HORIZONTAL VANE is changed in sequence:
Auto → Swing → Auto

To change the AIR FLOW blowing direction horizontally, press the button.

Each time the button is pressed, the mode of the VERTICAL VANE is changed in sequence:
Auto → Swing → Auto

- 1) Strong fan will only operation cooling & heating mode
- 2) Strong fan option is selectable via switch



TURNING OFF THE AIR CONDITIONER

Press Start /Stop button(1) to turn off the air conditioner. Indicator (A) on the air conditioner will be turned red. Indicating that the air conditioner is in Stand-by mode and ready to accept any new command from the remote control. The remote control LCD will display the clock time. The last operation set-up will kept for the next operation.



Ionizer / Fresh Air operation.(optional)

Pressing the Ionizer / Fresh air key will cycle in the following manner:

Fresh air (continual) & Ionizer → Fresh air (continual) → Ionizer → off

Fresh air option is selectable via switch

The function will be kept when mode is switch over

(E.S.F works together with Ionizer.)



CURRENT CLOCK TIME SET

Clock setting is performed when batteries are inserted. The remote control displays the setting and the clock display will blink 0:00 or 12:00 AM (AM sign will blink, too) till a new time is set.


For clock setting, use buttons (18) and (19) for setting the hours and minutes, respectively, and then press timer SET button (10). The clock setting can be also performed by pressing timer SET button (10) for 5 seconds.

The clock display will blink, for new setting follow the steps described above.



LOCK FUNCTION

By pressing LOCK button (16), the remote control will lock the last operation program. All the function buttons will be inoperative, including START/STOP button. By pressing LOCK button (16) again the remote control will be released from its locked position. When lock mode is functioning, the transmission sign (17) will be on.



INSTALLATION INSTRUCTIONS

ENGLISH

INSTRUCTIONS D'INSTALLATION

FRANÇAIS

INSTALLATION SANLEITUNG

DEUTSCH

INSTRUCCIONES DE INSTALACION

ESPAÑOL

ISTRUZIONE PER L'INSTALLAZIONE

ITALIANO

INSTALLATION INSTRUCTIONS

ENGLISH













1. ACCESSORIES SUPPLIED WITH THE AIR CONDITIONER
2. LOCATION OF INDOOR AND OUTDOOR UNIT
3. INSTALLATION/SERVICE TOOLS (ONLY FOR R410A PRODUCT)
4. INSTALLATION OF THE INDOOR UNIT
5. CONDENSATE HOSE CONNECTION
6. ELECTRICAL CONNECTION BETWEEN INDOOR AND OUTDOOR UNIT
7. REFRIGERANT TUBING
8. FINAL TASKS

The appliance shall not be installed in the laundry.

NOTE: This manual is for single split applications.
For multi split applications please use installation manual supplied within outdoor unit package.

INSTALLATION INSTRUCTIONS FOR DCI SPLIT WALL MOUNTED AIR CONDITIONER

1 ACCESSORIES SUPPLIED WITH THE AIR CONDITIONER

| Shape | Name | Qty | Used for |
|---|---|-----|---|
|  | Mounting plate | 1 | Wall mounting of the indoor unit |
|  | Remote control with batteries | 1 | Operation of unit |
|  | Remote control bracket | 1 | Wall mounting of the remote control |
|  | Screws washer dowels | 4 | Wall mounting of indoor unit |
|  | Screws dowels | 2 | Wall mounting of remote control bracket |
|  | Outdoor unit drain connector | 1 | Outdoor unit water drain |
|  | Mounting pads | 4 | Padding of outdoor unit bottom support |
|  | Cable ties | 4 | Securing wires in the indoor and outdoor unit |
|  | Power input cable (Optional) | 1 | Connecting indoor unit power |
|  | Cable terminals | 1 | Securing of grounding wire in the indoor and outdoor unit |
|  | Air purifying filter (Optional) | 2 | Cleaning the air |
|  | <ul style="list-style-type: none"> Remote control operation Unit operation Installation manual | 3 | Users and installers reference |

Indoor Unit's Accessories Only for One Unit.

2 LOCATION OF INDOOR AND OUTDOOR UNIT

Select the location considering the following:

INDOOR UNIT

1. Choose a location which will provide good air circulation.
2. Do not install the unit near a heat source or where it will be exposed to direct sunlight.
3. The location must allow convenient electrical wiring, drainage and tubing connections as shown in fig 3.
4. The appliance must be positioned so that the plug is accessible.
5. Installation site should provide an easy passage to outdoors.
6. The unit must be mounted on a strong wall that will withstand the generated vibrations.
7. Install the mounting plate as shown in fig 5.
8. Install the remote control bracket as shown in fig 4.

OUTDOOR UNIT

1. The location must allow easy servicing and provide good air circulation as shown in fig 5.
2. The unit may be suspended from a wall by a bracket (Optional) or located in a free standing position on the floor (preferably slightly elevated).
3. If the unit is suspended, ensure that the bracket is firmly connected and the wall is strong enough to withstand vibrations.
4. Unit location should not disturb neighbors with noise or exhaust air stream.
5. Place the mounting pads under the unit legs.
6. Refer to figure 5 for allowed installation distances.
7. When the unit is installed on a wall, install the drain connector hose and drain plug as shown in fig 1 and fig 2.

Fig.1
1.Bottom of outdoor unit
2.Drain connector








Fig.2
Drain installation
Example





NOTE:

- Distance between indoor and outdoor units should be $\leq 30\text{m}$.
- The indoor unit may be installed above or below the outdoor unit. Height difference between indoor and outdoor units should be $\leq 10\text{m}$.
- No additional charge is required.



Height = 7m max
Without siphon
Height = 10m max
Fit a siphon on the
gas line every 3m.





Fig.5
1. Mounting pads (X4)

INSTALLATION/SERVICE TOOLS (ONLY FOR R410A PRODUCT)

CAUTION

New Refrigerant Air Conditioner Installation








THIS AIR CONDITIONER ADOPTS THE NEW HFC REFRIGERANT (R410A) WHICH DOES NOT DESTROY OZONE LAYER. R410A refrigerant is apt to be affected by impurities such as water, oxidizing membrane, and oils because the working pressure of R410A refrigerant is approx. 1.6 times of refrigerant R22. Accompanied with the adoption of the new refrigerant, the refrigeration machine oil has also been changed. Therefore, during installation work, be sure that water, dust, former refrigerant, or refrigeration machine oil does not enter into the new type refrigerant R410A air conditioner circuit. To prevent mixing of refrigerant or refrigerating machine oil, the sizes of connecting sections of charging port on main unit and installation tools are different from those used for the conventional refrigerant units. Accordingly, special tools are required for the new refrigerant (R410A) units. For connecting pipes, use new and clean piping materials with high pressure fittings made for R410A only, so that water and/or dust does not enter. Moreover, do not use the existing piping because there are some problems with pressure fittings and possible impurities in existing piping.

Changes in the product and components

In air conditioners using R410A, in order to prevent any other refrigerant from being accidentally charged, the service port diameter size of the outdoor unit control valve (3 way valve) has been changed. (1/2 UNF 20 threads per inch)

- In order to increase the pressure resisting strength of the refrigerant piping, flare processing diameter and opposing flare nuts sizes have been changed. (for copper pipes with nominal dimensions 1/2 and 5/8)

New tools for R410A

| New tools for R410A | | Applicable to R22 model | Changes |
|---|---|---|--|
| Gauge manifold | × |  | As the working pressure is high, it is impossible to measure the working pressure using conventional gauges. In order to prevent any other refrigerant from being charged, the port diameters have been changed. |
| Charge hose | × |  | In order to increase pressure resisting strength, hose materials and port sizes have been changed (to 1/2 UNF 20 threads per inch). When purchasing a charge hose, be sure to confirm the port size. |
| Electronic balance for refrigerant charging | ○ |  | As working pressure is high and gasification speed is fast, it is difficult to read the indicated value by means of charging cylinder, as air bubbles occur. |
| Torque wrench (nominal dia. 1/2, 5/8) | × |  | The size of opposing flare nuts have been increased. Incidentally, a common wrench is used for nominal diameters 1/4 and 3/8. |
| Flare tool (clutch type) | ○ |  | By increasing the clamp bar's receiving hole size, strength of spring in the tool has been improved. |
| Gauge for projection adjustment | — | | Used when flare is made by using conventional flare tool. |
| Vacuum pump adapter | ○ |  | Connected to conventional vacuum pump. It is necessary to use an adapter to prevent vacuum pump oil from flowing back into the charge hose. The charge hose connecting part has two ports -- one for conventional refrigerant (7/16 UNF 20 threads per inch) and one for R410A. If the vacuum pump oil (mineral) mixes with R410A a sludge may occur and damage the equipment. |
| Gas leakage detector | × |  | Exclusive for HFC refrigerant. |

- Incidentally, the "refrigerant cylinder" comes with the refrigerant designation (R410A) and protector coating in the U.S.'s ARI specified rose color (ARI color code: PMS 507).
- Also, the "charge port and packing for refrigerant cylinder" requires 1/2 UNF 20 threads per inch corresponding to the charge hose's port size.


4 INSTALLATION OF THE INDOOR UNIT

Installation of the indoor unit only with one unit for the sample.

INSTALLATION OF THE MOUNTING PLATE

Figure 6 shows the location of the mounting plate relative to the unit size.

1. Locate the mounting plate on the wall in a horizontal position.
2. Mark the position of the four mounting holes on the wall and drill four holes to accommodate the dowels.
3. Mount the mounting plate on to the wall by the four screws. Ensure screws are tightened properly.



REFRIGERATION TUBE ROUTING

1. There are five possible routes for installing the refrigeration tube as shown in fig 7.
2. For route (6), cut the bottom notch in the rear.
3. For routes (4) or (7), cut the side notches in the rear and in the front panel.

Fig. 7

1. Front

2. Rear


3. Righthand rear outlet

4. Lefthand outlet

5. Lefthand rear outlet

6. Bottom outlet

7. Righthand outlet



PENETRATION OF WALL FOR TUBING

1. Mark the location of the hole on either side of the mounting plate as shown, in fig6 and drill it at a 5° downward angle, as shown in fig8.
2. The hole is drilled at an angle, to prevent condensed or rain water from penetrating back into the room.
3. Trim the hole in the wall with a $\phi 70$ mm commercial plastic tube.


Fig. 8

A. OUTDOOR SIDE

B. INDOOR SIDE

1. Drill 70mm

2. Wall



SUSPENDING AND RELEASING THE UNIT FROM THE MOUNTING PLATE

1. Make sure that the refrigerant tubes, electric cables and condensate water hose are well insulated with closed cell rubber based insulating tubes (6mm thickness), are wrapped together with UV stabilized nonadhesive plastic tape, and are passed through the hole in the wall.
2. Hang the indoor unit on the two hooks that are located near the top edge of the mounting plate as shown in fig 9 and fig 10.
3. Press the lower part of the indoor unit against the mounting plate until the catches snap into the slots and lock the indoor unit to the mounting plate.
4. Check the installation by pulling the unit towards you.
5. To release the unit from the mounting plate, lift up the unit and then pull the unit towards you, to ensure that the hooks are locked.

Fig.9

1. Indoor unit
2. Snap catches
3. Top hooks
4. Bottom hooks




Fig 9

Fig.10

1. Mounting plate
2. Lower hook




Fig 10

5 CONDENSATE HOSE CONNECTION

1. Attach the condensate drain hose to the corrugated hose in the rear groove of the indoor unit.

2. Wrap the drain hose together with the refrigerant tubes and electrical cables.

3. Ensure that the condensate drain hose is at all points installed in a downward slope manner.

Fig.11

1. Drain hose
2. Clamp
3. Downward slope




Fig 11

Fig.12

1. Trap
2. U-bend
3. End immersed in water




Fig 12

4. When installing the drain hose avoid traps and U-bends. The end of the drain hose should not be immersed in water.

Fig.13

1. Electric cable
2. Refrigerant tubing
3. Condensate drain hose
4. UV stabilized nonadhesive plastic tape




Fig 13

5. For a lefthand outlet, lay the drain hose on the bottom of the indoor unit rear groove.

Fig.14

1. Vent
2. Downward drain
3. Water drain hose




Fig 14

6. When the installation location requires long horizontal sections, a vent must be provided at the top of the hose to prevent overflow of the unit drain pan.

6

ELECTRICAL CONNECTION BETWEEN INDOOR AND OUTDOOR UNIT

ELECTRICAL REQUIREMENTS

Electrical wiring and connections should be made by qualified electricians and in accordance with local electrical codes and regulation. The air conditioner units must be grounded.

The air conditioner unit must be connected to an adequate power outlet from a separate branch circuit protected by a time delay circuit breaker, as specified on unit's nameplate.

Voltage should not vary beyond $\pm 10\%$ of the rated voltage.

1. Connect the power supply cable to the indoor unit of WNG.
2. To connect the indoor unit to the outdoor unit use the following electrical cables.

Electrical connections:

Power input cable: 3 wires \times 2.5 mm²

Cable between

Indoor and outdoor units: 4 wires \times 2.5 mm²

3. Prepare the cable ends for the power input and for the cables between outdoor and indoor units as shown in figure 16a and 16b respectively.
4. Connect the cable ends to the terminals of the indoor and outdoor units, as shown in fig 17.
5. Secure the multiple wire power cable with the cable clamps.

Fig.15

1. Terminal 2. Cover 3. Cable clamp




Fig 15

NOTES:

1. The wire color code can be selected by the installer.

• Power input cable




Fig16a

• Cable between indoor and outdoor units




Fig16b

Fig.16 A. OUTDOOR B. INDOOR




Fig 17

Fig.17

1. Indoor unit terminal
2. Ground wire.
3. Indoor coil.
4. Power cable in the indoor side.

5. Multiple wire cable.
 6. Cable clamp.
 7. Outdoor unit wire terminal.
- A. OUTDOOR B. INDOOR

REFRIGERANT TUBING

CONNECT THE INDOOR TO THE OUTDOOR UNIT

The indoor unit contains a small quantity of nitrogen. Do not unscrew the nuts from the unit until you are ready to connect the tubing. The outdoor unit is supplied with sufficient refrigerant charge (R410A). Refer to outdoor unit nameplate.

To prevent crushing, bend tubes using a bending tool.

NOTE: Use refrigeration R410A type copper tubing only.

1. Open the valve cover.
2. Use tubing diameter that corresponds to the tubing diameter of the indoor and outdoor units. Note that the liquid and suction tubes have different diameters. (See tube size, torque tightening table.)
3. Place flare nuts on tube ends before preparing them with a flaring tool. Use the flare nuts that are mounted on the supplied outdoor and indoor units.
4. Connect the all ends of the tubing to the indoor and outdoor units. Notice the sign. All ends should correspond one by one.
5. Insulate each tube separately, and their unions, with at least 13 mm thick of insulation. Wrap the refrigerant tubing, drain hose and electric cables together with a vinyl tape (UV protected).




Fig 18

Caution!
When unscrewing the valve caps, do not stand in front of them or the spindles at any time, as the system is under pressure.

Fig.18
1. INDOOR UNIT
2. Liquid tube (small dia.)
3. Suction tube (large dia.)
4. Plugs
5. Flare nuts
6. Tubing between units
7. Suction tube
8. Liquid tube
9. OUTDOOR UNIT
10. Flare nuts
11. Suction valve (larger)
12. Liquid valve (small)

Tightening torques of unions and valve caps:

| TUBE SIZE | TORQUE |
|-------------------|------------|
| Liquid line 1/4" | 15-20 N.M. |
| Suction line 3/8" | 30-35 N.M. |
| Suction line 1/2" | 50-54 N.M. |
| Suction line 5/8" | 75-78 N.M. |




Fig.19

1. Wrench
2. Torque wrench
3. Union




Fig.20

To prevent refrigerant leakage, coat the flared surface with refrigeration oil




Fig.21

1. Suction valve
2. Service port
3. Liquid valve

EVACUATION OF THE REFRIGERATION TUBES AND THE INDOOR UNIT

After connecting the unions of the indoor and outdoor units, purge the air from the tubes and indoor unit as follows:

1. Connect the charging hoses with a push pin to the low side of the charging set and the service port of the suction valve. Be sure to connect the end of the charging hose with the push pin to the service port.
2. Connect the center hose of the charging set to a vacuum pump.
3. Turn on the power switch of the vacuum pump, turn off the high side switch and make sure that the needle in the gauge moves from 0 MPa (0cm Hg) to -0.1 MPa (-76cm Hg). Let the pump run for fifteen minutes.
4. Close the valve of the low side of the charging set and turn off the vacuum pump. Note that the needle in the gauge should not move after approximately five minutes.
5. Not any problem for five minutes, turn on the power switch of the vacuum pump and open the valve of the low side of the charging set.
6. Disconnect the charging hose from the vacuum pump and from the service ports of the suction valve.
7. Tighten the service port caps of suction valve.
8. Redo 1 to 7 for other indoor units.
9. Remove the valve caps from all valves, and open them using a hexagonal Allen wrench.
10. Remount valve caps onto all of the valves.
11. Check for gas leaks from all the connecting position. Test with electronic leak detector or with a sponge immersed for soapy water for bubbles.




Fig 22

- Fig.22
1. Charging set
2. Vacuum pump
3. OUTDOOR UNIT
4. Service valve
5. Cap
6. Suction valve
7. Service valve*
8. Cap
9. Liquid valve
10. INDOOR UNIT
11. Suction flare connection
12. Liquid flare connection

*In some models only

NOTE
For additional charge of various tubing lengths, refer to outdoor unit nameplate.


8

FINAL TASKS

1. Check all valve caps and ensure that they had tightened properly. Close the valve cover.
2. Fill gaps on the wall between hole sides and tubing with sealer.
3. Attach wiring and tubing to the wall with clamps where necessary.
4. Operate the unit for no less than 5 minutes at heating or cooling mode.
5. Explain filter removal, cleaning and installation.
6. Operate the air conditioner together with the customer and explain all functions.
7. Give the operating and installation manuals to the customer.

AIR CONDITIONER SPLIT WALL MOUNTED

ENGLISH



PROGRAMMING AND OPERATING MANUAL

CONTENTS

| | |
|--|----|
| INTRODUCTION | 1 |
| SYSTEM DESCRIPTION | 2 |
| MODES OF OPERATION, FUNCTIONS AND FEATURES | 3 |
| ON-UNIT INDICATORS AND CONTROLS | 5 |
| ● On-unit Operation | 5 |
| PROTECTION MODES | 6 |
| CARE AND MAINTENANCE | 7 |
| OPERATING TIPS | 8 |
| PRECAUTIONS | 9 |
| BEFORE CALLING FOR SERVICE | 10 |

*PLEASE READ THESE
INSTRUCTIONS **BEFORE**
OPERATING THE AIR
CONDITIONER*

INTRODUCTION

Dear customer:

The DC Inverter air conditioner you have purchased is one of the most advanced units of its kind. The DC Inverter air conditioner is a variable capacity air conditioner which uses high efficiency DC motors for the compressor and the outdoor fan. Unlike other models, it can adjust its capacity according to the user setting and the environmental condition, thus saving up to 30% of the seasonal power consumption, while keeping maximum comfort level. This modern unit is also equipped with an ionizer (optional) and an Electrostatic filter (optional) to maximize your indoor air quality.

Detailed instruction as to the DC Inverter air conditioner (including Single & Multi Split type) functions and way of operation are provided in the following pages.

This Split Air Conditioner is designed for versatile application:



- Cooling.



- Dehumidifying.




- Heating.



- Air Filtration.



- Ventilation



OPERATING TEMPERATURE RANGE:

-15°C ~ 46°C

IMPORTANT NOTICE:

● This air conditioner must be grounded to protect against electrical shock.

● Installation of the air conditioner must be performed by an experienced air conditioning installer, observing good refrigeration practice.

● Electrical connections and power cord replacement should only be made by authorized electricians and in accordance with electrical regulations and local codes. The appliance must be positioned so that the plug is accessible.


● Failure to comply with the manufacturer's installation and operation instructions could affect the performance of the air conditioner and the validity of the warranty.

Test Mode

Test Mode is set only for performance testing purposes, and not for user operation. Test mode can be initiated by either one of the following conditions:










- 1) Operating the unit with the following remote control settings and temperature conditions:
Cool Mode, SPT=16°C and RAT=27±1°C,
OAT=35±1°C for 30 minutes;
Heat Mode, SPT=30°C and RAT=20±1°C,
OAT=7±1°C for 30 minutes.
- 2) Entering Diagnostics with Cool/SPT=16°C or Heat/SPT=30°C.






SYSTEM DESCRIPTION




※ Not connected in multi split applications

MODES OF OPERATION, FUNCTIONS AND FEATURES

| | | |
|---|------------------|---|
|  | COOL | Cools, dehumidifies and filters the room air. Maintains desired room temperature. |
|  | HEAT | Heats and filters the room air. Maintains the desired room temperature. |
|  | AUTO | Automatically select between cool and heat operation modes, according to the requested room temperature and the actual room conditions. |
|  | DRY | Dehumidifies and softly cools the room. In DRY Mode, the air conditioner operates at an increased dehumidifying power. This function is recommended to be used when temperature is rather low but the humidity is high. |
|  | FAN | Recirculates and filters the room air. Maintains constant air movement in the room. |
|  | AUTO FAN | The air conditioner automatically selects the FAN speed in accordance to the requested room temperature and the actual room temperature. During the first 30 minutes of unit operation after being turned ON, the unit operates at high fan speed to maximize the cooling/heating effect. As the room air approaches to the desired temperature, the fan switches to a lower speed for quieter operation. |
| | HOT KEEP | In HEATING, when unit is started, the indoor fan will not be turned on until the indoor coil reaches adequate temperature. This HOT KEEP feature prevents uncomfortable cold air drafts. |
|  | I FEEL | Switches the temperature sensing point to the place where the remote control (optional) is located. (Generally the temperature sensor is located behind the intake grille of the air conditioner). This function is designed to provide a personalized environment by transmitting the temperature control command from the location next to you. The communication between the Remote Control and the unit is done by infra-red signal. Therefore, in using this function, the Remote Control should always be aimed, without obstructions, at the air conditioner. |
|  | TIMER | Real time control and display, automatically turns the air conditioner ON and OFF according to the time of day setting, ensuring comfort conditions before returning home, without wasting electricity. It turns the air conditioner off automatically when sleeping. |
|  | SLEEP | Designed to create comfortable sleeping conditions. When in COOLING mode, the temperature rises one degree centigrade after each consecutive hour, up to three hours, from the start of the mode. The temperature rise prevents the feeling of over-cooling while sleeping (when your body is at rest). In HEATING mode the reverse occurs; the air conditioner lowers its temperature one degree every hour, up to three hours, from the start of the mode. When in SLEEP mode, the air conditioner will be automatically turned off after operated for eight hours. The result is a more comfortable and invigorating sleep, which leaves you feeling fresh and energetic in the morning. |
| | AUTO FLAP | The air flap (louvers) is automatically positioned for the most suitable blow-out angle, when COOL, HEAT, DRY or FAN modes are selected. When the air conditioner is turned off, the flap will close automatically for an aesthetic appearance. |

| | | |
|---|--|---|
|  | VERTICAL AIR SWING | Automatic swing of supply air in vertical direction. The flap moves automatically in upward and downward direction to spread the conditioned air evenly throughout the room. |
|  | AIR DIRECTION POSITIONING | Automatic swing of Horizontal air flow in Horizontal direction. The flap move automatically in right and left direction to spread the conditioned air evenly throughout the room. |
|  | ROOM TEMPERATURE | Measures and displays room temperature. |
|  | FILTER INDICATION | Filter indicator on the indoor unit display is turned on when the filter requires cleaning. After cleaning and reinstalling the filter, It should be reset. |
|  | BUZZER | A soft buzzer will sound from the indoor unit display to indicate that a command sent by the remote control has been accepted and stored in the unit's memory. This feature may be easily cancelled by the user from the display panel. |
| | ON UNIT OPERATION | The air conditioner can be turned ON for COOLING or HEATING or be turned OFF directly by "MODE" key without the use of the remote control. |
| | 3-MIN DELAYED RUN | The compressor is protected by a three-minute delayed restart. |
| | MEMORY | The microprocessor retains the last data entry whether or not the unit is plugged in. Therefore, when the unit restarts after a power failure, it will resume operating in the same mode as before the power was disrupted. |
| | LOCK | Freezes the last operation setting on the remote control. When LOCK is activated, the remote control will not be able to control the air-conditioner. |
| | ILLUMINATED KEYPAD AND LCD DISPLAY (optional) | By pressing any button in dark environment, the keypad and the LCD display will be illuminated. |
| | ELECTROSTATIC FILTER (optional) | They are capable of capturing small particles down to 0.1 microns, Such as atmospheric and house hold dust, coal dust, insecticide dust, mites, pollen, pet dander, tobacco smoke particles, cooking smoke and grease, mold fungi, bacteria, viruses and more. |
| | IONIZER (optional) | Ionizer makes the air more fresh and more comfortable. Slide switch (H) to the ON position to activate the ionizer. The blue light indicator (G) on the unit will light up indicating the ionizer in operation. To cancel the operation set slide switch to OFF position. Important Notice: When the air-conditioner is turned OFF or if the indoor fan stops operation, the IONIZER stops automatically. |

ON-UNIT INDICATORS AND CONTROLS



ON- UNIT OPERATION

If the air-conditioner cannot be operated by the Remote Control unit, it can be turned on for cooling or heating, or completely turned off, by pressing MODE button (H) on the air-conditioner. The MODE button will change the operating status of the unit between-COOLING-HEATING-STAND-BY positions, every time it is pressed. Indicators (G), (I) or (A) will light up respectively, to indicate in which mode the air-conditioner operates.

- A. Stand-by/Operation indicator
*Lights up in red when connected to power.
Lights up in green during operation.*
- B. ESF/Ionizer indicator
Lights up when the E.S.F or Ionizer operation.
- C. LCD operation display
- D. Signal receiver
Receiver signals from the remote control.
- E. Timer indicator
Lights up during timer and sleep operation.
- F. Filter indicator
Lights up when air filter requires cleaning.
- G. Cooling indicator
Lights up only when mode (H) is pressed.
- H. Unit mode button
Used to switch the unit off or turn it on for cooling or heating without the remote control.
- I. Heating indicator
Lights up when mode (H) is pressed.
- J. Electrostatic filter safety button
Turn off the Electrostatic filter when you open the grill.
- K. Reset button
 - Press to turn off the filter indicator and to reset the filter function, after the cleaned filter has been reinstalled.
 - Press to cancel the buzzer announcer.
- L. Ionizer indicator
Lights up during the ionizer is open.
- M. Ionizer on/off
Used to switch the ionizer on or off.

PROTECTION MODES

Your air conditioner includes several automatic protection modes which enables you to use it virtually at any time and in any season, regardless of the outdoor temperature. Some of the protection modes are listed below:

| Mode | Operation conditions | Protection from | Controlled remedy |
|---------|------------------------------------|---------------------------|--|
| Cooling | Low outdoor temperature | Indoor coil Freezes up | Stops outdoor fan and compressor when approaching freezing conditions Resumes operation automatically Operating indicator (A) blinks. |
| | High outdoor temperature | Outdoor coil overheating | Stops compressor when approaching overheating conditions. Resumes operation automatically. Operating indicator (A) blinks. |
| Heating | Low outdoor temperature | Outdoor coil ice build up | Reverses operation from heating to cooling for short periods to de-ice outdoor coil. Operating indicator (A) blinks. |
| | High Indoor or outdoor temperature | Indoor coil overheating | Stops outdoor fan and compressor when approaching high indoor coil temperature. Resumes operation automatically. Operating indicator (A) blinks. |


Note: When switching the unit to OFF after heating operation, the unit may perform outdoor coil deicing operation. In such a case, the compressor will continue to run for some time after the unit has switched to OFF, and the indoor unit louvers are closed. This feature is a part of the normal unit operation.

CARE AND MAINTENANCE

Before performing any maintenance procedure, make sure to disconnect the air conditioner from the power.

CLEANING THE AIR FILTER

- Your air conditioner is provided with a filter cleaning indicator. When the filter indicator (F) lights up, the filters should be removed for cleaning.
- To remove the air filters, lift up the panel, push the air filters up slightly to unlock them, pull out the filters. Clean the filters by washing in warm soapy water and dry thoroughly, align and fit the filters in place, close the panel by pushing it in the center to lock it in place.
- Reset button (K) to turn off filter indicator (F).




CLEANING THE ELECTROSTATIC FILTER

The electronic filter should be removed from the unit and cleaning once three month. The procedure is shown as following:

- 1 open the front panel
- 2 push the hook on the filter and pull out the electrostatic filter (Fig ①)
- 3 wash the filter with the warm soapy water and dry thoroughly
- 4 push the electrostatic filter into the right position
- 5 close the front panel

Note: the above procedure is used for cleaning the electrostatic filter.



PURIFICATION FILTER REPLACEMENT

The air purifying filter should be removed from the unit and replaced once a year, shown as following:

- 1 pulling out the filter. (Fig ②)
- 2 replacing and securing the filter in its frame.
- 3 sliding the filter back in its place.

Note: The above procedure is used for replacing the active carbon filter (when supplied).

DO NOT OPERATE THE UNIT WITHOUT FILTERS!

CLEANING THE AIR CONDITIONER

- Wipe the unit with a soft dry cloth or clean it using a vacuum cleaner
- Do not use hot water or volatile materials which could damage the surface of the air conditioner.

AT THE BEGINNING OF THE SEASON

- Make sure there are no obstacles blocking the flow of inlet or outlet air, in both indoor and outdoor units.
- Make sure the power is properly connected.

PROTECT THE ELECTRONIC SYSTEM

- Indoor unit and remote control must be at least 1 meter away from a TV, radio or any other home electronic appliance.
- Protect the inner unit from direct sun or lighting.

OPERATING TIPS

- Set a suitable room temperature; excessively low room temperature is not good for your health and wastes electricity. Avoid frequent setting of the temperature.
- During cooling, avoid direct sun. Keep curtains and blinds closed. Close doors and windows to keep the cool air in the room.
- Avoid generating heat or using of heating appliances while the air conditioner in cooling mode.
- Make sure that the air flap is positioned properly: horizontal flow in cooling and downward vertical flow for heating.
- Keep the room temperature uniform by adjusting the left/right vertical air blades.
- Position the air flap and the left/right air blades in such a manner as to prevent your body from being exposed directly to air drafts.
- During prolonged operation, ventilate the room occasionally by opening a window from time to time.
- In a power failure, the microprocessor memory is retained. When restarted, operation will be resumed in the last mode of operation. However, if the timer was used, the unit will be turned off by the timer only if the remote control is aimed at the unit. Otherwise the power failure will cause the timer data to be erased from the microprocessor memory.
- After turning on, allow more than 3 minutes for cooling, heating or dry operation to start.
- When COOL or DRY modes are used, make sure that the room's relative humidity is below 78%. If the unit is used for a prolonged period of time in high humidity, moisture may form on the air outlet and drip down.
- Remote control signals may not be received if the indoor unit controls cover is exposed to direct sunlight or strong light. In such a case, block the sunlight or dim the lighting.
- The remote control is operative in a range of 8 meters. If you are out of range, the remote control may have difficulties in transmitting signals.

PRECAUTIONS

- Use the proper electrical fuse.


Do not pull out the power cord unless the unit is turned off.



- Do not start or stop operation by disconnecting the power cord.




- Do not obstruct or block the air inlet or air outlet of the air conditioner.



- Do not insert any objects in the air outlet of the indoor or outdoor units.



- Do not splash water on air conditioner.




IF NOISE IS HEARD
There may be hissing sound during operation or just after shut down. This is caused by the refrigerant that is circulating inside the unit

There may be a cracking sound at starting and stopping of the unit's operation. This is caused by heat expansion or contraction of plastics.

BEFORE CALLING FOR SERVICE

Before calling for service, please check the following common malfunctions and correct as needed.

| Problem | Cause | Remedy |
|--|---|---|
| ● Unit does not operate. Stand-by indicator does not light up. | <input type="checkbox"/> Unit not connected to power <input type="checkbox"/> Power failure | ■ Plug in the power cord ■ Check main fuse |
| ● Unit does not operate. Stand-by indicator lights. | <input type="checkbox"/> Remote control malfunctions <input type="checkbox"/> The remote control is locked. | ■ Check remote control batteries. ■ Try to operate from a closer distance. ■ Start from on-unit controls. ■ Unlock the remote control. |
| ● Unit does not respond properly to remote control command. | <input type="checkbox"/> IR signal does not reach unit. <input type="checkbox"/> Distance between remote control and unit too large or aimed at from improper angle. <input type="checkbox"/> IR receiver on-unit exposed to strong light source. | ■ Check for obstruction between unit and remote control, Clear if needed. ■ Get closer to unit. ■ Dim lights, fluorescents especially |
| ● Air does not blow out from indoor unit. | <input type="checkbox"/> De-icing protection mode is activated. | ■ Normal operation in HEATING mode. |
| ● COOLING, DRY or HEATING does not start immediately. | <input type="checkbox"/> 3-min. Compressor delayed start | ■ Normal operation for these modes. |
| ● Unit functions but does not perform sufficiently. | <input type="checkbox"/> Improper temperature setting. <input type="checkbox"/> Unit capacity insufficient for load or room size. | ■ Reset temperature. ■ Consult your dealer |
| ● Filter indicator lights up | <input type="checkbox"/> Air Filter needs cleaning | ■ Clean filter, reinstall and reset indicator |



DC INVERTER

INSTALLATION INSTRUCTIONS

ENGLISH

INSTALLATION INSTRUCTIONS

ENGLISH













1. ACCESSORIES SUPPLIED WITH THE AIR CONDITIONER
2. LOCATION OF INDOOR AND OUTDOOR UNIT
3. INSTALLATION/SERVICE TOOLS (ONLY FOR R410A PRODUCT)
4. INSTALLATION OF THE INDOOR UNIT
5. CONDENSATE HOSE CONNECTION
6. ELECTRICAL CONNECTION BETWEEN INDOOR AND OUTDOOR UNIT
7. REFRIGERANT TUBING
8. FINAL TASKS

The appliance shall not be installed in the laundry.

INSTALLATION INSTRUCTIONS

FOR DCI SPLIT WALL MOUNTED AIR CONDITIONER

1 ACCESSORIES SUPPLIED WITH THE AIR CONDITIONER

| Shape | Name | Qty | Used for |
|---|---|-----|---|
|  | Mounting plate | 1 | Wall mounting of the indoor unit |
|  | Remote control with batteries | 1 | Operation of unit |
|  | Remote control bracket | 1 | Wall mounting of the remote control |
|  | Screws washer dowels | 4 | Wall mounting of indoor unit |
|  | Screws dowels | 2 | Wall mounting of remote control bracket |
|  | Outdoor unit drain connector | 1 | Outdoor unit water drain |
|  | Mounting pads | 4 | Padding of outdoor unit bottom support |
|  | Cable ties | 4 | Securing wires in the indoor and outdoor unit |
|  | Power input cable (Optional) | 1 | Connecting indoor unit power |
|  | Cable terminals | 1 | Securing of grounding wire in the indoor and outdoor unit |
|  | Air purifying filter (Optional) | 2 | Cleaning the air |
|  | <ul style="list-style-type: none"> Remote control operation Unit operation Installation manual | 3 | Users and installers reference |

Indoor Unit's Accessories Only for One Unit.

2 LOCATION OF INDOOR AND OUTDOOR UNIT

Select the location considering the following:

INDOOR UNIT

1. Choose a location which will provide good air circulation.
2. Do not install the unit near a heat source or where it will be exposed to direct sunlight.
3. The location must allow convenient electrical wiring, drainage and tubing connections as shown in fig 3.
4. The appliance must be positioned so that the plug is accessible.
5. Installation site should provide an easy passage to outdoors.
6. The unit must be mounted on a strong wall that will withstand the generated vibrations.
7. Install the mounting plate as shown in fig 5.
8. Install the remote control bracket as shown in fig 4.

OUTDOOR UNIT

1. The location must allow easy servicing and provide good air circulation as shown in fig 5.
2. The unit may be suspended from a wall by a bracket (Optional) or located in a free standing position on the floor (preferably slightly elevated).
3. If the unit is suspended, ensure that the bracket is firmly connected and the wall is strong enough to withstand vibrations.
4. Unit location should not disturb neighbors with noise or exhaust air stream.
5. Place the mounting pads under the unit legs.
6. Refer to figure 5 for allowed installation distances.
7. When the unit is installed on a wall, install the drain connector hose and drain plug as shown in fig 1 and fig 2.

Fig. 1
1. Bottom of outdoor unit
2. Drain connector







Fig. 2
Drain installation Example





NOTE:

- Distance between indoor and outdoor units should be $\leq 30\text{m}$.
- Height difference between indoor and outdoor units should be $\leq 15\text{m}$.
- No additional charge is required.




Fig.5
1. Mounting pads ($\times 4$)

INSTALLATION/SERVICE TOOLS (ONLY FOR R410A PRODUCT)

CAUTION

New Refrigerant Air Conditioner Installation

THIS AIR CONDITIONER ADOPTS THE NEW HFC REFRIGERANT (R410A) WHICH DOES NOT DESTROY OZONE LAYER. R410A refrigerant is apt to be affected by impurities such as water, oxidizing membrane, and oils because the working pressure of R410A refrigerant is approx. 1.6 times of refrigerant R22. Accompanied with the adoption of the new refrigerant, the refrigeration machine oil has also been changed. Therefore, during installation work, be sure that water, dust, former refrigerant, or refrigeration machine oil does not enter into the new type refrigerant R410A air conditioner circuit.








To prevent mixing of refrigerant or refrigerating machine oil, the sizes of connecting sections of charging port on main unit and installation tools are different from those used for the conventional refrigerant units. Accordingly, special tools are required for the new refrigerant (R410A) units. For connecting pipes, use new and clean piping materials with high pressure fittings made for R410A only, so that water and/or dust does not enter. Moreover, do not use the existing piping because there are some problems with pressure fittings and possible impurities in existing piping.

Changes in the product and components

In air conditioners using R410A, in order to prevent any other refrigerant from being accidentally charged, the service port diameter size of the outdoor unit control valve (3 way valve) has been changed. (1/2 UNF 20 threads per inch)

- In order to increase the pressure resisting strength of the refrigerant piping, flare processing diameter and opposing flare nuts sizes have been changed. (for copper pipes with nominal dimensions 1/2 and 5/8)

New tools for R410A

| New tools for R410A | Applicable to R22 model | Changes |
|---|-------------------------|--|
| Gauge manifold | × |  As the working pressure is high, it is impossible to measure the working pressure using conventional gauges. In order to prevent any other refrigerant from being charged, the port diameters have been changed. |
| Charge hose | × |  In order to increase pressure resisting strength, hose materials and port sizes have been changed (to 1/2 UNF 20 threads per inch). When purchasing a charge hose, be sure to confirm the port size. |
| Electronic balance for refrigerant charging | ○ |  As working pressure is high and gasification speed is fast, it is difficult to read the indicated value by means of charging cylinder, as air bubbles occur. |
| Torque wrench (nominal dia. 1/2, 5/8) | × |  The size of opposing flare nuts have been increased. Incidentally, a common wrench is used for nominal diameters 1/4 and 3/8. |
| Flare tool (clutch type) | ○ |  By increasing the clamp bar's receiving hole size, strength of spring in the tool has been improved. |
| Gauge for projection adjustment | — | Used when flare is made by using conventional flare tool. |
| Vacuum pump adapter | ○ |  Connected to conventional vacuum pump. It is necessary to use an adapter to prevent vacuum pump oil from flowing back into the charge hose. The charge hose connecting part has two ports -- one for conventional refrigerant (7/16 UNF 20 threads per inch) and one for R410A. If the vacuum pump oil (mineral) mixes with R410A a sludge may occur and damage the equipment. |
| Gas leakage detector | × |  Exclusive for HFC refrigerant. |

- Incidentally, the "refrigerant cylinder" comes with the refrigerant designation (R410A) and protector coating in the U.S's ARI specified rose color (ARI color code: PMS 507).
- Also, the "charge port and packing for refrigerant cylinder" requires 1/2 UNF 20 threads per inch corresponding to the charge hose's port size.

SUSPENDING AND RELEASING THE UNIT FROM THE MOUNTING PLATE

1. Make sure that the refrigerant tubes, electric cables and condensate water hose are well insulated with closed cell rubber based insulating tubes (6mm thickness), are wrapped together with UV stabilized nonadhesive plastic tape, and are passed through the hole in the wall.
2. Hang the indoor unit on the two hooks that are located near the top edge of the mounting plate as shown in fig. 10 and fig. 11.
3. Press the lower part of the indoor unit against the mounting plate until the catches snap into the slots and lock the indoor unit to the mounting plate.
4. Check the installation by pulling the unit towards you.
5. To release the unit from the mounting plate, lift up the unit and then pull the unit towards you, to ensure that the hooks are locked.

Fig.10

1. Indoor unit 3. Top hooks
2. Snap catches 4. Bottom hooks




Fig. 10

Fig.11

1. Mounting plate
2. Lower hook




Fig. 11

5 CONDENSATE HOSE CONNECTION

1. Attach the condensate drain hose to the corrugated hose in the rear groove of the indoor unit.
2. Wrap the drain hose together with the refrigerant tubes and electrical cables.
3. Ensure that the condensate drain hose is at all points installed in a downward slope manner.

Fig.12

1. Drain hose
2. Clamp
3. Downward slope




Fig. 12

Fig.13

1. Trap
2. U-bend
3. End immersed in water




Fig. 13

4. When installing the drain hose avoid traps and U-bends. The end of the drain hose should not be immersed in water.

Fig.14

1. Electric cable
2. Refrigerant tubing
3. Condensate drain hose
4. UV stabilized nonadhesive plastic tape




Fig. 14

5. For a lefthand outlet, lay the drain hose on the bottom of the indoor unit rear groove.

Fig.15

1. Vent
2. Downward drain
3. Water drain hose




Fig. 15

6. When the installation location requires long horizontal sections, a vent must be provided at the top of the hose to prevent overflow of the unit drain pan.

7. Upon completing the installation, test the water drain by pouring at least two liters of water into the unit drain pan. Check that the water drains off.

ELECTRICAL CONNECTION BETWEEN INDOOR AND OUTDOOR UNIT

ELECTRICAL REQUIREMENTS

Electrical wiring and connections should be made by qualified electricians and in accordance with local electrical codes and regulation. The air conditioner units must be grounded.

The air conditioner unit must be connected to an adequate power outlet from a separate branch circuit protected by a time delay circuit breaker, as specified on unit's nameplate.

Voltage should not vary beyond $\pm 10\%$ of the rated voltage.

1. Connect the power supply cable to the indoor unit of WNG.
2. To connect the indoor unit to the outdoor unit use the following electrical cables.

Electrical connections:

Power input cable: 3 wires \times 2.5 mm²

Cable between

Indoor and outdoor units: 4 wires \times 2.5 mm²

3. Prepare the cable ends for the power input and for the cables between outdoor and indoor units as shown in figure 17a and 17b respectively.
4. Connect the cable ends to the terminals of the indoor and outdoor units, as shown in fig. 18.
5. Secure the multiple wire power cable with the cable clamps.

Fig.16

1. Terminal 2. Cover 3. Cable clamp




Fig. 16

NOTES:

1. The wire color code can be selected by the installer.

• Power input cable




Fig. 17a

• Cable between indoor and outdoor units




Fig. 17b

Fig.17 A. OUTDOOR B. INDOOR




Fig. 18

Fig.18

1. Indoor unit terminal
 2. Ground wire.
 3. Indoor coil.
 4. Power cable in the indoor side.
 5. Multiple wire cable.
 6. Cable clamp.
 7. Outdoor unit wire terminal.
 8. Power cable in the outdoor side (only for outdoor unit power supply)
- A. OUTDOOR B. INDOOR

REFRIGERANT TUBING

CONNECT THE INDOOR TO THE OUTDOOR UNIT

The indoor unit contains a small quantity of nitrogen. Do not unscrew the nuts from the unit until you are ready to connect the tubing. The outdoor unit is supplied with sufficient refrigerant charge (R410A). Refer to outdoor unit nameplate.

To prevent crushing, bend tubes using a bending tool.

NOTE: Use refrigeration R410A type copper tubing only.

1. Open the valve cover.
2. Use tubing diameter that corresponds to the tubing diameter of the indoor and outdoor units. Note that the liquid and suction tubes have different diameters. (See tube size, torque tightening table.)
3. Place flares nuts on tube ends before preparing them with a flaring tool. Use the flare nuts that are mounted on the supplied outdoor and indoor units.
4. Connect the all ends of the tubing to the indoor and outdoor units. Notice the sign. All ends should correspond one by one.
5. Insulate each tube separately, and their unions, with at least 13 mm thick of insulation. Wrap the refrigerant tubing, drain hose and electric cables together with a vinyl tape (UV protected).




Fig. 19

Caution!
When unscrewing the valve caps, do not stand in front of them or the spindles at any time, as the system is under pressure.

- Fig. 19**
1. INDOOR UNIT
 2. Liquid tube (small dia.)
 3. Suction tube (large dia.)
 4. Plugs
 5. Flare nuts
 6. Tubing between units
 7. Suction tube
 8. Liquid tube
 9. OUTDOOR UNIT
 10. Flare nuts
 11. Liquid valve (small)
 12. Suction valve (larger)

Tightening torques of unions and valve caps:

| TUBE SIZE | TORQUE |
|-------------------|-------------|
| Liquid line 3/8" | 30-35 N.M. |
| Suction line 1/2" | 50-54 N.M. |
| Suction line 5/8" | 75-78 N.M. |
| Suction line 3/4" | 80-100 N.M. |




Fig. 20

1. Wrench
2. Torque wrench
3. Union




Fig. 21
To prevent refrigerant leakage, coat the flared surface with refrigeration oil




Fig. 22

1. Suction valve
2. Service port
3. Liquid valve

EVACUATION OF THE REFRIGERATION TUBES AND THE INDOOR UNIT

After connecting the unions of the indoor and outdoor units, purge the air from the tubes and indoor unit as follows:

1. Connect the charging hoses with a push pin to the low side of the charging set and the service port of the suction valve. Be sure to connect the end of the charging hose with the push pin to the service port.
2. Connect the center hose of the charging set to a vacuum pump.
3. Turn on the power switch of the vacuum pump, turn off the high side switch and make sure that the needle in the gauge moves from 0 MPa (0cm Hg) to -0.1 MPa (-76cm Hg). Let the pump run for fifteen minutes.
4. Close the valve of the low side of the charging set and turn off the vacuum pump. Note that the needle in the gauge should not move after approximately five minutes.
5. Not any problem for five minutes, turn on the power switch of the vacuum pump and open the valve of the low side of the charging set.
6. Disconnect the charging hose from the vacuum pump and from the service ports of the suction valve.
7. Tighten the service port caps of suction valve.
8. Redo 1 to 7 for other indoor units.
9. Remove the valve caps from all valves, and open them using a hexagonal Allen wrench.
10. Remount valve caps onto all of the valves.
11. Check for gas leaks from all the connecting position. Test with electronic leak detector or with a sponge immersed for soapy water for bubbles.




Fig. 23

- Fig. 23**
1. Charging set
 2. Vacuum pump
 3. OUTDOOR UNIT
 4. Service valve
 5. Cap
 6. Suction valve
 7. Service valve*
 8. Cap
 9. Liquid valve
 10. INDOOR UNIT
 11. Suction flare connection
 12. Liquid flare connection
- *In some models only

NOTE
For additional charge of various tubing lengths, refer to outdoor unit nameplate.

1. Check all valve caps and ensure that they had tightened properly. Close the valve cover.
2. Fill gaps on the wall between hole sides and tubing with sealer.
3. Attach wiring and tubing to the wall with clamps where necessary.
4. Operate the unit for no less than 5 minutes at heating or cooling mode.
5. Explain filter removal, cleaning and installation.
6. Operate the air conditioner together with the customer and explain all functions.
7. Give the operating and installation manuals to the customer.
8. An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring