





Just feel well

SERVICE MANUAL

LIGHT COMMERCIAL SERIES (DUCT + CASSTTE)
R410A ON OFF
English Manual

DFMD-050N-01M25 / YFAD-050R-01M25
DFMD-070N-01M25 / YFAD-070R-01M25
CFMD-035N-01M25 / YFAD-035R-01M25
CFMD-050N-01M25 / YFAD-050R-01M25
CFMD-070N-01M25 / YFAD-070R-01M25
CFMD-100N-01M25 / YFAD-100R-01T35
CFMD-140N-01M25 / YFAD-100R-01T35



IMPORTANT NOTE:

Read this manual carefully before installing or operating your new air conditioning unit. Make sure to save this manual for future reference.

21.AW.CFMD.35-140(DFMD.50-70).R410A.SM.EN.10.25

Table of Contents

§. Safety Precautions

1. Precautions
2. Information servicing

§. Model Reference & External Appearance

1. Model Reference
2. External Appearance

§. Indoor Unit

1. Indoor Unit - A6 Duct Type
2. Indoor Unit - Compact Four-way Cassette Type
3. Indoor Unit - New Four-way Cassette Type

§. Outdoor Unit

1. Dimensional Drawings
2. Service Space
3. Capacity Correction Factor for Height Difference
4. Noise Criterion Curves
5. Refrigerant Cycle Diagrams
6. Electrical Wiring Diagrams

§. Installation

§. Maintenance

§. Product Features

Table of Contents

§. Troubleshooting

1. Safety Caution
2. General Troubleshooting
3. Complain Record Form
4. Error Diagnosis and Troubleshooting Without Error Code
5. Quick Maintenance by Error Code
6. Troubleshooting by Error Code

§. Indoor Unit Disassembly

1. Indoor Unit - A6 Duct Type
2. Indoor Unit - Compact Four-way Cassette Type
3. Indoor Unit - New Four-way Cassette Type

§. Outdoor Unit Disassembly

Appendix

- i) Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 (°C – K)
- ii) Temperature Sensor Resistance Value Table for TP(for some units) (°C – K)
- iii) Pressure On Service Port

Safety Precautions

Contents

1.	Precautions.....	2
2.	Information servicing(For flammable materials).....	3

1. Precautions

To prevent personal injury, or property or unit damage, adhere to all precautionary measures and instructions outlined in this manual. Before servicing a unit, refer to this service manual and its relevant sections.

Failure to adhere to all precautionary measures listed in this section may result in personal injury, damage to the unit or to property, or in extreme cases, death.

 **WARNING** indicates a potentially hazardous situation which if not avoided could result in serious personal injury, or death.

 **CAUTION** indicates a potentially hazardous situation which if not avoided could result in minor or moderate personal injury, or unit damage.

1.1 In case of Accidents or Emergency

 **WARNING**

- If a gas leak is suspected, immediately turn off the gas and ventilate the area if a gas leak is suspected before turning the unit on.
- If strange sounds or smoke is detected from the unit, turn the breaker off and disconnect the power supply cable.
- If the unit comes into contact with liquid, contact an authorized service center.
- If liquid from the batteries makes contact with skin or clothing, immediately rinse or wash the area well with clean water.
- Do not insert hands or other objects into the air inlet or outlet while the unit is plugged in.
- Do not operate the unit with wet hands.
- Do not use a remote controller that has previously been exposed to battery damage or battery leakage.

 **CAUTION**

- Clean and ventilate the unit at regular intervals when operating it near a stove or near similar devices.
- Do not use the unit during severe weather conditions. If possible, remove the product from the window before such occurrences.

1.2 Pre-Installation and Installation

 **WARNING**

- Use this unit only on a dedicated circuit.
- Damage to the installation area could cause the unit to fall, potentially resulting in personal injury, property damage, or product failure.
- Only qualified personnel should disassemble, install, remove, or repair the unit.
- Only a qualified electrician should perform electrical work. For more information, contact your dealer, seller, or an authorized service center.

 **CAUTION**

- While unpacking be careful of sharp edges around the unit as well as the edges of the fins on the condenser and evaporator.

1.3 Operation and Maintenance

 **WARNING**

- Do not use defective or under-rated circuit breakers.
- Ensure the unit is properly grounded and that a dedicated circuit and breaker are installed.
- Do not modify or extend the power cable. Ensure the power cable is secure and not damaged during operation.
- Do not unplug the power supply plug during operation.
- Do not store or use flammable materials near the unit.
- Do not open the inlet grill of the unit during operation.
- Do not touch the electrostatic filter if the unit is equipped with one.
- Do not block the inlet or outlet of air flow to the unit.
- Do not use harsh detergents, solvents, or similar items to clean the unit. Use a soft cloth for cleaning.
- Do not touch the metal parts of the unit when removing the air filter as they are very sharp.
- Do not step on or place anything on the unit or outdoor units.
- Do not drink water drained from the unit
- Avoid direct skin contact with water drained from the unit.
- Use a firm stool or step ladder according to manufacturer procedures when cleaning or maintaining the unit.

 **CAUTION**

- Do not install or operate the unit for an extended period of time in areas of high humidity or in an environment directly exposing it to sea wind or salt spray.
- Do not install the unit on a defective or damaged installation stand, or in an unsecure location.
- Ensure the unit is installed at a level position
- Do not install the unit where noise or air discharge created by the outdoor unit will negatively impact the environment or nearby residences.
- Do not expose skin directly to the air discharged by the unit for prolonged periods of time.
- Ensure the unit operates in areas water or other liquids.
- Ensure the drain hose is installed correctly to ensure proper water drainage.
- When lifting or transporting the unit, it is recommended that two or more people are used for this task.
- When the unit is not to be used for an extended time, disconnect the power supply or turn off the breaker.

2. Information servicing(For flammable materials)

2.1 Checks to the area

- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized.
- For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.

2.2 Work procedure

- Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.

2.3 Work procedure

- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.
- Work in confined spaces shall be avoided.
- The area around the work space shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.

2.4 Checking for presence of refrigerant

- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. no sparking, adequately sealed or intrinsically safe.

2.5 Presence of fire extinguisher

- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand.
- Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.

2.6 No ignition sources

- No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.

- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- NO SMOKING signs shall be displayed.

2.7 Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

2.8 Checks to the refrigeration equipment

- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using flammable refrigerants:
 - the charge size is in accordance with the room size within which the refrigerant containing parts are installed;
 - the ventilation machinery and outlets are operating adequately and are not obstructed;
 - if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant; marking to the equipment continues to be visible and legible.
 - markings and signs that are illegible shall be corrected;
 - refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

2.9 Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include:

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that there no live electrical components and wiring are exposed while charging, recovering or purging the system;
- that there is continuity of earth bonding.

2.10 Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
 - Ensure that apparatus is mounted securely.
 - Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE: The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

2.11 Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use. Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

2.12 Cabling

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check

shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

2.13 Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

2.14 Leak detection methods

- The following leak detection methods are deemed acceptable for systems containing flammable refrigerants. Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
 - If a leak is suspected, all naked flames shall be removed or extinguished.
 - If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

2.15 Removal and evacuation

- When breaking into the refrigerant circuit to make repairs or for any other purpose, conventional procedures shall be used. However, it is important that best practice is followed since flammability is a consideration.
- The following procedure shall be adhered to:
 - remove refrigerant;
 - purge the circuit with inert gas;
 - evacuate;
 - purge again with inert gas;
 - open the circuit by cutting or brazing.

- The refrigerant charge shall be recovered into the correct recovery cylinders. The system shall be flushed with OFN to render the unit safe. This process may need to be repeated several times. Compressed air or oxygen shall not be used for this task. Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. This operation is absolutely vital if brazing operations on the pipe-work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and there is ventilation available.

2.16 Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed:
 - Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
 - Cylinders shall be kept upright.
 - Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
 - Label the system when charging is complete (if not already).
 - Extreme care shall be taken not to overfill the refrigeration system.
 - Prior to recharging the system it shall be pressure tested with OFN. The system shall be leak tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

2.17 Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken.

In case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- Become familiar with the equipment and its operation.
- Isolate system electrically.

- Before attempting the procedure ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards.
- Pump down refrigerant system, if possible.
- If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- Make sure that cylinder is situated on the scales before recovery takes place.
- Start the recovery machine and operate in accordance with manufacturer's instructions.
- Do not overfill cylinders. (No more than 80 % volume liquid charge).
- Do not exceed the maximum working pressure of the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

2.18 Labelling

- Equipment shall be labelled stating that it has been de-commissioned and emptied of
- refrigerant. The label shall be dated and signed. Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

2.19 Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct numbers of cylinders for holding the total system charge are available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.

-
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
 - The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order.
 - Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
 - If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

Model Reference

Contents

1.	Model Reference.....	2
2	External Appearance	3

1. Model Reference

Refer to the following table to determine the specific indoor and outdoor unit model number of your purchased equipment.

Indoor Unit Model		Universal Outdoor Unit Model	Capacity (Btu/h)	Power Supply	
Cassette	CFMD-035N-01M25	YFAD-035R-01M25	12k	220-240V,1Ph,50Hz	
A6 Duct	DFMD-050N-01M25	YFAD-050R-01M25	18k		
Cassette	CFMD-050N-01M25				
A6 Duct	DFMD-070N-01M25	YFAD-070R-01M25	24k		
Cassette	CFMD-070N-01M25				
Cassette	CFMD-100N-01M25	YFAD-100R-01T35	36k	380-415V,3Ph,50Hz	
Cassette	CFMD-140N-01M25	YFAD-140R-01T35	48k		

2. External Appearance

2.1 Indoor Unit

A6 Duct



Compact Four-way Cassette



New Four-way Cassette



2.2 Outdoor Unit

Single Fan Outdoor Unit



Double Fan Outdoor Unit



Indoor Unit-A6 Duct


Contents

1.	Feature.....	2
2.	Dimensional Drawings	4
3.	Part names	6
4.	Service Place.....	6
5.	Accessories	7
6	Fan Performance.....	8
7.	Capacity Tables	11
8.	Noise Criterion Curves.....	16
9.	Electrical Characteristics.....	18
10.	Electrical Wiring Diagrams.....	18

1. Feature

1.1 Eccentric Fan Design

New eccentric fan design improves the airflow at the air outlet, resulting better performance.




1.2 Slim Design

The industry lowest height is designed to be fitted into tight roof space.


1.3 Flexible Air Intake

The frame size of air inlet in rear and bottom is the same. It's very easy to switch to match different applications.




1.4 Built-in Drain Pump(Optional)

The built-in drain pump can lift condensing water up to 750mm.




1.5 Easy Clean

You can pull out the filter from left, right, or from the bottom for easy cleaning.




2. Dimensional Drawings




Model (kBtu/h)	unit	A	B	C	D	E	F	G	H	I	J	K	L	M	H1	H2	W1	W2
12	mm	700	200	506	450	137	537	30	152	599	186	50	741	360	84	140	84	84
	inch	27.56	7.87	19.92	17.72	5.39	21.14	1.18	5.98	23.58	7.32	1.97	29.17	14.17	3.31	5.51	3.31	3.31
18	mm	880	210	674	600	140	706	50	136	782	190	40	920	508	78	148	88	112
	inch	34.65	8.27	26.54	23.62	5.51	27.8	1.97	5.35	30.79	7.48	1.57	36.22	20	3.07	5.83	3.46	4.41
24	mm	1100	249	774	700	140	926	50	175	1001	228	5	1140	598	80	150	130	155
	inch	43.31	9.80	30.47	27.56	5.51	36.46	1.97	6.89	39.41	8.98	0.2	44.88	23.54	3.15	5.91	5.12	6.10

3. Part names








4. Service Place



5. Accessories

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or equipment failure.


	Name	Shape	Quantity
Tubing & Fittings	Soundproof / insulation sheath		2
	Seal sponge (some models)		1
	Orifice (some models)		1
Drainpipe Fittings (for cooling & heating)	Drain joint (some models)		1
	Seal ring (some models)		1
EMC Magnetic Ring (some models)	Magnetic ring(Wrap the electric wires S1 & S2 (P & Q & E) around the magnetic ring twice)	 S1&S2(P&Q&E)	1
	Magnetic ring(Hitch on the connective cable between the indoor unit and outdoor unit after installation.)		1
Others	Owner's manual&Installation manual	-	1
	Transfer connector($\phi 12.7-\phi 15.9$)/($\phi 0.5in-\phi 0.63in$)(Packed with the indoor unit) NOTE: Pipe size may differ from appliance to appliance. To meet different pipe size requirements, sometimes the pipe connections need a transfer connector installed on the outdoor unit.		1 (on some models)
	Transfer connector($\phi 6.35-\phi 9.52$)/($\phi 0.25in-\phi 0.375in$)(Packed with the indoor unit) NOTE: Pipe size may differ from appliance to appliance. To meet different pipe size requirements, sometimes the pipe connections need a transfer connector installed on the outdoor unit.		1 (on some models)
	Transfer connector($\phi 9.52-\phi 12.7$)/($\phi 0.375in-\phi 0.5in$)(Packed with the indoor unit) NOTE: Pipe size may differ from appliance to appliance. To meet different pipe size requirements, sometimes the pipe connections need a transfer connector installed on the outdoor unit.		1 (on some models)
	Connecting wire for display (2m)	-	1(on some models)
	Cord protection rubber ring		1(on some models)
	Display panel *Just for testing purposes only		1(on some models-KJR-120G,KJR-120H)

Optional accessories:


- There are two types of remote controls: wired and wireless.
- Select a remote controller based on customer preferences and requirements and install in an appropriate place.
- Refer to catalogues and technical literature for guidance on selecting a suitable remote controller.

6. Fan Performance


12k



18k



24k



7. Capacity Tables

7.1 Cooling

		12k																	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	16.0				18.0				19.0				22.0				
		ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	
310	18	TC	3.60	3.60	3.60	3.60	3.82	3.80	3.80	3.80	3.92	3.92	3.92	3.92	4.21	4.21	4.21	4.21	
		S/T	0.68	0.73	0.79	0.85	0.57	0.62	0.68	0.73	0.52	0.57	0.63	0.68	0.40	0.45	0.50	0.55	
		PI	0.87	0.88	0.88	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.86	0.86	0.86	0.86	
	25	TC	3.37	3.37	3.37	3.37	3.57	3.57	3.57	3.57	3.69	3.69	3.69	3.69	3.98	3.98	3.98	3.98	
		S/T	0.68	0.74	0.80	0.86	0.57	0.63	0.68	0.74	0.52	0.57	0.63	0.69	0.40	0.45	0.50	0.55	
		PI	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	
	30	TC	3.20	3.20	3.20	3.20	3.43	3.43	3.43	3.43	3.52	3.52	3.52	3.52	3.80	3.80	3.80	3.80	
		S/T	0.68	0.75	0.81	0.88	0.57	0.63	0.69	0.75	0.51	0.57	0.63	0.69	0.39	0.44	0.50	0.55	
		PI	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.11	1.11	1.11	1.11	
	35	TC	3.05	3.05	3.05	3.08	3.26	3.26	3.26	3.26	3.34	3.34	3.34	3.34	3.60	3.60	3.60	3.60	
		S/T	0.69	0.76	0.82	0.89	0.57	0.63	0.70	0.76	0.51	0.58	0.64	0.70	0.38	0.44	0.50	0.56	
		PI	1.20	1.20	1.20	1.20	1.21	1.21	1.21	1.21	1.21	1.21	1.21	1.22	1.22	1.22	1.22	1.22	
	40	TC	2.82	2.82	2.82	2.85	3.03	3.03	3.03	3.03	3.11	3.11	3.11	3.11	3.36	3.36	3.36	3.36	
		S/T	0.70	0.77	0.85	0.92	0.57	0.64	0.71	0.78	0.51	0.58	0.65	0.72	0.38	0.44	0.50	0.56	
		PI	1.38	1.38	1.38	1.38	1.39	1.39	1.39	1.39	1.39	1.39	1.39	1.40	1.40	1.40	1.40	1.40	
	43	TC	2.67	2.67	2.67	2.70	2.87	2.87	2.87	2.87	2.96	2.96	2.96	2.96	3.19	3.19	3.19	3.19	
		S/T	0.70	0.78	0.86	0.94	0.57	0.65	0.72	0.79	0.51	0.58	0.65	0.72	0.37	0.44	0.50	0.57	
		PI	1.48	1.48	1.48	1.48	1.49	1.49	1.49	1.49	1.49	1.49	1.49	1.50	1.50	1.50	1.50	1.50	
400	18	TC	3.66	3.66	3.66	3.69	3.89	3.89	3.89	3.89	4.01	4.01	4.01	4.01	4.30	4.30	4.30	4.30	
		S/T	0.70	0.77	0.84	0.91	0.57	0.64	0.71	0.78	0.51	0.58	0.65	0.71	0.38	0.44	0.50	0.56	
		PI	0.88	0.88	0.88	0.88	0.88	0.88	0.88	0.88	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	
	25	TC	3.43	3.43	3.43	3.46	3.63	3.63	3.63	3.63	3.75	3.75	3.75	3.75	4.04	4.04	4.04	4.04	
		S/T	0.70	0.78	0.86	0.94	0.57	0.65	0.72	0.80	0.51	0.58	0.66	0.73	0.37	0.44	0.50	0.57	
		PI	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	1.02	
	30	TC	3.26	3.26	3.26	3.29	3.49	3.49	3.49	3.49	3.57	3.57	3.57	3.57	3.86	3.86	3.86	3.86	
		S/T	0.71	0.79	0.88	0.96	0.58	0.65	0.73	0.81	0.51	0.59	0.66	0.74	0.37	0.44	0.51	0.58	
		PI	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	1.11	
	35	TC	3.11	3.11	3.14	3.17	3.32	3.32	3.32	3.32	3.40	3.40	3.40	3.40	3.66	3.66	3.66	3.66	
		S/T	0.72	0.81	0.89	0.97	0.58	0.66	0.74	0.82	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.58	
		PI	1.21	1.21	1.21	1.21	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.22	
	40	TC	2.85	2.85	2.88	2.91	3.04	3.04	3.04	3.04	3.12	3.12	3.12	3.14	3.38	3.38	3.38	3.38	
		S/T	0.74	0.83	0.93	1.00	0.59	0.68	0.77	0.86	0.52	0.60	0.69	0.78	0.36	0.44	0.52	0.60	
		PI	1.38	1.38	1.38	1.38	1.39	1.39	1.39	1.39	1.39	1.39	1.39	1.40	1.40	1.40	1.40	1.40	
	43	TC	2.70	2.70	2.73	2.76	2.88	2.88	2.88	2.88	2.96	2.96	2.96	2.96	3.22	3.22	3.22	3.22	
		S/T	0.75	0.85	0.94	1.00	0.59	0.69	0.78	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60	
		PI	1.48	1.48	1.48	1.48	1.49	1.49	1.49	1.49	1.49	1.49	1.49	1.51	1.51	1.51	1.51	1.51	
510	18	TC	3.72	3.72	3.75	3.78	3.95	3.95	3.95	3.95	4.06	4.06	4.06	4.06	4.35	4.35	4.35	4.35	
		S/T	0.73	0.82	0.91	1.00	0.59	0.67	0.76	0.85	0.52	0.60	0.69	0.77	0.36	0.44	0.51	0.59	
		PI	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.89	0.89	0.89	0.89	
	25	TC	3.49	3.49	3.52	3.55	3.69	3.69	3.69	3.69	3.81	3.81	3.81	3.81	4.09	4.09	4.09	4.09	
		S/T	0.75	0.84	0.94	1.00	0.59	0.68	0.78	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60	
		PI	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	1.04	
	30	TC	3.32	3.32	3.34	3.37	3.55	3.55	3.55	3.57	3.63	3.63	3.63	3.63	3.92	3.92	3.92	3.92	
		S/T	0.76	0.86	0.96	1.00	0.60	0.69	0.79	0.88	0.52	0.62	0.71	0.81	0.35	0.44	0.52	0.61	
		PI	1.13	1.13	1.13	1.13	1.13	1.13	1.13	1.14	1.14	1.14	1.14	1.14	1.14	1.14	1.14	1.14	
	35	TC	3.14	3.14	3.17	3.20	3.37	3.37	3.37	3.40	3.46	3.46	3.46	3.46	3.75	3.75	3.75	3.75	
		S/T	0.77	0.88	0.99	1.00	0.60	0.70	0.81	0.90	0.53	0.62	0.72	0.82	0.35	0.44	0.53	0.62	
		PI	1.24	1.24	1.24	1.24	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.26	1.26	1.26	1.26	1.26	
	40	TC	2.88	2.90	2.93	2.96	3.09	3.09	3.09	3.12	3.18	3.18	3.18	3.18	3.45	3.45	3.45	3.45	
		S/T	0.80	0.91	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.90	
		PI	1.41	1.41	1.41	1.41	1.42	1.42	1.42	1.42	1.42	1.42	1.42	1.43	1.43	1.43	1.43	1.43	
	43	TC	2.73	2.76	2.79	2.82	2.93	2.93	2.93	2.96	3.02	3.02	3.02	3.02	3.28	3.28	3.28	3.28	
		S/T	0.81	0.93	1.00	1.00	0.62	0.74	0.86	0.97	0.54	0.65	0.76	0.88	0.34	0.44	0.55	0.92	
		PI	1.52	1.52	1.52	1.52	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.54	1.54	1.54	1.54	1.54	

TC:Total Cooling Capacity (kW)

S/T:Sensible Cooling Capacity Ratio

PI:Power Input(kW)

		18k																	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	16.0				18.0				19.0				22.0				
		ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	
		TC	5.34	5.33	5.39	5.44	5.66	5.67	5.67	5.67	5.82	5.82	5.82	5.82	6.25	6.25	6.25	6.25	
740	18	S/T	0.73	0.83	0.92	1.00	0.59	0.67	0.76	0.85	0.52	0.60	0.69	0.77	0.36	0.44	0.52	0.59	
		PI	1.35	1.35	1.35	1.35	1.34	1.34	1.34	1.34	1.34	1.34	1.34	1.34	1.33	1.33	1.33	1.33	
		TC	4.99	4.99	5.04	5.10	5.30	5.30	5.30	5.30	5.47	5.47	5.47	5.47	5.87	5.87	5.87	5.87	
	25	S/T	0.75	0.85	0.94	1.00	0.59	0.69	0.78	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.61	
		PI	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	1.55	
		TC	4.76	4.76	4.81	4.87	5.07	5.07	5.13	5.22	5.22	5.22	5.22	5.22	5.62	5.62	5.62	5.62	
	30	S/T	0.76	0.86	0.96	1.00	0.60	0.69	0.79	0.89	0.52	0.62	0.71	0.81	0.35	0.44	0.53	0.61	
		PI	1.69	1.69	1.69	1.69	1.70	1.70	1.70	1.70	1.70	1.70	1.70	1.70	1.71	1.71	1.71	1.71	
		TC	4.53	4.53	4.59	4.64	4.81	4.81	4.87	4.96	4.96	5.04	4.96	5.36	5.36	5.36	5.36	5.36	
	35	S/T	0.77	0.88	0.99	1.00	0.60	0.71	0.81	0.91	0.53	0.63	0.72	0.83	0.35	0.44	0.53	0.62	
		PI	1.86	1.86	1.86	1.86	1.86	1.86	1.86	1.87	1.87	1.87	1.87	1.88	1.88	1.88	1.88	1.88	
		TC	4.13	4.15	4.19	4.22	4.39	4.39	4.39	4.43	4.54	4.54	4.57	4.54	4.90	4.90	4.90	4.90	
	40	S/T	0.80	0.92	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64	
		PI	2.12	2.12	2.12	2.13	2.13	2.13	2.13	2.13	2.13	2.13	2.13	2.15	2.15	2.15	2.15	2.15	
		TC	3.92	3.94	3.97	4.00	4.17	4.17	4.17	4.20	4.31	4.31	4.31	4.31	4.65	4.65	4.65	4.65	
	43	S/T	0.81	0.93	1.00	1.00	0.62	0.74	0.86	0.97	0.54	0.65	0.76	0.88	0.34	0.44	0.55	0.65	
		PI	2.28	2.28	2.28	2.28	2.29	2.29	2.29	2.29	2.29	2.29	2.29	2.29	2.31	2.31	2.31	2.31	
		TC	5.48	5.48	5.53	5.59	5.79	5.79	5.79	5.79	5.96	5.96	5.96	5.96	6.39	6.39	6.39	6.39	
830	18	S/T	0.75	0.86	0.95	1.00	0.60	0.69	0.79	0.88	0.52	0.61	0.71	0.80	0.35	0.44	0.52	0.61	
		PI	1.38	1.38	1.38	1.38	1.37	1.37	1.37	1.37	1.36	1.36	1.36	1.36	1.36	1.36	1.36	1.36	
		TC	5.10	5.10	5.16	5.22	5.42	5.42	5.42	5.48	5.59	5.59	5.59	5.59	6.02	6.02	6.02	6.02	
	25	S/T	0.77	0.88	0.98	1.00	0.60	0.71	0.81	0.91	0.53	0.62	0.72	0.82	0.35	0.44	0.53	0.62	
		PI	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	
		TC	4.87	4.93	4.99	5.05	5.19	5.19	5.19	5.25	5.33	5.33	5.33	5.33	5.76	5.76	5.76	5.76	
	30	S/T	0.78	0.89	1.00	1.00	0.61	0.72	0.82	0.93	0.53	0.63	0.74	0.84	0.34	0.44	0.54	0.63	
		PI	1.73	1.73	1.73	1.73	1.73	1.73	1.73	1.73	1.74	1.74	1.74	1.74	1.74	1.74	1.74	1.74	
		TC	4.62	4.67	4.73	4.79	4.93	4.93	4.93	4.99	5.07	5.07	5.16	5.07	5.48	5.48	5.48	5.48	
	35	S/T	0.80	0.92	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64	
		PI	1.90	1.90	1.90	1.90	1.90	1.90	1.90	1.90	1.91	1.91	1.91	1.91	1.91	1.91	1.91	1.91	
		TC	4.24	4.28	4.32	4.36	4.52	4.52	4.56	4.62	4.67	4.67	4.70	4.70	5.05	5.05	5.05	5.05	
	40	S/T	0.83	0.96	1.00	1.00	0.63	0.76	0.88	1.00	0.54	0.66	0.78	0.90	0.33	0.45	0.56	0.67	
		PI	2.17	2.17	2.17	2.17	2.18	2.18	2.18	2.18	2.18	2.18	2.18	2.19	2.19	2.19	2.19	2.19	
		TC	4.03	4.06	4.09	4.12	4.29	4.29	4.34	4.40	4.43	4.43	4.43	4.49	4.80	4.80	4.80	4.80	
	43	S/T	0.84	0.98	1.00	1.00	0.64	0.77	0.89	1.00	0.55	0.67	0.80	0.92	0.33	0.45	0.56	0.68	
		PI	2.33	2.33	2.33	2.33	2.34	2.34	2.34	2.34	2.34	2.34	2.34	2.36	2.36	2.36	2.36	2.36	
		TC	5.59	5.65	5.71	5.76	5.93	5.93	5.93	5.99	6.08	6.08	6.08	6.08	6.54	6.54	6.54	6.54	
1020	18	S/T	0.80	0.92	1.00	1.00	0.62	0.74	0.85	0.96	0.54	0.65	0.76	0.87	0.34	0.44	0.55	0.65	
		PI	1.41	1.41	1.41	1.41	1.40	1.40	1.40	1.40	1.39	1.39	1.39	1.39	1.38	1.38	1.38	1.38	
		TC	5.22	5.28	5.33	5.39	5.56	5.56	5.56	5.62	5.73	5.73	5.73	5.79	6.16	6.16	6.16	6.16	
	25	S/T	0.83	0.95	1.00	1.00	0.63	0.75	0.88	1.00	0.54	0.66	0.78	0.89	0.33	0.45	0.56	0.67	
		PI	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	1.62	
		TC	4.99	5.05	5.10	5.16	5.30	5.30	5.36	5.42	5.45	5.45	5.45	5.45	5.88	5.88	5.88	5.88	
	30	S/T	0.84	0.97	1.00	1.00	0.64	0.77	0.89	1.00	0.55	0.67	0.80	0.92	0.33	0.45	0.56	0.68	
		PI	1.77	1.77	1.77	1.77	1.77	1.77	1.77	1.77	1.77	1.77	1.77	1.78	1.78	1.78	1.78	1.78	
		TC	4.73	4.79	4.85	4.90	5.05	5.05	5.10	5.16	5.19	5.19	5.28	5.33	5.59	5.59	5.59	5.59	
	35	S/T	0.86	1.00	1.00	1.00	0.65	0.79	0.92	1.00	0.55	0.68	0.81	0.93	0.33	0.45	0.57	0.70	
		PI	1.94	1.94	1.94	1.94	1.94	1.94	1.94	1.94	1.95	1.95	1.95	1.95	1.96	1.96	1.96	1.96	
		TC	4.34	4.38	4.42	4.46	4.64	4.64	4.69	4.75	4.78	4.78	4.81	4.87	5.16	5.16	5.16	5.16	
	40	S/T	0.90	1.00	1.00	1.00	0.67	0.82	0.96	1.00	0.57	0.71	0.85	0.99	0.32	0.46	0.59	0.90	
		PI	2.21	2.21	2.21	2.21	2.22	2.22	2.22	2.22	2.22	2.22	2.22	2.24	2.24	2.24	2.24	2.24	
		TC	4.12	4.14	4.17	4.20	4.40	4.40	4.46	4.52	4.54	4.54	4.54	4.60	4.92	4.92	4.92	4.92	
	43	S/T	0.92	1.00	1.00	1.00	0.68	0.84	0.98	1.00	0.57	0.72	0.87	1.00	0.32	0.46	0.60	0.92	
		PI	2.38	2.38	2.38	2.38	2.39	2.39	2.39	2.39	2.39	2.39	2.39	2.39	2.41	2.41	2.41	2.41	
		TC	5.59	5.65	5.71	5.76	5.93	5.93	5.93	5.99	6.08	6.08	6.08	6.08	6.54	6.54	6.54	6.54	

TC:Total Cooling Capacity (kW)
S/T:Sensible Cooling Capacity Ratio
PI:Power Input(kW)

INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	24k															
			16.0				18.0				19.0				22.0			
			ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0
950	18	TC	7.14	7.15	7.20	7.29	7.57	7.58	7.58	7.58	7.78	7.78	7.78	7.78	8.35	8.35	8.35	8.35
		S/T	0.73	0.81	0.90	0.98	0.58	0.67	0.75	0.83	0.52	0.60	0.68	0.76	0.36	0.44	0.51	0.59
		PI	1.88	1.87	1.87	1.88	1.86	1.86	1.86	1.86	1.86	1.86	1.86	1.86	1.85	1.85	1.85	1.85
	25	TC	6.69	6.69	6.74	6.80	7.09	7.09	7.09	7.09	7.32	7.32	7.32	7.32	7.86	7.86	7.86	7.86
		S/T	0.74	0.83	0.93	1.00	0.59	0.68	0.77	0.86	0.52	0.60	0.69	0.78	0.36	0.44	0.52	0.60
		PI	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16
	30	TC	6.37	6.37	6.43	6.49	6.77	6.77	6.77	6.77	6.97	6.97	6.97	6.97	7.52	7.52	7.52	7.52
		S/T	0.75	0.85	0.95	1.00	0.59	0.69	0.78	0.88	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.61
		PI	2.37	2.37	2.37	2.37	2.37	2.37	2.37	2.37	2.37	2.37	2.37	2.37	2.38	2.38	2.38	2.38
	35	TC	6.06	6.06	6.11	6.17	6.43	6.43	6.43	6.49	6.63	6.63	6.74	6.63	7.17	7.17	7.17	7.17
		S/T	0.76	0.87	0.97	1.00	0.60	0.70	0.80	0.89	0.52	0.62	0.71	0.81	0.35	0.44	0.53	0.61
		PI	2.58	2.58	2.58	2.58	2.59	2.59	2.59	2.59	2.60	2.60	2.60	2.61	2.61	2.61	2.61	2.61
	40	TC	5.53	5.56	5.62	5.68	5.88	5.88	5.88	5.94	6.08	6.08	6.12	6.08	6.57	6.57	6.57	6.57
		S/T	0.79	0.90	1.00	1.00	0.61	0.72	0.83	0.93	0.53	0.63	0.74	0.85	0.34	0.44	0.54	0.63
		PI	2.95	2.95	2.95	2.96	2.96	2.96	2.96	2.97	2.97	2.97	2.97	2.99	2.99	2.99	2.99	2.99
	43	TC	5.24	5.29	5.35	5.41	5.58	5.58	5.58	5.64	5.78	5.78	5.78	5.78	6.23	6.23	6.23	6.23
		S/T	0.80	0.92	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64
		PI	3.17	3.17	3.17	3.17	3.18	3.18	3.18	3.18	3.19	3.19	3.19	3.19	3.22	3.22	3.22	3.22
1150	18	TC	7.29	7.29	7.38	7.46	7.72	7.72	7.72	7.81	7.95	7.95	7.95	7.95	8.56	8.56	8.56	8.56
		S/T	0.76	0.87	0.97	1.00	0.60	0.70	0.80	0.90	0.52	0.62	0.72	0.81	0.35	0.44	0.53	0.62
		PI	1.91	1.91	1.91	1.91	1.90	1.90	1.90	1.90	1.89	1.89	1.89	1.89	1.89	1.89	1.89	1.89
	25	TC	6.83	6.89	6.95	7.01	7.26	7.26	7.26	7.35	7.46	7.46	7.46	7.46	8.04	8.04	8.04	8.04
		S/T	0.78	0.89	1.00	1.00	0.61	0.71	0.82	0.92	0.53	0.63	0.73	0.84	0.34	0.44	0.54	0.63
		PI	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20	2.20
	30	TC	6.52	6.57	6.63	6.69	6.92	6.92	6.92	6.98	7.12	7.12	7.12	7.12	7.69	7.69	7.69	7.69
		S/T	0.79	0.91	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64
		PI	2.41	2.41	2.41	2.41	2.42	2.42	2.42	2.42	2.42	2.42	2.42	2.43	2.43	2.43	2.43	2.43
	35	TC	6.17	6.23	6.29	6.34	6.57	6.57	6.57	6.63	6.78	6.78	6.89	6.78	7.32	7.32	7.32	7.32
		S/T	0.81	0.93	1.00	1.00	0.62	0.74	0.86	0.97	0.54	0.65	0.76	0.88	0.34	0.44	0.55	0.65
		PI	2.63	2.63	2.63	2.63	2.64	2.64	2.64	2.64	2.65	2.65	2.65	2.65	2.65	2.65	2.65	2.65
	40	TC	5.70	5.76	5.81	5.87	6.06	6.06	6.10	6.16	6.27	6.27	6.31	6.30	6.78	6.78	6.78	6.78
		S/T	0.84	0.98	1.00	1.00	0.64	0.77	0.89	1.00	0.55	0.67	0.80	0.92	0.33	0.45	0.56	0.68
		PI	3.00	3.00	3.00	3.01	3.01	3.01	3.01	3.02	3.02	3.02	3.02	3.04	3.04	3.04	3.04	3.04
	43	TC	5.41	5.46	5.52	5.58	5.75	5.75	5.81	5.87	5.95	5.95	5.95	5.95	6.44	6.44	6.44	6.44
		S/T	0.86	1.00	1.00	1.00	0.65	0.78	0.91	1.00	0.55	0.68	0.81	0.94	0.33	0.45	0.57	0.69
		PI	3.22	3.22	3.22	3.24	3.24	3.24	3.24	3.24	3.24	3.24	3.24	3.27	3.27	3.27	3.27	3.27
1350	18	TC	7.44	7.52	7.61	7.69	7.90	7.90	7.90	7.98	8.12	8.12	8.12	8.12	8.73	8.73	8.73	8.73
		S/T	0.80	0.92	1.00	1.00	0.62	0.73	0.85	0.96	0.53	0.65	0.76	0.87	0.34	0.44	0.55	0.65
		PI	1.95	1.95	1.95	1.95	1.93	1.93	1.93	1.93	1.93	1.93	1.93	1.93	1.91	1.91	1.91	1.91
	25	TC	6.98	7.03	7.09	7.15	7.41	7.41	7.41	7.49	7.64	7.64	7.64	7.72	8.21	8.21	8.21	8.21
		S/T	0.82	0.95	1.00	1.00	0.63	0.75	0.88	0.99	0.54	0.66	0.78	0.89	0.34	0.45	0.56	0.67
		PI	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24	2.24
	30	TC	6.63	6.69	6.75	6.80	7.06	7.06	7.12	7.18	7.29	7.29	7.29	7.29	7.84	7.84	7.84	7.84
		S/T	0.84	0.97	1.00	1.00	0.64	0.77	0.89	1.00	0.55	0.67	0.79	0.91	0.33	0.45	0.56	0.68
		PI	2.45	2.45	2.45	2.45	2.45	2.45	2.45	2.45	2.46	2.46	2.46	2.47	2.47	2.47	2.47	2.47
	35	TC	6.32	6.37	6.43	6.49	6.72	6.72	6.78	6.83	6.92	6.92	7.03	7.09	7.46	7.46	7.46	7.46
		S/T	0.86	1.00	1.00	1.00	0.65	0.78	0.92	1.00	0.55	0.68	0.81	0.93	0.33	0.45	0.57	0.69
		PI	2.68	2.68	2.68	2.69	2.69	2.69	2.69	2.69	2.70	2.70	2.70	2.71	2.71	2.71	2.71	2.71
	40	TC	5.82	5.88	5.94	6.00	6.21	6.21	6.27	6.32	6.39	6.39	6.43	6.49	6.92	6.92	6.92	6.92
		S/T	0.90	1.00	1.00	1.00	0.67	0.82	0.96	1.00	0.56	0.71	0.85	0.99	0.32	0.46	0.59	0.90
		PI	3.05	3.05	3.05	3.05	3.07	3.07	3.07	3.07	3.08	3.08	3.08	3.09	3.09	3.09	3.09	3.09
	43	TC	5.52	5.58	5.64	5.69	5.90	5.90	5.95	6.01	6.07	6.07	6.13	6.59	6.59	6.59	6.59	6.59
		S/T	0.92	1.00	1.00	1.00	0.68	0.83	0.98	1.00	0.57	0.72	0.87	1.00	0.32	0.46	0.60	0.92
		PI	3.28	3.28	3.28	3.28	3.30	3.30	3.30	3.30	3.31	3.31	3.31	3.33	3.33	3.33	3.33	3.33

TC:Total Cooling Capacity (kW)

S/T:Sensible Cooling Capacity Ratio

PI:Power Input(kW)


7.2 Heating

18k								[SI_Unit]	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	HEATING PERFORMANCE AT INDOOR DRY BULB TEMPERATURE							
		TC:TOTAL CAPACITY IN KILOWATTS				PI: TOTAL POWER IN KILOWATTS			
		Indoor Conditions (DB C)				Indoor Conditions (DB C)			
		16.0	20.0	22.0	24.0	16.0	20.0	22.0	24.0
740	-7.0	3.61	3.56	3.53	3.53	1.09	1.12	1.17	1.20
	-5.6	3.82	3.76	3.73	3.73	1.13	1.18	1.21	1.23
	-2.8	4.02	3.96	3.94	3.91	1.20	1.25	1.28	1.31
	0.0	4.17	4.11	4.08	4.05	1.27	1.33	1.36	1.39
	2.8	4.49	4.43	4.40	4.34	1.35	1.42	1.45	1.48
	5.6	4.95	4.89	4.86	4.80	1.44	1.50	1.53	1.57
	7.0	5.46	5.39	5.22	5.19	1.48	1.61	1.59	1.62
	11.1	5.80	5.71	5.68	5.66	1.60	1.67	1.71	1.75
	13.9	6.12	6.03	5.97	5.95	1.67	1.75	1.79	1.83
	16.7	6.41	6.32	6.29	6.24	1.75	1.84	1.88	1.92
830	18.0	6.55	6.47	6.44	6.38	1.79	1.88	1.92	1.96
	-7.0	3.66	3.63	3.60	3.57	1.10	1.13	1.18	1.21
	-5.6	3.88	3.85	3.82	3.79	1.13	1.19	1.22	1.25
	-2.8	4.11	4.05	4.02	3.99	1.21	1.27	1.30	1.33
	0.0	4.25	4.20	4.17	4.14	1.28	1.34	1.37	1.41
	2.8	4.57	4.51	4.49	4.46	1.37	1.43	1.47	1.49
	5.6	5.06	4.98	4.95	4.92	1.46	1.52	1.55	1.59
	7.0	5.61	5.51	5.34	5.31	1.50	1.63	1.61	1.64
	11.1	5.92	5.86	5.80	5.77	1.62	1.69	1.73	1.77
	13.9	6.24	6.15	6.12	6.06	1.70	1.78	1.82	1.86
1020	16.7	6.55	6.47	6.44	6.38	1.78	1.86	1.90	1.95
	18.0	6.70	6.61	6.58	6.53	1.81	1.90	1.95	1.99
	-7.0	3.73	3.68	3.68	3.65	1.11	1.14	1.19	1.22
	-5.6	3.94	3.88	3.88	3.85	1.15	1.20	1.23	1.26
	-2.8	4.14	4.08	4.08	4.05	1.22	1.28	1.31	1.34
	0.0	4.31	4.25	4.23	4.20	1.29	1.36	1.39	1.42
	2.8	4.63	4.57	4.51	4.49	1.38	1.45	1.49	1.51
	5.6	5.12	5.04	5.01	4.98	1.47	1.54	1.57	1.61
	7.0	5.66	5.57	5.39	5.37	1.51	1.65	1.62	1.66
	11.1	5.97	5.92	5.86	5.83	1.64	1.71	1.75	1.79

24k								[SI_Unit]	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	HEATING PERFORMANCE AT INDOOR DRY BULB TEMPERATURE							
		TC:TOTAL CAPACITY IN KILOWATTS				PI: TOTAL POWER IN KILOWATTS			
		Indoor Conditions (DB C)				Indoor Conditions (DB C)			
		16.0	20.0	22.0	24.0	16.0	20.0	22.0	24.0
950	-7.0	4.94	4.88	4.86	4.83	1.47	1.51	1.58	1.62
	-5.6	5.23	5.17	5.15	5.12	1.52	1.59	1.63	1.67
	-2.8	5.52	5.44	5.41	5.38	1.62	1.70	1.74	1.78
	0.0	5.73	5.64	5.61	5.58	1.71	1.80	1.84	1.88
	2.8	6.16	6.08	6.05	5.99	1.83	1.92	1.97	2.01
	5.6	6.80	6.72	6.69	6.63	1.95	2.04	2.09	2.13
	7.0	7.48	7.39	7.16	7.13	2.01	2.18	2.16	2.20
	11.1	7.94	7.85	7.79	7.74	2.17	2.27	2.32	2.37
	13.9	8.37	8.26	8.20	8.14	2.27	2.38	2.43	2.49
	16.7	8.81	8.69	8.63	8.58	2.38	2.49	2.55	2.61
1150	18.0	9.01	8.90	8.84	8.75	2.43	2.55	2.61	2.67
	-7.0	5.04	4.99	4.96	4.93	1.49	1.53	1.60	1.64
	-5.6	5.35	5.29	5.26	5.23	1.54	1.61	1.65	1.69
	-2.8	5.64	5.55	5.52	5.49	1.63	1.71	1.75	1.79
	0.0	5.84	5.76	5.73	5.70	1.73	1.82	1.86	1.90
	2.8	6.28	6.19	6.16	6.10	1.85	1.94	1.99	2.03
	5.6	6.95	6.86	6.80	6.77	1.97	2.06	2.10	2.15
	7.0	7.63	7.53	7.30	7.27	2.03	2.20	2.17	2.22
	11.1	8.08	8.00	7.94	7.88	2.18	2.29	2.34	2.39
	13.9	8.52	8.43	8.37	8.32	2.29	2.40	2.46	2.51
1350	16.7	8.98	8.84	8.78	8.72	2.40	2.51	2.57	2.63
	18.0	9.18	9.04	8.98	8.92	2.45	2.57	2.63	2.69
	-7.0	5.11	5.03	5.00	4.97	1.50	1.54	1.61	1.65
	-5.6	5.41	5.32	5.29	5.26	1.55	1.62	1.66	1.70
	-2.8	5.70	5.61	5.58	5.55	1.65	1.73	1.77	1.81
	0.0	5.90	5.81	5.79	5.76	1.75	1.83	1.88	1.92
	2.8	6.34	6.25	6.22	6.16	1.87	1.96	2.00	2.04
	5.6	7.04	6.92	6.89	6.83	1.99	2.08	2.12	2.17
	7.0	7.75	7.62	7.39	7.33	2.05	2.22	2.19	2.24
	11.1	8.20	8.08	8.03	7.97	2.20	2.31	2.36	2.41
	13.9	8.63	8.52	8.46	8.40	2.31	2.42	2.48	2.53
	16.7	9.07	8.95	8.90	8.84	2.42	2.54	2.60	2.65
	18.0	9.30	9.16	9.10	9.04	2.47	2.59	2.65	2.71


8. Noise Criterion Curves

8.1 Indoor Unit



Notes:

- Sound measured at 1.5m away from the center of the unit.
- Data is valid at free field condition
- Data is valid at nominal operation condition
- Reference acoustic pressure OdB = 20µPa
- Sound level will vary depending on a range of factors such as the construction -(acoustic absorption coefficient) of particular room in which the equipment is installed.
- The operating conditions are assumed to be standard.



9. Electrical Characteristics


Capacity (Btu/h)		12k	18k	24k
INDOOR UNIT POWER	Phase	1-phase	1-phase	1-phase
	Frequency and Voltage	220-240V, 50Hz	220-240V, 50Hz	220-240V, 50Hz
	Power Wiring (mm ²)	3×1.5	3×2.5	3×2.5
	Circuit Breaker/ Fuse (A)	25/20	25/20	32/25
Indoor/Outdoor Connecting Wiring	Weak Electric Signal) (mm ²)		2x0.5	2x0.5
	Strong Electric Signal(mm ²)	3×1.5	3×2.5/2×1.0	3×2.5/3×1.0

10. Electrical Wiring Diagrams


IDU Capacity (Btu/h)	IDU Wiring Diagram
12k	16023000010446
18k	16023000011786
24k	16023000006721

Abbreviation	Paraphrase
Y/G	Yellow-Green Conductor
CAP	Indoor Fan Capacitor
AC FAN	Alternating Current Fan
DC FAN	Direct Current FAN
PUMP	PUMP
L	LIVE
N	NEUTRAL
TO CCM Comm.Bus	Central Controller
T1	Indoor Room Temperature
T2	Coil Temperature of Indoor Heat Exchanger
P1	Super High Speed
P2	High Speed


Indoor unit wiring diagram: 16023000010446




Indoor unit wiring diagram: 16023000011786



Indoor unit wiring diagram: 16023000006721





10.1 Some connectors introduce:



A. For new fresh motor terminal port (also for Anion generator) CN43:


1. Connect the fan motor to the port, no need care L/N of the motor;
2. The output voltage is the power supply;
3. The new fresh motor can not excess 200W or 1A, follow the smaller one;
4. The new fresh motor will be worked when the indoor fan motor work ;when the indoor fan motor stops , the new fresh motor would be stopped;
5. When the unit enters force cooling mode or capacity testing mode , the fresh motor isn't work.






B For ALARM terminal port CN33


1. Provide the terminal port to connect ALARM, but no voltage of the terminal port, the power from the ALARM system (not from the unit);
2. Although design voltage can support higher voltage, but we strongly ask you connect the power less than 24V, current less than 0.5A;
3. When the unit occurs the problem, the relay would be closed, then ALARM works.





C. For remote control (ON-OFF) terminal port CN23 and short connector of J7

1. Remove the short connector of J7 when you use ON-OFF function;
 2. When remote switch off (OPEN); the unit would be off;
 3. When remote switch on (CLOSE); the unit would be on;
 4. When close/open the remote switch, the unit would be responded the demand within 2 seconds;
 5. When the remote switch on, you can use remote controller/ wire controller to select the mode what you want; when the remote switch off, the unit would not respond the demand from remote controller/wire controller.
- when the remote switch off, but the remote controller/wire controller are on, CP code would be shown on the display board.
6. The voltage of the port is 12V DC, design Max. current is 5mA.



10.2 Micro-Switch Introduce:



FOR SETTING AUTO-RESTART		
SW3	ON 1	ON 1
MODE	AUTO-RESTART	NOT AUTO-RESTART
FACTORY SETTING	✓	

A. Micro-switch SW3 is for selection of auto-restart function.

Range: Active, inactive



FOR TEMP. COMPENSATION(HEATING)				
SW6	ON 1 2	ON 1 2	ON 1 2	ON 1 2
CODE	4°C	1°C	6°C	EEPROM DEFAULT
FACTORY SETTING	✓			

B. Micro-switch SW6 is for selection of temperature compensation in heating mode. This helps to reduce the real temperature difference between ceiling and floor so that the unit could run properly. If the height of installation is lower, smaller value could be chosen.

Range: 6°C, 4°C, 1°C, E function (reserved for special customizing)




FOR SETTING POWER(DC MOTOR MODEL ONLY)								
ENC1	CODE	3	4	5	7	8	C	9
CODE	3	4	5	7	8	C	9	A
POWER	≤ 35	36~53	54~71	72~90	91~105	106~120	121~140	141~160
FACTORY SETTING	ACCORDING TO RELATED MODEL.							

C. Dial-switch ENC1: The indoor PCB is universal designed for whole series units from 12K to 55K. This ENC1 setting will tell the main program what size the unit is.

NOTE: Usually there is glue on it because the switch position cannot be changed at random unless you want to use this PCB as a spare part to use in another unit. Then you have to select the right position to match the size of the unit.

"35" means 3.5kW (12K), "105" means 10.5kW(36K), and so on.



FOR SETTING NETADDRESS								
S1+S2	CODE	0~F	CODE	0~F	CODE	0~F	CODE	0~F
NETADDRESS	0~15	16~31	FACTORY SETTING	32~47	48~63	FACTORY SETTING	48~63	FACTORY SETTING
FACTORY SETTING	✓							

D. Micro-switch S1 and dial-switch S2 are for address setting when you want to control this unit by a central controller.

Range: 00-63

Indoor Unit-Compact Cassette

Contents

1.	Feature.....	2
2.	Dimensional Drawings	4
3.	Part names	5
4.	Service Place.....	6
5.	Accessories	7
6.	Air Velocity and Temperature Distributions	8
7.	Capacity Tables	16
8.	Noise Criterion Curves.....	20
9.	Electrical Characteristics.....	21
10.	Electrical Wiring Diagrams.....	21

1. Feature

1.1 Compact design

- The body size is 570×260×570mm, it's just smaller than the ceiling board, so it's very easy for installation and will not damage the decoration. The panel size is 647×50×647mm.
- The hooks are designed in the four corners of the body, which can save installation space.

1.2 Fire-proof Controller Box

- Electrical control box adopts new design which can meet higher fire safety requirements.


1.3 Reserved remote on-off and alarm ports(Optional for fixed-speed units, standard for inverter units)

- Remote on-off: With the reserved ports, a remote switch can be easily connected to realize remote control.
- Alarm: The built-in PCB can output alarm signal, which achieve setting up an external alarm light or vibration gauge possible.




1.4 Build-in Drain Pump

- The drain pump can lift the condensed water up to 750mm.
- It's convenient to install drainage piping under most space condition.



1.5 Fresh Air

- Fresh air intake function brings you fresh and comfortable air feeling.




1.6 Wired Controller(Optional)

- Compared with infrared remote controller, wired controller can be fixed on the wall and avoid mislaying. It's mainly used for commercial zone and makes air conditioner control more convenient.


1.7 Louver Position Memory (Standard for ERP models)

- When you start the unit next time, the angle of horizontal louver will automatically move to the same position as you set last time.




■ Previous Air-Flow Angle


2. Dimensional Drawings



3. Part names









4. Service Place



5. Accessories

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or equipment failure.

	Name	Shape	Quantity
Indoor unit installation	Installation paper template (some models)		1
Refrigeration Fittings	Insulation for gas pipe fitting (some models)		1
	Insulation for liquid pipe fitting (some models)		1
Drainpipe Fittings	Outlet pipe sheath(some models)		1
	Outlet pipe clasp(some models)		1
	Drain joint (some models)		1
	Seal ring (some models)		1
EMC Magnetic Ring (some models)	Magnetic ring (wrap the electric wires S1 & S2 (P & Q & E) around the magnetic ring twice)		1
	Magnetic ring (Hitch it on the connective cable between indoor unit and outdoor unit after installation.)		1
Installation Accessory (some models)	Ceiling hook		4
	Suspension bolt		4
	Throttle (some units)		1
	Anti-shock rubber		1
	Owner's manual&Installation manual		1

Optional accessories:


- There are two types of remote controls: wired and wireless.
- Select a remote controller based on customer preferences and requirements and install in an appropriate place.
- Refer to catalogues and technical literature for guidance on selecting a suitable remote controller.

6. Air Velocity and Temperature Distributions


12K

Discharge Angle 30°


Cooling airflow velocity distributions




Cooling temperature distributions



Heating airflow velocity distributions




Heating temperature distributions




Discharge Angle 60°


Cooling airflow velocity distributions




Cooling temperature distributions



Heating airflow velocity distributions




Heating temperature distributions




18K

Discharge Angle 30°


Cooling airflow velocity distributions




Cooling temperature distributions



Heating airflow velocity distributions




Heating temperature distributions




Discharge Angle 60°


Cooling airflow velocity distributions




Cooling temperature distributions



Heating airflow velocity distributions



Heating temperature distributions



7. Capacity Tables

7.1 Cooling

		12k																	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	16.0				18.0				19.0				22.0				
		ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	
388	18	TC	3.60	3.60	3.60	3.63	3.82	3.80	3.80	3.80	3.92	3.92	3.92	3.92	4.21	4.21	4.21	4.21	
		S/T	0.69	0.77	0.84	0.91	0.57	0.64	0.71	0.78	0.51	0.58	0.65	0.71	0.38	0.44	0.50	0.56	
		PI	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.75	0.74	0.74	0.74	0.74	
	25	TC	3.37	3.37	3.37	3.40	3.57	3.57	3.57	3.57	3.69	3.69	3.69	3.69	3.98	3.98	3.98	3.98	
		S/T	0.70	0.78	0.86	0.93	0.57	0.65	0.72	0.79	0.51	0.58	0.65	0.72	0.37	0.44	0.50	0.57	
	30	PI	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	0.87	
		TC	3.20	3.20	3.20	3.23	3.43	3.43	3.43	3.43	3.52	3.52	3.52	3.52	3.80	3.80	3.80	3.80	
		S/T	0.71	0.79	0.87	0.95	0.58	0.65	0.73	0.80	0.51	0.59	0.66	0.74	0.37	0.44	0.51	0.57	
477	35	PI	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.95	0.96	0.96	0.96	0.96	
		TC	3.05	3.05	3.08	3.11	3.26	3.26	3.26	3.26	3.34	3.34	3.34	3.34	3.60	3.60	3.60	3.60	
		S/T	0.72	0.80	0.89	0.97	0.58	0.66	0.74	0.82	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.58	
	40	PI	1.04	1.04	1.04	1.04	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.06	1.06	1.06	1.06	
		TC	2.82	2.82	2.85	2.88	3.03	3.03	3.03	3.03	3.11	3.11	3.11	3.11	3.36	3.36	3.36	3.36	
		S/T	0.74	0.83	0.92	1.00	0.59	0.67	0.76	0.85	0.52	0.60	0.69	0.77	0.36	0.44	0.51	0.59	
	43	PI	1.18	1.18	1.18	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.20	1.20	1.20	1.20	
		TC	2.67	2.67	2.70	2.73	2.87	2.87	2.87	2.87	2.96	2.96	2.96	2.96	3.19	3.19	3.19	3.19	
		S/T	0.75	0.85	0.94	1.00	0.59	0.68	0.77	0.86	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60	
612	18	PI	1.27	1.27	1.27	1.28	1.28	1.28	1.28	1.28	1.28	1.28	1.28	1.28	1.29	1.29	1.29	1.29	
		TC	3.66	3.66	3.69	3.72	3.89	3.89	3.89	3.89	4.01	4.01	4.01	4.01	4.30	4.30	4.30	4.30	
		S/T	0.72	0.81	0.90	0.98	0.58	0.66	0.75	0.83	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.59	
	25	PI	0.77	0.77	0.77	0.77	0.77	0.77	0.77	0.77	0.76	0.76	0.76	0.76	0.76	0.76	0.76	0.76	
		TC	3.43	3.43	3.46	3.49	3.63	3.63	3.63	3.63	3.75	3.75	3.75	3.75	4.04	4.04	4.04	4.04	
		S/T	0.74	0.83	0.92	1.00	0.59	0.67	0.76	0.85	0.52	0.60	0.69	0.77	0.36	0.44	0.52	0.60	
	30	PI	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	0.89	
		TC	3.26	3.26	3.29	3.32	3.49	3.49	3.49	3.49	3.57	3.57	3.57	3.57	3.86	3.86	3.86	3.86	
		S/T	0.75	0.85	0.94	1.00	0.59	0.68	0.77	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60	
	35	PI	0.97	0.97	0.97	0.97	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	
		TC	3.11	3.11	3.14	3.17	3.32	3.32	3.32	3.34	3.40	3.40	3.40	3.40	3.66	3.66	3.66	3.66	
		S/T	0.76	0.86	0.96	1.00	0.60	0.69	0.79	0.88	0.52	0.62	0.71	0.81	0.35	0.44	0.52	0.61	
	40	PI	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	1.07	
		TC	2.83	2.84	2.87	2.90	3.01	3.01	3.01	3.04	3.09	3.09	3.11	3.09	3.35	3.35	3.35	3.35	
		S/T	0.78	0.89	1.00	1.00	0.61	0.72	0.82	0.93	0.53	0.63	0.73	0.84	0.34	0.44	0.53	0.63	
	43	PI	1.21	1.21	1.21	1.21	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.22	1.23	1.23	1.23	1.23	
		TC	2.68	2.71	2.73	2.76	2.85	2.85	2.85	2.88	2.93	2.93	2.93	2.93	3.19	3.19	3.19	3.19	
		S/T	0.80	0.91	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64	
	18	PI	1.30	1.30	1.30	1.31	1.31	1.31	1.31	1.31	1.31	1.31	1.31	1.31	1.33	1.33	1.33	1.33	
		TC	3.72	3.75	3.78	3.81	3.95	3.95	3.95	3.98	4.06	4.06	4.06	4.06	4.35	4.35	4.35	4.35	
		S/T	0.78	0.88	0.99	1.00	0.61	0.71	0.81	0.92	0.53	0.63	0.73	0.83	0.34	0.44	0.53	0.63	
	25	PI	0.79	0.79	0.79	0.79	0.79	0.79	0.79	0.79	0.78	0.78	0.78	0.78	0.78	0.78	0.78	0.78	
		TC	3.49	3.52	3.55	3.57	3.69	3.69	3.69	3.72	3.81	3.81	3.81	3.81	4.09	4.09	4.09	4.09	
		S/T	0.79	0.91	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64	
	30	PI	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	0.91	
		TC	3.32	3.34	3.37	3.40	3.55	3.55	3.55	3.57	3.63	3.63	3.63	3.63	3.92	3.92	3.92	3.92	
		S/T	0.81	0.93	1.00	1.00	0.62	0.74	0.85	0.97	0.54	0.65	0.76	0.88	0.34	0.44	0.55	0.65	
	35	PI	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	
		TC	3.14	3.17	3.20	3.23	3.37	3.37	3.37	3.40	3.46	3.46	3.46	3.46	3.75	3.75	3.75	3.75	
		S/T	0.83	0.95	1.00	1.00	0.63	0.75	0.88	0.99	0.54	0.66	0.77	0.89	0.34	0.45	0.56	0.67	
	40	PI	1.09	1.09	1.09	1.09	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	
		TC	2.86	2.88	2.91	2.94	3.07	3.07	3.08	3.11	3.15	3.15	3.17	3.20	3.42	3.42	3.42	3.42	
		S/T	0.86	1.00	1.00	1.00	0.65	0.78	0.92	1.00	0.55	0.68	0.81	0.94	0.33	0.45	0.57	0.90	
	43	PI	1.24	1.24	1.24	1.24	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.26	1.26	1.26	1.26	
		TC	2.71	2.73	2.76	2.79	2.90	2.90	2.93	2.96	2.99	2.99	2.99	2.99	3.02	3.25	3.25	3.25	
		S/T	0.88	1.00	1.00	1.00	0.66	0.80	0.93	1.00	0.56	0.69	0.83	0.96	0.33	0.45	0.58	0.92	
	18	PI	1.33	1.33	1.33	1.33	1.34	1.34	1.34	1.34	1.34	1.34	1.34	1.34	1.36	1.36	1.36	1.36	

TC:Total Cooling Capacity (kW)

S/T:Sensible Cooling Capacity Ratio

PI:Power Input(kW)

18k																		
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	16.0				18.0				19.0				22.0			
		ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0
		TC	5.34	5.33	5.33	5.33	5.66	5.67	5.67	5.67	5.82	5.82	5.82	5.82	6.25	6.25	6.25	6.25
470	18	S/T	0.68	0.74	0.79	0.85	0.57	0.63	0.68	0.74	0.52	0.57	0.63	0.68	0.40	0.45	0.50	0.55
		PI	1.33	1.33	1.33	1.33	1.32	1.32	1.32	1.31	1.31	1.31	1.31	1.31	1.31	1.31	1.31	1.31
		TC	4.99	4.99	4.99	4.99	5.30	5.30	5.30	5.30	5.47	5.47	5.47	5.47	5.87	5.87	5.87	5.87
	25	S/T	0.68	0.74	0.81	0.87	0.57	0.63	0.69	0.75	0.51	0.57	0.63	0.69	0.39	0.45	0.50	0.55
		PI	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53	1.53
		TC	4.76	4.76	4.76	4.76	5.07	5.07	5.07	5.07	5.22	5.22	5.22	5.22	5.62	5.62	5.62	5.62
	30	S/T	0.68	0.75	0.82	0.88	0.57	0.63	0.69	0.75	0.51	0.57	0.63	0.69	0.39	0.44	0.50	0.56
		PI	1.67	1.67	1.67	1.67	1.67	1.67	1.67	1.67	1.67	1.67	1.67	1.67	1.68	1.68	1.68	1.68
		TC	4.53	4.53	4.53	4.59	4.81	4.81	4.81	4.81	4.96	4.96	4.96	4.96	5.36	5.36	5.36	5.36
	35	S/T	0.69	0.76	0.83	0.89	0.57	0.63	0.70	0.76	0.51	0.58	0.64	0.70	0.38	0.44	0.50	0.56
		PI	1.83	1.83	1.83	1.83	1.83	1.83	1.83	1.83	1.84	1.84	1.84	1.84	1.85	1.85	1.85	1.85
		TC	4.18	4.18	4.18	4.22	4.45	4.45	4.45	4.45	4.59	4.59	4.59	4.59	4.96	4.96	4.96	4.96
	40	S/T	0.70	0.78	0.85	0.93	0.57	0.64	0.72	0.79	0.51	0.58	0.65	0.72	0.37	0.44	0.50	0.57
		PI	2.09	2.09	2.09	2.09	2.09	2.09	2.09	2.10	2.10	2.10	2.10	2.10	2.12	2.12	2.12	2.12
		TC	3.97	3.97	3.97	4.00	4.22	4.22	4.22	4.22	4.37	4.37	4.37	4.37	4.71	4.71	4.71	4.71
	43	S/T	0.71	0.79	0.87	0.94	0.57	0.65	0.72	0.80	0.51	0.58	0.66	0.73	0.37	0.44	0.50	0.57
		PI	2.24	2.24	2.24	2.24	2.25	2.25	2.25	2.25	2.26	2.26	2.26	2.26	2.28	2.28	2.28	2.28
		TC	5.48	5.48	5.48	5.53	5.79	5.79	5.79	5.79	5.96	5.96	5.96	5.96	6.39	6.39	6.39	6.39
570	18	S/T	0.69	0.76	0.83	0.90	0.57	0.63	0.70	0.77	0.51	0.58	0.64	0.70	0.38	0.44	0.50	0.56
		PI	1.36	1.36	1.36	1.36	1.35	1.35	1.35	1.35	1.34	1.34	1.34	1.34	1.33	1.33	1.33	1.33
		TC	5.10	5.10	5.10	5.16	5.42	5.42	5.42	5.42	5.59	5.59	5.59	5.59	6.02	6.02	6.02	6.02
	25	S/T	0.70	0.77	0.85	0.92	0.57	0.64	0.71	0.78	0.51	0.58	0.65	0.72	0.38	0.44	0.50	0.57
		PI	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56	1.56
		TC	4.87	4.87	4.87	4.93	5.19	5.19	5.19	5.19	5.33	5.33	5.33	5.33	5.76	5.76	5.76	5.76
	30	S/T	0.70	0.78	0.86	0.93	0.57	0.65	0.72	0.79	0.51	0.58	0.66	0.73	0.37	0.44	0.50	0.57
		PI	1.70	1.70	1.70	1.70	1.71	1.71	1.71	1.71	1.71	1.71	1.71	1.71	1.72	1.72	1.72	1.72
		TC	4.62	4.62	4.62	4.67	4.93	4.93	4.93	4.93	5.07	5.07	5.07	5.07	5.48	5.48	5.48	5.48
	35	S/T	0.71	0.79	0.88	0.96	0.58	0.65	0.73	0.81	0.51	0.59	0.66	0.74	0.37	0.44	0.51	0.58
		PI	1.87	1.87	1.87	1.87	1.87	1.87	1.87	1.87	1.88	1.88	1.88	1.88	1.88	1.88	1.88	1.88
		TC	4.24	4.24	4.26	4.30	4.52	4.52	4.52	4.52	4.66	4.66	4.66	4.66	5.05	5.05	5.05	5.05
	40	S/T	0.73	0.82	0.91	0.99	0.58	0.67	0.75	0.84	0.52	0.60	0.68	0.76	0.36	0.44	0.51	0.59
		PI	2.13	2.13	2.13	2.13	2.14	2.14	2.14	2.14	2.15	2.15	2.15	2.15	2.16	2.16	2.16	2.16
		TC	4.03	4.03	4.06	4.09	4.29	4.29	4.29	4.29	4.43	4.43	4.43	4.43	4.80	4.80	4.80	4.80
	43	S/T	0.74	0.83	0.92	1.00	0.59	0.68	0.76	0.85	0.52	0.60	0.69	0.77	0.36	0.44	0.52	0.59
		PI	2.29	2.29	2.29	2.29	2.30	2.30	2.30	2.30	2.31	2.31	2.31	2.31	2.33	2.33	2.33	2.33
		TC	5.59	5.59	5.65	5.71	5.93	5.93	5.93	5.93	6.08	6.08	6.08	6.08	6.54	6.54	6.54	6.54
730	18	S/T	0.72	0.81	0.89	0.98	0.58	0.66	0.74	0.83	0.51	0.59	0.68	0.76	0.36	0.44	0.51	0.59
		PI	1.38	1.38	1.38	1.38	1.38	1.38	1.38	1.38	1.37	1.37	1.37	1.37	1.36	1.36	1.36	1.36
		TC	5.22	5.22	5.28	5.33	5.56	5.56	5.56	5.56	5.73	5.73	5.73	5.73	6.16	6.16	6.16	6.16
	25	S/T	0.74	0.83	0.92	1.00	0.59	0.67	0.76	0.85	0.52	0.60	0.69	0.77	0.36	0.44	0.52	0.59
		PI	1.60	1.60	1.60	1.60	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.59	1.60	1.60	1.60	1.60
		TC	4.99	4.99	5.05	5.10	5.30	5.30	5.30	5.30	5.45	5.45	5.45	5.45	5.88	5.88	5.88	5.88
	30	S/T	0.75	0.84	0.94	1.00	0.59	0.68	0.78	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60
		PI	1.74	1.74	1.74	1.74	1.74	1.74	1.74	1.74	1.75	1.75	1.75	1.75	1.75	1.75	1.75	1.75
		TC	4.73	4.73	4.79	4.85	5.05	5.05	5.05	5.05	5.10	5.10	5.10	5.10	5.59	5.59	5.59	5.59
	35	S/T	0.76	0.86	0.96	1.00	0.60	0.69	0.79	0.88	0.52	0.62	0.71	0.80	0.35	0.44	0.52	0.61
		PI	1.91	1.91	1.91	1.91	1.91	1.91	1.91	1.91	1.92	1.92	1.92	1.92	1.93	1.93	1.93	1.93
		TC	4.34	4.36	4.40	4.44	4.64	4.64	4.64	4.69	4.78	4.78	4.78	4.78	5.16	5.16	5.16	5.16
	40	S/T	0.78	0.89	1.00	1.00	0.61	0.72	0.82	0.92	0.53	0.63	0.74	0.84	0.34	0.44	0.53	0.90
		PI	2.18	2.18	2.18	2.18	2.18	2.18	2.18	2.18	2.19	2.19	2.19	2.19	2.21	2.21	2.21	2.21
		TC	4.11	4.14	4.17	4.20	4.40	4.40	4.40	4.46	4.54	4.54	4.54	4.54	4.91	4.91	4.91	4.91
	43	S/T	0.80	0.91	1.00	1.00	0.61	0.73	0.84	0.94	0.53	0.64	0.75	0.85	0.34	0.44	0.54	0.92
		PI	2.34	2.34	2.34	2.34	2.35	2.35	2.35	2.35	2.36	2.36	2.36	2.36	2.38	2.38	2.38	2.38
		TC	5.24	5.24	5.24	5.24	5.24	5.24	5.24	5.24	5.24	5.24	5.24	5.24	5.64	5.64	5.64	5.64

TC:Total Cooling Capacity (kW)

S/T:Sensible Cooling Capacity Ratio

PI:Power Input(kW)


7.2 Heating

		12k						[SI_Unit]	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	HEATING PERFORMANCE AT INDOOR DRY BULB TEMPERATURE							
		TC:TOTAL CAPACITY IN KILOWATTS				PI: TOTAL POWER IN KILOWATTS			
		Indoor Conditions (DB C)				Indoor Conditions (DB C)			
		16.0	20.0	22.0	24.0	16.0	20.0	22.0	
388	-7.0	2.46	2.43	2.40	2.40	0.78	0.80	0.84	0.86
	-5.6	2.60	2.57	2.54	2.54	0.80	0.84	0.86	0.88
	-2.8	2.75	2.72	2.69	2.66	0.85	0.90	0.92	0.94
	0.0	2.83	2.80	2.77	2.77	0.91	0.95	0.97	0.99
	2.8	3.06	3.01	2.98	2.98	0.97	1.02	1.04	1.06
	5.6	3.38	3.32	3.30	3.30	1.03	1.08	1.11	1.13
	7.0	3.76	3.69	3.58	3.55	1.07	1.16	1.14	1.17
	11.1	3.96	3.93	3.90	3.87	1.15	1.20	1.23	1.26
	13.9	4.19	4.13	4.10	4.07	1.21	1.26	1.29	1.32
	16.7	4.39	4.33	4.30	4.28	1.26	1.32	1.35	1.38
477	18.0	4.51	4.45	4.39	4.36	1.29	1.35	1.38	1.41
	-7.0	2.51	2.48	2.45	2.45	0.78	0.81	0.84	0.86
	-5.6	2.66	2.63	2.60	2.60	0.81	0.85	0.87	0.89
	-2.8	2.80	2.77	2.75	2.72	0.86	0.90	0.92	0.95
	0.0	2.92	2.86	2.83	2.83	0.91	0.96	0.98	1.00
	2.8	3.12	3.09	3.06	3.03	0.98	1.02	1.05	1.07
	5.6	3.44	3.41	3.38	3.35	1.04	1.09	1.11	1.14
	7.0	3.81	3.78	3.66	3.64	1.07	1.17	1.15	1.18
	11.1	4.07	4.01	3.98	3.96	1.16	1.22	1.24	1.27
	13.9	4.28	4.22	4.19	4.16	1.22	1.28	1.30	1.33
612	16.7	4.51	4.45	4.42	4.39	1.27	1.34	1.37	1.40
	18.0	4.60	4.54	4.51	4.48	1.30	1.36	1.40	1.43
	-7.0	2.54	2.51	2.49	2.49	0.79	0.81	0.85	0.87
	-5.6	2.69	2.66	2.63	2.63	0.81	0.85	0.87	0.89
	-2.8	2.83	2.80	2.77	2.77	0.87	0.91	0.93	0.95
	0.0	2.95	2.89	2.89	2.86	0.92	0.96	0.99	1.01
	2.8	3.15	3.12	3.09	3.06	0.98	1.03	1.06	1.08
	5.6	3.47	3.44	3.41	3.38	1.05	1.10	1.12	1.15
	7.0	3.84	3.81	3.69	3.66	1.08	1.18	1.16	1.19
	11.1	4.10	4.04	4.01	3.98	1.17	1.23	1.25	1.28

18k								[SI_Unit]	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	HEATING PERFORMANCE AT INDOOR DRY BULB TEMPERATURE							
		TC:TOTAL CAPACITY IN KILOWATTS				PI: TOTAL POWER IN KILOWATTS			
		Indoor Conditions (DB C)				Indoor Conditions (DB C)			
470	16.0	20.0	22.0	24.0	16.0	20.0	22.0	24.0	
	-7.0	3.61	3.56	3.53	3.53	1.12	1.15	1.20	1.23
	-5.6	3.82	3.76	3.73	3.73	1.16	1.21	1.24	1.27
	-2.8	4.02	3.96	3.94	3.91	1.23	1.29	1.32	1.35
	0.0	4.17	4.11	4.08	4.05	1.30	1.37	1.40	1.43
	2.8	4.49	4.43	4.40	4.34	1.39	1.46	1.49	1.53
	5.6	4.95	4.89	4.86	4.80	1.48	1.55	1.59	1.63
	7.0	5.46	5.39	5.22	5.19	1.52	1.66	1.63	1.67
	11.1	5.80	5.71	5.68	5.66	1.65	1.72	1.76	1.80
	13.9	6.12	6.03	5.97	5.95	1.73	1.81	1.85	1.89
570	16.7	6.41	6.32	6.29	6.24	1.81	1.90	1.94	1.98
	18.0	6.55	6.47	6.44	6.38	1.85	1.94	1.98	2.03
	-7.0	3.66	3.63	3.60	3.57	1.13	1.17	1.22	1.25
	-5.6	3.88	3.85	3.82	3.79	1.17	1.23	1.26	1.28
	-2.8	4.11	4.05	4.02	3.99	1.24	1.30	1.34	1.37
	0.0	4.25	4.20	4.17	4.14	1.32	1.38	1.42	1.45
	2.8	4.57	4.51	4.49	4.46	1.41	1.48	1.51	1.55
	5.6	5.06	4.98	4.95	4.92	1.50	1.57	1.61	1.65
	7.0	5.61	5.51	5.34	5.31	1.54	1.68	1.65	1.69
	11.1	5.92	5.86	5.80	5.77	1.66	1.75	1.79	1.83
730	13.9	6.24	6.15	6.12	6.06	1.75	1.83	1.87	1.92
	16.7	6.55	6.47	6.44	6.38	1.83	1.92	1.96	2.01
	18.0	6.70	6.61	6.58	6.53	1.87	1.96	2.01	2.05
	-7.0	3.73	3.68	3.68	3.65	1.14	1.17	1.23	1.25
	-5.6	3.94	3.88	3.88	3.85	1.18	1.24	1.26	1.29
	-2.8	4.14	4.08	4.08	4.05	1.25	1.32	1.35	1.38
	0.0	4.31	4.25	4.23	4.20	1.33	1.40	1.43	1.46
	2.8	4.63	4.57	4.51	4.49	1.42	1.49	1.53	1.56
	5.6	5.12	5.04	5.01	4.98	1.52	1.59	1.63	1.66
	7.0	5.66	5.57	5.39	5.37	1.56	1.70	1.67	1.71
	11.1	5.97	5.92	5.86	5.83	1.69	1.77	1.81	1.85
	13.9	6.29	6.21	6.18	6.15	1.77	1.86	1.90	1.94
	16.7	6.61	6.53	6.50	6.44	1.86	1.95	1.99	2.03
	18.0	6.79	6.70	6.64	6.58	1.90	1.99	2.03	2.08


7. Noise Criterion Curves

7.1 Indoor Unit



Notes:

- Sound measured at 1.4m away from the noisiest location of the unit.
- Data is valid at free field condition
- Data is valid at nominal operation condition
- Reference acoustic pressure OdB = 20μPa
- Sound level will vary depending on a range of factors such as the construction -(acoustic absorption coefficient) of particular room in which the equipment is installed.
- The operating conditions are assumed to be standard.



7. Electrical Characteristics


	Capacity (Btu/h)	12k/18k
Indoor Unit Power	Phase	1-phase
	Frequency and Voltage	220-240V, 50Hz
	Power Wiring (mm ²)	3×2.5
	Circuit Breaker/ Fuse (A)	25/20
Indoor/Outdoor Connecting Wiring	Weak Electric Signal)(mm ²)	2x0.5
	Strong Electric Signal(mm ²)	3×2.5/2×1.0

7. Electrical Wiring Diagrams

IDU Capacity (Btu/h)	IDU Wiring Diagram
12k/18k	16022500005103

Abbreviation	Paraphrase
Y/G	Yellow-Green Conductor
CAP1	Indoor Fan Capacitor
FAN1	Indoor Fan Motor
PUMP	PUMP
L	LIVE
N	NEUTRAL
TO CCM Comm.Bus	Central Controller
T1	Indoor Room Temperature
T2	Coil Temperature of Indoor Heat Exchanger
P3	Super High Speed
P2	High Speed

Indoor unit wiring diagram:16022500005103



Indoor Unit-New Four-way Cassette

Contents

1.	Feature.....	2
2.	Dimensional Drawings	5
3.	Part names	6
4.	Service Place.....	6
5.	Accessories	7
6.	Air Velocity and Temperature Distributions	8
7.	Capacity Tables	24
8.	Noise Criterion Curves.....	32
9.	Electrical Characteristics.....	34
10.	Electrical Wiring Diagrams.....	34

1. Feature

1.1 360° Air Flow


- 360° directional wind can deliver air evenly throughout every corner in any space, reducing hot and cold spots in the room.

1.2 Easy Installation

- The Cassette is much slimmer due to the redesigned heat exchanger and overall structures. It now requires less space for installation.

1.3 Reserved Air Outlet for Duct

- The cassette unit is equipped with reserved connection for air outlet at the side of the indoor unit. It can connect to an air duct to cool a small room nearby.



1.4 Reserved remote on-off and alarm ports(Optional for fixed-speed units, standard for inverter units)

- Remote on-off: With the reserved ports, a remote switch can be easily connected to realize remote control.
- Alarm: The built-in PCB can output alarm signal, which achieves setting up an external alarm light or vibration gauge possible.



1.5 Fresh Air


- Fresh air intake function brings you fresh and comfortable air feeling.



1.6 Wired Controller(Optional)


- Compared with infrared remote controller, wired controller can be fixed on the wall and avoid mislaying. It's mainly used for commercial zone and makes air conditioner control more convenient.

2. Dimensional Drawings




Model (KBtu/h)	Unit	A	B	C	D
24	mm	165	80	205	50
	inch	6.50	3.15	8.07	1.97
36~48	mm	165	100	245	60
	inch	6.50	3.94	9.65	2.36
60	mm	165	100	287	60
	inch	6.50	3.94	11.3	2.36

3. Part names







4. Service Place



5. Accessories

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or equipment failure.

	Name	Shape	Quantity
Indoor unit installation	Installation paper template (some models)		1
Refrigeration Fittings	Soundproof/insulation sheath (some models)		1
	Soundproof/insulation sheath (some models)		1
	Copper nut		2
Drainpipe Fittings	Outlet pipe sheath(some models)		1
	Outlet pipe clasp(some models)		1
	Drain joint (some models)		1
	Seal ring (some models)		1
	Throat bander		2
EMC Magnetic Ring (some models)	Magnetic ring (wrap the electric wires S1 & S2 (P & Q & E) around the magnetic ring twice)		1
	Magnetic ring (Hitch it on the connective cable between indoor unit and outdoor unit after installation)		1
Installation Accessory (some models)	Ceiling hook		4
	Suspension bolt		4
	Throttle		1
	Anti-shock rubber		1
	Manual		2-4

Optional accessories:


- There are two types of remote controls: wired and wireless.
- Select a remote controller based on customer preferences and requirements and install in an appropriate place.
- Refer to catalogues and technical literature for guidance on selecting a suitable remote controller.

6. Air Velocity and Temperature Distributions


24K

Discharge Angle 30°

Cooling airflow velocity distributions




Cooling temperature distributions




24K

Discharge Angle 30°

Heating airflow velocity distributions




Heating temperature distributions




24K

Discharge Angle 60°

Cooling airflow velocity distributions




Cooling temperature distributions




24K

Discharge Angle 60°

Heating airflow velocity distributions




Heating temperature distributions




36K

Discharge Angle 30°

Cooling airflow velocity distributions




Cooling temperature distributions




36K

Discharge Angle 30°

Heating airflow velocity distributions




Heating temperature distributions




36K

Discharge Angle 60°

Cooling airflow velocity distributions




Cooling temperature distributions




36K

Discharge Angle 60°

Heating airflow velocity distributions




Heating temperature distributions




48k

Discharge Angle 30°

Cooling airflow velocity distributions




Cooling temperature distributions




48k

Discharge Angle 30°

Heating airflow velocity distributions




Heating temperature distributions




48k

Discharge Angle 60°

Cooling airflow velocity distributions




Cooling temperature distributions




48k

Discharge Angle 60°

Heating airflow velocity distributions




Heating temperature distributions




55K

Discharge Angle 30°

Cooling airflow velocity distributions




Cooling temperature distributions




55K

Discharge Angle 30°

Heating airflow velocity distributions




Heating temperature distributions




55K

Discharge Angle 60°

Cooling airflow velocity distributions




Cooling temperature distributions




55K

Discharge Angle 60°

Heating airflow velocity distributions



Heating temperature distributions



7. Capacity Tables

7.1 Cooling

		24k																
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	16.0				18.0				19.0				22.0			
		ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0
820	18	TC	7.14	7.15	7.15	7.20	7.57	7.58	7.58	7.58	7.78	7.78	7.78	7.78	8.35	8.35	8.35	8.35
		S/T	0.70	0.78	0.86	0.93	0.57	0.65	0.72	0.79	0.51	0.58	0.65	0.72	0.37	0.44	0.50	0.57
		PI	1.81	1.80	1.80	1.81	1.79	1.79	1.79	1.79	1.79	1.79	1.79	1.79	1.78	1.78	1.78	1.78
	25	TC	6.69	6.69	6.69	6.74	7.09	7.09	7.09	7.09	7.32	7.32	7.32	7.32	7.86	7.86	7.86	7.86
		S/T	0.71	0.79	0.88	0.95	0.58	0.65	0.73	0.81	0.51	0.59	0.66	0.74	0.37	0.44	0.51	0.58
		PI	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07	2.07
	30	TC	6.37	6.37	6.43	6.49	6.77	6.77	6.77	6.77	6.97	6.97	6.97	6.97	7.52	7.52	7.52	7.52
		S/T	0.72	0.81	0.89	0.97	0.58	0.66	0.74	0.82	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.58
		PI	2.28	2.28	2.28	2.28	2.28	2.28	2.28	2.28	2.28	2.28	2.28	2.28	2.29	2.29	2.29	2.29
	35	TC	6.06	6.06	6.11	6.17	6.43	6.43	6.43	6.43	6.63	6.63	6.63	6.63	7.17	7.17	7.17	7.17
		S/T	0.73	0.82	0.91	0.99	0.58	0.67	0.75	0.84	0.52	0.60	0.68	0.76	0.36	0.44	0.51	0.59
		PI	2.48	2.48	2.48	2.49	2.49	2.49	2.49	2.49	2.50	2.50	2.50	2.50	2.51	2.51	2.51	2.51
	40	TC	5.58	5.58	5.64	5.69	5.94	5.94	5.94	5.94	5.97	6.14	6.14	6.14	6.63	6.63	6.63	6.63
		S/T	0.75	0.85	0.94	1.00	0.59	0.69	0.78	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60
		PI	2.84	2.84	2.84	2.85	2.85	2.85	2.85	2.86	2.86	2.86	2.86	2.86	2.88	2.88	2.88	2.88
	43	TC	5.29	5.29	5.35	5.40	5.63	5.63	5.63	5.63	5.69	5.83	5.83	5.83	6.29	6.29	6.29	6.29
		S/T	0.76	0.86	0.96	1.00	0.60	0.70	0.79	0.89	0.52	0.62	0.71	0.80	0.35	0.44	0.52	0.61
		PI	3.05	3.05	3.05	3.05	3.06	3.06	3.06	3.06	3.07	3.07	3.07	3.07	3.10	3.10	3.10	3.10
1000	18	TC	7.29	7.29	7.38	7.46	7.72	7.72	7.72	7.72	7.95	7.95	7.95	7.95	8.56	8.56	8.56	8.56
		S/T	0.73	0.82	0.91	1.00	0.58	0.67	0.76	0.85	0.52	0.60	0.68	0.77	0.36	0.44	0.51	0.59
		PI	1.84	1.84	1.84	1.84	1.83	1.83	1.83	1.83	1.82	1.82	1.82	1.82	1.82	1.82	1.82	1.82
	25	TC	6.83	6.83	6.89	6.95	7.26	7.26	7.26	7.26	7.46	7.46	7.46	7.46	8.04	8.04	8.04	8.04
		S/T	0.75	0.84	0.94	1.00	0.59	0.68	0.78	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60
		PI	2.12	2.12	2.12	2.12	2.11	2.11	2.11	2.11	2.11	2.11	2.11	2.11	2.12	2.12	2.12	2.12
	30	TC	6.52	6.52	6.57	6.63	6.92	6.92	6.92	6.98	7.12	7.12	7.12	7.12	7.69	7.69	7.69	7.69
		S/T	0.76	0.86	0.96	1.00	0.60	0.69	0.79	0.88	0.52	0.62	0.71	0.80	0.35	0.44	0.52	0.61
		PI	2.32	2.32	2.32	2.32	2.33	2.33	2.33	2.33	2.33	2.33	2.33	2.33	2.34	2.34	2.34	2.34
	35	TC	6.17	6.17	6.23	6.29	6.57	6.57	6.57	6.63	6.78	6.78	6.78	6.78	7.32	7.32	7.32	7.32
		S/T	0.77	0.88	0.98	1.00	0.60	0.70	0.81	0.91	0.53	0.62	0.72	0.82	0.35	0.44	0.53	0.62
		PI	2.53	2.53	2.53	2.53	2.54	2.54	2.54	2.54	2.55	2.55	2.55	2.55	2.55	2.55	2.55	2.55
	40	TC	5.64	5.64	5.68	5.74	5.79	5.79	5.79	5.79	6.21	6.21	6.21	6.21	6.71	6.71	6.71	6.71
		S/T	0.80	0.91	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64
		PI	2.89	2.89	2.89	2.89	2.90	2.90	2.90	2.90	2.91	2.91	2.91	2.91	2.93	2.93	2.93	2.93
	43	TC	5.35	5.41	5.47	5.53	5.70	5.70	5.70	5.70	5.75	5.90	5.90	5.90	6.38	6.38	6.38	6.38
		S/T	0.81	0.93	1.00	1.00	0.62	0.74	0.86	0.97	0.54	0.65	0.76	0.87	0.34	0.44	0.55	0.65
		PI	3.11	3.11	3.11	3.11	3.12	3.12	3.12	3.12	3.13	3.13	3.13	3.13	3.16	3.16	3.16	3.16
1300	18	TC	7.44	7.52	7.61	7.69	7.90	7.90	7.90	7.98	8.12	8.12	8.12	8.12	8.73	8.73	8.73	8.73
		S/T	0.79	0.90	1.00	1.00	0.61	0.72	0.83	0.94	0.53	0.64	0.75	0.85	0.34	0.44	0.54	0.64
		PI	1.87	1.87	1.87	1.87	1.86	1.86	1.86	1.86	1.86	1.86	1.86	1.86	1.84	1.84	1.84	1.84
	25	TC	6.98	7.03	7.09	7.15	7.41	7.41	7.41	7.49	7.64	7.64	7.64	7.64	8.21	8.21	8.21	8.21
		S/T	0.81	0.93	1.00	1.00	0.62	0.74	0.86	0.97	0.54	0.65	0.77	0.88	0.34	0.44	0.55	0.66
		PI	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16	2.16
	30	TC	6.63	6.69	6.75	6.80	7.06	7.06	7.06	7.12	7.29	7.29	7.29	7.29	7.84	7.84	7.84	7.84
		S/T	0.83	0.96	1.00	1.00	0.63	0.76	0.88	1.00	0.54	0.66	0.78	0.90	0.33	0.45	0.56	0.67
		PI	2.36	2.36	2.36	2.36	2.36	2.36	2.36	2.36	2.36	2.36	2.36	2.36	2.37	2.37	2.37	2.37
	35	TC	6.32	6.37	6.43	6.49	6.72	6.72	6.78	6.83	6.92	6.92	7.03	7.09	7.46	7.46	7.46	7.46
		S/T	0.85	0.98	1.00	1.00	0.64	0.77	0.90	1.00	0.55	0.67	0.79	0.91	0.33	0.45	0.57	0.68
		PI	2.58	2.58	2.58	2.58	2.59	2.59	2.59	2.59	2.60	2.60	2.60	2.60	2.61	2.61	2.61	2.61
	40	TC	5.77	5.82	5.88	5.94	6.15	6.15	6.21	6.26	6.33	6.33	6.37	6.43	6.85	6.85	6.85	6.85
		S/T	0.88	1.00	1.00	1.00	0.66	0.80	0.94	1.00	0.56	0.70	0.84	0.97	0.33	0.45	0.58	0.90
		PI	2.95	2.95	2.95	2.95	2.96	2.96	2.96	2.96	2.97	2.97	2.97	2.97	2.99	2.99	2.99	2.99
	43	TC	5.47	5.53	5.58	5.64	5.84	5.84	5.90	5.95	6.01	6.01	6.07	6.52	6.52	6.52	6.52	6.52
		S/T	0.90	1.00	1.00	1.00	0.67	0.82	0.96	1.00	0.57	0.71	0.85	0.99	0.32	0.46	0.59	0.92
		PI	3.17	3.17	3.17	3.17	3.18	3.18	3.18	3.18	3.19	3.19	3.19	3.19	3.22	3.22	3.22	3.22

TC:Total Cooling Capacity (kW)

S/T:Sensible Cooling Capacity Ratio

PI:Power Input(kW)

36k																		
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	16.0				18.0				19.0				22.0			
		ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0
		TC	10.74	10.75	10.86	10.98	11.39	11.38	11.38	11.38	11.73	11.73	11.73	11.73	12.59	12.59	12.59	12.59
1400	18	S/T	0.72	0.81	0.89	0.98	0.58	0.66	0.75	0.83	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.59
		PI	2.50	2.50	2.50	2.50	2.48	2.48	2.48	2.48	2.48	2.48	2.48	2.48	2.46	2.46	2.46	2.46
		TC	10.06	10.06	10.17	10.29	10.69	10.69	10.69	10.69	11.01	11.01	11.01	11.01	11.84	11.84	11.84	11.84
	25	S/T	0.74	0.83	0.92	1.00	0.59	0.67	0.76	0.85	0.52	0.60	0.69	0.77	0.36	0.44	0.52	0.59
		PI	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87	2.87
		TC	9.57	9.57	9.66	9.74	10.20	10.20	10.20	10.20	10.49	10.49	10.49	10.49	11.32	11.32	11.32	11.32
	30	S/T	0.75	0.84	0.94	1.00	0.59	0.68	0.77	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60
		PI	3.15	3.15	3.15	3.15	3.15	3.15	3.15	3.15	3.16	3.16	3.16	3.17	3.17	3.17	3.17	3.17
		TC	9.11	9.11	9.20	9.28	9.68	9.68	9.68	9.77	10.00	10.00	10.14	10.00	10.78	10.78	10.78	10.78
	35	S/T	0.76	0.86	0.96	1.00	0.60	0.69	0.79	0.88	0.52	0.62	0.71	0.80	0.35	0.44	0.52	0.61
		PI	3.44	3.44	3.44	3.44	3.45	3.45	3.45	3.46	3.46	3.46	3.46	3.48	3.48	3.48	3.48	3.48
		TC	8.29	8.35	8.43	8.52	8.85	8.85	8.85	8.93	9.12	9.12	9.18	9.12	9.86	9.86	9.86	9.86
	40	S/T	0.78	0.89	1.00	1.00	0.61	0.72	0.82	0.92	0.53	0.63	0.73	0.84	0.34	0.44	0.53	0.63
		PI	3.92	3.92	3.92	3.94	3.94	3.94	3.94	3.95	3.95	3.95	3.95	3.98	3.98	3.98	3.98	3.98
		TC	7.86	7.94	8.03	8.11	8.40	8.40	8.40	8.48	8.65	8.65	8.65	8.65	9.37	9.37	9.37	9.37
	43	S/T	0.80	0.91	1.00	1.00	0.61	0.73	0.84	0.94	0.53	0.64	0.75	0.85	0.34	0.44	0.54	0.64
		PI	4.21	4.21	4.21	4.21	4.23	4.23	4.23	4.23	4.24	4.24	4.24	4.24	4.28	4.28	4.28	4.28
		TC	10.95	10.95	11.07	11.18	11.61	11.61	11.61	11.96	11.96	11.96	11.96	12.82	12.82	12.82	12.82	12.82
1660	18	S/T	0.75	0.86	0.95	1.00	0.60	0.69	0.79	0.88	0.52	0.61	0.71	0.80	0.35	0.44	0.52	0.61
		PI	2.55	2.55	2.55	2.55	2.53	2.53	2.53	2.53	2.53	2.53	2.53	2.51	2.51	2.51	2.51	2.51
		TC	10.26	10.26	10.38	10.49	10.90	10.90	10.90	11.01	11.21	11.21	11.21	11.21	12.07	12.07	12.07	12.07
	25	S/T	0.77	0.88	0.98	1.00	0.60	0.71	0.81	0.91	0.53	0.62	0.72	0.82	0.35	0.44	0.53	0.62
		PI	2.92	2.92	2.92	2.92	2.92	2.92	2.92	2.92	2.92	2.92	2.92	2.93	2.93	2.93	2.93	2.93
		TC	9.77	9.86	9.95	10.03	10.41	10.41	10.41	10.52	10.72	10.72	10.72	10.72	11.53	11.53	11.53	11.53
	30	S/T	0.78	0.89	1.00	1.00	0.61	0.72	0.82	0.93	0.53	0.63	0.74	0.84	0.34	0.44	0.54	0.63
		PI	3.21	3.21	3.21	3.21	3.22	3.22	3.22	3.22	3.22	3.22	3.22	3.23	3.23	3.23	3.23	3.23
		TC	9.29	9.37	9.46	9.54	9.89	9.89	9.89	9.98	10.18	10.18	10.35	10.18	10.98	10.98	10.98	10.98
	35	S/T	0.80	0.92	1.00	1.00	0.62	0.73	0.84	0.95	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64
		PI	3.50	3.50	3.50	3.50	3.52	3.52	3.52	3.52	3.52	3.52	3.52	3.52	3.52	3.52	3.52	3.52
		TC	8.55	8.64	8.72	8.81	9.12	9.12	9.17	9.26	9.39	9.39	9.45	9.44	10.16	10.16	10.16	10.16
	40	S/T	0.83	0.96	1.00	1.00	0.63	0.76	0.88	1.00	0.54	0.66	0.78	0.90	0.33	0.45	0.56	0.67
		PI	4.01	4.01	4.01	4.01	4.03	4.03	4.03	4.03	4.04	4.04	4.04	4.05	4.05	4.05	4.05	4.05
		TC	8.11	8.20	8.28	8.37	8.66	8.66	8.74	8.83	8.91	8.91	9.00	9.00	9.66	9.66	9.66	9.66
	43	S/T	0.84	0.98	1.00	1.00	0.64	0.77	0.89	1.00	0.55	0.67	0.80	0.92	0.33	0.45	0.56	0.68
		PI	4.31	4.31	4.31	4.31	4.33	4.33	4.33	4.33	4.34	4.34	4.34	4.37	4.37	4.37	4.37	4.37
		TC	11.18	11.30	11.41	11.53	11.84	11.84	11.84	11.96	12.19	12.19	12.19	12.19	13.08	13.08	13.08	13.08
1960	18	S/T	0.79	0.91	1.00	1.00	0.62	0.73	0.84	0.94	0.53	0.64	0.75	0.86	0.34	0.44	0.54	0.64
		PI	2.60	2.60	2.60	2.60	2.58	2.58	2.58	2.58	2.58	2.58	2.58	2.56	2.56	2.56	2.56	2.56
		TC	10.46	10.58	10.69	10.81	11.10	11.10	11.10	11.21	11.44	11.44	11.44	11.44	12.30	12.30	12.30	12.30
	25	S/T	0.81	0.93	1.00	1.00	0.63	0.74	0.86	0.98	0.54	0.65	0.77	0.88	0.34	0.44	0.55	0.66
		PI	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98	2.98
		TC	9.98	10.06	10.18	10.29	10.61	10.61	10.61	10.72	10.92	10.92	10.92	10.92	11.76	11.76	11.76	11.76
	30	S/T	0.83	0.96	1.00	1.00	0.63	0.76	0.88	1.00	0.54	0.66	0.78	0.90	0.33	0.45	0.56	0.67
		PI	3.27	3.27	3.27	3.27	3.28	3.28	3.28	3.28	3.28	3.28	3.28	3.30	3.30	3.30	3.30	3.30
		TC	9.46	9.54	9.63	9.72	10.06	10.06	10.18	10.29	10.38	10.38	10.55	10.67	11.21	11.21	11.21	11.21
	35	S/T	0.85	0.98	1.00	1.00	0.64	0.77	0.90	1.00	0.55	0.68	0.80	0.92	0.33	0.45	0.57	0.68
		PI	3.57	3.57	3.57	3.57	3.59	3.59	3.59	3.59	3.59	3.60	3.59	3.62	3.62	3.62	3.62	3.62
		TC	8.71	8.79	8.88	8.97	9.27	9.27	9.37	9.47	9.57	9.57	9.64	9.73	10.37	10.37	10.37	10.37
	40	S/T	0.89	1.00	1.00	1.00	0.66	0.81	0.95	1.00	0.56	0.70	0.84	0.97	0.33	0.45	0.58	0.90
		PI	4.08	4.08	4.08	4.08	4.10	4.10	4.10	4.10	4.11	4.11	4.11	4.15	4.15	4.15	4.15	4.15
		TC	8.25	8.34	8.43	8.51	8.80	8.80	8.89	8.97	9.09	9.09	9.09	9.17	9.86	9.86	9.86	9.86
	43	S/T	0.90	1.00	1.00	1.00	0.67	0.82	0.97	1.00	0.57	0.71	0.86	1.00	0.32	0.46	0.59	0.92
		PI	4.39	4.39	4.39	4.39	4.41	4.41	4.41	4.41	4.42	4.42	4.42	4.46	4.46	4.46	4.46	4.46

TC:Total Cooling Capacity (kW)

S/T:Sensible Cooling Capacity Ratio

PI:Power Input(kW)

48k																		
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	16.0				18.0				19.0				22.0			
		ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0
		TC	14.28	14.29	14.29	14.43	15.14	15.15	15.15	15.15	15.58	15.58	15.58	15.58	16.73	16.73	16.73	16.73
1620	18	S/T	0.70	0.78	0.85	0.92	0.57	0.64	0.71	0.79	0.51	0.58	0.65	0.72	0.37	0.44	0.50	0.57
		PI	3.60	3.60	3.60	3.60	3.58	3.58	3.58	3.58	3.57	3.57	3.57	3.55	3.55	3.55	3.55	3.55
		TC	13.37	13.37	13.37	13.52	14.21	14.21	14.21	14.21	14.64	14.64	14.64	14.64	15.73	15.73	15.73	15.73
	25	S/T	0.71	0.79	0.87	0.95	0.58	0.65	0.73	0.80	0.51	0.59	0.66	0.73	0.37	0.44	0.51	0.57
		PI	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14	4.14
		TC	12.74	12.74	12.86	12.97	13.55	13.55	13.55	13.55	13.95	13.95	13.95	13.95	15.04	15.04	15.04	15.04
	30	S/T	0.72	0.80	0.88	0.97	0.58	0.66	0.74	0.82	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.58
		PI	4.53	4.53	4.53	4.53	4.54	4.54	4.54	4.54	4.55	4.55	4.55	4.55	4.57	4.57	4.57	4.57
		TC	12.11	12.11	12.23	12.34	12.89	12.89	12.89	12.89	13.29	13.29	13.29	13.29	14.32	14.32	14.32	14.32
	35	S/T	0.73	0.82	0.90	0.99	0.58	0.67	0.75	0.83	0.52	0.60	0.68	0.76	0.36	0.44	0.51	0.59
		PI	4.95	4.95	4.95	4.95	4.97	4.97	4.97	4.97	4.98	4.98	4.98	4.98	5.02	5.02	5.02	5.02
		TC	11.13	11.13	11.25	11.36	11.85	11.85	11.85	11.85	12.24	12.24	12.24	12.24	13.23	13.23	13.23	13.23
	40	S/T	0.75	0.85	0.94	1.00	0.59	0.68	0.78	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60
		PI	5.66	5.66	5.66	5.66	5.69	5.69	5.69	5.69	5.70	5.70	5.70	5.70	5.75	5.75	5.75	5.75
		TC	10.55	10.55	10.67	10.78	11.24	11.24	11.24	11.24	11.61	11.61	11.61	11.61	12.59	12.59	12.59	12.59
	43	S/T	0.76	0.86	0.96	1.00	0.60	0.69	0.79	0.88	0.52	0.61	0.71	0.80	0.35	0.44	0.52	0.61
		PI	6.08	6.08	6.08	6.08	6.11	6.11	6.11	6.11	6.13	6.13	6.13	6.13	6.18	6.18	6.18	6.18
		TC	14.58	14.58	14.58	14.73	15.47	15.47	15.47	15.47	15.91	15.91	15.91	15.91	17.08	17.08	17.08	17.08
1780	18	S/T	0.71	0.79	0.87	0.95	0.58	0.65	0.73	0.81	0.51	0.59	0.66	0.74	0.37	0.44	0.51	0.58
		PI	3.68	3.68	3.68	3.68	3.65	3.65	3.65	3.65	3.64	3.64	3.64	3.64	3.62	3.62	3.62	3.62
		TC	13.67	13.67	13.81	13.95	14.50	14.50	14.50	14.50	14.93	14.93	14.93	14.93	16.08	16.08	16.08	16.08
	25	S/T	0.72	0.81	0.89	0.97	0.58	0.66	0.74	0.83	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.58
		PI	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22	4.22
		TC	13.01	13.01	13.15	13.29	13.84	13.84	13.84	13.84	14.27	14.27	14.27	14.27	15.36	15.36	15.36	15.36
	30	S/T	0.73	0.82	0.91	1.00	0.58	0.67	0.76	0.84	0.52	0.60	0.68	0.77	0.36	0.44	0.51	0.59
		PI	4.62	4.62	4.62	4.62	4.63	4.63	4.63	4.63	4.64	4.64	4.64	4.64	4.66	4.66	4.66	4.66
		TC	12.37	12.37	12.49	12.60	13.15	13.15	13.15	13.15	13.58	13.58	13.58	13.58	14.64	14.64	14.64	14.64
	35	S/T	0.74	0.84	0.93	1.00	0.59	0.68	0.77	0.86	0.52	0.61	0.69	0.78	0.36	0.44	0.52	0.60
		PI	5.05	5.05	5.05	5.05	5.07	5.07	5.07	5.07	5.08	5.08	5.08	5.08	5.08	5.08	5.08	5.08
		TC	11.39	11.46	11.57	11.69	12.14	12.14	12.14	12.22	12.54	12.54	12.62	12.54	13.55	13.55	13.55	13.55
	40	S/T	0.76	0.87	0.97	1.00	0.60	0.70	0.80	0.89	0.52	0.62	0.72	0.81	0.35	0.44	0.53	0.62
		PI	5.78	5.78	5.78	5.78	5.80	5.80	5.80	5.80	5.81	5.81	5.82	5.81	5.84	5.84	5.84	5.84
		TC	10.78	10.90	11.01	11.13	11.53	11.53	11.53	11.64	11.90	11.90	11.90	11.90	12.88	12.88	12.88	12.88
	43	S/T	0.78	0.88	0.99	1.00	0.61	0.71	0.81	0.91	0.53	0.63	0.73	0.83	0.35	0.44	0.53	0.62
		PI	6.21	6.21	6.21	6.21	6.24	6.24	6.24	6.24	6.25	6.25	6.25	6.25	6.30	6.30	6.30	6.30
		TC	14.90	14.90	15.04	15.19	15.79	15.79	15.79	15.79	16.25	16.25	16.25	16.25	17.46	17.46	17.46	17.46
1916	18	S/T	0.72	0.81	0.89	0.97	0.58	0.66	0.74	0.82	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.58
		PI	3.75	3.75	3.75	3.75	3.73	3.73	3.73	3.73	3.71	3.71	3.71	3.71	3.69	3.69	3.69	3.69
		TC	13.95	13.95	14.10	14.24	14.81	14.81	14.81	15.25	15.25	15.25	15.25	16.42	16.42	16.42	16.42	16.42
	25	S/T	0.73	0.82	0.91	1.00	0.58	0.67	0.76	0.84	0.52	0.60	0.68	0.77	0.36	0.44	0.51	0.59
		PI	4.31	4.31	4.31	4.31	4.30	4.30	4.30	4.30	4.30	4.30	4.30	4.30	4.31	4.31	4.31	4.31
		TC	13.29	13.29	13.44	13.58	14.13	14.13	14.13	14.13	14.56	14.56	14.56	14.56	15.68	15.68	15.68	15.68
	30	S/T	0.74	0.84	0.93	1.00	0.59	0.68	0.77	0.86	0.52	0.61	0.69	0.78	0.35	0.44	0.52	0.60
		PI	4.71	4.71	4.71	4.71	4.72	4.72	4.72	4.72	4.73	4.73	4.73	4.73	4.75	4.75	4.75	4.75
		TC	12.63	12.63	12.75	12.86	13.44	13.44	13.44	13.44	13.87	13.87	13.87	13.87	14.96	14.96	14.96	14.96
	35	S/T	0.75	0.86	0.95	1.00	0.59	0.69	0.79	0.88	0.52	0.61	0.70	0.80	0.35	0.44	0.52	0.61
		PI	5.15	5.15	5.15	5.15	5.17	5.17	5.17	5.17	5.18	5.18	5.19	5.18	5.22	5.22	5.22	5.22
		TC	11.63	11.70	11.81	11.93	12.40	12.40	12.40	12.47	12.79	12.79	12.87	12.79	13.83	13.83	13.83	13.83
	40	S/T	0.78	0.89	0.99	1.00	0.61	0.71	0.82	0.92	0.53	0.63	0.73	0.83	0.35	0.44	0.53	0.90
		PI	5.89	5.89	5.89	5.89	5.91	5.91	5.91	5.91	5.92	5.92	5.93	5.92	5.98	5.98	5.98	5.98
		TC	11.01	11.13	11.24	11.36	11.76	11.76	11.76	11.87	12.13	12.13	12.13	12.13	13.14	13.14	13.14	13.14
	43	S/T	0.79	0.90	1.00	1.00	0.61	0.72	0.83	0.94	0.53	0.64	0.74	0.85	0.34	0.44	0.54	0.92
		PI	6.33	6.33	6.33	6.33	6.36	6.36	6.36	6.36	6.37	6.37	6.37	6.37	6.43	6.43	6.43	6.43

TC:Total Cooling Capacity (kW)

S/T:Sensible Cooling Capacity Ratio

PI:Power Input(kW)

60k																		
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	ID WB (C)	16.0				18.0				19.0				22.0			
		ID DB (C)	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0	23.0	25.0	27.0	29.0
		TC	16.39	16.40	16.40	16.57	17.38	17.38	17.38	17.38	17.87	17.87	17.87	17.87	19.19	19.19	19.19	19.19
1730	18	S/T	0.69	0.76	0.83	0.90	0.57	0.64	0.70	0.77	0.51	0.58	0.64	0.71	0.38	0.44	0.50	0.56
		PI	4.34	4.34	4.34	4.34	4.32	4.32	4.32	4.32	4.30	4.30	4.30	4.30	4.27	4.27	4.27	4.27
		TC	15.34	15.34	15.34	15.48	16.29	16.29	16.29	16.29	16.77	16.77	16.77	16.77	18.07	18.07	18.07	18.07
	25	S/T	0.70	0.77	0.85	0.92	0.57	0.64	0.71	0.79	0.51	0.58	0.65	0.72	0.37	0.44	0.50	0.57
		PI	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98	4.98
		TC	14.62	14.62	14.62	14.76	15.54	15.54	15.54	15.54	16.03	16.03	16.03	16.03	17.26	17.26	17.26	17.26
	30	S/T	0.71	0.79	0.86	0.94	0.57	0.65	0.72	0.80	0.51	0.58	0.66	0.73	0.37	0.44	0.50	0.57
		PI	5.46	5.46	5.46	5.46	5.47	5.47	5.47	5.47	5.47	5.47	5.47	5.47	5.50	5.50	5.50	5.50
		TC	13.90	13.90	13.90	14.05	14.79	14.79	14.79	14.79	15.25	15.25	15.25	15.25	16.46	16.46	16.46	16.46
	35	S/T	0.71	0.80	0.88	0.96	0.58	0.66	0.73	0.81	0.51	0.59	0.66	0.74	0.37	0.44	0.51	0.58
		PI	5.97	5.97	5.97	5.97	5.99	5.99	5.99	5.99	6.00	6.00	6.01	6.01	6.04	6.04	6.04	6.04
		TC	12.80	12.80	12.87	13.00	13.64	13.64	13.64	13.64	14.08	14.08	14.17	14.08	15.22	15.22	15.22	15.22
	40	S/T	0.73	0.82	0.91	1.00	0.58	0.67	0.76	0.84	0.52	0.60	0.68	0.77	0.36	0.44	0.51	0.59
		PI	6.82	6.82	6.82	6.85	6.85	6.85	6.85	6.85	6.87	6.87	6.87	6.92	6.92	6.92	6.92	6.92
		TC	12.13	12.13	12.25	12.36	12.94	12.94	12.94	12.94	13.37	13.37	13.37	13.37	14.46	14.46	14.46	14.46
	43	S/T	0.74	0.84	0.93	1.00	0.59	0.68	0.77	0.86	0.52	0.60	0.69	0.78	0.36	0.44	0.52	0.60
		PI	7.32	7.32	7.32	7.32	7.36	7.36	7.36	7.36	7.38	7.38	7.38	7.38	7.44	7.44	7.44	7.44
		TC	16.72	16.72	16.72	16.90	17.73	17.73	17.73	17.73	18.25	18.25	18.25	18.25	19.60	19.60	19.60	19.60
1920	18	S/T	0.70	0.78	0.86	0.93	0.57	0.65	0.72	0.79	0.51	0.58	0.65	0.72	0.37	0.44	0.50	0.57
		PI	4.44	4.44	4.44	4.44	4.41	4.41	4.41	4.41	4.40	4.40	4.40	4.40	4.36	4.36	4.36	4.36
		TC	15.66	15.66	15.66	15.80	16.64	16.64	16.64	16.64	17.13	17.13	17.13	17.13	18.45	18.45	18.45	18.45
	25	S/T	0.71	0.79	0.88	0.95	0.58	0.65	0.73	0.81	0.51	0.59	0.66	0.74	0.37	0.44	0.51	0.58
		PI	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09	5.09
		TC	14.91	14.91	15.06	15.20	15.86	15.86	15.86	15.86	16.35	16.35	16.35	16.35	17.61	17.61	17.61	17.61
	30	S/T	0.72	0.81	0.89	0.97	0.58	0.66	0.74	0.82	0.51	0.59	0.67	0.75	0.36	0.44	0.51	0.58
		PI	5.57	5.57	5.57	5.57	5.59	5.59	5.59	5.59	5.59	5.59	5.59	5.59	5.62	5.62	5.62	5.62
		TC	14.17	14.17	14.31	14.45	15.09	15.09	15.09	15.09	15.57	15.57	15.57	15.57	16.78	16.78	16.78	16.78
	35	S/T	0.73	0.82	0.91	0.99	0.58	0.67	0.75	0.84	0.52	0.60	0.68	0.76	0.36	0.44	0.51	0.59
		PI	6.10	6.10	6.10	6.10	6.12	6.12	6.12	6.12	6.13	6.13	6.14	6.13	6.13	6.13	6.13	6.13
		TC	13.02	13.02	13.15	13.27	13.88	13.88	13.88	13.97	14.34	14.34	14.42	14.34	15.49	15.49	15.49	15.49
	40	S/T	0.75	0.85	0.95	1.00	0.59	0.69	0.78	0.87	0.52	0.61	0.70	0.79	0.35	0.44	0.52	0.60
		PI	6.97	6.97	6.97	6.97	7.00	7.00	7.00	7.00	7.01	7.01	7.02	7.01	7.05	7.05	7.05	7.05
		TC	12.34	12.34	12.46	12.57	13.17	13.17	13.17	13.32	13.61	13.61	13.61	13.61	14.72	14.72	14.72	14.72
	43	S/T	0.76	0.86	0.96	1.00	0.60	0.70	0.79	0.89	0.52	0.62	0.71	0.81	0.35	0.44	0.52	0.61
		PI	7.48	7.48	7.48	7.48	7.52	7.52	7.52	7.54	7.54	7.54	7.54	7.54	7.60	7.60	7.60	7.60
		TC	17.07	17.07	17.07	17.24	18.10	18.10	18.10	18.62	18.62	18.62	18.62	18.62	20.00	20.00	20.00	20.00
2100	18	S/T	0.71	0.79	0.88	0.96	0.58	0.65	0.73	0.81	0.51	0.59	0.66	0.74	0.37	0.44	0.51	0.58
		PI	4.53	4.53	4.53	4.53	4.53	4.53	4.53	4.53	4.49	4.49	4.49	4.49	4.46	4.46	4.46	4.46
		TC	15.98	15.98	16.15	16.32	16.98	16.98	16.98	17.47	17.47	17.47	17.47	18.79	18.79	18.79	18.79	18.79
	25	S/T	0.72	0.81	0.90	0.98	0.58	0.66	0.75	0.83	0.51	0.60	0.68	0.76	0.36	0.44	0.51	0.59
		PI	5.20	5.20	5.20	5.20	5.19	5.19	5.19	5.19	5.19	5.19	5.19	5.19	5.20	5.20	5.20	5.20
		TC	15.23	15.23	15.37	15.52	16.18	16.18	16.18	16.18	16.69	16.69	16.69	16.69	17.99	17.99	17.99	17.99
	30	S/T	0.73	0.83	0.91	1.00	0.59	0.67	0.76	0.85	0.52	0.60	0.68	0.77	0.36	0.44	0.51	0.59
		PI	5.69	5.69	5.69	5.69	5.70	5.70	5.70	5.70	5.71	5.71	5.71	5.71	5.73	5.73	5.73	5.73
		TC	14.45	14.45	14.60	14.74	15.40	15.40	15.40	15.40	15.86	15.86	15.86	15.86	17.13	17.13	17.13	17.13
	35	S/T	0.74	0.84	0.94	1.00	0.59	0.68	0.77	0.86	0.52	0.61	0.69	0.79	0.35	0.44	0.52	0.60
		PI	6.23	6.23	6.23	6.23	6.25	6.25	6.25	6.25	6.26	6.26	6.27	6.26	6.30	6.30	6.30	6.30
		TC	13.29	13.36	13.49	13.61	14.16	14.16	14.16	14.25	14.62	14.62	14.72	14.62	15.82	15.82	15.82	15.82
	40	S/T	0.77	0.87	0.98	1.00	0.60	0.70	0.80	0.90	0.52	0.62	0.72	0.82	0.35	0.44	0.53	0.60
		PI	7.11	7.11	7.11	7.11	7.14	7.14	7.14	7.14	7.16	7.16	7.16	7.16	7.21	7.21	7.21	7.21
		TC	12.60	12.72	12.83	12.94	13.43	13.43	13.43	13.58	13.89	13.89	13.89	13.89	15.04	15.04	15.04	15.04
	43	S/T	0.78	0.89	0.99	1.00	0.61	0.71	0.82	0.92	0.53	0.63	0.73	0.83	0.35	0.44	0.53	0.62
		PI	7.64	7.64	7.64	7.64	7.68	7.68	7.68	7.68	7.70	7.70	7.70	7.70	7.76	7.76	7.76	7.76

TC:Total Cooling Capacity (kW)

S/T:Sensible Cooling Capacity Ratio

PI:Power Input(kW)

7.2 Heating


		24k				[SI_Unit]			
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	HEATING PERFORMANCE AT INDOOR DRY BULB TEMPERATURE							
		TC:TOTAL CAPACITY IN KILOWATTS				PI: TOTAL POWER IN KILOWATTS			
		Indoor Conditions (DB C)			Indoor Conditions (DB C)				
		16.0	20.0	22.0	24.0	16.0	20.0	22.0	
820	-7.0	4.94	4.88	4.86	4.83	1.45	1.49	1.56	1.60
	-5.6	5.23	5.17	5.15	5.12	1.50	1.57	1.61	1.65
	-2.8	5.52	5.44	5.41	5.38	1.59	1.67	1.71	1.75
	0.0	5.73	5.64	5.61	5.58	1.69	1.77	1.82	1.86
	2.8	6.16	6.08	6.05	5.99	1.81	1.90	1.93	1.98
	5.6	6.80	6.72	6.69	6.63	1.92	2.01	2.06	2.10
	7.0	7.48	7.39	7.16	7.13	1.98	2.16	2.13	2.17
	11.1	7.94	7.85	7.79	7.74	2.14	2.23	2.29	2.34
	13.9	8.37	8.26	8.20	8.14	2.24	2.35	2.40	2.46
	16.7	8.81	8.69	8.63	8.58	2.34	2.46	2.52	2.57
1000	18.0	9.01	8.90	8.84	8.75	2.40	2.51	2.57	2.63
	-7.0	5.04	4.99	4.96	4.93	1.47	1.51	1.58	1.61
	-5.6	5.35	5.29	5.26	5.23	1.52	1.59	1.63	1.66
	-2.8	5.64	5.55	5.52	5.49	1.61	1.69	1.73	1.77
	0.0	5.84	5.76	5.73	5.70	1.71	1.79	1.83	1.88
	2.8	6.28	6.19	6.16	6.10	1.83	1.91	1.95	2.00
	5.6	6.95	6.86	6.80	6.77	1.93	2.03	2.08	2.12
	7.0	7.63	7.53	7.30	7.27	2.00	2.17	2.15	2.19
	11.1	8.08	8.00	7.94	7.88	2.16	2.25	2.31	2.36
	13.9	8.52	8.43	8.37	8.32	2.26	2.37	2.42	2.48
1300	16.7	8.98	8.84	8.78	8.72	2.37	2.48	2.54	2.59
	18.0	9.18	9.04	8.98	8.92	2.42	2.53	2.59	2.65
	-7.0	5.11	5.03	5.00	4.97	1.48	1.52	1.59	1.63
	-5.6	5.41	5.32	5.29	5.26	1.53	1.60	1.64	1.68
	-2.8	5.70	5.61	5.58	5.55	1.63	1.71	1.75	1.79
	0.0	5.90	5.81	5.79	5.76	1.72	1.81	1.85	1.89
	2.8	6.34	6.25	6.22	6.16	1.84	1.92	1.97	2.01
	5.6	7.04	6.92	6.89	6.83	1.95	2.05	2.10	2.14
	7.0	7.75	7.62	7.39	7.33	2.02	2.19	2.17	2.21
	11.1	8.20	8.08	8.03	7.97	2.17	2.28	2.33	2.38

36k								[SI_Unit]	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	HEATING PERFORMANCE AT INDOOR DRY BULB TEMPERATURE							
		TC:TOTAL CAPACITY IN KILOWATTS				PI: TOTAL POWER IN KILOWATTS			
		Indoor Conditions (DB C)				Indoor Conditions (DB C)			
1400	16.0	20.0	22.0	24.0	16.0	20.0	22.0	24.0	
	-7.0	7.26	7.15	7.12	7.06	2.38	2.43	2.54	2.60
	-5.6	7.67	7.55	7.52	7.47	2.44	2.56	2.62	2.68
	-2.8	8.08	7.96	7.90	7.87	2.60	2.73	2.79	2.85
	0.0	8.37	8.25	8.19	8.13	2.75	2.89	2.96	3.02
	2.8	8.98	8.86	8.80	8.75	2.94	3.09	3.16	3.23
	5.6	9.94	9.79	9.73	9.67	3.13	3.29	3.35	3.43
	7.0	10.95	10.79	10.47	10.38	3.24	3.52	3.47	3.54
	11.1	11.60	11.43	11.37	11.28	3.49	3.66	3.74	3.82
	13.9	12.21	12.07	11.98	11.89	3.66	3.84	3.93	4.01
1660	16.7	12.85	12.67	12.59	12.50	3.83	4.02	4.11	4.20
	18.0	13.14	12.96	12.88	12.79	3.92	4.11	4.20	4.28
	-7.0	7.37	7.29	7.23	7.18	2.39	2.46	2.57	2.63
	-5.6	7.82	7.73	7.67	7.61	2.47	2.59	2.65	2.71
	-2.8	8.22	8.13	8.08	8.02	2.62	2.75	2.82	2.88
	0.0	8.54	8.43	8.37	8.31	2.78	2.92	2.99	3.06
	2.8	9.18	9.06	8.98	8.92	2.98	3.12	3.19	3.27
	5.6	10.14	10.02	9.94	9.88	3.17	3.32	3.39	3.47
	7.0	11.15	11.02	10.70	10.62	3.28	3.56	3.51	3.59
	11.1	11.83	11.69	11.60	11.54	3.53	3.70	3.78	3.87
1960	13.9	12.47	12.33	12.24	12.15	3.70	3.88	3.97	4.06
	16.7	13.11	12.94	12.85	12.76	3.88	4.07	4.16	4.25
	18.0	13.43	13.25	13.17	13.05	3.96	4.15	4.25	4.34

48k								[SI_Unit]	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	HEATING PERFORMANCE AT INDOOR DRY BULB TEMPERATURE							
		TC:TOTAL CAPACITY IN KILOWATTS				PI: TOTAL POWER IN KILOWATTS			
		Indoor Conditions (DB C)				Indoor Conditions (DB C)			
1620	16.0	20.0	22.0	24.0	16.0	20.0	22.0	24.0	
	-7.0	9.85	9.74	9.69	9.63	3.14	3.22	3.37	3.44
	-5.6	10.44	10.32	10.26	10.20	3.24	3.40	3.47	3.55
	-2.8	11.02	10.87	10.81	10.73	3.44	3.61	3.69	3.78
	0.0	11.42	11.28	11.19	11.10	3.64	3.82	3.91	4.00
	2.8	12.29	12.12	12.03	11.94	3.90	4.09	4.19	4.28
	5.6	13.60	13.39	13.31	13.22	4.15	4.36	4.45	4.55
	7.0	15.03	14.80	14.37	14.25	4.30	4.68	4.61	4.70
	11.1	15.91	15.70	15.59	15.50	4.64	4.85	4.96	5.08
	13.9	16.78	16.55	16.43	16.31	4.86	5.09	5.21	5.33
1780	16.7	17.62	17.39	17.27	17.16	5.09	5.34	5.46	5.58
	18.0	18.06	17.79	17.68	17.56	5.20	5.45	5.58	5.70
	-7.0	10.06	9.95	9.87	9.81	3.18	3.25	3.41	3.48
	-5.6	10.67	10.55	10.46	10.41	3.27	3.43	3.50	3.58
	-2.8	11.25	11.10	11.02	10.96	3.47	3.64	3.73	3.81
	0.0	11.65	11.51	11.42	11.33	3.68	3.86	3.95	4.04
	2.8	12.52	12.35	12.26	12.17	3.94	4.13	4.23	4.32
	5.6	13.86	13.68	13.57	13.48	4.19	4.40	4.49	4.59
	7.0	15.29	15.10	14.63	14.54	4.34	4.72	4.65	4.75
	11.1	16.23	16.02	15.91	15.79	4.68	4.90	5.01	5.12
1916	13.9	17.10	16.87	16.75	16.63	4.90	5.14	5.26	5.38
	16.7	17.97	17.74	17.62	17.48	5.14	5.38	5.51	5.63
	18.0	18.38	18.14	18.03	17.88	5.25	5.50	5.63	5.74
	-7.0	10.20	10.06	10.00	9.95	3.21	3.29	3.43	3.51
	-5.6	10.78	10.64	10.58	10.52	3.31	3.46	3.54	3.62
	-2.8	11.36	11.22	11.13	11.07	3.51	3.68	3.77	3.85
	0.0	11.77	11.62	11.54	11.45	3.72	3.90	3.99	4.09
	2.8	12.67	12.49	12.41	12.32	3.98	4.17	4.27	4.37
	5.6	14.00	13.80	13.71	13.62	4.23	4.43	4.53	4.64
	7.0	15.46	15.24	14.78	14.69	4.38	4.76	4.69	4.79
	11.1	16.37	16.17	16.05	15.94	4.72	4.95	5.06	5.17
	13.9	17.24	17.04	16.92	16.81	4.95	5.19	5.31	5.43
	16.7	18.14	17.88	17.77	17.65	5.19	5.44	5.56	5.69
	18.0	18.55	18.32	18.17	18.06	5.30	5.55	5.68	5.80


60k								[SI_Unit]	
INDOOR AIRFLOW (CMH)	OUTDOOR DB(C)	HEATING PERFORMANCE AT INDOOR DRY BULB TEMPERATURE							
		TC:TOTAL CAPACITY IN KILOWATTS				PI: TOTAL POWER IN KILOWATTS			
		Indoor Conditions (DB C)				Indoor Conditions (DB C)			
		16.0	20.0	22.0	24.0	16.0	20.0	22.0	24.0
1730	-7.0	11.59	11.45	11.40	11.31	3.82	3.92	4.10	4.20
	-5.6	12.26	12.12	12.06	11.97	3.94	4.13	4.23	4.33
	-2.8	12.93	12.76	12.67	12.61	4.19	4.40	4.50	4.61
	0.0	13.42	13.22	13.13	13.05	4.44	4.66	4.76	4.87
	2.8	14.41	14.21	14.12	14.03	4.74	4.97	5.09	5.21
	5.6	15.95	15.71	15.63	15.51	5.05	5.30	5.42	5.54
	7.0	17.61	17.36	16.83	16.72	5.22	5.68	5.59	5.72
	11.1	18.66	18.40	18.28	18.17	5.63	5.90	6.04	6.17
	13.9	19.65	19.39	19.27	19.13	5.91	6.19	6.34	6.48
	16.7	20.66	20.37	20.23	20.11	6.19	6.49	6.63	6.78
1920	18.0	21.13	20.84	20.72	20.58	6.32	6.62	6.77	6.92
	-7.0	11.84	11.67	11.62	11.53	3.86	3.96	4.15	4.24
	-5.6	12.52	12.35	12.29	12.21	3.98	4.18	4.28	4.37
	-2.8	13.19	13.02	12.93	12.84	4.24	4.45	4.55	4.65
	0.0	13.68	13.48	13.39	13.31	4.49	4.71	4.81	4.92
	2.8	14.70	14.50	14.41	14.29	4.79	5.03	5.14	5.26
	5.6	16.26	16.03	15.92	15.83	5.10	5.35	5.48	5.60
	7.0	17.96	17.70	17.18	17.07	5.28	5.74	5.65	5.78
	11.1	19.04	18.78	18.66	18.52	5.69	5.96	6.10	6.24
	13.9	20.05	19.79	19.65	19.50	5.97	6.26	6.40	6.55
2100	16.7	21.07	20.78	20.66	20.52	6.25	6.56	6.70	6.85
	18.0	21.56	21.27	21.13	20.98	6.39	6.69	6.84	6.99
	-7.0	11.94	11.80	11.72	11.66	3.90	4.00	4.19	4.28
	-5.6	12.64	12.50	12.41	12.35	4.02	4.22	4.32	4.42
	-2.8	13.34	13.16	13.08	12.99	4.28	4.49	4.59	4.70
	0.0	13.83	13.63	13.54	13.45	4.54	4.75	4.86	4.97
	2.8	14.84	14.64	14.55	14.44	4.84	5.08	5.20	5.32
	5.6	16.41	16.21	16.09	15.97	5.16	5.41	5.53	5.66
	7.0	18.10	17.88	17.36	17.24	5.33	5.80	5.71	5.84
	11.1	19.21	18.95	18.84	18.72	5.75	6.03	6.17	6.30
	13.9	20.26	19.97	19.85	19.71	6.03	6.33	6.47	6.61
	16.7	21.27	20.98	20.84	20.69	6.32	6.62	6.77	6.92
	18.0	21.77	21.48	21.33	21.19	6.46	6.76	6.91	7.07

8. Noise Criterion Curves



Notes:

- Sound measured at 1.4m away from the noisiest location of the unit.
- Data is valid at free field condition
- Data is valid at nominal operation condition
- Reference acoustic pressure OdB = 20µPa
- Sound level will vary depending on a range of factors such as the construction -(acoustic absorption coefficient) of particular room in which the equipment is installed.
- The operating conditions are assumed to be standard.



9. Electrical Characteristics


Capacity (Btu/h)		24k	36k	48k~60k
Indoor Unit Power	Phase	1-phase		3-phase
	Frequency and Voltage	220-240V, 50Hz		380-415V, 50Hz
	Power Wiring (mm ²)	3x2.5		5x2.5
	Circuit Breaker/ Fuse (A)	32/25		32/25
Outdoor Unit Power	Phase		3-phase	
	Frequency and Voltage		380-415V, 50Hz	
	Power Wiring (mm ²)		5x2.5	
	Circuit Breaker/ Fuse (A)		25/20	
Indoor/Outdoor Connecting Wiring	Weak Electric Signal) (mm ²)	2x0.5		
	Strong Electric Signal(mm ²)	3x2.5/3x1.0	3x1.5/3x1.0	5x2.5/3x1.0


10. Electrical Wiring Diagrams

IDU Capacity (Btu/h)	IDU Wiring Diagram
24k	16022500005063
36k~60k	16022500005143


Abbreviation	Paraphrase
Y/G	Yellow-Green Conductor
CAP1	Indoor Fan Capacitor
FAN1	Indoor Fan Motor
M	Swing Motor
PUMP	PUMP
L	LIVE
N	NEUTRAL
T1	Indoor Room Temperature
T2	Coil Temperature of Indoor Heat Exchanger

Indoor unit wiring diagram:16022500005143





10.1 Some connectors introduce:





A For remote control (ON-OFF) terminal port CN23 and short connector of JR6

1. Remove the short connector of JR6 when you use ON-OFF function;
2. When remote switch off (OPEN) ;the unit would be off;
3. When remote switch on (CLOSE) ;the unit would be on;
4. When close/open the remote switch, the unit would be responded the demand within 2 seconds;
5. When the remote switch on. you can use remote controller/ wire controller to select the mode what you want ;when the remote switch off , the unit would not respond the demand from remote controller/wire controller.

when the remote switch off , but the remote controller / wire controller are on, CP code would be shown on the display board.


- 6.The voltage of the port is 12V DC , design Max.current is 5mA.






B For ALARM terminal port CN33


1. Provide the terminal port to connect ALARM ,but no voltage of the terminal port , the power from the ALARM system (not from the unit)
2. Although design voltage can support higher voltage ,but we strongly ask you connect the power less than 24V, current less than 0.5A
3. When the unit occurs the problem , the relay would be closed , then ALARM works





C. For new fresh motor terminal port CN8

1. Connect the fan motor to the port , no need care L/N of the motor ;
2. The output voltage is the power supply;
3. The fresh motor can not excess 200W or 1A , follow the smaller one ;
4. The new fresh motor will be worked when the indoor fan motor work ;when the indoor fan motor stops , the new fresh motor would be stopped ;
5. When the unit enter force cooling mode or capacity testing mode , the fresh motor isn't work .




10.2 Micro-Switch Introduce:



SW3	SWITCH	FOR AUTO-RESTART SETTING
ON	ON	ON
STATE		
MODE	REMEMBER	NO_REMEMBER
Factory Setting	<input checked="" type="checkbox"/>	

A. Micro-switch SW3 is for selection of auto-restart function.

Range: Active, inactive



SWITCH FOR CCM UNIT ADDRESS	
S2	<input type="checkbox"/> OFF
+ S1	<input type="checkbox"/> ON
ADDRESS	0~15 16~31
Factory Setting	<input checked="" type="checkbox"/>
S2	<input type="checkbox"/> OFF
+ S1	<input type="checkbox"/> ON
ADDRESS	32~47 48~63
Factory Setting	

B. Micro-switch S1 and dial-switch S2 are for address setting when you want to control this unit by a central controller.

Range: 00-63

Outdoor Unit

Contents


1.	Dimensional Drawings	2
2.	Service Place.....	12
3.	Capacity Correction Factor for Height Difference	13
4.	Noise Criterion Curves.....	18
5.	Refrigerant Cycle Diagrams	20
6.	Electrical Wiring Diagrams.....	22

1. Dimensional Drawings


Please check the corresponding dimensional drawing according to the panel plate.

ODU Model	Panel Plate
YFAD-035R-01M25	X330
YFAD-050R-01M25	X330
YFAD-070R-01M25	X430
YFAD-100R-01T35	D30
YFAD-140R-01T35	590

Panel Plate B30




Panel Plate BA30






◀ Outdoor Unit 4 ▶


Panel Plate CA30




Panel Plate D30



Panel Plate X230




Panel Plate X330




◀ Outdoor Unit 8 ▶


Panel Plate X430




Panel Plate E30



Panel Plate 590



2. Service Place



3. Capacity Correction Factor for Height Difference

Capacity(Btu/h)	12k		Pipe Length (m)		
	Cooling		5	8	15
Height difference H (m)	Indoor Upper than Outdoor	8		0.972	0.941
		5	0.995	0.982	0.950
		0	1.000	0.986	0.955
	Outdoor Upper than Indoor	-5	1.000	0.986	0.955
		-8		0.986	0.955
	Heating		5	8	15
Height difference H (m)	Indoor Upper than Outdoor	8		0.994	0.981
		5	1.000	0.994	0.981
		0	1.000	0.994	0.981
	Outdoor Upper than Indoor	-5	0.992	0.986	0.973
		-8		0.979	0.966

Capacity(Btu/h)	18k		Pipe Length (m)		
	Cooling		5	10	15
Height difference H (m)	Indoor Upper than Outdoor	15		0.915	0.861
		10		0.957	0.929
		5	0.995	0.967	0.939
		0	1.000	0.972	0.944
	Outdoor Upper than Indoor	-5	1.000	0.972	0.944
		-10		0.972	0.944
		-15			0.944
	Heating		5	10	20
Height difference H (m)	Indoor Upper than Outdoor	15		0.977	0.953
		10		0.988	0.977
		5	1.000	0.988	0.977
		0	1.000	0.988	0.977
	Outdoor Upper than Indoor	-5	0.992	0.980	0.969
		-10		0.973	0.961
		-15			0.953
	30				

Capacity(Btu/h)	24k		Pipe Length (m)			
	Cooling		5	10	15	25
Height difference H (m)	Indoor Upper than Outdoor	15			0.900	0.830
		10		0.949	0.914	0.842
		5	0.995	0.959	0.923	0.851
	Outdoor Upper than Indoor	0	1.000	0.964	0.928	0.855
		-5	1.000	0.964	0.928	0.855
		-10		0.964	0.928	0.855
		-15			0.928	0.855
Heating			5	10	20	30
Height difference H (m)	Indoor Upper than Outdoor	15			0.973	0.946
		10		0.987	0.973	0.946
		5	1.000	0.987	0.973	0.946
	Outdoor Upper than Indoor	0	1.000	0.987	0.973	0.946
		-5	0.992	0.979	0.965	0.938
		-10		0.971	0.957	0.931
		-15			0.950	0.923

Capacity (Btu/h)	30k		Pipe Length (m)					
	Cooling		5	10	15	20	25	
Height difference H (m)	Indoor Upper than Outdoor	20				0.838	0.798	0.759
		15			0.890	0.850	0.810	0.770
		10		0.944	0.904	0.863	0.823	0.782
		5	0.995	0.954	0.913	0.872	0.831	0.790
	Outdoor Upper than Indoor	0	1.000	0.959	0.918	0.876	0.835	0.794
		-5	1.000	0.959	0.918	0.876	0.835	0.794
		-10		0.959	0.918	0.876	0.835	0.794
		-15			0.918	0.876	0.835	0.794
Heating			5	10	15	20	25	
Height difference H (m)	Indoor Upper than Outdoor	20				0.941	0.922	0.902
		15			0.961	0.941	0.922	0.902
		10		0.980	0.961	0.941	0.922	0.902
		5	1.000	0.980	0.961	0.941	0.922	0.902
	Outdoor Upper than Indoor	0	1.000	0.980	0.961	0.941	0.922	0.902
		-5	0.992	0.973	0.953	0.934	0.914	0.895
		-10		0.965	0.945	0.926	0.907	0.888
		-15			0.938	0.919	0.900	0.881
						0.911	0.892	0.873


Capacity (Btu/h)	36k		Pipe Length (m)					
	Cooling		5	10	15	20	25	30
Height difference H (m)	Indoor Upper than Outdoor	20				0.820	0.775	0.729
		15			0.878	0.832	0.786	0.740
		10		0.938	0.892	0.845	0.798	0.752
		5	0.995	0.948	0.901	0.854	0.806	0.759
	Outdoor Upper than Indoor	0	1.000	0.953	0.905	0.858	0.810	0.763
		-5	1.000	0.953	0.905	0.858	0.810	0.763
		-10		0.953	0.905	0.858	0.810	0.763
		-15			0.905	0.858	0.810	0.763
		-20				0.858	0.810	0.763
Heating			5	10	15	20	25	30
Height difference H (m)	Indoor Upper than Outdoor	20				0.935	0.914	0.892
		15			0.957	0.935	0.914	0.892
		10		0.978	0.957	0.935	0.914	0.892
		5	1.000	0.978	0.957	0.935	0.914	0.892
	Outdoor Upper than Indoor	0	1.000	0.978	0.957	0.935	0.914	0.892
		-5	0.992	0.971	0.949	0.928	0.906	0.885
		-10		0.963	0.942	0.920	0.899	0.878
		-15			0.934	0.913	0.892	0.871
		-20				0.906	0.885	0.864
Capacity (Btu/h)	42k		Pipe Length (m)					
	Cooling		5	10	20	30	40	50
Height difference H (m)	Indoor Upper than Outdoor	30				0.820	0.766	0.712
		20			0.888	0.833	0.778	0.723
		10		0.957	0.901	0.846	0.790	0.734
		5	0.995	0.967	0.910	0.854	0.798	0.741
	Outdoor Upper than Indoor	0	1.000	0.972	0.915	0.858	0.802	0.745
		-5	1.000	0.972	0.915	0.858	0.802	0.745
		-10		0.972	0.915	0.858	0.802	0.745
		-20			0.915	0.858	0.802	0.745
		-30				0.858	0.802	0.745
Heating			5	10	20	30	40	50
Height difference H (m)	Indoor Upper than Outdoor	30				0.936	0.911	0.885
		20			0.962	0.936	0.911	0.885
		10		0.987	0.962	0.936	0.911	0.885
		5	1.000	0.987	0.962	0.936	0.911	0.885
	Outdoor Upper than Indoor	0	1.000	0.987	0.962	0.936	0.911	0.885
		-5	0.992	0.979	0.954	0.929	0.903	0.878
		-10		0.971	0.946	0.921	0.896	0.871
		-20			0.939	0.914	0.889	0.864
		-30				0.907	0.882	0.857

Capacity (Btu/h)	48k		Pipe Length (m)					
	Cooling		5	10	20	30	40	50
Height difference H (m)	Indoor Upper than Outdoor	30				0.808	0.749	0.690
		20			0.880	0.820	0.760	0.701
		10		0.955	0.894	0.833	0.772	0.711
		5	0.995	0.964	0.903	0.841	0.780	0.718
		0	1.000	0.969	0.907	0.846	0.784	0.722
	Outdoor Upper than Indoor	-5	1.000	0.969	0.907	0.846	0.784	0.722
		-10		0.969	0.907	0.846	0.784	0.722
		-20			0.907	0.846	0.784	0.722
		-30				0.846	0.784	0.722
	Heating		5	10	20	30	40	50
Height difference H (m)	Indoor Upper than Outdoor	30				0.929	0.901	0.873
		20			0.958	0.929	0.901	0.873
		10		0.986	0.958	0.929	0.901	0.873
		5	1.000	0.986	0.958	0.929	0.901	0.873
		0	1.000	0.986	0.958	0.929	0.901	0.873
	Outdoor Upper than Indoor	-5	0.992	0.978	0.950	0.922	0.894	0.866
		-10		0.970	0.942	0.915	0.887	0.859
		-20			0.935	0.907	0.880	0.852
		-30				0.900	0.873	0.845

Capacity (Btu/h)	55k		Pipe Length (m)					
	Cooling		5	10	20	30	40	50
Height difference H (m)	Indoor Upper than Outdoor	30				0.786	0.719	0.651
		20			0.867	0.798	0.730	0.661
		10		0.950	0.880	0.810	0.741	0.671
		5	0.995	0.960	0.889	0.819	0.748	0.678
		0	1.000	0.965	0.894	0.823	0.752	0.681
	Outdoor Upper than Indoor	-5	1.000	0.965	0.894	0.823	0.752	0.681
		-10		0.965	0.894	0.823	0.752	0.681
		-20			0.894	0.823	0.752	0.681
		-30				0.823	0.752	0.681
	Heating		5	10	20	30	40	50
Height difference H (m)	Indoor Upper than Outdoor	30				0.918	0.886	0.853
		20			0.951	0.918	0.886	0.853
		10		0.984	0.951	0.918	0.886	0.853
		5	1.000	0.984	0.951	0.918	0.886	0.853
		0	1.000	0.984	0.951	0.918	0.886	0.853
	Outdoor Upper than Indoor	-5	0.992	0.976	0.943	0.911	0.879	0.846
		-10		0.968	0.936	0.904	0.872	0.839
		-20			0.928	0.896	0.865	0.833
		-30				0.889	0.858	0.826

Capacity (Btu/h)	60k		Pipe Length (m)					
	Cooling		5	10	20	30	40	50
Height difference H (m)	Indoor Upper than Outdoor	30				0.772	0.698	0.625
		20			0.858	0.784	0.709	0.634
		10		0.947	0.871	0.796	0.720	0.644
		5	0.995	0.957	0.880	0.804	0.727	0.650
		0	1.000	0.962	0.885	0.808	0.731	0.654
	Outdoor Upper than Indoor	-5	1.000	0.962	0.885	0.808	0.731	0.654
		-10		0.962	0.885	0.808	0.731	0.654
		-20			0.885	0.808	0.731	0.654
		-30				0.808	0.731	0.654
	Heating		5	10	20	30	40	50
Height difference H (m)	Indoor Upper than Outdoor	30				0.909	0.872	0.836
		20			0.945	0.909	0.872	0.836
		10		0.982	0.945	0.909	0.872	0.836
		5	1.000	0.982	0.945	0.909	0.872	0.836
		0	1.000	0.982	0.945	0.909	0.872	0.836
	Outdoor Upper than Indoor	-5	0.992	0.974	0.938	0.902	0.865	0.829
		-10		0.966	0.930	0.894	0.858	0.823
		-20			0.923	0.887	0.852	0.816
		-30				0.880	0.845	0.810

4. Noise Criterion Curves




Note: $H = 0.5 \times \text{height of outdoor unit}$


Notes:

- Sound measured at 1.0m away from the center of the unit.
- Data is valid at free field condition
- Data is valid at nominal operation condition
- Reference acoustic pressure $OdB=20\mu Pa$
- Sound level will vary depending on arrangement of actors such as the construction (acoustic absorption coefficient) of particular room in which the equipment is installed.
- The operating conditions are assumed to be standard.


YFAD-035R-01M25




YFAD-050R-01M25




YFAD-070R-01M25



YFAD-100R-01T35




YFAD-140R-01T35




5. Refrigerant Cycle Diagrams

5.1 Cooling Only




Model No.	Pipe Size (Diameter:Ø) mm(inch)		Piping length (m/ft)		Elevation (m/ft)		Additional Refrigerant
	Gas	Liquid	Rated	Max.	Rated	Max.	
12k	12.7(1/2)	6.35(1/4)	5/16.4	15/49.2	0	8/26.3	15g/m (0.16oz/ft)


5.2 Heat Pump




Model No.	Pipe Size (Diameter:Ø) mm(inch)		Piping length (m/ft)		Elevation (m/ft)		Additional Refrigerant
	Gas	Liquid	Rated	Max.	Rated	Max.	
12k	12.7(1/2)	6.35(1/4)	5/16.4	15/49.2	0	8/26.3	15g/m (0.16oz/ft)
18k	12.7(1/2)	6.35(1/4)	5/16.4	25/82	0	15/49.2	



Model No.	Pipe Size (Diameter:∅) mm(inch)		Piping length (m/ft)		Elevation (m/ft)		Additional Refrigerant
	Gas	Liquid	Rated	Max.	Rated	Max.	
24k	15.9(5/8)	9.52(3/8)	5/16.4	25/82	0	15/49.2	30g/m (0.32oz/ft)



Model No.	Pipe Size (Diameter:Ø) mm(inch)		Piping length (m/ft)		Elevation (m/ft)		Additional Refrigerant
	Gas	Liquid	Rated	Max.	Rated	Max.	
36k	19(3/4)	9.52(3/8)	5/16.4	30/98.4	0	20/65.6	30g/m (0.32oz/ft)




Model No.	Pipe Size (Diameter:Ø) mm(inch)		Piping length (m/ft)		Elevation (m/ft)		Additional Refrigerant
	Gas	Liquid	Rated	Max.	Rated	Max.	
48k/60k	19(3/4)	9.52(3/8)	5/16.4	50/164	0	30/98.4	30g/m (0.32oz/ft)

6. Electrical Wiring Diagrams


ODU Model	ODU Wiring Diagram
YFAD-035R-01M25	16023000004182
YFAD-050R-01M25	16023000004182
YFAD-070R-01M25	16022700001316
YFAD-100R-01T35	16022000029729
YFAD-140R-01T35	16022000033211

Abbreviation	Paraphrase
COMP	Compressor
CAP1	Compressor Capacitor
FAN	Outdoor Fan Motor
CAP2/CAP3/CAP4	Outdoor Fan Capacitor
RT3/T3	Pipe Temperature Sensor
RT4/RT6	Outdoor Room Temperature Sensor
KM	AC Contactor
S.V.	4-way Valve
H-PRO/K1	High Pressure Switch/Shorting Stub
L-PRO/K2	Low Pressure Switch/Shorting Stub
K3	Gas Temperature Protector
Trans/T5	Power Transformer
CT1	Current Detector


Outdoor unit wiring diagram: 16022000033609




Outdoor unit wiring diagram:16023000004182




Outdoor unit wiring diagram:16022700001316




Outdoor unit wiring diagram: 16022000029729



Outdoor unit wiring diagram: 16022000033211



Outdoor unit wiring diagram: 16022000034793




Installation

Contents

1. Installation Overview
2. Location Selection
3. Indoor Unit Installation
4. Outdoor Unit Installation
5. Drainage Pipe Installation
6. Refrigerant Pipe Installation
7. Vacuum Drying and Leakage Checking
8. Additional Refrigerant Charge
9. Engineering of Insulation
10. Engineering of Electrical Wiring
11. Test Operation

1. Installation Overview




2. Location selection

2.1 Unit location selection can refer to installation manual.

2.2 DO NOT install the unit in the following locations:

- Where oil drilling or fracking is taking place.
- Coastal areas with high salt content in the air.
- Areas with caustic gases in the air, such as near hot springs.
- Areas with power fluctuations, such as factories.
- Enclosed spaces, such as cabinets.
- Areas with strong electromagnetic waves.
- Areas that store flammable materials or gas.
- Rooms with high humidity, such as bathrooms or laundry rooms.
- If possible, DO NOT install the unit where it is exposed to direct sunlight.


2.3 The minimum distance between the outdoor unit and walls described in the installation guide does not apply to airtight rooms. Be sure to keep the unit unobstructed in at least two of the three directions (M, N, P)




2.4 Rows of series installation

The relations between H, A and L are as follows.


	L	A
L ≤ H	L ≤ 1/2H	25 cm / 9.8" or more
	1/2H < L ≤ H	30 cm / 11.8" or more
L > H	Can not be installed	



DO NOT install the rows of series like following figure.




2.5. If the location is exposed to strong winds (for example: near a seaside), the unit must be placed against the wall to shelter it from the wind. If necessary, use an awning.




3. Indoor Unit Installation(Duct)

3.1 Service space for indoor unit



3.2 Hang Indoor Unit

1. Please refer to the following diagrams to locate the four positioning screw bolt hole on the ceiling. Be sure to mark the areas where ceiling hook holes will be drilled.



2. Install and fit pipes and wires after you have finished installing the main body. When choosing where to start, determine the direction of the pipes to be drawn out.


Especially in cases where there is a ceiling involved, align the refrigerant pipes, drain pipes, and indoor and outdoor lines with their connection points before mounting the unit..

3. Install hanging screw bolts.


- 1) Cut off the roof beam.
- 2) Strengthen the point at which the cut was made. Consolidate the roof beam..
4. After you select an installation location, align the refrigerant pipes, drain pipes, as well as indoor and outdoor wires with their connection points before mounting the unit..

5. Drill 4 holes 10cm (4") deep at the ceiling hook positions in the internal ceiling. Be sure to hold the drill at a 90° angle to the ceiling.

6. Secure the bolt using the included washers and nuts.
7. Install the four suspension bolts.
8. Mount the indoor unit with at least two people to lift and secure it. Insert suspension bolts into the unit's hanging holes. Fasten them using the washers and nuts provided.




9. Mount the indoor unit onto the hanging screw bolts with a block. Position the indoor unit flat using a level indicator to prevent leaks.



Note: Confirm the minimum drain tilt is 1/100 or more.

3.3 Duct and accessories installation

1. Install the filter(optional) according to air inlet size.
2. Install the canvas tie-in between the body and duct.
3. The air inlet and air outlet duct should be far enough apart enough to a avoid air passage short-circuit.
4. Connect the duct according to the following diagram.




5. For DC motor models, you can change the fan motor static pressure according to external duct static pressure.


- **NOTE:** 1. Do not put the connecting duct weight on the indoor unit.
- 2. When connecting the duct, use an nonflammable canvas tie-in to prevent vibrating.
- 3. When connecting duct, install in place prone to takedown for maintenance.
- 4. Change the fan motor static pressure corresponding to external duct static pressure.
- 5. If installed in place like meeting room where noise is easy to be perceived, design isolation booth and internal duct underlayer to muffle the duct system and weaken the air encounter noise in the duct.

3.4 Adjust the air inlet direction(From rear side to under-side.)


1. Take off ventilation panel and flange,




Bend the rear ventilation panel 90 degrees along the dotted line into a descending ventilation panel.(some models)




2. Change the mounting positions of ventilation panel and air return flange .



3. When installing the filter mesh, fit it into the flange as illustrated in the following figure.




Or



NOTE: All the figures in this manual are for demonstration purposes only. The air conditioner you have purchased may be slightly different in design, though similar in shape.

3.5 Fresh air duct installation


Dimension :



3.6 Horizontal Installation(only for A6 duct type)


3.6.1 With External pump (9K, 12K models)

Cut both ends of the rubber hose into a straight one, use it to connect the drain Connector A and the external pump and safety it with clamps on both ends. Then connect the drainpipe to the Connector B.



3.6.2 With External pump (18K model only)

Drain connector A, B & C are covered with caps originally. Take the cap on drain connector B off, connect the external pump to drain connector B using a hose & two hose clamps. Then connect the drainpipe to the connector D.



Plug the external pump to the "PUMP" pin and the water level sensor to the "CN5" to enable the pump.





Fig. 1

3.6.3 With Built-in pump (24K, 36K, 48K models)

Drain connector A, B & C are covered with caps originally. Connect the drainpipe to the connector D.



3.7 Vertical Installation(only for A6 duct type)


3.7.1 No need pump (Disable pump)


The pump must be disabled while the unit is installed vertically or the pump assembly is removed from its original position.

Open the cover of E-Parts Box assembly, unplug the "PUMP" pin to disable the pump function, and short connect "CN5" plug to disable the water level sensor. (see Fig. 1)

3.7.2 Drain pipe connecting


When installed vertically (up flow), the pump must be disabled firstly. Follow the 3.7.1 steps to disable the pump. For the unit with external pump (9K, 12K & 18K models), the whole pump assembly can be removed. Then take the cap on drain connector off and connect the drainpipe to drain connector .





3. Indoor Unit Installation(Compact Cassette Type)



3.1 Service space for indoor unit



3.2 Hang Indoor Unit

1. Use the included paper template to cut a rectangular hole in the ceiling, leaving at least 1m (39.4") on all sides. The cut hole size should be 4cm(1.6") larger than the body size.

Be sure to mark the areas where ceiling hook holes will be drilled.




- 1 Suspension bolt pitch dimensions
- 2 Body dimensions
- 3 Decoration panel dimensions
- 4 Refrigerant piping
- 5 Suspension bolt (x4)
- 6 Ceiling opening dimensions
- 7 Hanger bracket
- 8 Ceiling board

2. Drill 4 holes 5cm (2") deep at the ceiling hook positions in the internal ceiling. Be sure to hold the drill at a 90° angle to the ceiling.
3. Using a hammer, insert the ceiling hooks into the pre-drilled holes. Secure the bolt using the included washers and nuts.
4. Install the four suspension bolts




5. Mount the indoor unit. You will need two people to lift and secure it. Insert suspension bolts into the unit's hanging holes. Fasten them using the included washers and nuts



Adjust the position to ensure the gaps between the indoor


unit and the four sides of false ceiling are even. The bottom of the unit should be 24mm / 0.9in higher than ceiling board. Generally, L should be half the length of the suspension bolt or long enough to prevent the nuts from coming off.



CAUTION:

Ensure that the unit is completely level.

The unit is equipped with a built-in drain pump and float switch. If the unit is tilted against the direction of condensate flows (the drainpipe side is raised), the float switch may malfunction and cause water to leak.




NOTE FOR NEW HOME INSTALLATION


When installing the unit in a new home, the ceiling hooks can be embedded in advance. Make sure that the hooks do not come loose due to concrete shrinkage. After installing the indoor unit, fasten the installation paper template onto the unit with bolts (M6X12) to determine in advance the dimension and position of the opening on the ceiling. Follow the instructions above for the remainder of the installation.

3.3.1 Remove the front grille

- Slide the 2 grille hooks toward the middle of the decoration panel.




- Hold the grille at a 45° angle, lift it up slightly and detach it from the main body.




3.3.2 Install the panel

- Align the indicate "△" on the decoration panel to the indicate "△" on the unit .
- Attach the decoration panel to the unit with the supplied screws as shown in figure below.




- After installing the panel, ensure that there is no space between the unit body and decoration panel. Otherwise air may leak through the gap and cause dewdrop.




3.3 Compact Cassette Panel Installation

3.3.3 Mount the grille


Ensure that the buckles at the back of the grille be properly seated in the groove of the panel.




3.3.6 Close the front grille, and close the two grille hooks.



3.3.4 Connect the two wires of the panel to the main board of the unit.




3.3.5 Fasten the control box lid with two screws .



3. Indoor Unit Installation(Super-slim Cassette Type)


3.1 Service space for indoor unit



3.2 Hang Indoor Unit

1. Use the included paper template to cut a rectangular hole in the ceiling, leaving at least 1m (39.4") on all sides. The cut hole size should be 4cm(1.6") larger than the body size.

Be sure to mark the areas where ceiling hook holes will be drilled.




2. Drill 4 holes 12cm-15.5cm (4.7"-6.1") deep at the ceiling hook positions in the internal ceiling. Be sure to hold the drill at a 90° angle to the ceiling.

3. Using a hammer, insert the ceiling hooks into the pre-drilled holes. Secure the bolt using the included washers and nuts.

4. Install the four suspension bolts




5. Mount the indoor unit. You will need two people to lift and secure it. Insert suspension bolts into the unit's hanging holes. Fasten them using the included washers and nuts



Adjust the position to ensure the gaps between the indoor unit and the four sides of false ceiling are even. The bottom of the unit should be 10 - 25mm (0.4-0.98") higher than ceiling board.


Generally, L should be half the length of the suspension bolt or long enough to prevent the nuts from coming off



CAUTION:

Ensure that the unit is completely level.

The unit is equipped with a built-in drain pump and float switch. If the unit is tilted against the direction of condensate flows (the drainpipe side is raised), the float switch may malfunction and cause water to leak.



NOTE FOR NEW HOME INSTALLATION

When installing the unit in a new home, the ceiling hooks can be embedded in advance. Make sure that the hooks do not come loose due to concrete shrinkage. After installing the indoor unit, fasten the installation paper template onto the unit with bolts (M6X12) to determine in advance the dimension and position of the opening on the ceiling. Follow the instructions above for the remainder of the installation.

3.3 Panel Installation of Super-slim Cassette


3.3.1 Remove the front grille

1. Push one side of the grille screw cover then remove the grid screw.


2. Push both of the tabs towards the middle

simultaneously to unlock the hook on the grille.

3. Hold the grille at a 45° angle, lift it up slightly and detach it from the main body



3.3.2 Remove the installation covers at the four corners by sliding them outwards.




3.3.3 Install the panel


1. Align the front panel to the main body, taking into account the position of the piping and drain sides. Hang the four latches of the decorative panel to the hooks of the indoor unit. Tighten the panel hook screws evenly at the four corners.

Note: Tighten the screws until the thickness of the sponge between the main body and the panel reduces to 4-6mm (0.2-0.3"). The edge of the panel should be in contact with the ceiling well.


2. Adjust the panel by turning it to the direction of arrow shown in figure below so that the ceiling opening is completely covered.



NOTE: If the height of the indoor unit needs to be adjusted, you can do so through the openings at the panel's four corners. Make sure that the internal wiring and drainpipe are not affected by this adjustment.



Failure to tighten screws can cause water leakage.




If the unit is not hung correctly and a gap exists, the unit's height must be adjusted to ensure proper function. The unit's height can be adjusted by loosening the upper nut, and adjusting the lower nut.

3. Hang the intake grille on the panel, and then connect the lead connectors of the louver motor and the control box on the panel to the corresponding connectors of the main body.

4. Re-installed into the style grid.

5. Reinstall the installation cover.

Fix the installation cover plate rope to the pillar of the installation cover plate, and gently press the installation cover plate into the panel.




When installing the cover, slide the four slide fasteners into the corresponding slots on the panel.


NOTE: After installation, the butt plugs of display, swing, water pump and other wire bodies must be placed in the electric control box.

4. Outdoor unit installation

4.1 Service space for outdoor unit




4.2 Bolt pitch



Panel Plate	Unit	D	A	B	C
B30	mm	333	514	340	365
	inch	13.11	20.23	13.39	14.37
CA30	mm	363	540	350	375
	inch	14.29	21.26	13.78	14.8
D30	mm	410	673	403	455
	inch	16.14	26.50	15.87	17.9
X2	mm	303	452	286	314
	inch	11.93	17.80	11.26	12.36
X3	mm	330	511	317	346
	inch	12.99	20.12	12.48	13.62
X4	mm	342	663	354	394
	inch	13.46	26.1	13.94	15.5
E30	mm	415	634	404	457
	inch	16.34	24.96	15.9	17.99
590	mm	350	590	378	400
	inch	13.78	23.23	14.88	15.75

4.3 Install Outdoor Unit

Fix the outdoor unit with anchor bolts(M10)



Caution

Since the gravity center of the unit is not at its physical center, so please be careful when lifting it with a sling.

Never hold the inlet of the outdoor unit to prevent it from deforming.

Do not touch the fan with hands or other objects.

Do not lean it more than 45°, and do not lay it sidelong.

Make concrete foundation according to the specifications of the outdoor units.

Fasten the feet of this unit with bolts firmly to prevent it from collapsing in case of earthquake or strong wind.

5. Drainage Pipe Installation

Install the drainage pipe as shown below and take measures against condensation. Improperly installation could lead to leakage and eventually wet furniture and belongings.

5.1 Installation principle

- Ensure at least 1/100 slope of the drainage pipe
- Adopt suitable pipe diameter
- Adopt nearby condensate water discharge

5.2 Key points of drainage water pipe installation

1. Considering the pipeline route and elevation.

- Before installing condensate water pipeline, determine its route and elevation to avoid intersection with other pipelines and ensure slope is straight.

2. Drainage pipe selection

- The drainage pipe diameter shall not be smaller than the drain hose of indoor unit
- According to the water flowrate and drainage pipe slope to choose the suitable pipe, the water flowrate is decided by the capacity of indoor unit.

Relationship between water flowrate and capacity of indoor unit

Capacity (kBtu/h)	Water flowrate (l/h)
12	2.4
18	4
24	6
30	7
36	8
42	10
48	12
60	14

According to the above table to calculate the total water flowrate for the confluence pipe selection.

For horizontal drainage pipe (The following table is for reference)

PVC pipe	Reference value of inner diameter of pipe (mm)	Allowable maximum water flowrate (l/h)		Remark
		Slope 1/50	Slope 1/100	
PVC25	20	39	27	For branch pipe
PVC32	25	70	50	
PVC40	31	125	88	Could be used for confluence pipe
PVC50	40	247	175	
PVC63	51	473	334	

Attention: Adopt PVC40 or bigger pipe to be the main pipe.

For Vertical drainage pipe (The following table is for reference)

PVC pipe	Reference value of inner diameter of pipe (mm)	Allowable maximum water flowrate (l/h)	Remark
PVC25	20	220	For branch pipe
PVC32	25	410	
PVC40	31	730	
PVC50	40	1440	Could be used for confluence pipe
PVC63	51	2760	
PVC75	67	5710	
PVC90	77	8280	


Attention: Adopt PVC40 or bigger pipe to be the main pipe.

3. Individual design of drainage pipe system


- The drainage pipe of air conditioner shall be installed separately with other sewage pipe, rainwater pipe and drainage pipe in building.
- The drainage pipe of the indoor unit with water pump should be apart from the one without water pump.


4. Supporter gap of drainage pipe

- In general, the supporter gap of the drainage pipe horizontal pipe and vertical pipe is respectively 1m~1.5m and 1.5m~2.0m.
- Each vertical pipe shall be equipped with not less than two hangers.
- Overlarge hanger gap for horizontal pipe shall create bending, thus leading to air block.



5. The horizontal pipe layout should avoid converse flow or bad flow






- The correct installation will not cause converse water flow and the slope of the branch pipes can be adjusted freely
- The false installation will cause converse water flow and the slope of the branch pipe can not be adjusted.

6. Water storage pipe setting

- If the indoor unit has high extra static pressure and without water pump to elevate the condensate water, such as high extra static pressure duct unit , the water storage pipe should be set to avoid converse flow or blow water phenomena.




7. Lifting pipe setting of indoor unit with water pump

- The length of lifting pipe should not exceed 750mm/29.5in;

The drainage pipe should be set down inclined after the lifting pipe immediately to avoid wrong operation of water level switch.

- Refer the following picture for installation reference.




8. Blowhole setting

- For the concentrated drainage pipe system, there should design a blowhole at the highest point of main pipe to ensure the condensate water discharge smoothly.
- The air outlet shall face down to prevent dirt enter-

ing pipe.

- Each indoor unit of the system should be installed it.
- The installation should be considering the convenience for future cleaning.



9. The end of drainage pipe shall not contact with ground directly.

5.3 Insulation work of drainage pipe

Refer the introduction to the insulation engineering parts.

6. Refrigerant Pipe Installation

6.1 Maximum length and drop height

Ensure that the length of the refrigerant pipe, the number of bends, and the drop height between the indoor and outdoor units meets the requirements shown in the following table.

For North America, Australia and Europe 3D Inverter models:

Capacity(kBtu/h)	Max. Length (m/ft)	Max. Elevation (m/ft)
<15	25/82	10/32.8
15~23	30/98.4	20/65.6
24~35	50/164	25/82
36~60	65/213.3	30/98.4

For other models:

Capacity(kBtu/h)	Max. Length (m/ft)	Max. Elevation (m/ft)
12	15/49	8/26
18~24	25/82	15/49
30~36	30/98.4	20/65.6
42~60	50/164	30/98.4

Caution:


1. The capacity test is based on the standard length and the maximum permissive length is based on the system reliability.

2. Oil traps

-If oil flows back into the outdoor unit's compressor, this might cause liquid compression or deterioration of oil return. Oil traps in the rising gas piping can prevent this.


-An oil trap should be installed every 6m(20ft) of vertical suction line riser (<36000Btu/h unit).

-An oil trap should be installed every 10m(32.8ft) of vertical suction line riser ($\geq 36000\text{Btu/h}$ unit).



6.2 The procedure of connecting pipes

1. Choose the pipe size according to the specification table.
2. Confirm the cross way of the pipes.
3. Measure the necessary pipe length.
4. Cut the selected pipe with pipe cutter
 - Make the section flat and smooth.




5. Insulate the copper pipe

- Before test operation, the joint parts should not be heat insulated.

6. Flare the pipe

- Insert a flare nut into the pipe before flaring the pipe
- According to the following table to flare the pipe.

Pipe diameter (inch(mm))	Flare dimension A (mm/inch)		Flare shape
	Min	Max	
1/4" (6.35)	8.4/0.33	8.7/0.34	
3/8" (9.52)	13.2/0.52	13.5/0.53	
1/2" (12.7)	16.2/0.64	16.5/0.65	
5/8" (15.9)	19.2/0.76	19.7/0.78	
3/4" (19)	23.2/0.91	23.7/0.93	
7/8" (22)	26.4/1.04	26.9/1.06	



- After flared the pipe, the opening part must be seal by end cover or adhesive tape to avoid duct or exogenous impurity come into the pipe.

7. Drill holes if the pipes need to pass the wall.

8. According to the field condition to bend the pipes so that it can pass the wall smoothly.

9. Bind and wrap the wire together with the insulated pipe if necessary.

10. Set the wall conduit

11. Set the supporter for the pipe.


12. Locate the pipe and fix it by supporter

- For horizontal refrigerant pipe, the distance between supporters should not be exceed 1m.
- For vertical refrigerant pipe, the distance between supporters should not be exceed 1.5m.

13. Connect the pipe to indoor unit and outdoor unit by using two spanners.

- Be sure to use two spanners and proper torque to fasten the nut, too large torque will damage the bellmouthing, and too small torque may cause leakage. Refer the following table for different pipe connection.

Pipe Diameter	Torque	Sketch map
	N.m(lb.ft)	
1/4" (6.35)	15~16 (11~11.8)	
3/8" (9.52)	25~26 (18.4~19.18)	
1/2" (12.7)	35~36 (25.8~26.55)	
5/8" (15.9)	45~47 (33.19~34.67)	
3/4" (19)	65~67 (47.94~49.42)	
7/8" (22)	75~85 (55.3~62.7)	



7. Vacuum Drying and Leakage Checking

7.1 Purpose of vacuum drying

- Eliminating moisture in system to prevent the phenomena of ice-blockage and copper oxidation. Ice-blockage shall cause abnormal operation of system, while copper oxide shall damage compressor.
- Eliminating the non-condensable gas (air) in system to prevent the components oxidizing, pressure fluctuation and bad heat exchange during the operation of system.

7.2 Selection of vacuum pump

- The ultimate vacuum degree of vacuum pump shall be -756mmHg or above.
- Precision of vacuum pump shall reach 0.02mmHg or above.

7.3 Operation procedure for vacuum drying

Due to different construction environment, two kinds of vacuum drying ways could be chosen, namely ordinary vacuum drying and special vacuum drying.

7.3.1 Ordinary vacuum drying

- When conduct first vacuum drying, connect pressure gauge to the infusing mouth of gas pipe and liquid pipe, and keep vacuum pump running for 1 hour (vacuum degree of vacuum pump shall be reached -755mmHg).
- If the vacuum degree of vacuum pump could not reach -755mmHg after 1 hour of drying, it indicates that there is moisture or leakage in pipeline system and need to go on with drying for half an hour.
- If the vacuum degree of vacuum pump still could not reach -755mmHg after 1.5 hours of drying, check whether there is leakage source.
- Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

7.3.2 Special vacuum drying

The special vacuum drying method shall be adopted when:

- Finding moisture during flushing refrigerant pipe.
- Conducting construction on rainy day, because rain water might penetrated into pipeline.
- Construction period is long, and rain water might penetrated into pipeline.

4. Rain water might penetrate into pipeline during construction.

Procedures of special vacuum drying are as follows:

1. Vacuum drying for 1 hour.
2. Vacuum damage, filling nitrogen to reach 0.5Kgf/cm² .

Because nitrogen is dry gas, vacuum damage could achieve the effect of vacuum drying, but this method could not achieve drying thoroughly when there is too much moisture. Therefore, special attention shall be drawn to prevent the entering of water and the formation of condensate water.

3. Vacuum drying again for half an hour.

If the pressure reached -755mmHg, start to pressure leakage test. If it cannot reached the value, repeat vacuum damage and vacuum drying again for 1 hour.

4. Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

8. Additional Refrigerant Charge

- After the vacuum drying process is carried out, the additional refrigerant charge process need to be performed.
- The outdoor unit is factory charged with refrigerant. The additional refrigerant charge volume is decided by the diameter and length of the liquid pipe between indoor and outdoor unit. Refer the following formula to calculate the charge volume.

	Diameter of liquid pipe (mm(inch))	Formula
R410A(Throttling part in the indoor unit)	6.35(1/4)	$V=30(0.32)g/m(oz/ft)\times(L-\text{standard pipe length})$
	9.52(3/8)	$V=65(0.69)g/m(oz/ft)\times(L-\text{standard pipe length})$
	12.7(1/2)	$V=115(1.23)g/m(oz/ft)\times(L-\text{standard pipe length})$
R410A(Throttling part in the outdoor unit)	6.35(1/4)	$V=15(0.16)g/m(oz/ft)\times(L-\text{standard pipe length})$
	9.52(3/8)	$V=30(0.32)g/m(oz/ft)\times(L-\text{standard pipe length})$
	12.7(1/2)	$V=65(0.69)g/m(oz/ft)\times(L-\text{standard pipe length})$

V: Additional refrigerant charge volume. **L**

: The length of the liquid pipe.

Note:

- Refrigerant may only be charged after performed the vacuum drying process.
- Always use gloves and glasses to protect your hands and eyes during the charge work.
- Use electronic scale or fluid infusion apparatus to weight refrigerant to be recharged. Be sure to avoid extra refrigerant charged, it may cause liquid hammer of the compressor or protections.
- Use supplementing flexible pipe to connect refrigerant cylinder, pressure gauge and outdoor unit. And The refrigerant should be charged in liquid state. Before recharging, The air in the flexible pipe and manifold gauge should be exhausted.
- After finished refrigerant recharge process, check whether there is refrigerant leakage at the connection joint part.(Using gas leakage detector or soap water to detect).

9 . Engineering of Insulation

9.1 Insulation of refrigerant pipe

1. Operational procedure of refrigerant pipe insulation

Cut the suitable pipe → insulation (except joint section) → flare the pipe → piping layout and connection → vacuum drying → insulate the joint parts

2. Purpose of refrigerant pipe insulation


- During operation, temperature of gas pipe and liquid pipe shall be over-heating or over-cooling extremely. Therefore, it is necessary to carry out insulation; otherwise it shall debase the performance of unit and burn compressor.
- Gas pipe temperature is very low during cooling. If insulation is not enough, it shall form dew and cause leakage.
- Temperature of gas pipe is very high (generally 50-100 °C) during heating. Insulation work must be carried out to prevent hurt by carelessness touching.

3. Insulation material selection for refrigerant pipe

- The burning performance should over 120 °C
- According to the local law to choose insulation materials
- The thickness of insulation layer shall be above 10mm. If in hot or wet environment place, the layer of insulation should be thicker accordingly.

4. Installation highlights of insulation construction

- Gas pipe and liquid pipe shall be insulated separately, if the gas pipe and liquid pipe were insulated together; it will decrease the performance of air conditioner.



- The insulation material at the joint pipe shall be 5~10cm longer than the gap of the insulation material.
- The insulation material at the joint pipe shall be inserted into the gap of the insulation material.
- The insulation material at the joint pipe shall be banded to the gap pipe and liquid pipe tightly.
- The linking part should be use glue to paste together
- Be sure not bind the insulation material over-tight, it may extrude out the air in the material to cause bad

insulation and cause easy aging of the material.

9.2 Insulation of drainage pipe

1. Operational procedure of refrigerant pipe insulation

Select the suitable pipe → insulation (except joint section) → piping layout and connection → drainage test → insulate the joint parts

2. Purpose of drainage pipe insulation

The temperature of condensate drainage water is very low. If insulation is not enough, it shall form dew and cause leakage to damage the house decoration.

3. Insulation material selection for drainage pipe

- The insulation material should be flame retardant material, the flame retardancy of the material should be selected according to the local law.
- Thickness of insulation layer is usually above 10mm.
- Use specific glue to paste the seam of insulation material, and then bind with adhesive tape. The width of tape shall not be less than 5cm. Make sure it is firm and avoid dew.

4. Installation and highlights of insulation construction

- The single pipe should be insulated before connecting to another pipe, the joint part should be insulated after the drainage test.
- There should be no insulation gap between the insulation material.

10. Engineering of Electrical Wring

1. Highlights of electrical wiring installation

- All field wiring construction should be finished by qualified electrician.
- Air conditioning equipment should be grounded according to the local electrical regulations.
- Current leakage protection switch should be installed.
- Do not connect the power wire to the terminal of signal wire.
- When power wire is parallel with signal wire, put wires to their own wire tube and remain at least 300mm gap.
- According to table in indoor part named "the specification of the power" to choose the wiring, make sure the selected wiring not small than the date showing in the table.
- Select different colors for different wire according to relevant regulations.
- Do not use metal wire tube at the place with acid or alkali corrosion, adopt plastic wire tube to replace it.
- There must be not wire connect joint in the wire tube If joint is a must, set a connection box at the place.
- The wiring with different voltage should not be in one wire tube.
- Ensure that the color of the wires of outdoor and the terminal No. are same as those of indoor unit respectively.

Table: Minimum Cross-Sectional Area able of Power and Signal Cables

For North America:

Rated Current of Appliance (A)	AWG
≤ 6	18
6 - 10	16
10 - 16	14
16 - 25	12
25 - 32	10

For the other regions:

Rated Current of Appliance (A)	Nominal Cross-Sectional Area(mm ²)
≤ 6	0.75
6 - 10	1
10 - 16	1.5
16 - 25	2.5
25 - 32	4
32 - 45	6

11. Test Operation

1. The test operation must be carried out after the entire installation has been completed.

2. Please confirm the following points before the test operation.

- The indoor unit and outdoor unit are installed properly.
- Piping and wiring are properly connected.
- Ensure that there are no obstacles near the inlet and outlet of the unit that might cause poor performance or product malfunction.
- The refrigeration system does not leak.
- The drainage system is unimpeded and draining to a safe location.
- The heating insulation is properly installed.
- The grounding wires are properly connected
- The length of the piping and the added refrigerant stow capacity have been recorded.
- The power voltage is the correct voltage for the air conditioner.

CAUTION: Failure to perform the test run may result in unit damage, property damage or personal injury.

3. Test Run Instructions

1. Open both the liquid and gas stop valves.
2. Turn on the main power switch and allow the unit to warm up.
3. Set the air conditioner to COOL mode, and check the following points.

Indoor unit

- Whether the switch on the remote controller works well.
- Whether the buttons on the remote controller works well.
- Whether the air flow louver moves normally.
- Whether the room temperature is adjusted well.
- Whether the indicator lights normally.
- Whether the temporary buttons works well.
- Whether the drainage is normal.
- Whether there is vibration or abnormal noise during operation.

Outdoor unit

- Whether there is vibration or abnormal noise during operation.
- Whether the generated wind, noise, or condensed of by the air conditioner have influenced your neighborhood.
- Whether any of the refrigerant is leaked.

4. Drainage Test

- a. Ensure the drainpipe flow smoothly. New buildings should perform this test before finishing the ceiling.
- b. Remove the test cover. Add 2000ml of water to the tank through the attached tube.
- c. Turn on the main power switch and run the air conditioner in COOL mode.
- d. Listen to the sound of the drain pump to see if it makes any unusual noises.
- e. Check to see that the water is discharged. It may take up to one minute before the unit begins to drain depending on the drainpipe.
- f. Make sure that there are no leaks in any of the piping.
- g. Stop the air conditioner. Turn off the main power switch and reinstall the test cover.

Maintenance

Contents

1.	First Time Installation Check	2
2	Refrigerant Recharge	4
3	Re-Installation	5
3.1	Indoor Unit.....	5
3.2	Outdoor Unit.....	7

1. First Time Installation Check

Air and moisture trapped in the refrigerant system affects the performance of the air conditioner by:


- Increasing pressure in the system.
- Increasing the operating current.
- Decreasing the cooling or heating efficiency.
- Congesting the capillary tubing due to ice build-up in the refrigerant circuit.
- Corroding the refrigerant system.

To prevent air and moisture from affecting the air conditioner's performance, the indoor unit, as well as the pipes between the indoor and outdoor unit, must be leak tested and evacuated.

Leak test (soap water method)

Use a soft brush to apply soapy water or a neutral liquid detergent onto the indoor unit connections and outdoor unit connections. If there is gas leakage, bubbles will form on the connection.


Air purging with vacuum pump



Procedure:

1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
3. Connect another charge hose to the vacuum pump.
4. Fully open the Handle Lo manifold valve.
5. Using the vacuum pump, evacuate the system for 30 minutes.
 - a. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
 - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
 - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
6. If the pressure successfully reaches -0.1 MPa (14.5 Psi), fully close the Handle Lo valve, then cease vacuum pump operations.
- b. Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check whether there is gas leakage.
6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
 - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
 - b. Remove the charge hose from the 3-way valve.
7. Fully open the 2- and 3-way valves and tighten the cap of the 2- and 3-way valves.

2. Refrigerant Recharge




Procedure:

1. Close both 2- and 3-way valves.
2. Slightly connect the Handle Lo charge hose to the 3-way service port.
3. Connect the charge hose to the valve at the bottom of the cylinder.
4. If the refrigerant is R410A/R32, invert the cylinder to ensure a complete liquid charge.
5. Open the valve at the bottom of the cylinder for 5 seconds to purge the air in the charge hose, then fully tighten the charge hose with push pin Handle Lo to the service port of 3-way valve..
6. Place the charging cylinder onto an electronic scale and record the starting weight.
7. Fully open the Handle Lo manifold valve, 2- and 3-way valves.
8. Operate the air conditioner in cooling mode to charge the system with liquid refrigerant.
9. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm, the value of pressure refers to chapter Appendix), turn off the air conditioner, then disconnect the charge hose from the 3-way service port immediately..
10. Mount the caps of service port and 2- and 3-way valves.
11. Use a torque wrench to tighten the caps to a torque of 18 N.m.
12. Check for gas leakage.

3. Re-Installation

3.1 Indoor Unit


Collecting the refrigerant into the outdoor unit



Procedure:

1. Confirm that the 2- and 3-way valves are opened.
2. Connect the charge hose with the push pin of Handle Lo to the 3-way valve's gas service port.
3. Open the Handle Lo manifold valve to purge air from the charge hose for 5 seconds and then close it quickly.
4. Close the 2-way valve.
5. Operate the air conditioner in cooling mode. Cease operations when the gauge reaches 0.1 MPa (14.5 Psi).
6. Close the 3-way valve so that the gauge rests between 0.3 MPa (43.5 Psi) and 0.5 MPa (72.5 Psi).
7. Disconnect the charge set and mount the caps of service port and 2- and 3-way valves.
8. Use a torque wrench to tighten the caps to a torque of 18 N.m.
9. Check for gas leakage.

Air purging with vacuum pump




Procedure:

1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
3. Connect another charge hose to the vacuum pump.
4. Fully open the Handle Lo manifold valve.
5. Using the vacuum pump, evacuate the system for 30 minutes.
 - a. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
 - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
 - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
6. If the pressure successfully reaches -0.1 MPa (14.5 Psi), fully close the Handle Lo valve, then cease vacuum pump operations.
 - b. Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check whether there is gas leakage.
 6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
 - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
 - b. Remove the charge hose from the 3-way valve.
7. Fully open the 2- and 3-way valves and tighten the cap of the 2- and 3-way valves.

3.2 Outdoor Unit


Evacuation for the whole system



Procedure:

1. Confirm that the 2- and 3-way valves are opened.
2. Connect the vacuum pump to the 3-way valve's service port.
3. Evacuate the system for approximately one hour. Confirm that the compound meter indicates -0.1 MPa (14.5Psi).
4. Close the valve (Low side) on the charge set and turn off the vacuum pump.
5. Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check whether there is gas leakage.
6. Disconnect the charge hose from the vacuum pump.
7. Mount the caps of service port and 2- and 3-way valves.
8. Use a torque wrench to tighten the caps to a torque of 18 N.m.

Refrigerant charging



Procedure:

1. Close both 2- and 3-way valves.
2. Slightly connect the Handle Lo charge hose to the 3-way service port.
3. Connect the charge hose to the valve at the bottom of the cylinder.
4. If the refrigerant is R410A/R32, invert the cylinder to ensure a complete liquid charge.
5. Open the valve at the bottom of the cylinder for 5 seconds to purge the air in the charge hose, then fully tighten the charge hose with push pin Handle Lo to the service port of 3-way valve..
6. Place the charging cylinder onto an electronic scale and record the starting weight.
7. Fully open the Handle Lo manifold valve, 2- and 3-way valves.
8. Operate the air conditioner in cooling mode to charge the system with liquid refrigerant.
9. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm, the value of pressure refers to chapter Appendix), turn off the air conditioner, then disconnect the charge hose from the 3-way service port immediately..
10. Mount the caps of service port and 2- and 3-way valves.
11. Use a torque wrench to tighten the caps to a torque of 18 N.m.
12. Check for gas leakage.

Note: 1. Mechanical connectors used indoors shall comply with local regulations.

2. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated.


Product Features

Contents


1.	Display Function	2
2	Safety Features	5
3.	Basic Functions.....	6
3.1	Table	6
3.2	Abbreviation.....	7
3.3	Fan Mode.....	7
3.4	Cooling Mode	7
3.5	Heating Mode(Heat Pump Units)	7
3.6	Auto-mode.....	8
3.7	Drying Mode	8
3.8	Forced Operation Function	8
3.9	Timer Function	9
3.10	Sleep Function.....	9
3.11	Auto-Restart Function.....	9
3.12	Drain Pump Control.....	9
4.	Optional Functions	10
5.	Remote Controller Functions	11
5.1	Infrared Wireless Remote Controller.....	11
5.2	LCD Wired Remote Controller	16
5.3	Centralized Controller	23

1. Display Function


Floor Ceiling Type




Display 1




Display 3




Display 5




Display 7




Display 2



Display 4




Display 6




Display 8


New 4-way Cassette Type




Duct Type




Compact Cassette Type



Console Type



Display 1



Display 2

Note: Please select the display function according to your purchase product.

2. Safety Features

Compressor three-minute delay at restart

Compressor functions are delayed for up to three minutes upon startup of the unit.

Indoor fan delayed operation

- When the unit starts, the louver is automatically activated and the indoor fan will operate after a period of time.
- If the unit is in heating mode, the indoor fan is regulated by the anti-cold wind function.

Sensor redundancy and automatic shutoff

- If one temperature sensor malfunctions, the air conditioner ceases operation.

Refrigerant leakage detection

Only active in cooling mode. It prevents the compressor from being damaged by refrigerant leakage or compressor overload. This is measured using the coil temperature of evaporator T2 when the compressor is in operation.

Phase check function(for 3-phase models)

If the phase sequence is detected wrong or lack of 1 or 2 phase, the unit won't start and there is error code displayed on outdoor PCB.

3. Basic Functions

3.1 Table

Functions		Heating Mode			
		Defrosting Mode		Anti-cold Air Function	
Cases		Case 1:TE18	Case 2: TE18&TE16	Case 1: TE1,TE2,TE3,TE4	Case 2: TE1,TE2,TE3,TE4,TE7,TE10
Models	CFMD-035N-01M25	✓		✓	
	CFMD-050N-01M25	✓		✓	
	DFMD-050N-01M25	✓		✓	
	DFMD-070N-01M25	✓		✓	
	CFMD-070N-01M25	✓		✓	
	CFMD-100N-01M25	✓		✓	
	CFMD-140N-01M25	✓		✓	

Note: The detailed description of case 1 or case 2 is shown in the following function sections(3.5).

3.2 Abbreviation

Unit element abbreviations

Abbreviation	Element
T1	Indoor room temperature
T2	Coil temperature of evaporator
T3	Coil temperature of condenser
T4	Outdoor ambient temperature
TS	Set temperature

In this manual, such as TE1, TE2...etc., they are well-setting parameter of EEPROM.

3.3 Fan Mode

When fan mode is activated:

- The outdoor fan and compressor are stopped.
- Temperature control is disabled and no temperature setting is displayed.
- The indoor fan speed can be set to high, medium, low, or auto.
- The louver operations are identical to those in cooling mode.
- Auto fan: In fan-only mode, AC operates the same as auto fan in cooling mode with the temperature set at 24°C(75.2°F).


3.4 Cooling Mode

3.4.1 Compressor Control

- When indoor room temperature T1 is lower than setting value, the compressor and outdoor fan cease operation.

3.4.2 Indoor Fan Control

- In cooling mode, the indoor fan operates continuously. The fan speed can be set to high, medium, low, turbo or auto.
- The auto fan acts as below rules:



3.4.3 Outdoor Fan Control

For single-fan units: The operation of outdoor fan is consistent with the operation of compressor. Except the following situations:

- Condenser high temperature protection
- Current protection

For double-fan units: The outdoor fans run depending on T3.

3.4.4 Condenser Temperature Protection(For the units have T3 sensor)

When condenser temperature is more than setting value, the compressor ceases operation.

3.4.5 Evaporator Temperature Protection

When evaporator temperature drops below a configured value, the compressor and outdoor fan cease operation.

3.5 Heating Mode(Heat pump units)


3.5.1 Compressor Control

Once the compressor starts up, it will keep running for 7 minutes, then indoor room temperature T1 is higher than setting value, the compressor and outdoor fan cease operation.


3.5.2 Indoor Fan Control:

- When the compressor is on, the indoor fan speed can be set to high, medium, low, or auto. And the anti-cold wind function has the priority.
- Anti-cold air function
 - When indoor unit coil temperature T2 is low, the anti-cold air function will start and the indoor fan is controlled by indoor unit coil temperature T2.


Case 1:



Case 2:



- Auto fan action in heating mode:



3.5.3 Outdoor Fan Control:

For single-fan units: The operation of outdoor fan is consistent with the operation of compressor. Except the following situations:

- Evaporator high temperature protection
- Defrosting
- Current protection.

For double-fan units: The outdoor fans run depending on T4.

3.5.4 Defrosting mode

- The unit enters defrosting mode according to the value of temperature of T3 and the value range of temperature change of T3 as well as the compressor runtime.

Case 1:

- If any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
 - T3 rises above TE18.
 - Unit runs for 10 minutes consecutively in defrosting mode.

Case 2:

- If any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
 - T3 rises above TE18.
 - T3 maintained above TE16 for 80 seconds;
 - Unit runs for 10 minutes consecutively in defrosting mode.

3.5.5 Evaporator Temperature Protection

When the evaporator temperature exceeds a preset protection value, the compressor ceases operation.

3.6 Auto-mode

- This mode can be selected with the remote controller and the setting temperature can be changed between 17°C~30°C(62°F~86°F).
- In auto mode, the machine selects cooling, heating, or fan-only mode on the basis of ΔT ($\Delta T = T1 - TS$).

ΔT	Running mode
$\Delta T > 2^\circ C$	Cooling
$-1^\circ C \leq \Delta T \leq 2^\circ C$	Fan-only
$\Delta T < -1^\circ C$	Heating*

Heating*: In auto mode, cooling only models run the fan


- Indoor fan will run at auto fan speed.
- The unit selects a new running mode,
 - when unit receives the auto signal;
 - when setting temperature is modified;
 - after the compressor pauses for a period of time when a running mode is selected.

3.7 Drying mode

- Indoor fan speed is fixed at low and can't be changed. The louver angle is the same as in cooling mode.
- All protections are active and the same as that in cooling mode.

3.8 Forced operation function

Press the AUTO/COOL button, the AC will run as below sequence:



- Forced cooling mode:

The compressor and outdoor fan continue to run and the indoor fan runs at low speed. After running for 30

minutes, the AC will switch to auto mode with a preset temperature of 24°C(76°F).

- Forced auto mode:

Forced auto mode operates the same as normal auto mode with a preset temperature of 24°C(76°F).

- The unit exits forced operation when it receives the following signals:
 - Switch on
 - Switch off
 - Timer on
 - Timer off
 - Changes in:
 - mode
 - fan speed
 - sleep mode
 - Follow me

3.9 Timer Function

- The timing range is 24 hours.
- Timer On. The machine turns on automatically at the preset time.
- Timer Off. The machine turns off automatically at the preset time.
- Timer On/Off. The machine turns on automatically at the preset On Time, and then turns off automatically at the preset Off Time.
- Timer Off/On. The machine turns off automatically at the preset Off Time and then turns on automatically at the preset On Time.
- The timer does not change the unit operation mode. If the unit is off now, it does not start up immediately after the "timer off" function is set. When the setting time is reached, the timer LED switches is off and the unit running mode remains unchanged.
- The timer uses relative time, not clock time.

3.10 Sleep function

- The sleep function is available in cooling, heating, or auto mode.
- The operational process for sleep mode is as follows:
 - When cooling, the temperature rises 1°C(2°F) (to not higher than 30°C(86°F)) every hour. After 2 hours, the temperature stops rising and the indoor fan is fixed at auto speed.
 - When heating, the temperature decreases 1°C(2°F) (to not lower than 17°C(62.6°F)) every hour. After

2 hours, the temperature stops decreasing and the indoor fan is fixed at auto speed. Anti-cold wind function takes priority.

3.11 Auto-Restart function

- The indoor unit has an auto-restart module that allows the unit to restart automatically. The module automatically stores the current settings and, in the case of a sudden power failure, will restore those setting automatically within 3 minutes after power returns.

3.12 Drain Pump Control(Standard for cassette type)

- Use the water-level switch to control drain pump.
- The system checks the water level every 5 seconds.
- When the A/C operates in cooling, the pump begins running immediately and continuously until cooling stops.
- When the A/C operates in forced cooling mode and defrosting mode, the pump is running continuously.
- If the water level increases up to the control point, the LED displays an alarm code and the drain pump opens and continually monitors the water level. If the water level falls and LED alarm code is no longer displayed (drain pump close delay is 1 minute), the unit goes back into its last mode. Otherwise, the entire system (including the pump) stops and the LED displays an alarm again after 3 minutes.

4. Optional Functions

4.1 8°C Heating

In heating mode, the temperature can be set to as low as 8°C, preventing the indoor area from freezing if unoccupied during severe cold weather.

4.2 Self clean

- If you press “Self Clean” when the unit is in cooling or drying mode:
 - For cooling models, the indoor unit will run in low fan mode for a certain time, then ceases operation.
 - For heat pump models, the indoor unit will run in fan-only mode, then low heat, and finally in fan-only mode.
- Self Clean keeps the indoor unit dry and prevents mold growth.
- When match with multi outdoor unit, this function is disabled.

4.3 Follow me

- If you press “Follow Me” on the remote, the indoor unit will beep. This indicates the follow me function is active.
- Once active, the remote control will send a signal every 3 minutes, with no beeps. The unit automatically sets the temperature according to the measurements from the remote control.
- The unit will only change modes if the information from the remote control makes it necessary, not from the unit’s temperature setting.
- If the unit does not receive a signal for 7 minutes or you press “Follow Me,” the function turns off. The unit regulates temperature based on its own sensor and settings.


5. Remote Controller Functions

5.1 Infrared Wireless Remote Controller

5.1.1 Remote Controller Specifications

Model	
Rated Voltage	3.0V (Dry batteries R03/ LR03x2)
Reaching Distance	8m((when using 3.0 voltage, it Gets 11m))
Environment Temperature Range	-5°C~60°C (23°F~140°F)

Buttons and Functions



1. TEMP UP ▲ : Push this button to increase the indoor temperature setting in 1°C increments to 30°C

2. TEMP DOWN ▼ : Push this button to decrease the indoor temperature setting in 1°C increments to 17°C.

3. MODE: Once pressing, running mode will be selected in the following sequence:



NOTE: No heating mode for cool only type unit.

4. VERT SWING: Used to stop or start horizontal louver movement. The louver will swing up and down automatically if push this button.


AIR DIRECTION: Used to set the desired up/down air flow direction. The louver changes 6 degree in angle for each press.

5. HORIZ SWING: Used to stop or start vertical louver movement.

6. FAN SPEED+ MODE: Press the Mode and Fan speed button simultaneously for 2 seconds. The remote controls into faceplate setting state and the LCD shows F2. Press the TEMPUP(▲) to control the faceplate up and press the TEMP DOWN(▼) to control the faceplate down. Press any button to exit the faceplate setting state, then the LCD back to the normal display.

7. ON/OFF: For turning on or turning off the air conditioner.

8. FAN SPEED: Fan speed will be selected in following sequence once pressing this button:



9. TIME ON: For time ON setting. Press this button to activate the Auto-on time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-on time setting, just press the button until the time setting is 0.0.

10. ECO: Select this function during the sleeping time. It can maintain the most comfortable temperature and save energy. This function is available on COOL, HEAT or AUTO mode only .

NOTE: While the unit is running under Energy-saving mode, it would be cancelled if press MODE, FAN SPEED or ON/OFF button.

11. TIME OFF: For time OFF setting. Press this button to activate the Auto-off time setting. Each press will increase

the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-off time setting, just press the button until the time setting is 0.0.


12. LOCK (inner located): Push this button to lock in all the current settings, and the remote controller will not accept any operation except that of the LOCK. Use the LOCK mode when you want to prevent settings from being changed accidentally. Press the LOCK button again to cancel the LOCK function. A lock symbol will appear on the remote controller display when the lock function is activated.

13. RESET (inner located): Once the recessed RESET button is pressed, all of the current settings will be cancelled and the controller will return to the initial settings..

5.1.2 (Standard for some units) Remote Controller Specifications

Model	
Rated Voltage	3.0V (Dry batteries R03/ LR03x2)
Reaching Distance	8m (when using 3.0 voltage, it Gets 11m)
Environment Temperature Range	-5°C~60°C (23°F~140°F)

Buttons and Functions



1. TEMP UP ▲ : Push this button to increase the indoor temperature setting in 1°C increments to 30°C
2. TEMP DOWN ▼ : Push this button to decrease the indoor temperature setting in 1°C increments to 17°C.
3. MODE: Once pressing, running mode will be selected in the following sequence:



NOTE: No heating mode for cool only type unit.

4. VERT SWING: Used to stop or start horizontal louver movement. The louver will swing up and down automatically if push this button.
5. HORIZ SWING: Used to stop or start vertical louver

movement.

AIR DIRECTION: Used to set the desired up/down air flow direction. The louver changes 6 degree in angle for each press.

6. RESET (inner located): Once the recessed RESET button is pressed, all of the current settings will be cancelled and the controller will return to the initial settings..

7. ON/OFF: For turning on or turning off the air conditioner.

8. FAN SPEED: Fan speed will be selected in following sequence once pressing this button:

► AUTO→ LOW→ MED→ HIGH

9. TIME ON: For time ON setting. Press this button to activate the Auto-on time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-on time setting, just press the button until the time setting is 0.0.

10. ECO: Select this function during the sleeping time. It can maintain the most comfortable temperature and save energy. This function is available on COOL, HEAT or AUTO mode only .

NOTE: While the unit is running under Energy-saving mode, it would be cancelled if press MODE, FAN SPEED or ON/OFF button.


11. TIME OFF: For time OFF setting. Press this button to activate the Auto-off time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-off time setting, just press the button until the time setting is 0.0.

12. C/H (inner located): Press this recessed button to shift the mode between Cooling only and Cooling & Heating according to the feature of the machine. The factory default setting mode is Cooling & Heating. For example, the unit you purchased is Cooling only models, please press this recessed button with a needle of 1mm to shift the operation mode.

5.1.3 (Standard for some units) Remote Controller Specifications

Model	
Rated Voltage	3.0V (Dry batteries R03/LR03×2)
Lowest Voltage of CPU Emitting Signal	2.0V
Reaching Distance	8m (when using 3.0 voltage, it can get 11m)
Environment Temperature Range	-5°C~60°C (23°F~140°F)

Buttons and Functions



1. ON/OFF: For turning on or turning off the air conditioner.

2. MODE: Once pressing, running mode will be selected in the following sequence:

► AUTO→ COOL→ DRY→ [HEAT]→ FAN

NOTE: Please do not select HEAT mode if the machine you purchased is cooling only type.

3. FAN SPEED: Fan speed will be selected in following sequence once pressing this button:

► AUTO→ LOW→ MED→ HIGH

4. SLEEP: Select this function during the sleeping time. It keeps the most comfortable temperature and save energy. This function is available on COOL, HEAT or AUTO mode only.

NOTE: While the unit is running in sleep mode, it would be cancelled if MODE, FAN SPEED or ON/OFF button is pressed.

5. TURBO Button: Active/Disable Turbo function. Turbo function enables the unit to reach the preset temperature at cooling or heating operation in the shortest time(if the indoor unit does not support this function, there is no corresponding operation happened when pressing this button.)

6. UP Button(▲): Increase the set temperature. Keeping pressing will increase the temp with 1°C per 0.5s.

DOWN Button(▼): Decrease the set temperature. Keeping pressing will decrease the temp with 1°C per 0.5s.

NOTE: Temperature control is not available in Fan mode.

7. SHORTCUT Button

Used to restore the current settings or resume previous settings.

On the first time connecting to the power, if push the SHORTCUT button, the unit will operate on AUTO mode, 26°C, and fan speed is Auto.

Push this button when remote controller is on, the system will automatically revert back to the previous settings including operating mode, setting temperature, fan speed level and sleep feature (if activated).

If pushing more than 2 seconds, the system will automatically restore the current operation settings including operating mode, setting temperature, fan speed level and sleep feature (if activated).

8. TIME ON: For time ON setting. Once pressing this button, the time will increase by 0.5 hour. When the time exceeds 10 hours, pressing the button will increase the time by 1 hour. Adjust the figure to 0.00 will cancel time ON setting.

9. TIME OFF: For time OFF setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour. Adjust the figure to 0.00 will cancel time ON setting.

10. SWING ◀▶ Button

Used to stop or start vertical louver movement and set the desired left/right air flow direction. The vertical louver changes 6 degree in angle for each press.

Used to stop or start horizontal louver auto swing feature.

11. SWING ◀ Button

Used to stop or start horizontal louver movement or set the desired up/down air flow direction. The louver changes 6 degree in angle for each press. If keep pushing more than 2 seconds, the louver will swing up and down automatically.

12. LED


Disable/Active indoor screen Display. When pushing the button, the indoor screen display is cleared, press it again to light the display.

5.1.4 RG51F/EF(Standard for some units)

Remote Controller Specifications

Model	
Rated Voltage	3.0V (Dry batteries R03/ LR03x2)
Reaching Distance	8m (when using 3.0 voltage, it Gets 11m)
Environment Temperature Range	-5°C~60°C (23°F~140°F)

Buttons and Functions



1. TEMP DOWN▼ : Push this button to decrease the indoor temperature setting in 1°C increments to 17°C.

2. TEMP UP▲ : Push this button to increase the indoor temperature setting in 1°C increments to 30°C

3. ON/OFF: For turning on or turning off the air conditioner.

4. FAN SPEED: Fan speed will be selected in following sequence once pressing this button:

► AUTO→ LOW→ MED→ HIGH

5. MODE: Once pressing, running mode will be selected in the following sequence:

► AUTO→ COOL→ DRY→ [HEAT]→ FAN

NOTE: No heating mode for cool only type unit.

6. TIME ON: For time ON setting. Press this button to activate the Auto-on time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-on time setting, just press the button until the time setting is 0.0.

7. SWING: Used to stop or start horizontal louver movement. Hold down for 2 seconds to initiate vertical louver auto swing feature(some units) .

8. SLEEP: Select this function during the sleeping time. It keeps the most comfortable temperature and save energy. This function is available on COOL, HEAT or AUTO mode only.

NOTE: While the unit is running in sleep mode, it would be cancelled if MODE, FAN SPEED or ON/OFF button is pressed.

9. SHORTCUT Button

Used to restore the current settings or resume previous settings.

Push this button when remote controller is on, the system will automatically revert back to the previous settings including operating mode, setting temperature, fan speed level and sleep feature (if activated).

If pushing more than 2 seconds, the system will automatically restore the current operation settings including operating mode, setting temperature, fan speed level and sleep feature (if activated).

10. TIME OFF: For time OFF setting. Press this button to activate the Auto-off time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-off time setting, just press the button until the time setting is 0.0.

NOTE: Press together the SHORTCUT & TIME OFF buttons simultaneously for 5 seconds to lock the keyboard. Press together the two buttons for 2 seconds to unlock the keyboard.

11. I SENSE: Temperature sensing and room temperature display button. When the I SENSE function is activated, the remote display is actual temperature at its location. The remote control will send this signal to the air conditioner every 3 minutes interval until press the I SENSE button again.

NOTE: Press this button for seven seconds to start/stop memory feature of I SENSE function.


12. LED DISPLAY: Disable/Active indoor screen display. When pushing the button, the indoor screen display is cleared, press it again to light the display.

5.2 LCD Wired Remote Controller


5.2.1 LCD Wired Remote Controller

The wired remote controller is standard for Duct type and is optional for some types.

i) Buttons and Functions




ii) LCD Screen




iii) Installation

- Dimensions




- Wiring diagram

Refer to the following diagram to wire the wall-mounted remote control to the indoor unit.




- Installation Diagram

Connect the wire from the display panel of the indoor unit to a connecting cable. Then connect the other side of the connecting cable to the remote control.




Note: Be sure to reserve a length of the connecting wire for periodic maintenance.




Note: DO NOT allow water to enter the remote control. Use the trap and putty to seal the wires.

- For exposed mounting, cut holes on four of the sides according to the picture below.




- For shielded wiring, please refer to the picture below.



5.2.2 LCD Wired Remote Controller (Optional)

The wired remote controller is optional for some types.

i) Buttons and Functions



1. POWER button

Turn on or turn off the unit.

2. MODE(A/B) button

Used to select the operation mode: Auto / Cooling / Drying / Heating / Fan;

Hold to active the operation of auto-lifting panel when off

3. Adjust button

To set temperature, time and timer; set up or down the auto-lifting panel

4. FAN SPEED button

Used to select the fan speed.

5. Up-down airflow direction and swing Button

Press for adjusting the angel of louver, hold for vertical swing; individual louver control for cassette panel

6. Left-right airflow swing Button

Press for stop or start the horizontal swing

7. FOLLOW ME(PTC) button

Allows the remote control to act as a remote thermostat and send temperature information from its current location.

8. TIMER button

To set timer on and timer off time of one day

9. DELAY/DAY OFF button

To set 1 to 2 hours delay off for each day or a whole day off in a weekly timer schedule

10. CONFIRM button

To confirm an setting or call up the menu

11. BACK button


Back to previous operation or superior menu

12. COPY button

Copy timer setting of one day to another in weekly schedule setting

13 Infrared remote receiver (on some models)


ii) LCD Screen



- 1 Operation mode indication
- 2 Fan speed indication
- 3 Left-right swing indication
- 4 Up-down swing indication
- 5 Faceplate function indication
- 6 Main unit and secondary unit indication
- 7 Follow me function indication
- 8 PTC function indication
- 9 C° / F° indication
- 10 Temperature display
- 11 Lock indication
- 12 Room temperature indication
- 13 Clock display
- 14 On/Off timer
- 15 Timer display


iii) Installation

- Dimensions




- Wiring diagram


Refer to the following diagram to wire the wall-mounted remote control to the indoor unit.



- Installation Diagram


Connect the female joint of wires group from the main board with the male joint of connective wires group. Then connect the other side of connective wires group with the male joint of wires group leads from wire controller.






Note: DO NOT allow water to enter the remote control. Use the trap and putty to seal the wires.

- For exposed mounting, four outletting positions. There are three need cutting.




- For shielded wiring, please refer to the picture below.



5.3 Centralized Controller

1) Connection

For Light commercial air conditioner with XYE port, it can be directly connected to Centralized Controller (CCM03, CCM09).



2) Address setting

When setting the address, please make sure the unit is powered off. The address can be set from 0 to 63 by the switch. Turn on the unit, then the address will be effective.

SWITCH FOR CCM UNIT ADDRESS	
S2 + S1	
ADDRESS	0~15
Factory Setting	✓
S2 + S1	
ADDRESS	16~31
Factory Setting	
S2 + S1	
ADDRESS	32~47
Factory Setting	
S2 + S1	
ADDRESS	48~63
Factory Setting	

Note: For light commercial air conditioner with XYE port, it can be also connected to BMS (Building Management System).

If there is any CAC (central air conditioner) connecting with the central controller at the same time, please set the address from largest (63,62,61...), since the CAC units could obtain address automatically from the smallest (00,01,02...)

Troubleshooting

Contents

1.	Safety Caution	3
2.	General Troubleshooting	4
3.	Complain Record Form	6
4.	Error Diagnosis and Troubleshooting Without Error Code.....	8
4.1	Remote maintenance.....	8
4.2	Field maintenance	9
5.	Quick Maintenance by Error Code.....	14
6.	Troubleshooting by Error Code.....	15
TS01	EEPROM Parameter Error Diagnosis and Solution	
TS04	The indoor fan Speed is Operating Outside of The Normal Range Diagnosis and Solution	
TS05	Open Circuit or Short Circuit of Temperature Sensor Diagnosis and Solution	
TS06	Refrigerant Leakage Detection Diagnosis and Solution	
TS15	Water-Level Alarm Malfunction Diagnosis and Solution	
TS08	Overload Current Protection Diagnosis and Solution Diagnosis and Solution	
TS23	Communication error between indoor two chips diagnosis and solution	
TS24	Phase sequence error diagnosis and solution	

Troubleshooting

Contents

TS25 Lack of Phase diagnosis and solution

TS26 Open-circuit and short-circuit trouble of T4 or High temperature or protection of pressure diagnosis and solution

TS27 High temperature protection of condenser diagnosis and solution

1. Safety Caution


⚠️ WARNING

Be sure to turns off all power supplies or disconnect all wires to avoid electric shock.
While checking indoor/outdoor PCB, please equip oneself with antistatic gloves or wrist strap to avoid damage to the board.

⚠️ WARNING

Electricity remains in capacitors even when the power supply is off.
Ensure the capacitors are fully discharged before troubleshooting.

Test the voltage between the two pins of the compressor capacitor. If the voltage is zero, the capacitors are fully discharged.



Note: This picture is for reference only. Actual appearance may vary.

2. General Troubleshooting

2.1 Error Display (Indoor Unit)

When the indoor unit encounters a recognized error on different models ,

1. the running LED, the timer LED, the defrosting LED or alarm LED may turn on or begin flashing;
2. an error code will be displayed;
3. both 1 and 2.

These error codes are described in the following tables:

Running LED	Timer LED	Display	Error Information	Solution
1 time	OFF	EH00	Indoor EEPROM malfunction	TS01-IDU
4 times	OFF	EH03	The indoor fan speed is operating outside of the normal range	TS04-L-IDU
6 times	OFF	EH60	Indoor room temperature sensor T1 is in open circuit or has short circuited	TS05-IDU
6 times	OFF	EH61	Evaporator coil temperature sensor T2 is in open circuit or has short circuited	TS05-IDU
8 times	OFF	EL0C	Refrigerant leakage detection	TS06-ON
13 times	OFF	EH0E	Water level alarm malfunction	TS15
5 times	OFF	EC52	Condenser coil temperature sensor T3 is in open circuit or has short circuited	TS05-ODU
9 times	OFF	EH0b	Communication error between indoor two chips	TS23

For other errors:

The display board may show a garbled code or a code undefined by the service manual. Ensure that this code is not a temperature reading.

Troubleshooting:

Test the unit using the remote control. If the unit does not respond to the remote, the indoor PCB requires replacement. If the unit responds, the display board requires replacement.

LED flash frequency:



2.2 Error Display (Outdoor Unit 36k or more)

LED1	LED2	LED3	Error Information	Solution
Flash	OFF	OFF	Phase sequence	TS24
Flash	OFF	OFF	Lack of phase(A,B)	TS25
OFF	OFF	OFF	Lack of phase(C)	TS25
Flash	Flash	OFF	Low pressure protection	TS26-ON
Off	OFF	Flash	Current overload protection	TS08-L-ON
Flash	OFF	Flash	Indoor/outdoor unit communication error	TS02-L-ON
OFF	Flash	Flash	Condenser coil temperature sensor T3 is in open circuit or has short circuited	TS05-ODU
OFF	Flash	OFF	Open-circuit and short-circuit trouble of T4 or high pressure protection or discharge temperature protection of compressor	TS26-ON
Flash	Flash	Flash	High temperature protection of condenser	TS27-ON

3. Complain Record Form

Complain Record Form

Request No.:

Date:

Installation Date:

Service Date:

Customer Information			
Name		Telephone No.	
Home Address			
Email			
Product Information			
Indoor Unit Model		Outdoor Unit Model	
Serial No. of indoor unit			
Serial No. of outdoor unit			
Working Mode	<input type="checkbox"/> Cooling	<input type="checkbox"/> Heating	<input type="checkbox"/> Fan only
Setting temperature	_____ °C / °F	Fan speed	<input type="checkbox"/> Turbo <input type="checkbox"/> High <input type="checkbox"/> Medium <input type="checkbox"/> Low <input type="checkbox"/> Auto
Temperature of air inlet	_____ °C / °F	Temperature of air outlet	_____ °C / °F
Installation / Condition Information			
Indoor temperature	_____ °C / °F	Indoor humidity	_____ %RH
Outdoor temperature	_____ °C / °F	Outdoor humidity	_____ %RH
Length of Connecting pipe		Pipe diameter	Gas pipe: Liquid pipe:
Length of Wiring		wire diameter	
System Running Pressure	_____ MPa	or _____ Bar	or _____ PSI
Room size (L*W*H)			
Photo of Installation of Indoor unit (Photo #1)		Photo of Installation of Outdoor unit (Photo #2)	
Failure Description			
Error Code of Indoor unit		Code of Outdoor PCB	
Unit does not start			
Remote control does not work			
Indoor display shows nothing			
No cooling or heating at all			
Less cooling or heating			
Unit starts but stops shortly			
High noise			
High vibration			
Approval from Manufacturer			

<input type="checkbox"/> Approved	
<input type="checkbox"/> More Proof needed	
<input type="checkbox"/> Rejected	

4. Error Diagnosis and Troubleshooting Without Error Code



WARNING

Be sure to turn off unit before any maintenance to prevent damage or injury.

4.1 Remote maintenance

SUGGESTION: When troubles occur, please check the following points with customers before field maintenance.

No.	Problem	Solution
1	Unit will not start	10~11
2	The power switch is on but fans will not start	10~11
3	The temperature on the display board cannot be set	10~11
4	Unit is on but the wind is not cold(hot)	10~11
5	Unit runs, but shortly stops	10~11
6	The unit starts up and stops frequently	10~11
7	Unit runs continuously but insufficient cooling(heating)	10~11
8	Cool can not change to heat	10~11
9	Unit is noisy	10~11

4.3 Field maintenance

	Problem	Solution
1	Unit will not start	12~13
2	Compressor will not start but fans run	12~13
3	Compressor and condenser (outdoor) fan will not start	12~13
4	Evaporator (indoor) fan will not start	12~13
5	Condenser (Outdoor) fan will not start	12~13
6	Unit runs, but shortly stops	12~13
7	Compressor short-cycles due to overload	12~13
8	High discharge pressure	12~13
9	Low discharge pressure	12~13
10	High suction pressure	12~13
11	Low suction pressure	12~13
12	Unit runs continuously but insufficient cooling	12~13
13	Too cool	12~13
14	Compressor is noisy	12~13
15	Horizontal louver can not revolve	12~13

1.Remote Maintenance	Electrical Circuit	Refrigerant Circuit
Possible causes of trouble		
Unit will not start	☆ Power failure ☆ The main power tripped ☆ Loose connections	
The power switch is on but fans will not start	☆ ☆ ☆	
The temperature on the display board cannot be set	☆ ☆	
Unit is on but the wind is not cold(hot)		☆
Unit runs, but shortly stops	☆	☆
The unit starts up and stops frequently	☆	☆
Unit runs continuously but insufficient cooling(heating)	☆ ☆	☆
Cool can not change to heat		☆
Unit is noisy		
Test method / remedy	Test voltage Close the power switch Inspect connections - tighten Change the transformer Test voltage Replace the battery of the remote control Replace the remote control Clean or replace Clean Adjust the setting temperature Turn the AC later Adjust to cool mode Turn off SILENCE function. Turn the AC later	The setting temperature is higher/lower than the room's(cooling/heating) The ambient temperature is too high/low when the mode is cooling/heating Fan mode SILENCE function is activated(optional function) Frosting and defrosting frequently

1.Remote Maintenance	Others				
Possible causes of trouble	Heavy load condition	Loosen hold down bolts and / or screws	Bad airproof	The air inlet or outlet of either unit is blocked	Interference from cell phone towers and remote boosters
Unit will not start					
The power switch is on but fans will not start				☆	
The temperature on the display board cannot be set					
Unit is on but the wind is not cold(hot)					
Unit runs, but shortly stops					
The unit starts up and stops frequently			☆		
Unit runs continuously but insufficient cooling(heating)	☆	☆	☆		
Cool can not change to heat					
Unit is noisy	☆				☆
Test method / remedy	Check heat load	Tighten bolts or screws	Close all the windows and doors	Remove the obstacles	Reconnect the power or press ON/OFF button on remote control to restart operation Remove them

2.Field Maintenance	Refrigerant Circuit										Others		
Possible causes of trouble													
Unit will not start													
Compressor will not start but fans run	☆												
Compressor and condenser (outdoor) fan will not start													
Evaporator (indoor) fan will not start													
Condenser (Outdoor) fan will not start													
Unit runs, but shortly stops		☆	☆										
Compressor short-cycles due to overload	☆												
High discharge pressure									☆				
Low discharge pressure		☆											
High suction pressure							☆						
Low suction pressure		☆	☆	☆	☆	☆							
Unit runs continuously but insufficient cooling	☆	☆	☆	☆	☆	☆							
Too cool													
Compressor is noisy							☆						
Horizontal louver can not revolve													
Test method / remedy													
Replace the compressor													
Leak test													
Replace restricted part													
Clean or replace													
Clean coil													
Check fan													
Change charged refrigerant volume													
Clean condenser or remove obstacle													
Purge, evacuate and recharge													
Remove obstruction to air flow													
Remove obstruction in air or water flow													
Remove obstruction in air or water flow													
Replace compressor							☆						
Test compressor efficiency								☆					
Replace valve									☆				
Replace valve									☆				
Replace valve										☆			
Fix feeler bulb										☆			
Check heat load											☆		
Tighten bolts or screws											☆		
Remove them											☆		
Choose AC of larger capacity or add the number of AC plate												☆	
Rectify piping so as not to contact each other or with external plate													☆

2. Field Maintenance		Electrical Circuit														
Possible causes of trouble		Power failure	Blown fuse or varistor	Loose connections	Shorted or broken wires	Safety device opens	Faulty thermostat / room temperature sensor	Wrong setting place of temperature sensor	Faulty transformer	Shorted or open capacitor	Faulty magnetic contactor for compressor	Faulty magnetic contactor for fan	Low voltage	Faulty stepping motor	Shorted or grounded compressor	Shorted or grounded fan motor
Unit will not start		☆	☆	☆	☆	☆		☆								
Compressor will not start but fans run				☆		☆			☆	☆			☆			
Compressor and condenser (outdoor) fan will not start				☆		☆				☆						
Evaporator (indoor) fan will not start				☆					☆		☆			☆		
Condenser (Outdoor) fan will not start			☆			☆			☆		☆			☆		
Unit runs, but shortly stops									☆		☆		☆			
Compressor short-cycles due to overload									☆		☆		☆			
High discharge pressure																
Low discharge pressure																
High suction pressure																
Low suction pressure																
Unit runs continuously but insufficient cooling							☆	☆								
Too cool							☆	☆								
Compressor is noisy																
Horizontal louver can not revolve		☆	☆								☆					
Test method / remedy																
		Test voltage	Inspect fuse type & size	Inspect connections - tighten	Test circuits with tester	Test continuity of safety device	Test continuity of thermostat / sensor & wiring Place the temperature sensor at the central of the air inlet grille.	Check control circuit with tester	Check capacitor with tester	Test continuity of coil & contacts	Test continuity of coil & contacts	Test voltage	Replace the stepping motor	Check resistance with multimeter	Check resistance with multimeter	

5. Quick Maintenance by Error Code

If you do not have the time to test which specific parts are faulty, you can directly change the required parts according to the error code.

You can find the parts to replace by error code in the following table.

Part requiring replacement	Error Code							
	EH00	EH03	EH60	EH61	EL0C	ER0E	EC52	ER0B
Indoor PCB	✓	✓	✓	✓	✓	✓	x	✓
Outdoor PCB	x	x	x	x	x	x	✓	x
Indoor fan motor	x	✓	x	x	x	x	x	x
T1 sensor	x	x	✓	x	x	x	x	x
T2 Sensor	x	x	x	✓	✓	x	x	x
T3 Sensor	x	x	x	x	x	x	✓	x
Compressor	x	x	x	x	✓	x	x	x
Additional refrigerant	x	x	x	x	✓	x	x	x
Water-level switch	x	x	x	x	x	✓	x	x
Water pump	x	x	x	x	x	✓	x	x
Capacitor of compressor	x	x	x	x	✓	x	x	x
Capacitor of fan motor	x	x	x	x	✓	x	x	x

6. Troubleshooting by Error Code


TS01-IDU: Indoor EEPROM parameter error diagnosis and solution

Description: Indoor PCB main chip does not receive feedback from EEPROM chip.

Recommended parts to prepare:

- Indoor PCB


Troubleshooting and repair:



Remarks:

EEPROM: A read-only memory whose contents can be erased and reprogrammed using a pulsed voltage.

The location of the EEPROM chip on the indoor PCB is shown in the following image:



Note: This pictures are only for reference, actual appearance may vary.


TS02-L-ON: Indoor and Outdoor Unit Communication Error Diagnosis and Solution

Description: Indoor unit can not communicate with outdoor unit

Recommended parts to prepare:

- Signal wires
- Magnet ring
- Indoor PCB
- Outdoor PCB

Troubleshooting and repair:




TS04-L-IDU: The Indoor fan speed is operating outside of normal range diagnosis and solution

Description: When indoor fan speed keeps too low or too high for a certain time, the LED displays the failure code and the AC turns off.

Recommended parts to prepare:

- Connection wires
- Fan assembly
- Fan motor
- Indoor main PCB

Troubleshooting and repair:




Index:**1. DC Fan Motor(control chip is in fan motor)**

Power on and when the unit is in standby, measure the voltage of pin1-pin3, pin4-pin3 in fan motor connector. If the value of the voltage is not in the range showing in below table, the PCB must has problems and need to be replaced.

- DC motor voltage input and output:

No.	Color	Signal	Voltage
1	Red	Vs/Vm	200V~380V
2	---	---	---
3	Black	GND	0V
4	White	Vcc	13.5-16.5V
5	Yellow	Vsp	0~6.5V
6	Blue	FG	13.5-16.5V





TS05-IDU: Open circuit or short circuit of indoor temperature sensor(T1, T2) diagnosis and solution

Description: If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays the failure code.

Recommended parts to prepare:

- Connection wires
- Sensors
- Indoor main PCB

Troubleshooting and repair:



Note: This picture and the value are only for reference, actual appearance and value may vary.



TS05-ODU: Open circuit or short circuit of outdoor temperature sensor(T3, T4, TP, T2B, TH) diagnosis and solution

Description: If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays the failure code.

Recommended parts to prepare:

- Connection wires
- Sensors
- Outdoor main PCB

Troubleshooting and repair:



Note: For certain models, outdoor PCB could not be removed separately. In this case, the outdoor electric control box should be replaced as a whole. For certain models, outdoor unit uses combination sensor, T3,T4 and TP are the same of sensor. This picture and the value are only for reference, actual appearance and value may vary.

TS06-ON: Refrigerant Leakage Detection diagnosis and solution


Description: Define the evaporator coil temperature T2 of the compressor just starts running as Tcool.

In the beginning 5 minutes after the compressor starts up, if $T2 < Tcool - 1^\circ\text{C}$ (1.8°F) does not keep continuous 4 seconds and compressor running frequency higher than 50Hz does not keep for 3 minutes, and this situation happens 3 times, the LED displays the failure code and the AC turns off.

Recommended parts to prepare:

- T2 sensor
- Compressor
- Capacitor of compressor
- Indoor PCB
- System problems, such as leakage or blockages
- Capacitor of fan motor
- Outdoor fan

Troubleshooting and repair:




TS15: Water-Level Alarm Malfunction Diagnosis and Solution

Description: If the sampling voltage is not 5V, the LED displays the failure code.

Recommended parts to prepare:

- Connection wires
- Water-level switch
- Water pump
- Indoor PCB




TS08-L-ON: Current overload protection Diagnosis and Solution

Description: An abnormal current rise is detected by checking the specified current detection circuit.

Recommended parts to prepare:

- Outdoor PCB
- Outdoor fan
- Compressor

Troubleshooting and repair:




TS23: Communication error between indoor two chips diagnosis and solution

Description: Indoor PCB main chip does not receive feedback from another chip.

Recommended parts to prepare:

- Indoor PCB

Troubleshooting and repair:




TS24: Phase sequence error diagnosis and solution

Description: Outdoor PCB detects the wrong phase sequence of 3-phase power supply.

Recommended parts to prepare:

- Power wiring
- Outdoor PCB

Troubleshooting and repair:




TS25: Lack of Phase diagnosis and solution

Description: Outdoor PCB detects the voltage of one or two phase are very low.

Recommended parts to prepare:

- Power wiring
- Outdoor PCB

Troubleshooting and repair:




TS26-ON: Open-circuit and short-circuit trouble of T4 or High temperature or protection of pressure diagnosis and solution

Description: For some modes, if the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays the failure code. For some models with pressure switch, the high pressure switch detects a ultra high pressure or the Low pressure switch detects a ultra low switch, which could damage the system.

Recommended parts to prepare:

- T4 sensor
- Outdoor main PCB
- Connecting wire
- Pressure switches
- Refrigeration system is over load or blocked or lack of refrigerant

Troubleshooting and repair:




TS27-ON: High temperature protection of condenser diagnosis and solution

Description: The PCB detects a high temperature of the condenser which could damage the system.

Recommended parts to prepare:

- T3 sensor
- Refrigeration system is over load or blocked or lack of refrigerant

Troubleshooting and repair:





Indoor Unit Disassembly -A6 DUCT

Contents



1.	Indoor Unit Disassembly	1
1.1	Electrical Parts	2
1.2	Fan Motor and Fan	5
1.3	Evaporator.....	7

1. Indoor Unit Disassembly


1.1 Electrical Parts (Antistatic gloves must be worn.)

Procedure	Illustration
1) Remove 5 screws of the cover of electronic control box and then remove the cover. (see CJ_A6_001)	 CJ_A6_001
2) Remove 2 screws of the electronic control box. Then release 2 hooks of the main control board. (see CJ_A6_002)	 CJ_A6_002

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>3) Disconnect the connectors and then remove the front main control board. (see CJ_A6_003)</p>	 <p style="text-align: center;">CJ_A6_003</p>
<p>4) Turn over the electronic control box. Disconnect the connectors and remove 2 screws of rear main control board. (see CJ_A6_004)</p>	 <p style="text-align: center;">CJ_A6_004</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
5) Remove 2 screws of reactor and remove the reactor. (see CJ_A6_005)	 <p data-bbox="949 1096 1097 1129">CJ_A6_005</p>

Note: This section is for reference only. Actual unit appearance may vary.

1.2 Fan motor and fan



Procedure	Illustration
1) Remove 10 screws of the top cover and then remove the top cover. (see CJ_A6_006)	 CJ_A6_006
2) Release 3 hooks of volute shell. (see CJ_A6_007)	 CJ_A6_007

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
3) Remove the fiing screws of fan (2 screws). (see CJ_A6_008)	 <p data-bbox="928 932 1071 977">CJ_A6_008</p>

Note: This section is for reference only. Actual unit appearance may vary.

1.3 Evaporator

Procedure	Illustration
1) Remove 9 Screws of the water collector and remove the water collector. (see CJ_A6_009)	 CJ_A6_009
2) Remove the screws of the pipe clamp board and the left side board (3 for the pipe clamp and 9 for left side board). (see CJ_A6_010)	 CJ_A6_010

Note: Remove the front panel (refer to 1. Front panel) before disassembling electrical parts.

Procedure	Illustration
3) Remove 2 screws of the evaporator support and then pull up the temperature sensor. (see CJ_A6_011)	 <p style="text-align: center;">CJ_A6_011</p>
4) Remove the screw of the evaporator and then remove it. (see CJ_A6_012)	 <p style="text-align: center;">CJ_A6_012</p>

Note: This section is for reference only. Actual unit appearance may vary.



Indoor Unit Disassembly-Compact Cassette

Contents



1.	Indoor Unit Disassembly	1
1.1	Front Panel and Display Board.....	2
1.2	Electrical Parts	5
1.3	Fan Motor and Fan.....	7
1.4	Water Pump	9
1.5	Evaporator.....	11

1. Indoor Unit Disassembly


1.1 Front Panel and Display Board

Procedure	Illustration
1) Release 2 hooks and open the panel. (see CJ_MCA_001)	 <p>CJ_MCA_001</p>
2) Remove two screws of wire line. (see CJ_MCA_002)	 <p>CJ_MCA_002</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
3) Release the hook then pull up the filter(see CJ_MCA_003)	 <p style="text-align: center;">CJ_MCA_003</p>
4) Remove 4 screws of cover and remove the display board(see CJ_MCA_004)	 <p style="text-align: center;">CJ_MCA_004</p>



Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
5) Remove 2 screws of display board and remove PCB.(see CJ_MCA_005)	 <p data-bbox="922 887 1102 923">CJ_MCA_005</p>

Note: This section is for reference only. Actual unit appearance may vary.




1.2 Electrical Parts(Antistatic gloves must be worn.)

Note: Remove the front panel (refer to 1.1 Front Panel and display) before disassembling electrical parts.

Procedure	Illustration
1) Remove 4 screws of the panel and pull up the panel. (see CJ_MCA_006)	 <p>CJ_MCA_006</p>
2) Remove 3 screws of electrical cover. (see CJ_MCA_007)	 <p>CJ_MCA_007</p>

Note: This section is for reference only. Actual unit appearance may vary.



◀ Indoor Unit Disassembly 5 ▶

Procedure	Illustration
3) Disconnect the connectors of PCB. (see CJ_MCA_008)	
4) Remove 2 screws of main control board and remove PCB.(see CJ_MCA_009)	
5) Remove 2 screws of electronic control box and remove electronic control box.(see CJ_MCA_010)	


Note: This section is for reference only. Actual unit appearance may vary.

1.3 Fan motor and fan

Note: Remove the front panel and electrical parts (refer to 1.1 &1.2) before disassembling fan motor.

Procedure	Illustration
1) Remove 4 screws of water collector then remove it.(see CJ_MCA_011)	 <p>CJ_MCA_011</p>
2) Remove the nut of the fan and then pull up the fan.(see CJ_MCA_012)	 <p>CJ_MCA_012</p>



Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
3) Remove the nuts and remove the fan motor(see CJ_MCA_013)	 <p data-bbox="922 1044 1097 1080">CJ_MCA_013</p>


Note: This section is for reference only. Actual unit appearance may vary.

1.4 Water Pump

Note: Remove the front panel, electrical parts and water collector (refer to 1.1,1.2 &1.3) before disassembling water pump.

Procedure	Illustration
1) Take off the fasten belt of the water pump. (see CJ_MCA_014)	 CJ_MCA_014
2) Pinch the metal wire in the direction shown in the figure to release it. (see CJ_MCA_015)	 CJ_MCA_015



Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
3) Remove 3 screws and then remove the water pump. (see CJ_MCA_016)	 <p data-bbox="922 1131 1097 1163">CJ_MCA_016</p>


Note: This section is for reference only. Actual unit appearance may vary.

1.5 Evaporator

Note: Remove the front panel, electrical parts and fan(refer to 1.1,1.2 &1.3) before disassembling evaporator.

Procedure	Illustration
1) Remove 3 screws of pipe clamp board assembly then remove it.(see CJ_MCA_017)	 CJ_MCA_017
2) Remove 4 screws of evaporator fixing board then remove it.(see CJ_MCA_018)	 CJ_MCA_018

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
3) Remove 1 screw of evaporator fixing hook and remove it. (see CJ_MCA_019)	 <p data-bbox="922 1064 1097 1098">CJ_MCA_019</p>

Note: This section is for reference only. Actual unit appearance may vary.



Indoor Unit Disassembly-New 4-way Cassette

Contents



1.	Indoor Unit Disassembly	1
1.1	Front Panel	2
1.2	Electrical Parts	5
1.3	Display Board	6
1.4	Water Pump	8
1.5	Water Collector & Water Level Switch.....	9
1.6	Fan Motor and Fan	11
1.7	Evaporator.....	12

1. Indoor Unit Disassembly


1.1 Front Panel

Procedure	Illustration
1) Push one side of the grille clamp. (see CJ_MCD1_001)	 <p>CJ_MCD1_001</p>
2) Remove one screw then push two grille clamps to remove the air inlet grille assembly.(see CJ_MCD1_002)	 <p>CJ_MCD1_002</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
3) Turn over the air inlet grille assembly then pull up the filter. (see CJ_MCD1_003)	
4) Remove 2 screws and remove the cover of electronic control box. (see CJ_MCD1_004)	

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
5) Disconnect the connectors of display board and stepper motor and release the panel. (see CJ_MCD1_005)	 <p data-bbox="913 864 1103 898">CJ_MCD1_005</p>



Note: This section is for reference only. Actual unit appearance may vary.

1.2 Electrical Parts (Antistatic gloves must be worn.)


Procedure	Illustration
<ol style="list-style-type: none">1) Remove 3 screws of electronic control box and 1 screw of earth wire.(see CJ_MCD1_006)2) Disconnect the connectors of temperature sensor, pump, motor and water level switch. (see CJ_MCD1_006)3) Remove the electronic control box subassembly. (see CJ_MCD1_006)	 <p>CJ_MCD1_006</p>
<ol style="list-style-type: none">4) Remove 2 screws of the main control board and 2 screws of earth wire. (see CJ_MCD1_007)5) Disconnect connectors and then remove the main control board. (see CJ_MCD1_007)	 <p>CJ_MCD1_007</p>

Note: This section is for reference only. Actual unit appearance may vary.

1.3 Display Board



Procedure	Illustration
1) Open the install cover assembly(with display board) (see CJ_MCD1_008)	 CJ_MCD1_008
2) Remove 1 screw of display window board. (see CJ_MCD1_009)	 CJ_MCD1_009

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
3) Turn over the display board, push the switch to remove the display board. (see CJ_MCD1_010)	 <p>CJ_MCD1_010</p>



Note: This section is for reference only. Actual unit appearance may vary.

1.4 Water Pump



Procedure	Illustration
1) Remove 5 screws fixing external water pump box assembly.(see CJ_MCD1_011)	 CJ_MCD1_011
2) Remove the water pump box assembly. (see CJ_MCD1_012)	 CJ_MCD1_012

Note: This section is for reference only. Actual unit appearance may vary.

1.5 Water Collector and Water Level Switch



Procedure	Illustration
1) Remove the 2 screws of the ventilation ring. (see CJ_MCD1_013)	 CJ_MCD1_013
2) Remove the 2 screws fixing the water collector. (see CJ_MCD1_014)	 CJ_MCD1_014

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
3) Remove the 5 screws of the water collector subassembly. (see CJ_MCD1_015)	
4) Turn over the water collector subassembly and remove the water level switch. (see CJ_MCD1_016)	



Note: This section is for reference only. Actual unit appearance may vary.

1.6 Fan Motor and Fan

Procedure	Illustration
1) Remove the nut of the fan and then pull up the fan. (see CJ_MCD1_017)	 CJ_MCD1_017
2) Remove 2 screws of fixing board and 3 nuts of fan motor. (see CJ_MCD1_018)	 CJ_MCD1_018

Note: This section is for reference only. Actual unit appearance may vary.

1.7 Evaporator

Procedure	Illustration
1) Remove 2 screws of pipe clamp board. (see CJ_MCD1_019)	 CJ_MCD1_019
2) Remove 4 screws of the evaporator fixing bracket and then remove it. (see CJ_MCD1_020)	 CJ_MCD1_020

Note: This section is for reference only. Actual unit appearance may vary.

Outdoor Unit Disassembly

Contents

1.	Outdoor Unit Table.....	2
2.	Outdoor Unit Disassembly.....	3
2.1	Panel Plate.....	3
2.2	Electrical Parts	25
2.3	Fan Assembly	51
2.4	Fan Motor	52
2.5	Sound Blanket.....	53
2.6	Four-way Valve	54
2.7	Compressor.....	55

1. Outdoor Unit Disassembly



1.1 Outdoor Unit Table

Outdoor Unit Model	Panel Plate	PCB Board
YFAD-035R-01M25	X330	PCB Board 1
YFAD-050R-01M25	X330	PCB Board 1
YFAD-070R-01M25	X430	PCB Board 1
YFAD-100R-01T35	D30	PCB Board 14
YFAD-140R-01T35	590	PCB Board 15



2. Outdoor Unit Disassembly

2.1 Panel Plate



1. BA30

Procedure	Illustration
<ol style="list-style-type: none">1) Turn off the air conditioner and the power breaker.2) Remove the screws of the big handle and then remove the big handle (1 screws) (see CJ_BA30_001).	 <p>Big Handle</p> <p>For US models (3 screws)</p>
<ol style="list-style-type: none">3) Remove the screws of the top cover and then remove the top cover (3 screws). One of the screws is located underneath the big handle (see CJ_BA30_002).	 <p>Top Cover</p> <p>CJ_BA30_001</p> <p>CJ_BA30_002</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>4) Remove the screws of the front panel and then remove the front panel (7 screws) (see CJ_BA30_003).</p>	 <p style="text-align: center;">CJ_BA30_003</p>
<p>5) Remove the screws of water collecting cover (2 screws) (see CJ_BA30_004).</p>	 <p style="text-align: center;">CJ_BA30_004</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
6) Remove the screws of the rear net and then remove the rear net (2 screws) (see CJ_BA30_005). (for some models)	 <p style="text-align: center;">CJ_BA30_005</p>
7) Remove the screws of the right panel and then remove the right panel (6 screws) (see CJ_BA30_006).	 <p style="text-align: center;">CJ_BA30_006</p>

Note: This section is for reference only. Actual unit appearance may vary.



2. B30

Procedure	Illustration
<ol style="list-style-type: none">1) Turn off the air conditioner and the power breaker.2) Remove the screws of the big handle and then remove the big handle (1 screws) (see CJ_B30_001).	
<ol style="list-style-type: none">3) Remove the screws of the top cover and then remove the top cover (3 screws). One of the screws is located underneath the big handle (see CJ_B30_002).	

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>4) Remove the screws of the front panel and then remove the front panel (8 screws) (see CJ_B30_003).</p>	 <p style="text-align: center;">CJ_B30_003</p>
<p>5) Remove the screws of water collecting cover and then remove the water collecting cover (2 screws) (see CJ_B30_004).</p>	 <p style="text-align: center;">CJ_B30_004</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
6) Remove the screws of the rear net and then remove the rear net (2 screws) (see CJ_B30_005). (for some models)	 <p style="text-align: center;">CJ_B30_005</p>
7) Remove the screws of the right panel and then remove the right panel (5 screws) (see CJ_B30_006).	 <p style="text-align: center;">CJ_B30_006</p> <p style="text-align: right;">Right Panel</p>

Note: This section is for reference only. Actual unit appearance may vary.



3. CA30

Procedure	Illustration
<ol style="list-style-type: none">1) Turn off the air conditioner and the power breaker.2) Remove the screws of the big handle and then remove the big handle (1 screws) (see CJ_CA30_001).	 <p>Big Handle</p> <p>For US models (3 screws)</p>
<ol style="list-style-type: none">3) Remove the screws of the top cover and then remove the top cover (3 screws). One of the screws is located underneath the big handle (see CJ_CA30_002).	 <p>Top Cover</p>

Note: This section is for reference only. Actual unit appearance may vary.




Procedure	Illustration
4) Remove the screws of the front panel and then remove the front panel (7 screws) (see CJ_CA30_003).	 <p style="text-align: center;">CJ_CA30_003</p>
5) Remove the screws of water collecting cover and then remove the water collecting cover (2 screws) (see CJ_CA30_004).	 <p style="text-align: center;">CJ_CA30_004</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>6) Remove the screws of the rear net and then remove the rear net (2 screws) (see CJ_CA30_005). (for some models)</p>	 <p style="text-align: center;">CJ_CA30_005</p>
<p>7) Remove the screws of the right panel and then remove the right panel (7 screws) (see CJ_CA30_006).</p>	 <p style="text-align: center;">CJ_CA30_006</p>

Note: This section is for reference only. Actual unit appearance may vary.



4. D30

Procedure	Illustration
<p>1) Turn off the air conditioner and the power breaker.</p> <p>2) Remove the screws of the big handle and then remove the big handle (2 screws) (see CJ_D30_001).</p> <p>3) Remove the screws of the top cover and then remove the top cover (4 screws). Two of the screws is located underneath the big handle (see CJ_D30_002).</p>	  <p style="text-align: center;">CJ_D30_001</p>  <p style="text-align: center;">CJ_D30_002</p>


Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>4) Remove the screws of the front right panel and then remove the front right panel (2 screws) (see CJ_D30_003).</p>	 <p>CJ_D30_003</p>
<p>5) Remove the screws of the front panel and then remove the front panel (9 screws) (see CJ_D30_004).</p>	 <p>CJ_D30_004</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
6) Remove the screws of water collecting cover and then remove the water collecting cover (2 screws) (see CJ_D30_005).	 <p style="text-align: center;">CJ_D30_005</p>
7) Remove the screws of the rear net and then remove the rear net (2 screws) (see CJ_D30_006). (for some models)	 <p style="text-align: center;">CJ_D30_006</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
8) Remove the screws of the right panel and then remove the right panel (8 screws) (see CJ_D30_007).	 <p>CJ_D30_007</p>

Note: This section is for reference only. Actual unit appearance may vary.


5. X230/X330

Procedure	Illustration
<ol style="list-style-type: none">1) Turn off the air conditioner and the power breaker.2) Remove the screw of the big handle and then remove the big handle (1 screws) (see CJ_X230_001).	 <p>CJ_X230_001</p>
<ol style="list-style-type: none">3) Remove the screws of the top cover and then remove the top cover (4 screws). One of the screws is located underneath the big handle (see CJ_X230_002).	 <p>CJ_X230_002</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>4) Remove the screws of water collecting cover and then remove the water collecting cover (2 screws) (see CJ_X230_003).</p>	 <p style="text-align: center;">CJ_X230_003</p>
<p>5) Remove the screws of the front panel and then remove the front panel (7 screws(onoff models) or 9 screws(inverter models) (see CJ_X230_004).</p>	 <p style="text-align: center;">CJ_X230_004</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
6) Remove the screws of the right panel and then remove the right panel (5 screws) (see CJ_X230_005).	 <p data-bbox="922 923 1102 956">CJ_X230_005</p>

Note: This section is for reference only. Actual unit appearance may vary.


6.X430

Procedure	Illustration
<ol style="list-style-type: none">1) Turn off the air conditioner and the power breaker.2) Remove the screw of the big handle and then remove the big handle (1 screw) (see CJ_X430_001).	 <p data-bbox="1040 729 1151 752">Big Handle</p> <p data-bbox="1230 909 1389 932">For US models (3 screws)</p>
<ol style="list-style-type: none">3) Remove the screws of the top cover and then remove the top cover (3 screws). One of the screws is located underneath the big handle (see CJ_X430_002).	 <p data-bbox="770 1201 865 1224">Top Cover</p>

Note: This section is for reference only. Actual unit appearance may vary.




Procedure	Illustration
<p>4) Remove the screws of water collecting cover and then remove the water collecting cover (2 screws) (see CJ_X430_003).</p>	 <p style="text-align: center;">CJ_X430_003</p>
<p>5) Remove the screws of the front panel and then remove the front panel (7 screws(onoff models) or 9 screws(inverter models) (see CJ_X430_004).</p>	 <p style="text-align: center;">CJ_X430_004</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
6) Remove the screws of the right panel and then remove the right panel (6 screws) (see CJ_X430_005).	 <p data-bbox="921 1145 1095 1179">CJ_X430_005</p>

Note: This section is for reference only. Actual unit appearance may vary.



6. E30/590

Procedure	Illustration
<ol style="list-style-type: none">1) Turn off the air conditioner and the power breaker.2) Remove the screws of the big handle and then remove the big handle (2 screws) (see CJ_E30_001).	
	CJ_E30_001
<ol style="list-style-type: none">3) Remove the screws of the top cover and then remove the top cover (4 screws). Two of the screws is located underneath the big handle (see CJ_E30_002).	
	CJ_E30_002
<ol style="list-style-type: none">4) Remove the screws of water collecting cover and then remove the water collecting cover (2 screw) (see CJ_E30_003).	
	CJ_E30_003

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
5) Remove the screws of the front right panel and then remove the front right panel (2 screws) (see CJ_E30_004).	 <p data-bbox="928 1358 1087 1392">CJ_E30_004</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>1) Remove the screws of the front panel and then remove the front panel (7 screws) (see CJ_E30_005).</p>	 <p style="text-align: center;">CJ_E30_005</p>
<p>2) Remove the screws of the right panel and then remove the right panel (10 screws) (see CJ_E30_006).</p>	 <p style="text-align: center;">CJ_E30_006</p>

Note: This section is for reference only. Actual unit appearance may vary.



2.2 Electrical parts

! WARNING: Antistatic gloves must be worn when you disassemble the electronic box.



Note: Remove the air outlet grille(refer to 3.1 Panel Plate) before disassembling electrical parts.

i) PCB for ON-OFF Models

1. PCB board 1

Procedure	Illustration
<ol style="list-style-type: none"> 1) Remove the two screws fixed the electronic control board (see CJ_ODU_PCB_001). 2) Disconnect the connectors for fan motor. (Blue wire, yellow wire, red wire, brown wire and black wire. The blue wire and red wire are on the capacitor. The black wire connects with terminal 4.) (see CJ_ODU_PCB_001) 3) Disconnect the wires connected to the compressor. (Black wire connects with terminal 1,blue wire and red wire connect with the compressor capacitor) (see CJ_ODU_PCB_001) 4) Disconnect the wires connected to 4-way valve.(Blue wires on terminal 2&3) (see CJ_ODU_PCB_001) 5) Remove the fixing screw of the compressor capacitor, then pull it out (see CJ_ODU_PCB_001) 6) Remove the electrical parts (see CJ_ODU_PCB_001) 7) For models with AC conductor, remove 2 screws of it showed in the figure. 	 <p>CJ_ODU_PCB_001-01</p>  <p>CJ_ODU_PCB_001-02</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
8) For models with subzero refrigeration control board, remove 3 screws of it showed in the figure.	 <p style="text-align: center;">CJ_ODU_PCB_001-03</p>
9) The subzero refrigeration control board is in the back of the metal sheet.	 <p style="text-align: center;">CJ_ODU_PCB_001-04</p>



Note: This section is for reference only. Actual unit appearance may vary.

2. PCB board 2



Procedure	Illustration
<ol style="list-style-type: none">1) Disconnect the power transformer (see CJ_ODU_010)2) Disconnect the wires connected to terminals. (see CJ_ODU_010)3) Disconnect the wires connected to contactor. (see CJ_ODU_010)4) Disconnect the wires connected to T3/T4 sensor. (see CJ_ODU_010)	<p>The diagram illustrates the PCB board 2 with various electronic components and their connections. Key components shown include a central microcontroller, a fan motor driver, a power transformer, a contactor, and a terminal block. Wires are color-coded and labeled: T3(Black) and T4(White) at the top; Fan Motor, Contactor, and Power Transformer on the bottom left; and Terminal on the right. Dashed lines indicate the points of disconnection for the procedure steps.</p>

Note: This section is for reference only. Actual unit appearance may vary.

3. PCB board 3



Procedure	Illustration
<ol style="list-style-type: none"> 1) Disconnect the wires connected to the transformer. (see CJ_ODU_PCB_003-1) 2) Disconnect the wires connected to high/low pressure switch. (see CJ_ODU_PCB_003-1) 3) Disconnect the wires connected to indoor unit. (see CJ_ODU_PCB_003-1) 4) Disconnect the wires connected to AC contactor. (see CJ_ODU_PCB_003-1) 	 <p>CJ_ODU_PCB_003-1</p>
<ol style="list-style-type: none"> 5) Remove the screws of the capacitor and then remove it (1 screw for each capacitor). (see CJ_ODU_PCB_003-2) 	 <p>CJ_ODU_PCB_003-2</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
6) Remove the 1 screw of the AC contactor and then remove it. (see CJ_ODU_PCB_003-3)	
7) Remove 2 screws of the transformer and then remove it. (see CJ_ODU_PCB_003-4)	 <p style="text-align: center;">CJ_ODU_PCB_003-4</p>

Note: This section is for reference only. Actual unit appearance may vary.

4. PCB board 14




Procedure	Illustration
<ol style="list-style-type: none">1) Remove the fixing screw of the compressor capacitor, then pull it out (see CJ_ODU_PCB_014-1)2) Remove 2 screws of the transformer and then remove it. (see CJ_ODU_PCB_014-1)3) Remove the fixing screw of the fan motor capacitor, then remove it. (see CJ_ODU_PCB_014-1)4) Remove the 4 screws of the electronic installing box and then remove it. (see CJ_ODU_PCB_014-1) (for some models)	 <p>CJ_ODU_PCB_014-1</p>
<ol style="list-style-type: none">5) Remove the 2 screws of the AC contactor and then remove it. (see CJ_ODU_PCB_014-2)	 <p>CJ_ODU_PCB_014-2</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>6) Disconnect the power transformer (see CJ_ODU_014-3)</p> <p>7) Disconnect the wires connected to terminals. (see CJ_ODU_014-3)</p> <p>8) Disconnect the wires connected to contactor. (see CJ_ODU_014-3)</p> <p>9) Disconnect the wires connected to T3/T4 sensor. (see CJ_ODU_014-3)</p>	 <p>CJ_ODU_PCB_014-3</p>

Note: This section is for reference only. Actual unit appearance may vary.

5. PCB board 15

Procedure	Illustration
<p>1) Remove the 5 screws of the electronic installing box and then remove it. (see CJ_ODU_PCB_015-1)(for some models)</p>	 <p style="text-align: center;">CJ_ODU_PCB_015-1</p>
<p>2) Remove the 2 screws of the AC contactor and then remove it. (see CJ_ODU_PCB_015-2)</p>	 <p style="text-align: center;">CJ_ODU_PCB_015-2</p>
<p>3) Remove the screws of the capacitor and then remove it (1 screw for each capacitor). (see CJ_ODU_PCB_015-3)</p>	 <p style="text-align: center;">CJ_ODU_PCB_015-3</p>




Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>4) Remove 2 screws of the transformer and then remove it. (see CJ_ODU_PCB_015-4)</p>	
<p>5) Disconnect the wires connected to the transformer. (see CJ_ODU_PCB_015-5)</p> <p>6) Disconnect the wires connected to high/low pressure switch. (see CJ_ODU_PCB_015-5)</p> <p>7) Disconnect the wires connected to T3/T4 sensor. (see CJ_ODU_015-5)</p> <p>8) Disconnect the wires connected to terminal. (see CJ_ODU_PCB_015-5)</p>	 <p>CJ_ODU_PCB_015-4</p> <p>CJ_ODU_PCB_015-5</p>

Note: This section is for reference only. Actual unit appearance may vary.



ii) PCB for Inverter Models

6. PCB board 4

Procedure	Illustration
1) Remove the screws of the top cover. (2 screws) (see CJ_ODU_PCB_004-1).	 CJ_ODU_PCB_004-1
2) Unfix the hooks and then open the electronic control box cover (4 hooks) (see CJ_ODU_PCB_004-2).	 CJ_ODU_PCB_004-2
3) Disconnect the connector for fan motor from the electronic control board (see CJ_ODU_PCB_004-3). 4) Remove the connector for the compressor (see CJ_ODU_PCB_004-3). 5) Pull out the two blue wires connected with the four way valve (CJ_ODU_PCB_004-3). 6) Pull out connectors of the condenser coil temp. sensor(T3),outdoor ambient temp. sensor(T4) and discharge temp. sensor(TP) (CJ_ODU_PCB_004-3). 7) Disconnect the electronic expansion valve wire (CJ_ODU_PCB_004-3). 8) Then remove the electronic control board.	 CJ_ODU_PCB_004-3



Note: This section is for reference only. Actual unit appearance may vary.

7. PCB board 5

Procedure	Illustration
<ol style="list-style-type: none"> 1) Unfix the hooks and then open the electronic control box cover (4 hooks) (see CJ_ODU_PCB_005-1). 2) Disconnect the connector for fan motor from the electronic control board (see CJ_ODU_PCB_005-2). 3) Remove the connector for the compressor (see CJ_ODU_PCB_005-2). 4) Pull out the two blue wires connected with the four way valve (see CJ_ODU_PCB_005-2). 5) Pull out connectors of the condenser coil temp. sensor(T3),outdoor ambient temp. sensor(T4) and discharge temp. sensor(TP) (see CJ_ODU_PCB_005-2). 6) Disconnect the electronic expansion valve wire (see Fig CJ_ODU_PCB_005-2). 7) Then remove the electronic control board. 	 




Note: This section is for reference only. Actual unit appearance may vary.

8. PCB board 6


Procedure	Illustration
<p>1) Remove the screws and unfix the hooks, then open the electronic control box cover (5 screws and 2 hooks)(see CJ_ODU_PCB_006-1).</p>	 <p style="text-align: center;">CJ_ODU_PCB_006-1</p>
<p>2) Disconnect the connector for fan motor from the electronic control board (see CJ_ODU_PCB_006-2).</p> <p>3) Remove the connector for the compressor (see CJ_ODU_PCB_006-2).</p> <p>4) Pull out the two blue wires connected with the four way valve (see CJ_ODU_PCB_006-2).</p> <p>5) Pull out connectors of the condenser coil temp. sensor(T3),outdoor ambient temp. sensor(T4) and discharge temp. sensor(TP) (see CJ_ODU_PCB_006-2).</p> <p>6) Disconnect the electronic expansion valve wire (see Fig CJ_ODU_PCB_006-2).</p> <p>7) Remove the connector for the DR and reactor (see Fig CJ_ODU_PCB_006-2).</p> <p>8) Then remove the electronic control board.</p>	 <p style="text-align: center;">CJ_ODU_PCB_006-2</p>

Note: This section is for reference only. Actual unit appearance may vary.

9. PCB board 7



Procedure	Illustration
1) Remove the screws of the top cover. (1 screws) (see CJ_ODU_PCB_007-1).	 <p style="text-align: center;">CJ_ODU_PCB_007-1</p>
2) Unfix the hooks and then open the electronic control box cover (5 hooks) (see CJ_ODU_PCB_007-2).	 <p style="text-align: center;">CJ_ODU_PCB_007-2</p>
3) Disconnect the connector for fan motor from the IPM board (see CJ_ODU_PCB_007-3). 4) Remove the connector for the compressor (see CJ_ODU_PCB_007-3).	 <p style="text-align: center;">CJ_ODU_PCB_007-3</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>5) Pull out the wire connected with the terminal. (see CJ_ODU_PCB_007-4).</p> <p>6) Pull out connectors of the condenser coil temp. sensor(T3),outdoor ambient temp. sensor(T4) and discharge temp. sensor(TP) (see CJ_ODU_PCB_007-4).</p> <p>7) Disconnect the electronic expansion valve wire (see Fig CJ_ODU_PCB_007-4).</p> <p>8) Remove the connector for 4-way valve. (see Fig CJ_ODU_PCB_007-4).</p> <p>9) Remove the connector for the reactor (see Fig CJ_ODU_PCB_007-4).</p> <p>10) Then remove the electronic control box (see Fig CJ_ODU_PCB_007-4).</p>	 <p style="text-align: center;">CJ_ODU_PCB_007-4</p>



Note: This section is for reference only. Actual unit appearance may vary.

10. PCB board 8


Procedure	Illustration
<ol style="list-style-type: none"> 1) Unfix the hooks and then open the electronic control box cover (4 hooks) (see CJ_ODU_PCB_008-1). 2) Disconnect the connector for outdoor DC fan from the electronic control board (see CJ_ODU_PCB_008-2). 3) Remove the connector for the compressor (see CJ_ODU_PCB_008-2). 4) Pull out the two blue wires connected with the four way valve (see CJ_ODU_PCB_008-2). 5) Pull out connectors of the condenser coil temp. sensor(T3),outdoor ambient temp. sensor(T4) and discharge temp. sensor(TP) (see CJ_ODU_PCB_008-2). 6) Disconnect the electronic expansion valve wire (see Fig CJ_ODU_PCB_008-2). 7) Disconnect the communication wire indoor PCB (see Fig CJ_ODU_PCB_008-2). 8) Disconnect the PFC inductor (see Fig CJ_ODU_PCB_008-2). 9) Then remove the electronic control box (see CJ_ODU_PCB_008-2). 	 <p style="text-align: center;">CJ_ODU_PCB_008-1</p>  <p style="text-align: center;">CJ_ODU_PCB_008-2</p>

Note: This section is for reference only. Actual unit appearance may vary.

11. PCB board 9



Procedure	Illustration
1) Unfix the hooks and then open the electronic control box cover (4 hooks) (see CJ_ODU_PCB_009-1).	 CJ_ODU_PCB_009-1
2) Remove 8 screws on the electronic control board and then turn over the electronic control board (see CJ_ODU_PCB_009-2).	 CJ_ODU_PCB_009-2

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>3) Pull out the two blue wires connected with the four way valve. (see CJ_ODU_PCB_009-3)(for heat pump models)</p> <p>4) Pull out connectors of the condenser coil temp. sensor(T3),outdoor ambient temp. sensor(T4) and discharge temp. sensor(TP). (see CJ_ODU_PCB_009-3)</p> <p>5) Disconnect the electronic expansion valve wire. (see Fig CJ_ODU_PCB_009-3)(for some models)</p> <p>6) Remove four screws and unfix the 3 hooks and then remove the main control board. (see CJ_ODU_PCB_009-3)</p> <p>7) Disconnect the connector for outdoor DC fan from the IPM board. (see CJ_ODU_PCB_009-3)(for some models)</p> <p>8) Remove the connector for the compressor. (see CJ_ODU_PCB_009-3)</p> <p>9) Remove the connector for the PFC Inductor. (see CJ_ODU_PCB_009-3)</p> <p>10)Pull out 3 connectors between IPM board and main control board.(see CJ_ODU_PCB_009-3)</p> <p>11)Remove two screws and unfix the 4 hooks and then remove the IPM board. (see CJ_ODU_PCB_009-3)</p>	 <p style="text-align: center;">CJ_ODU_PCB_009-3</p>

Note: This section is for reference only. Actual unit appearance may vary.


12. PCB board 10

Procedure	Illustration
1) Unfix the hooks and then open the electronic control box cover (4 hooks) (see CJ_ODU_PCB_010-1).	 CJ_ODU_PCB_010-1
2) Remove 4 screws on the electronic control board and then turn over the electronic control board (see CJ_ODU_PCB_010-2).	 CJ_ODU_PCB_010-2

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>3) Pull out the connectors (see CJ_ODU_PCB_010-3).</p> <p>4) Remove the 9 screws and unfix the 3 hooks and then remove the electronic control board(see CJ_ODU_PCB_010-3).</p>	 <p style="text-align: center;">CJ_ODU_PCB_010-3</p>
<p>5) Remove two screws and then remove the electronic control box subassembly on partition board assembly. (see CJ_ODU_PCB_010-4).</p>	 <p style="text-align: center;">CJ_ODU_PCB_010-4</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>6) Remove two screws and two connectors and then remove the inverter control board (see CJ_ODU_PCB_010-5).</p>	 <p>Connect to CN301</p> <p>Connect to FM1</p> <p>CJ_ODU_PCB_010-5</p>


Note: This section is for reference only. Actual unit appearance may vary.

13. PCB board 11

Procedure	Illustration
<ol style="list-style-type: none"> 1) Remove 2 screws to disconnect the power supply wires. (see CJ_ODU_PCB_011-1) 2) Remove 3 screws to disconnect ground wires. (see CJ_ODU_PCB_011-1) 3) Disconnect the wires connected to main control board. (see CJ_ODU_PCB_011-1) 4) Disconnect the wires between main control board and IPM module board. (see CJ_ODU_PCB_011-1) 5) Remove the 4 screws and unfix the 6 hooks and then remove the main control board.(see CJ_ODU_PCB_011-1) 6) Remove 1 screw to remove the fan motor capacitor(1 screw for each capacitor).(see CJ_ODU_PCB_004-1). 	


CJ_ODU_PCB_011-1

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<ol style="list-style-type: none"> 1) Remove 2 screws to disconnect the power supply wires. (see CJ_ODU_PCB_011-2) 2) Remove 3 screws to disconnect the wires connected to the compressor. (see CJ_ODU_PCB_011-2) 3) Remove 3 screws to remove the radiator.(see CJ_ODU_PCB_011-2) 4) Disconnect the wires between IPM module board and main control board. (see CJ_ODU_PCB_011-2) 5) Remove the 4 screws and unfix the 4 hooks and then remove the IPM moduel board.(see CJ_ODU_PCB_011-2) 	 <p>CJ_ODU_PCB_011-2</p>

Note: This section is for reference only. Actual unit appearance may vary.

14. PCB board 12



Procedure	Illustration
<ol style="list-style-type: none">1) Remove 3 screws to disconnect the wires connected to the compressor. (see CJ_ODU_PCB_012-1)2) Remove 2 screws to disconnect the power supply wires. (see CJ_ODU_PCB_012-1)3) Disconnect the wires connected to main control board. (see CJ_ODU_PCB_012-1)4) Remove the 4 screws and unfix the 6 hooks and then remove the main control board.(see CJ_ODU_PCB_012-1)5) Remove the screw of the fan capacitor and then remove it (1 screw for each capacitor). (see CJ_ODU_PCB_012-1)	 <p>Fan motor capacitors</p> <p>CJ_ODU_PCB_012-1</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>6) Remove 3 screws to disconnect the power supply wires. (see CJ_ODU_PCB_012-1)</p> <p>7) Remove 3 screws to disconnect ground wires. (see CJ_ODU_PCB_012-1)</p> <p>8) Disconnect the wires connected to main control board. (see CJ_ODU_PCB_012-2)</p> <p>9) Remove the 4 screws and unfix the 4 hooks and then remove the filter board.(see CJ_ODU_PCB_012-2)</p> <p>10)Remove the 2 screws of the reactor and then remove it . (see CJ_ODU_PCB_012-2)</p>	
<p>11)Disconnect the wires connected to main control board. (see CJ_ODU_PCB_012-3)(for some models)</p> <p>12)Remove the 2 screws and then remove the DC motor driver board. (see CJ_ODU_PCB_012-3)(for some models)</p>	<p>CJ_ODU_PCB_012-2</p>  <p>CJ_ODU_PCB_012-3 (for some models)</p>

Note: This section is for reference only. Actual unit appearance may vary.

15. PCB board 13

Procedure	Illustration
1) Unfix the hooks and then open the electronic control box cover (4 hooks) (see CJ_ODU_PCB_013-1).	 CJ_ODU_PCB_013-1
2) Remove 6 screws on the electronic control board and then turn over the electronic control board (see CJ_ODU_PCB_013-2).	 CJ_ODU_PCB_013-2


Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>3) Pull out the connectors (see CJ_ODU_PCB_013-3).</p> <p>4) Remove the 4 screws and then remove the electronic control board(see CJ_ODU_PCB_013-3).</p>	
<p>5) Pull out the connector, remove one screw and then remove the key board subassembly on terminal board. (see CJ_ODU_PCB_013-4) (for some units).</p>	

Note: This section is for reference only. Actual unit appearance may vary.

2.3 Fan Assembly


Note: Remove the panel plate (refer to 3.1 Panel Plate) before disassembling fan.

Procedure	Illustration
<ol style="list-style-type: none">1) Remove the nut securing the fan with a spanner (see CJ_ODU_FAN_001-1&2).2) Remove the fan.	 <p>CJ_ODU_FAN_001-1</p> <p>CJ_ODU_FAN_001-2</p>

Note: This section is for reference only. Actual unit appearance may vary.

2.4 Fan Motor


Note: Remove the panel plate and the connection of fan motor on PCB (refer to 3.1 Panel Plate and 3.2 Electrical parts) before disassembling fan motor.

Procedure	Illustration
<ol style="list-style-type: none">3) Remove the fixing screws of the fan motor (4 screws) (see CJ_ODU_MOTOR_001).4) Remove the fan motor.	 <p>CJ_ODU_MOTOR_001</p>

Note: This section is for reference only. Actual unit appearance may vary.

2.5 Sound blanket

Note: Remove the panel plate (refer to 3.1 Panel plate) before disassembling sound blanket.


Procedure	Illustration
1) Remove the sound blanket (side and top) (see CJ_ODU_BLANKET_001).	 <p data-bbox="627 685 801 707">Sound Blanket(top)</p> <p data-bbox="706 808 881 831">Sound Blanket(side)</p> <p data-bbox="865 977 1167 999">CJ_ODU_BLANKET_001</p>

Note: This section is for reference only. Actual unit appearance may vary.

2.6 Four-way valve (for heat pump models)

! WARNING: Evacuate the system and confirm that there is no refrigerant left in the system before removing the four-way valve and the compressor. (For R32 & R290, you should evacuate the system with the vacuum pump; flush the system with nitrogen; then repeat the two steps before heating up the brazed parts. The operations above should be implemented by professionals.)

Note: Remove the panel plate, connection of four-way valve on PCB (refer to 3.1 Panel plate and 3.2 Electrical parts) before disassembling sound blanket.



Procedure	Illustration
<ol style="list-style-type: none">1) Heat up the brazed parts and then detach the the four-way valve and the pipe (see CJ_ODU_VALVE_001).2) Remove the four-way valve assembly with pliers.	 <p>CJ_ODU_VALVE_001</p>

Note: This section is for reference only. Actual unit appearance may vary.



2.7 Compressor

! WARNING: Evacuate the system and confirm that there is no refrigerant left in the system before removing the four-way valve and the compressor. (For R32 & R290, you should evacuate the system with the vacuum pump; flush the system with nitrogen; then repeat the two steps before heating up the brazed parts. The operations above should be implemented by professionals.)

Note: Remove the panel plate, connection of compressor on PCB (refer to 3.1 Panel plate and 3.2 Electrical parts) before disassembling sound blanket.

Procedure	Illustration
1) Remove the flange nut of terminal cover and remove the terminal cover (see CJ_ODU_COMP_001).	 CJ_ODU_COMP_001
2) Disconnect the connectors (see CJ_ODU_COMP_002).	 CJ_ODU_COMP_002

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>3) Remove the hex nuts and washers securing the compressor, located on the bottom plate (see CJ_ODU_COMP_003).</p>	 <p>CJ_ODU_COMP_003</p>
<p>4) Heat up the brazed parts and then remove the discharge pipe and the suction pipe (see CJ_ODU_COMP_004). 5) Lift the compressor from the base pan assembly with pliers.</p>	 <p>CJ_ODU_COMP_004</p>

Note: This section is for reference only. Actual unit appearance may vary.

Appendix

Contents

- i) Temperature Sensor Resistance Value Table for T1, T2, T3, and T4 (°C – K)2
- ii) Temperature Sensor Resistance Value Table for TP (for some units)(°C --K)3
- iii) Pressure On Service Port4

i) Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 (°C – K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	115.266	20	68	12.6431	60	140	2.35774	100	212	0.62973
-19	-2	108.146	21	70	12.0561	61	142	2.27249	101	214	0.61148
-18	0	101.517	22	72	11.5	62	144	2.19073	102	216	0.59386
-17	1	96.3423	23	73	10.9731	63	145	2.11241	103	217	0.57683
-16	3	89.5865	24	75	10.4736	64	147	2.03732	104	219	0.56038
-15	5	84.219	25	77	10	65	149	1.96532	105	221	0.54448
-14	7	79.311	26	79	9.55074	66	151	1.89627	106	223	0.52912
-13	9	74.536	27	81	9.12445	67	153	1.83003	107	225	0.51426
-12	10	70.1698	28	82	8.71983	68	154	1.76647	108	226	0.49989
-11	12	66.0898	29	84	8.33566	69	156	1.70547	109	228	0.486
-10	14	62.2756	30	86	7.97078	70	158	1.64691	110	230	0.47256
-9	16	58.7079	31	88	7.62411	71	160	1.59068	111	232	0.45957
-8	18	56.3694	32	90	7.29464	72	162	1.53668	112	234	0.44699
-7	19	52.2438	33	91	6.98142	73	163	1.48481	113	235	0.43482
-6	21	49.3161	34	93	6.68355	74	165	1.43498	114	237	0.42304
-5	23	46.5725	35	95	6.40021	75	167	1.38703	115	239	0.41164
-4	25	44	36	97	6.13059	76	169	1.34105	116	241	0.4006
-3	27	41.5878	37	99	5.87359	77	171	1.29078	117	243	0.38991
-2	28	39.8239	38	100	5.62961	78	172	1.25423	118	244	0.37956
-1	30	37.1988	39	102	5.39689	79	174	1.2133	119	246	0.36954
0	32	35.2024	40	104	5.17519	80	176	1.17393	120	248	0.35982
1	34	33.3269	41	106	4.96392	81	178	1.13604	121	250	0.35042
2	36	31.5635	42	108	4.76253	82	180	1.09958	122	252	0.3413
3	37	29.9058	43	109	4.5705	83	181	1.06448	123	253	0.33246
4	39	28.3459	44	111	4.38736	84	183	1.03069	124	255	0.3239
5	41	26.8778	45	113	4.21263	85	185	0.99815	125	257	0.31559
6	43	25.4954	46	115	4.04589	86	187	0.96681	126	259	0.30754
7	45	24.1932	47	117	3.88673	87	189	0.93662	127	261	0.29974
8	46	22.5662	48	118	3.73476	88	190	0.90753	128	262	0.29216
9	48	21.8094	49	120	3.58962	89	192	0.8795	129	264	0.28482
10	50	20.7184	50	122	3.45097	90	194	0.85248	130	266	0.2777
11	52	19.6891	51	124	3.31847	91	196	0.82643	131	268	0.27078
12	54	18.7177	52	126	3.19183	92	198	0.80132	132	270	0.26408
13	55	17.8005	53	127	3.07075	93	199	0.77709	133	271	0.25757
14	57	16.9341	54	129	2.95896	94	201	0.75373	134	273	0.25125
15	59	16.1156	55	131	2.84421	95	203	0.73119	135	275	0.24512
16	61	15.3418	56	133	2.73823	96	205	0.70944	136	277	0.23916
17	63	14.6181	57	135	2.63682	97	207	0.68844	137	279	0.23338
18	64	13.918	58	136	2.53973	98	208	0.66818	138	280	0.22776
19	66	13.2631	59	138	2.44677	99	210	0.64862	139	282	0.22231


ii) Temperature Sensor Resistance Value Table for TP(for some units) (°C --K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	542.7	20	68	68.66	60	140	13.59	100	212	3.702
-19	-2	511.9	21	70	65.62	61	142	13.11	101	214	3.595
-18	0	483	22	72	62.73	62	144	12.65	102	216	3.492
-17	1	455.9	23	73	59.98	63	145	12.21	103	217	3.392
-16	3	430.5	24	75	57.37	64	147	11.79	104	219	3.296
-15	5	406.7	25	77	54.89	65	149	11.38	105	221	3.203
-14	7	384.3	26	79	52.53	66	151	10.99	106	223	3.113
-13	9	363.3	27	81	50.28	67	153	10.61	107	225	3.025
-12	10	343.6	28	82	48.14	68	154	10.25	108	226	2.941
-11	12	325.1	29	84	46.11	69	156	9.902	109	228	2.86
-10	14	307.7	30	86	44.17	70	158	9.569	110	230	2.781
-9	16	291.3	31	88	42.33	71	160	9.248	111	232	2.704
-8	18	275.9	32	90	40.57	72	162	8.94	112	234	2.63
-7	19	261.4	33	91	38.89	73	163	8.643	113	235	2.559
-6	21	247.8	34	93	37.3	74	165	8.358	114	237	2.489
-5	23	234.9	35	95	35.78	75	167	8.084	115	239	2.422
-4	25	222.8	36	97	34.32	76	169	7.82	116	241	2.357
-3	27	211.4	37	99	32.94	77	171	7.566	117	243	2.294
-2	28	200.7	38	100	31.62	78	172	7.321	118	244	2.233
-1	30	190.5	39	102	30.36	79	174	7.086	119	246	2.174
0	32	180.9	40	104	29.15	80	176	6.859	120	248	2.117
1	34	171.9	41	106	28	81	178	6.641	121	250	2.061
2	36	163.3	42	108	26.9	82	180	6.43	122	252	2.007
3	37	155.2	43	109	25.86	83	181	6.228	123	253	1.955
4	39	147.6	44	111	24.85	84	183	6.033	124	255	1.905
5	41	140.4	45	113	23.89	85	185	5.844	125	257	1.856
6	43	133.5	46	115	22.89	86	187	5.663	126	259	1.808
7	45	127.1	47	117	22.1	87	189	5.488	127	261	1.762
8	46	121	48	118	21.26	88	190	5.32	128	262	1.717
9	48	115.2	49	120	20.46	89	192	5.157	129	264	1.674
10	50	109.8	50	122	19.69	90	194	5	130	266	1.632
11	52	104.6	51	124	18.96	91	196	4.849			
12	54	99.69	52	126	18.26	92	198	4.703			
13	55	95.05	53	127	17.58	93	199	4.562			
14	57	90.66	54	129	16.94	94	201	4.426			
15	59	86.49	55	131	16.32	95	203	4.294			
16	61	82.54	56	133	15.73	96	205	4.167			
17	63	78.79	57	135	15.16	97	207	4.045			
18	64	75.24	58	136	14.62	98	208	3.927			
19	66	71.86	59	138	14.09	99	210	3.812			

iii) Pressure On Service Port


Cooling chart(R410A):

°F(°C)	ODU(DB) IDU(DB/WB)										
		0(-17)	5(-15)	15 (-9.44)	45 (7.22)	75 (23.89)	85 (29.44)	95 (35)	105 (40.56)	115 (46.11)	120 (48.89)
BAR	70/59 (21.11/15)	6.4	6.5	7.3	8.0	8.2	7.8	8.1	8.6	10.1	10.6
	75/63 (23.89/17.22)	6.7	6.8	7.9	8.6	8.6	8.3	8.7	9.1	10.7	11.2
	80/67 (26.67/19.44)	7.1	7.2	8.5	9.5	9.3	8.9	9.1	9.6	11.2	11.9
	90/73 (32.22/22.78)	7.7	7.8	9.6	10.5	10.3	9.5	10.0	10.6	12.4	13.0
PSI	70/59 (21.11/15)	93	94	106	116	119	113	117	125	147	154
	75/63 (23.89/17.22)	97	99	115	125	124	120	126	132	155	162
	80/67 (26.67/19.44)	103	104	123	138	135	129	132	140	162	173
	90/73 (32.22/22.78)	112	113	139	152	149	138	145	154	180	189
MPa	70/59 (21.11/15)	0.64	0.65	0.73	0.8	0.82	0.78	0.81	0.86	1.01	1.06
	75/63 (23.89/17.22)	0.67	0.68	0.79	0.86	0.86	0.83	0.87	0.91	1.07	1.12
	80/67 (26.67/19.44)	0.71	0.72	0.85	0.95	0.93	0.89	0.91	0.96	1.12	1.19
	90/73 (32.22/22.78)	0.77	0.78	0.96	1.05	1.03	0.95	1	1.06	1.24	1.3



Heating chart(R410A):

$^{\circ}\text{F}(\text{ }^{\circ}\text{C})$	ODU(DB/WB) IDU(DB)	57/53 (13.89/11.67)	47/43 (8.33/6.11)	37/33 (2.78/0.56)	27/23 (-2.78/-5)	17/13 (-8.33/-10.56)	0/-2 (-17/-19)	-17/-18 (-27/-28)
BAR	55(12.78)	30.3	28.5	25.3	22.8	20.8	18.5	16.5
	65(18.33)	32.5	30.0	26.6	25.4	23.3	20.5	19.0
	75(23.89)	33.8	31.5	27.8	26.3	24.9	21.5	20.0
PSI	55(12.78)	439	413	367	330	302	268	239
	65(18.33)	471	435	386	368	339	297	276
	75(23.89)	489	457	403	381	362	312	290
MPa	55(12.78)	3.03	2.85	2.53	2.28	2.08	1.85	1.65
	65(18.33)	3.25	3.00	2.66	2.54	2.33	2.05	1.90
	75(23.89)	3.38	3.15	2.78	2.63	2.49	2.15	2.00



System Pressure Table-R410A

Pressure			Temperature		Pressure			Temperature	
Kpa	bar	PSI	°C	°F	Kpa	bar	PSI	°C	°F
100	1	14.5	-51.623	-60.921	2350	23.5	340.75	38.817	101.871
150	1.5	21.75	-43.327	-45.989	2400	24	348	39.68	103.424
200	2	29	-36.992	-34.586	2450	24.5	355.25	40.531	104.956
250	2.5	36.25	-31.795	-25.231	2500	25	362.5	41.368	106.462
300	3	43.5	-27.351	-17.232	2550	25.5	369.75	42.192	107.946
350	3.5	50.75	-23.448	-10.206	2600	26	377	43.004	109.407
400	4	58	-19.953	-3.915	2650	26.5	384.25	43.804	110.847
450	4.5	65.25	-16.779	1.798	2700	27	391.5	44.592	112.266
500	5	72.5	-13.863	7.047	2750	27.5	398.75	45.37	113.666
550	5.5	79.75	-11.162	11.908	2800	28	406	46.136	115.045
600	6	87	-8.643	16.444	2850	28.5	413.25	46.892	116.406
650	6.5	94.25	-6.277	20.701	2900	29	420.5	47.638	117.748
700	7	101.5	-4.046	24.716	2950	29.5	427.75	48.374	119.073
750	7.5	108.75	-1.933	28.521	3000	30	435	49.101	120.382
800	8	116	0.076	32.137	3050	30.5	442.25	49.818	121.672
850	8.5	123.25	1.993	35.587	3100	31	449.5	50.525	122.945
900	9	130.5	3.826	38.888	3150	31.5	456.75	51.224	124.203
950	9.5	137.75	5.584	42.052	3200	32	464	51.914	125.445
1000	10	145	7.274	45.093	3250	32.5	471.25	52.596	126.673
1050	10.5	152.25	8.901	48.022	3300	33	478.5	53.27	127.886
1100	11	159.5	10.471	50.848	3350	33.5	485.75	53.935	129.083
1150	11.5	166.75	11.988	53.578	3400	34	493	54.593	130.267
1200	12	174	13.457	56.223	3450	34.5	500.25	55.243	131.437
1250	12.5	181.25	14.879	58.782	3500	35	507.5	55.885	132.593
1300	13	188.5	16.26	61.268	3550	35.5	514.75	56.52	133.736
1350	13.5	195.75	17.602	63.684	3600	36	522	57.148	134.866
1400	14	203	18.906	66.031	3650	36.5	529.25	57.769	135.984
1450	14.5	210.25	20.176	68.317	3700	37	536.5	58.383	137.089
1500	15	217.5	21.414	70.545	3750	37.5	543.75	58.99	138.182
1550	15.5	224.75	22.621	72.718	3800	38	551	59.591	139.264
1600	16	232	23.799	74.838	3850	38.5	558.25	60.185	140.333
1650	16.5	239.25	24.949	76.908	3900	39	565.5	60.773	141.391
1700	17	246.5	26.074	78.933	3950	39.5	572.75	61.355	142.439
1750	17.5	253.75	27.174	80.913	4000	40	580	61.93	143.474
1800	18	261	28.251	82.852	4050	40.5	587.25	62.499	144.498
1850	18.5	268.25	29.305	84.749	4100	41	594.5	63.063	145.513
1900	19	275.5	30.338	86.608	4150	41.5	601.75	63.62	146.516
1950	19.5	282.75	31.351	88.432	4200	42	609	64.172	147.510
2000	20	290	32.344	90.219	4250	42.5	616.25	64.719	148.494
2050	20.5	297.25	33.319	91.974	4300	43	623.5	65.259	149.466
2100	21	304.5	34.276	93.697	4350	43.5	630.75	65.795	150.431
2150	21.5	311.75	35.215	95.387	4400	44	638	66.324	151.383
2200	22	319	36.139	97.050	4450	44.5	645.25	66.849	152.328
2250	22.5	326.25	37.047	98.685	4500	45	652.5	67.368	153.262
2300	23	333.5	37.939	100.290					



WARNING :

The design and specifications are subject to change without prior notice for product improvement. Consult with the sales agency or manufacturer for details.

ATTENTION :

Le design et les données techniques sont donnés à titre indicatif et peuvent être modifiés sans préavis.



AIRWELL RESIDENTIAL SAS
10,Rue du Fort de Saint Cyr,
78180 Montigny le Bretonneux - France
www.airwell.com