



Service Manual

JMF ON-OFF Series

Indoor Units		Outdoor Units	
ELSI-JMF009-N11	ESP022508	ELAU-VMF009-H11	ESP062770
ELSI-JMF012-N11	ESP022509	ELAU-VMF012-H11	ESP062771
ELSI-JMF018-N11	ESP022510	ELAU-VMF018-H11	ESP062772
ELSI-JMF024-N11	ESP022511	ELAU-VMF024-H11	ESP062773



REFRIGERANT

R410A

SM JMF ON-OFF 1 GB

HEATPUMP

Jan - 2016

CONTENTS

1. Precaution	3
1.1 Safety Precaution	3
1.2 Warning	3
2. Function	6
3. Product Specification	7
4. Dimension	11
4.1 Indoor Unit.....	11
4.2 Outdoor Unit	14
5. Performance curves	18
7. Installation Details	23
7.1 Wrench torque sheet for installation	23
7.2 Connecting the cables	23
7.3 Pipe length and the elevation	24
7.4 Installation for the first time.....	25
7.5 Adding the refrigerant after running the system for many years	26
7.6 Re-installation while the indoor unit need to be repaired	27
7.7 Re-installation while the outdoor unit need to be repaired	28
8. Operation Characteristics	29
9. Electronic function	30
9.1 Abbreviation.....	30
9.2 Display function	30
9.3 Main Protection.....	31
9.4 Operation Modes and Functions.....	32
10. Troubleshooting	37
10.1 Indoor Unit Error Display	37
10.2 Diagnosis and Solution.....	38
11. Exploded view and spare part list	48

1. Precaution

1.1 Safety Precaution

- To prevent injury to the user or other people and property damage, the following instructions must be followed.
- Incorrect operation due to ignoring instruction will cause harm or damage.
- Before service the unit, be sure to read this service manual at first.

1.2 Warning

➤ Installation

- Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.

There is risk of fire or electric shock.

- For electrical work, contact the dealer, seller, a qualified electrician, or an authorized service center.

Do not disassemble or repair the product, there is risk of fire or electric shock.

- Always ground the product.

There is risk of fire or electric shock.

- Install the panel and the cover of control box securely.

There is risk of fire or electric shock.

- Always install a dedicated circuit and breaker.

Improper wiring or installation may cause fire or electric shock.

- Use the correctly rated breaker or fuse.

There is risk of fire or electric shock.

- Do not modify or extend the power cable.

There is risk of fire or electric shock.

- Do not install, remove, or reinstall the unit by yourself (customer).

There is risk of fire, electric shock, explosion, or injury.

- Be caution when unpacking and installing the product.

Sharp edges could cause injury, be especially careful of the case edges and the fins on the condenser and evaporator.

- For installation, always contact the dealer or an authorized service center.

- Do not install the product on a defective installation stand.

- Be sure the installation area does not deteriorate with age.

If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury.

- Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.

- Take care to ensure that power cable could not be pulled out or damaged during operation.

There is risk of fire or electric shock.

- Do not place anything on the power cable.

There is risk of fire or electric shock.

- **Do not plug or unplug the power supply plug during operation.**

There is risk of fire or electric shock.

- **Do not touch (operation) the product with wet hands.**
- **Do not place a heater or other appliance near the power cable.**

There is risk of fire and electric shock.

- **Do not allow water to run into electrical parts.**

It may cause fire, failure of the product, or electric shock.

- **Do not store or use flammable gas or combustible near the product.**

There is risk of fire or failure of product.

- **Do not use the product in a tightly closed space for a long time.**

Oxygen deficiency could occur.

- **When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.**
- **If strange sounds or smoke comes from product, turn the breaker off or disconnect the power supply cable.**

There is risk of electric shock or fire.

- **Stop operation and close the window in storm or hurricane. If possible, remove the product from the window before the hurricane arrives.**

There is risk of property damage, failure of product, or electric shock.

- **Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)**

There is risk of physical injury, electric shock, or product failure.

- **When the product is soaked, contact an authorized service center.**

There is risk of fire or electric shock.

- **Be caution that water could not enter the product.**

There is risk of fire, electric shock, or product damage.

- **Ventilate the product from time to time when operating it together with a stove etc.**

There is risk of fire or electric shock.

- **Turn the main power off when cleaning or maintaining the product.**

There is risk of electric shock.

- **When the product is not be used for a long time, disconnect the power supply plug or turn off the breaker.**

There is risk of product damage or failure, or unintended operation.

- **Take care to ensure that nobody could step on or fall onto the outdoor unit.**

This could result in personal injury and product damage.

➤ CAUTION

- **Always check for gas (refrigerant) leakage after installation or repair of product.**

Low refrigerant levels may cause failure of product.

- **Install the drain hose to ensure that water is drained away properly.**

A bad connection may cause water leakage.

- **Keep level even when installing the product.**

It can avoid vibration of water leakage.

- **Do not install the product where the noise or hot air from the outdoor unit could damage the neighborhoods.**

It may cause a problem for your neighbors.

- **Use two or more people to lift and transport the product.**
- **Do not install the product where it will be exposed to sea wind (salt spray) directly.**

It may cause corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient operation.

➤ Operational

- **Do not expose the skin directly to cool air for long time. (Do not sit in the draft).**
- **Do not use the product for special purposes, such as preserving foods, works of art etc.**

It is a consumer air conditioner, not a precision refrigerant system.

There is risk of damage or loss of property.

- **Do not block the inlet or outlet of air flow.**
- **Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.**

There is risk of fire, electric shock, or damage to the plastic parts of the product.

■ **Do not touch the metal parts of the product when removing the air filter. They are very sharp.**

- **Do not step on or put anything on the product. (outdoor units)**

■ **Always insert the filter securely. Clean the filter every two weeks or more often if necessary.**

A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.

■ **Do not insert hands or other objects through air inlet or outlet while the product is operated.**

- **Do not drink the water drained from the product.**
- **Use a firm stool or ladder when cleaning or maintaining the product.**

Be careful and avoid personal injury.

■ **Replace the all batteries in the remote control with new ones of the same type. Do not mix old and new batteries or different types of batteries.**

There is risk of fire or explosion.

- **Do not recharge or disassemble the batteries. Do not dispose of batteries in a fire.**


They may burn or explode.

■ **If the liquid from the batteries gets onto your skin or clothes, wash it well with clean water. Do not use the remote if the batteries have leaked.**

2. Function

Model Names of Indoor/Outdoor Units

	Capacity	Indoor units	Outdoor units
On-Off	7k	MS12F-07HRN1-QC2	MOAB30-07HN1-QC2
	9k	MS12F-09HRN1-QC2	MOAB31-09HN1-QC2
	12k	MS12F-12HRN1-QC2	MOBA31-12HN1-QC2
	18k	MS12F-18HRN1-QC2	MOBA30-18HN1-QC2
	24k	MS12F-24HRN1-QB8W	MOCA30-24HN1-QB8W
	28k	MS12F-28HRN1-QB8W	MOCA30-28HN1-QB8W



O: optional

3. Product Specification

3.1 ELSI-JMF009-N11 / ELAU-VMF009-H11

Model Indoor Unit		ELSI-JMF009-N11	
Model Outdoor Unit		ELAU-VMF009-H11	
Installation Method of Pipe		Flared	
Characteristics		Units	Cooling
Capacity ⁽¹⁾		kW	2.6
Power input		kW	0.805
SEER /SCOP ⁽²⁾		W/W	3,22
Energy efficiency class			A
Power supply		V/Ph/Hz	220-240V/Single/50Hz
Circuit breaker rating		A	10
INDOOR	Fan type & quantity		Cross flow fan x1
	Fan speeds	H/M/L/VL	RPM
	Air flow ⁽³⁾	H/M/L/VL	m3/hr
	External static pressure	Min-Max	Pa
	Sound power level ⁽⁴⁾	H/M/L	dB(A)
	Sound pressure level ⁽⁵⁾	H/M/L/VL	dB(A)
	Moisture removal		l/hr
	Condensate drain tube I.D		mm
	Dimensions	WxHxD	mm
	Weight		kg
	Package dimensions	LxWxH	mm
	Packaged weight		kg
	Stacking height		units
	OUTDOOR	Refrigerant control	
Compressor type, model		Rotary DC Inverter	
Fan type & quantity		Axial x 1	
Fan speeds		H/L	RPM
Air flow		H/L	m3/hr
Sound power level ⁽⁴⁾		H/L	dB(A)
Sound pressure level ⁽⁵⁾		H/L	dB(A)
Dimensions		WxHxD	mm
Weight			kg
Package dimensions		LxWxH	mm
Packaged weight			kg
Stacking height			Units
Refrigerant type		R410A	
Refrigerant charge (standard connecting tubing length)		kg(5m)	
Additional charge per 1 meter		gr / 1m	
Connections between units		Liquid line	In.(mm)
		Suction line	In.(mm)
	Max.tubing length	m.	
	Max.height difference	m.	
Operation control type		Remote control	
Heating elements		kW	
Others			

3.2 ELSI-JMF012-N11 / ELAU-VMF012-H11

Model Indoor Unit		ELSI-JMF012-N11		
Model Outdoor Unit		ELAU-VMF012-H11		
Installation Method of Pipe		Flared		
Characteristics	Units	Cooling	Heating	
Capacity ⁽¹⁾	kW	3.5	3.8	
Power input	kW	1.09	1.05	
SEER /SCOP ⁽²⁾	W/W	3,23	3,61	
Energy efficiency class		A	A	
Power supply	V/Ph/Hz	220-240V/Single/50Hz		
Circuit breaker rating	A	10		
INDOOR	Fan type & quantity		Cross flow fan x1	
	Fan speeds	H/M/L/VL	RPM	1200/1050/800
	Air flow ⁽³⁾	H/M/L/VL	m3/hr	580/490/370
	External static pressure	Min-Max	Pa	0
	Sound power level ⁽⁴⁾	H/M/L	dB(A)	50
	Sound pressure level ⁽⁵⁾	H/M/L/VL	dB(A)	40/36/28
	Moisture removal		l/hr	1,2
	Condensate drain tube I.D		mm	16
	Dimensions	WxHxD	mm	800x275x188
	Weight		kg	8.0
	Package dimensions	LxWxH	mm	865x265x350
	Packaged weight		kg	10.0
	Stacking height		units	8
	OUTDOOR	Refrigerant control		EEV
Compressor type, model		Rotary DC Inverter		
Fan type & quantity		Axial x 1		
Fan speeds		H/L	RPM	850
Air flow		H/L	m3/hr	2000
Sound power level ⁽⁴⁾		H/L	dB(A)	66
Sound pressure level ⁽⁵⁾		H/L	dB(A)	56
Dimensions		WxHxD	mm	770x300x555
Weight			kg	30.2
Package dimensions		LxWxH	mm	900x345x585
Packaged weight			kg	32.4
Stacking height			Units	4
Refrigerant type			R410A	
Refrigerant charge (standard connecting tubing length)		kg(5m)	0.95	
Additional charge per 1 meter		gr / 1m	20	
Connections between units		Liquid line	In.(mm)	1/4"
		Suction line	In.(mm)	3/8"
	Max.tubing length	m.	20	
	Max.height difference	m.	8	
Operation control type			Remote control	
Heating elements		kW	NA	
Others				

3.3 ELSI-JMF018-N11 / ELAU-VMF018-H11


Model Indoor Unit		ELSI-JMF018-N11		
Model Outdoor Unit		ELAU-VMF018-H11		
Installation Method of Pipe		Flared		
Characteristics	Units	Cooling	Heating	
Capacity ⁽¹⁾	kW	5.3	5.8	
Power input	kW	1.65	1.605	
SEER /SCOP ⁽²⁾	W/W	3,22	3,61	
Energy efficiency class		A	A	
Power supply	V/Ph/Hz	220-240V/Single/50Hz		
Circuit breaker rating	A	16		
INDOOR	Fan type & quantity		Cross flow fan x1	
	Fan speeds	H/M/L/VL	RPM	1280/1100/800
	Air flow ⁽³⁾	H/M/L/VL	m3/hr	800/670/450
	External static pressure	Min-Max	Pa	0
	Sound power level ⁽⁴⁾	H/M/L	dB(A)	54
	Sound pressure level ⁽⁵⁾	H/M/L/VL	dB(A)	44/39/31
	Moisture removal		l/hr	1,8
	Condensate drain tube I.D		mm	16
	Dimensions	WxHxD	mm	940x275x205
	Weight		kg	10
	Package dimensions	LxWxH	mm	1015x265x350
	Packaged weight		kg	12
	Stacking height		units	7
	OUTDOOR	Refrigerant control		EEV
Compressor type, model		Rotary DC Inverter		
Fan type & quantity		Axial x 1		
Fan speeds		H/L	RPM	880
Air flow		H/L	m3/hr	2300
Sound power level ⁽⁴⁾		H/L	dB(A)	68
Sound pressure level ⁽⁵⁾		H/L	dB(A)	58
Dimensions		WxHxD	mm	770x300x555
Weight			kg	36.5
Package dimensions		LxWxH	mm	900x345x585
Packaged weight			kg	38.5
Stacking height			Units	4
Refrigerant type			R410A	
Refrigerant charge (standard connecting tubing length)		kg(5m)	1.2	
Additional charge per 1 meter		gr / 1m	20	
Connections between units		Liquid line	In.(mm)	1/4"
		Suction line	In.(mm)	1/2"
	Max.tubing length	m.	25	
	Max.height difference	m.	10	
Operation control type			Remote control	
Heating elements		kW	NA	
Others				

3.4 ELSI-JMF024-N11 / ELAU-VMF024-H11


Model Indoor Unit		ELSI-JMF024-N11		
Model Outdoor Unit		ELAU-VMF024-H11		
Installation Method of Pipe		Flared		
Characteristics	Units	Cooling	Heating	
Capacity ⁽¹⁾	kW	7	7.5	
Power input	kW	2.5	2.335	
SEER /SCOP ⁽²⁾	W/W	2,81	3,21	
Energy efficiency class		C	C	
Power supply	V/Ph/Hz	220-240V/Single/50Hz		
Circuit breaker rating	A	25		
INDOOR	Fan type & quantity		Cross flow fan x1	
	Fan speeds	H/M/L/VL	RPM	1180 / 1100 / 900
	Air flow ⁽³⁾	H/M/L/VL	m3/hr	1100/1000/780
	External static pressure	Min-Max	Pa	0
	Sound power level ⁽⁴⁾	H/M/L	dB(A)	56
	Sound pressure level ⁽⁵⁾	H/M/L/VL	dB(A)	46/43/37
	Moisture removal		l/hr	3
	Condensate drain tube I.D		mm	16
	Dimensions	WxHxD	mm	1045x315x235
	Weight		kg	12.7
	Package dimensions	LxWxH	mm	1135x395x315
	Packaged weight		kg	16.1
	Stacking height		units	7
	OUTDOOR	Refrigerant control		EEV
Compressor type, model		Rotary DC Inverter		
Fan type & quantity		Axial x 1		
Fan speeds		H/L	RPM	860
Air flow		H/L	m3/hr	2800
Sound power level ⁽⁴⁾		H/L	dB(A)	70
Sound pressure level ⁽⁵⁾		H/L	dB(A)	60
Dimensions		WxHxD	mm	845x363x702
Weight			kg	49
Package dimensions		LxWxH	mm	965x395x755
Packaged weight			kg	52
Stacking height			Units	3
Refrigerant type			R410A	
Refrigerant charge (standard connecting tubing length)		kg(5m)	1.8	
Additional charge per 1 meter		gr / 1m	20	
Connections between units		Liquid line	In.(mm)	3/8"
		Suction line	In.(mm)	5/8"
	Max.tubing length	m.	25	
	Max.height difference	m.	10	
Operation control type			Remote control	
Heating elements		kW	NA	
Others				

4. Dimension


4.1 Indoor Unit



Model	W	D	H
ELSI-JMF009-N11	715	188	250
ELSI-JMF012-N11	800	188	275
ELSI-JMF018-N11	940	205	275
ELSI-JMF024-N11	1045	235	315




For ELSI-JMF009-N11




For ELSI-JMF012-N11

Version – 1




MODEL B

For ELSI-JMF018-N11




MODEL C

For ELSI-JMF024-N11




MODEL D

4.2 Outdoor Unit




DIMENSION


For ELAU-VMF009-H11



For ELAU-VMF012-H11, ELAU-VMF018-H11



For ELAU-VMF024-H11



5. Performance curves

5.1 ELSI-JMF009-N11 / ELAU-VMF009-H11

1) Cooling

Entering Air DB OD Coil(°C)	Data	Entering Air WB/DB ID Coil(°C)				
		15/21	17/24	19/27	21/29	23/32
20	TC	2.65	2.79	2.88	2.95	3.01
	SC	1.75	1.84	1.92	1.97	2.01
	PI	0.62	0.62	0.62	0.63	0.63
25	TC	2.51	2.71	2.85	2.93	3.01
	SC	1.70	1.81	1.90	1.96	2.00
	PI	0.67	0.67	0.68	0.68	0.69
30	TC	2.35	2.55	2.76	2.86	2.94
	SC	1.65	1.75	1.86	1.92	1.95
	PI	0.72	0.73	0.74	0.75	0.75
35	TC	2.17	2.36	2.60	2.73	2.86
	SC	1.57	1.68	1.82	1.87	1.91
	PI	0.78	0.79	0.81	0.81	0.82
40	TC	1.98	2.15	2.35	2.57	2.70
	SC	1.48	1.59	1.72	1.78	1.81
	PI	0.84	0.85	0.87	0.88	0.89
46	TC	1.71	1.87	2.06	2.28	2.45
	SC	1.36	1.46	1.57	1.62	1.66
	PI	0.92	0.93	0.95	0.97	0.98

LEGEND

TC - Total Cooling Capacity,KW SC - Sensible Capacity,KW PI - Power Input
 WB - Wet Bulb Temp(°C) DB - Dry Bulb Temp(°C)
 ID – Indoor OU - Outdoor

2) Heating

ENTERING WB OD COIL(°C)	ENTERING AIR DB ID COIL(°C)					
	15		20		25	
	TH	PI	TH	PI	TH	PI
-10	1.47	0.62	1.41	0.66	1.36	0.69
-7	1.58	0.64	1.53	0.67	1.47	0.71
-2	1.68	0.64	1.62	0.68	1.57	0.72
2	2.04	0.67	1.96	0.72	1.88	0.76
6	2.88	0.72	2.80	0.78	2.70	0.82
10	3.14	0.76	3.05	0.82	2.97	0.87
15	3.39	0.80	3.30	0.86	3.22	0.91
20	3.57	0.82	3.49	0.89	3.39	0.96

LEGEND

TC - Total Cooling Capacity,KW PI - Power Input
 WB - Wet Bulb Temp(°C) DB - Dry Bulb Temp(°C)
 ID – Indoor OU - Outdoor

5.2 ELSI-JMF012-N11 / ELAU-VMF012-H11

1) Cooling

Entering Air DB OD Coil(°C)	Data	Entering Air WB/DB ID Coil(°C)				
		15/21	17/24	19/27	21/29	23/32
20	TC	3.57	3.76	3.88	3.97	4.06
	SC	2.35	2.48	2.58	2.66	2.71
	PI	0.84	0.84	0.84	0.85	0.85
25	TC	3.38	3.65	3.83	3.95	4.05
	SC	2.29	2.43	2.56	2.64	2.69
	PI	0.91	0.91	0.92	0.93	0.93
30	TC	3.16	3.44	3.71	3.85	3.96
	SC	2.22	2.36	2.51	2.58	2.63
	PI	0.98	0.99	1.00	1.01	1.02
35	TC	2.92	3.17	3.50	3.68	3.85
	SC	2.11	2.26	2.45	2.52	2.57
	PI	1.05	1.07	1.09	1.10	1.10
40	TC	2.66	2.89	3.16	3.45	3.63
	SC	1.99	2.14	2.32	2.39	2.44
	PI	1.14	1.16	1.18	1.19	1.20
46	TC	2.31	2.52	2.77	3.06	3.30
	SC	1.83	1.96	2.11	2.19	2.24
	PI	1.24	1.26	1.29	1.31	1.32

LEGEND

TC - Total Cooling Capacity,KW SC - Sensible Capacity,KW PI - Power Input
 WB - Wet Bulb Temp(°C) DB - Dry Bulb Temp(°C)
 ID – Indoor OU – Outdoor

2) Heating

ENTERING WB OD COIL(°C)	ENTERING AIR DB ID COIL(°C)					
	15		20		25	
	TH	PI	TH	PI	TH	PI
-10	2.00	0.84	1.92	0.89	1.84	0.94
-7	2.15	0.86	2.07	0.91	2.00	0.96
-2	2.28	0.87	2.20	0.92	2.13	0.98
2	2.77	0.91	2.66	0.97	2.55	1.03
6	3.91	0.98	3.80	1.05	3.67	1.12
10	4.26	1.04	4.14	1.11	4.03	1.18
15	4.60	1.08	4.48	1.17	4.37	1.24
20	4.85	1.11	4.73	1.21	4.60	1.30

LEGEND

TC - Total Cooling Capacity,KW PI - Power Input
 WB - Wet Bulb Temp(°C) DB - Dry Bulb Temp(°C)
 ID – Indoor OU - Outdoor

5.3 ELSI-JMF018-N11 / ELAU-VMF018-H11

1) Cooling

Entering Air DB OD Coil(°C)	Data	Entering Air WB/DB ID Coil(°C)				
		15/21	17/24	19/27	21/29	23/32
20	TC	5.40	5.70	5.88	6.02	6.14
	SC	3.56	3.75	3.91	4.02	4.10
	PI	1.27	1.27	1.28	1.29	1.29
25	TC	5.11	5.52	5.81	5.98	6.13
	SC	3.47	3.68	3.88	3.99	4.07
	PI	1.37	1.38	1.39	1.40	1.41
30	TC	4.78	5.21	5.63	5.83	6.00
	SC	3.36	3.57	3.80	3.91	3.98
	PI	1.48	1.50	1.52	1.53	1.54
35	TC	4.43	4.80	5.30	5.57	5.83
	SC	3.20	3.43	3.71	3.82	3.89
	PI	1.60	1.62	1.65	1.66	1.67
40	TC	4.03	4.38	4.78	5.23	5.50
	SC	3.01	3.24	3.51	3.62	3.70
	PI	1.72	1.75	1.78	1.80	1.82
46	TC	3.49	3.82	4.20	4.64	5.00
	SC	2.77	2.97	3.20	3.31	3.39
	PI	1.88	1.91	1.95	1.98	2.00

LEGEND

TC - Total Cooling Capacity,KW SC - Sensible Capacity,KW PI - Power Input
 WB - Wet Bulb Temp(°C) DB - Dry Bulb Temp(°C)
 ID – Indoor OU - Outdoor

2) Heating

ENTERING WB OD COIL(°C)	ENTERING AIR DB ID COIL(°C)					
	15		20		25	
	TH	PI	TH	PI	TH	PI
-10	3.05	1.28	2.93	1.37	2.81	1.44
-7	3.28	1.32	3.16	1.39	3.05	1.46
-2	3.48	1.33	3.36	1.41	3.25	1.49
2	4.23	1.40	4.06	1.48	3.89	1.57
6	5.97	1.50	5.80	1.61	5.60	1.70
10	6.50	1.58	6.32	1.69	6.15	1.81
15	7.02	1.65	6.84	1.78	6.67	1.89
20	7.40	1.70	7.22	1.85	7.02	1.99

LEGEND

TC - Total Cooling Capacity,KW PI - Power Input
 WB - Wet Bulb Temp(°C) DB - Dry Bulb Temp(°C)
 ID – Indoor OU - Outdoor

5.4 ELSI-JMF024-N11 / ELAU-VMF024-H11

1) Cooling

Entering Air DB OD Coil(°C)	Data	Entering Air WB/DB ID Coil(°C)				
		15/21	17/24	19/27	21/29	23/32
20	TC	7.14	7.52	7.76	7.94	8.12
	SC	4.70	4.96	5.17	5.31	5.41
	PI	1.92	1.93	1.94	1.95	1.95
25	TC	6.75	7.29	7.67	7.90	8.09
	SC	4.58	4.86	5.13	5.28	5.37
	PI	2.08	2.09	2.11	2.12	2.14
30	TC	6.32	6.88	7.43	7.69	7.92
	SC	4.44	4.72	5.02	5.16	5.26
	PI	2.24	2.28	2.30	2.31	2.34
35	TC	5.85	6.35	7.00	7.35	7.70
	SC	4.22	4.52	4.90	5.04	5.14
	PI	2.42	2.46	2.50	2.52	2.53
40	TC	5.32	5.79	6.32	6.91	7.26
	SC	3.98	4.28	4.64	4.78	4.88
	PI	2.61	2.65	2.70	2.73	2.76
46	TC	4.61	5.04	5.55	6.13	6.60
	SC	3.66	3.93	4.23	4.37	4.47
	PI	2.85	2.89	2.96	3.00	3.04

LEGEND

TC - Total Cooling Capacity,KW SC - Sensible Capacity,KW PI - Power Input
 WB - Wet Bulb Temp(°C) DB - Dry Bulb Temp(°C)
 ID – Indoor OU - Outdoor


2) Heating

ENTERING WB OD COIL(°C)	ENTERING AIR DB ID COIL(°C)					
	15		20		25	
	TH	PI	TH	PI	TH	PI
-10	3.94	1.87	3.79	1.99	3.64	2.09
-7	4.24	1.91	4.09	2.02	3.94	2.13
-2	4.50	1.94	4.35	2.05	4.20	2.17
2	5.48	2.03	5.25	2.16	5.03	2.29
6	7.73	2.18	7.50	2.34	7.24	2.48
10	8.40	2.30	8.18	2.46	7.95	2.63
15	9.08	2.41	8.85	2.59	8.63	2.76
20	9.56	2.48	9.34	2.69	9.08	2.90

LEGEND

TC - Total Cooling Capacity,KW PI - Power Input
 WB - Wet Bulb Temp(°C) DB - Dry Bulb Temp(°C)
 ID – Indoor OU - Outdoor

6. Refrigerant Cycle Diagram



T3 temp. Sensor is only for ELAU-VMF024-H11

7. Installation Details

7.1 Wrench torque sheet for installation

Outside diameter		Torque	Additional tightening torque
mm	inch	N.cm	N.cm
Φ6.35	1/4	1500(153kgf.cm)	1600(163kgf.cm)
Φ9.52	3/8	2500(255kgf.cm)	2600(265kgf.cm)
Φ12.7	1/2	3500(357kgf.cm)	3600(367kgf.cm)
Φ15.9	5/8	4500(459kgf.cm)	4700(479kgf.cm)
Φ19	3/4	6500(663kgf.cm)	6700(683kgf.cm)

7.2 Connecting the cables

The power cord of connect should be selected according to the following specifications sheet.


Rated current of appliance	Nominal cross-sectional area (mm ²)
>3 and ≤6	0.75
>6 and ≤10	1
>10 and ≤16	1.5
>16 and ≤25	2.5

The cable size and the current of the fuse or switch are determined by the maximum current indicated on the nameplate which located on the side panel of the unit. Please refer to the nameplate before selecting the cable, fuse and switch.

7.3 Pipe length and the elevation

The pipe length and refrigerant amount:

Model	Pipe size		Standard length (m)	Max. Elevation B (m)	Max. Length A (m)	Additional refrigerant (g/m)
	Gas	Liquid				
ELSI-J,F009-N11 / ELAU-VMF009-H11	3/8" (Φ9.52)	1/4" (Φ6.35)	5	8	20	20
ELSI-J,F012-N11 / ELAU-VMF012-H11	1/2" (Φ12.7)	1/4" (Φ6.35)	5	8	20	20
ELSI-J,F018-N11 / ELAU-VMF018-H11	1/2" (Φ12.7)	1/4" (Φ6.35)	5	10	25	20
ELSI-J,F024-N11 / ELAU-VMF024-H11	5/8" (Φ15.9)	3/8" (Φ9.52)	5	10	25	40



Caution:

The capacity test is based on the standard length and the maximum permissible length is based on the system reliability.

7.4 Installation for the first time

Air and moisture in the refrigerant system have undesirable effects as below:


- Pressure in the system rises.
- Operating current rises.
- Cooling or heating efficiency drops.
- Moisture in the refrigerant circuit may freeze and block capillary tubing.
- Water may lead to corrosion of parts in the refrigerant system.

Therefore, the indoor units and the pipes between indoor and outdoor units must be leak tested and evacuated to remove gas and moisture from the system.

Gas leak check (Soap water method):

Apply soap water or a liquid neutral detergent on the indoor unit connections or outdoor unit connections by a soft brush to check for leakage of the connecting points of the piping. If bubbles come out, the pipes have leakage.

1. Air purging with vacuum pump



- 1) Completely tighten the flare nuts of the indoor and outdoor units, confirm that both the 2-way and 3-way valves are set to the closed position.
- 2) Connect the charge hose with the push pin of handle lo to the 3-way valves gas service port..
- 3) Connect the charge hose of handle hi

- connection to the vacuum pump.
- 4) Fully open the handle Lo of the manifold valve.
- 5) Operate the vacuum pump to evacuate.
- 6) Make evacuation for 30 minutes and check whether the compound meter indicates -0.1Mpa. If the meter does not indicate -0.1Mpa after pumping 30 minutes, it should be pumped 20 minutes more. If the pressure can't achieve -0.1Mpa after pumping 50 minutes, please check if there are some leakage points.


Fully close the handle Lo valve of the manifold valve and stop the operation of the vacuum pump. Confirm that the gauge needle does not move (approximately 5 minutes after turning off the vacuum pump).

- 7) Turn the flare nut of the 3-way valves about 45° counterclockwise for 6 or 7seconds after the gas

coming out, then tighten the flare nut again. Make sure the pressure display in the pressure indicator is a little higher than the atmosphere pressure. Then remove the charge hose from the 3 way valve.

- 8) Fully open the 2 way valve and 3 way valve and securely tighten the cap of the 3 way valve.

2. Air purging by refrigerant



Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the closed position.
- 2). Connect the charge set and a charging cylinder to the service port of the 3-way valve.
- 3). Air purging.

Open the valves on the charging cylinder and the charge set. Purge the air by loosening the flare nut on the 2-way valve approximately 45' for 3 seconds then closing it for 1 minute; repeat 3 times.

After purging the air, use a torque wrench to tighten the flare nut on the 2-way valve.

4). Check the gas leakage.

Check the flare connections for gas leakage.

5). Discharge the refrigerant.

Close the valve on the charging cylinder and discharge the refrigerant by loosening the flare nut on the 2-way valve approximately 45' until the gauge indicates 0.3 to 0.5 Mpa.

6). Disconnect the charge set and the charging cylinder, and set the 2-way and 3-way valves to the open position.


Be sure to use a hexagonal wrench to operate the valve stems.

7). Mount the valve stems nuts and the service port cap.

Be sure to use a torque wrench to tighten the service port cap to a torque 18N·m.

Be sure to check the gas leakage.

3. Adding the refrigerant if the pipe length >5m



Procedure:

1). Connect the charge hose to the charging cylinder, open the 2-way valve and the 3-way valve.

Connect the charge hose which you disconnected from the vacuum pump to the valve at the bottom of the cylinder. If the refrigerant is R410A, make the cylinder bottom up to ensure the liquid charge.

2). Purge the air from the charge hose.

Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).

3) Put the charging cylinder onto the electronic scale and record the weight.

4) Operate the air conditioner at the cooling mode.

5) Open the valves (Low side) on the charge set and charge the system with liquid refrigerant.


6).When the electronic scale displays the proper weight (refer to the table), disconnect the charge hose from the 3-way valve's service port immediately and turn off the air conditioner before disconnecting the hose.

7). Mount the valve stem caps and the service port

Use torque wrench to tighten the service port cap to a torque of 18N.m.

Be sure to check for gas leakage.

7.5 Adding the refrigerant after running the system for many years



Procedure:

1). Connect the charge hose to the 3-way service port, open the 2-way valve and the 3-way valve. Connect the charge hose to the valve at the bottom of the cylinder. If the refrigerant is R410A, make the cylinder bottom up to ensure liquid charge.

2). Purge the air from the charge hose. Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).

3) Put the charging cylinder onto the electronic


scale and record the weight.

- 4) Operate the air conditioner at the cooling mode.
- 5) Open the valves (Low side) on the charge set and charge the system with liquid refrigerant.
- 6) When the electronic scale displays the proper weight (refer to the gauge and the pressure of the low side), disconnect the charge hose from the 3-way valve's service port immediately and turn off the air conditioner before disconnecting the hose.
- 7). Mount the valve stem caps and the service port

Use torque wrench to tighten the service port cap to a torque of 18N.m.
Be sure to check for gas leakage.

7.6 Re-installation while the indoor unit need to be repaired

1. Collecting the refrigerant into the outdoor unit



Procedure

- 1). Confirm that both the 2-way and 3-way valves are set to the opened position
Remove the valve stem caps and confirm that the valve stems are in the opened position.
Be sure to use a hexagonal wrench to operate the valve stems.
- 2). Connect the charge hose with the push pin of handle lo to the 3-way valves gas service port.
- 3). Air purging of the charge hose.
Open the handle Lo valve of the manifold valve slightly to purge air from the charge hose for 5 seconds and then close it quickly.
- 4). Set the 2-way valve to the close position.

- 5). Operate the air conditioner at the cooling cycle and stop it when the gauge indicates 0.1MPa.
- 6). Set the 3-way valve to the closed position immediately


Do this quickly so that the gauge ends up indicating 0.3 to 0.5Mpa.

Disconnect the charge set, and tighten the 2-way and 3-way valve's stem nuts.

Use a torque wrench to tighten the 3-way valves service port cap to a torque of 18N.m.

Be sure to check for gas leakage.

2. Air purging by the refrigerant



Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the closed position.
- 2). Connect the charge set and a charging cylinder to the service port of the 3-way valve
Leave the valve on the charging cylinder closed.
- 3). Air purging.
Open the valves on the charging cylinder and the charge set. Purge the air by loosening the flare nut on the 2-way valve approximately 45' for 3 seconds then closing it for 1 minute; repeat 3 times.
After purging the air, use a torque wrench to tighten the flare nut on the 2-way valve.
- 4). Check the gas leakage
Check the flare connections for gas leakage.
- 5). Discharge the refrigerant.
Close the valve on the charging cylinder and discharge the refrigerant by loosening the flare nut on the 2-way valve approximately 45' until the gauge indicates 0.3 to 0.5 Mpa.
- 6). Disconnect the charge set and the charging cylinder, and set the 2-way and 3-way valves to the open position

Be sure to use a hexagonal wrench to operate the valve stems.


7). Mount the valve stems nuts and the service port cap

Be sure to use a torque wrench to tighten the service port cap to a torque 18N.m.

Be sure to check the gas leakage.

7.7 Re-installation while the outdoor unit need to be repaired


1. Evacuation for the whole system



Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the opened position.
- 2). Connect the vacuum pump to 3-way valve's service port.
- 3). Evacuation for approximately one hour. Confirm that the compound meter indicates -0.1Mpa.
- 4). Close the valve (Low side) on the charge set, turn off the vacuum pump, and confirm that the gauge needle does not move (approximately 5 minutes after turning off the vacuum pump).
- 5). Disconnect the charge hose from the vacuum pump.

2. Refrigerant charging



Procedure:

- 1). Connect the charge hose to the charging cylinder, open the 2-way valve and the 3-way valve

Connect the charge hose which you disconnected from the vacuum pump to the valve at the bottom of the cylinder. If the refrigerant is R410A, make the cylinder bottom up to ensure liquid charge.

- 2). Purge the air from the charge hose

Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).

- 3) Put the charging cylinder onto the electronic scale and record the weight.

- 4). Open the valves (Low side) on the charge set and charge the system with liquid refrigerant

If the system cannot be charge with the specified amount of refrigerant, or can be charged with a little at a time (approximately 150g each time) , operating the air conditioner in the cooling cycle; however, one time is not sufficient, wait approximately 1 minute and then repeat the procedure.

- 5).When the electronic scale displays the proper weight, disconnect the charge hose from the 3-way valve's service port immediately

If the system has been charged with liquid refrigerant while operating the air conditioner, turn off the air conditioner before disconnecting the hose.

- 6). Mounted the valve stem caps and the service port

Use torque wrench to tighten the service port cap to a torque of 18N.m.

Be sure to check for gas leakage

8. Operation Characteristics

Model Temperature	Cooling operation	Heating operation	Drying operation
Room temperature	17°C ~ 32°C	0°C ~ 30°C	10°C ~ 32°C 17°C ~ 32°C
Outdoor temperature	18°C ~ 43°C	-7°C ~ 24°C	11°C ~ 43°C 18°C ~ 43°C
	(-7°C ~ 43°C: For the models with low temperature cooling system)		18°C ~ 52°C (For special tropical models)
	(18°C ~ 52°C: For special tropical models)		

CAUTION:

1. If the air conditioner is used beyond the above conditions, certain safety protection features may come into operation and cause the unit to operate abnormally.
2. The room relative humidity should be less than 80%. If the air conditioner operates beyond this figure, the surface of the air conditioner may attract condensation. Please set the vertical air flow louver to its maximum angle (vertically to the floor), and set HIGH fan mode.
3. The optimum performance will be achieved during this operating temperature zone.





9. Electronic function

9.1 Abbreviation

- T1: Indoor room temperature
- T2: Coil temperature of evaporator
- T3: Coil temperature of condenser
- T4: Outdoor ambient temperature
- T5: Compressor discharge temperature

9.2 Display function

1.1.1 Icon explanation on indoor display board.

<p>2* 7 segments display</p>	<ol style="list-style-type: none"> 1. In normal situation, the setting temperature is displayed. (display room temp. in fan mode.) 2. Shows "SC" when self clean function is activated, "FP" when 8°C heating function is activated. 3. Shows the alarm code whenever there is an alarm.
<p>ION INDICATOR (optional)</p> 	<p>Lights up when ionizer or plasma function is activated.</p>
<p>DEFROSTING INDICATOR</p> 	<p>Lights up when the unit is under defrosting operation or when the anti-cold air function is activated.</p>
<p>RUN INDICATOR</p> 	<p>Lights up when the unit is in operation.</p>
<p>TIMER INDICATOR</p> 	<p>Lights up when TIMER function is activated.</p>

9.3 Main Protection

1.1.2 Three minutes delay at restart for compressor

Less than 1 minute delay for the 1st time stand-up and 3 minutes delay for others.

1.1.3 Sensor protection at open circuit and breaking disconnection.


1.1.4 Zero crossing detection error protection

If AC can not detect zero crossing signal for 4 minutes or the zero crossing signal time interval is not correct, the unit will stop and the LED will display the failure. The correct zero crossing signal time interval should be between 6-13ms.

1.1.5 Fan Speed is out of control

When Indoor Fan Speed is too low(lower than 300RPM) lasting 2 minutes, the unit stops and LED displays failure information and can't returns to normal operation automatically.

1.1.6 Current protection



The current exceeds setting value for certain time, the compressor and outdoor fan will shut off.

1.1.7 Indoor fan delayed open function

When the unit starts up, the indoor fan will open 4s later.

If the unit runs in heating mode, the indoor fan will be also controlled by anti-cold wind function.

1.1.8 Refrigerant leakage detection

This function is only active in cooling mode. It can better prevent the compressor being damaged by refrigerant leakage or compressor overload.


Open condition:

When compressor is active, the value of the Coil temperature of evaporator T2 has no change or very little change.

9.4 Operation Modes and Functions

1.1.9 Fan mode


- (1) Outdoor fan and compressor stop.
- (2) Temperature setting function is disabled, and no setting temperature is displayed.
- (3) Indoor fan can be set to high/med/low/auto.
- (4) The louver operates the same as in cooling mode.
- (5) Auto fan:



1.1.10 Cooling Mode

1.1.10.1 Compressor running rules

When indoor room temp. T1 is lower than setting value, the compressor and outdoor fan will shut off. When T1 is higher than setting value, the compressor and outdoor fan will start up.




1.1.10.2 Outdoor fan running rules

The On-off outdoor units have single fan speed. The outdoor fan will run following the compressor except when AC is in evaporator high temp. protection in heating mode, condenser high temp. protection in cooling mode, defrosting mode and the current protection.


1.1.10.3 Indoor fan running rules

In cooling mode, indoor fan runs all the time and the speed can be selected as high, medium, low and auto.

The auto fan:




1.1.10.4 Low evaporator coil temperature T2 protection



When the evaporator coil temp. T2 keeps lower than setting value, the compressor and outdoor fan will shut off.

1.1.10.5 High condenser temperature T3 protection

(only for ELAU-VMF024-H11)




When high condenser temp. T3 is more than setting value, the compressor will stop. During the protection, the outdoor fan keeps working.

1.1.11 Heating Mode

1.1.11.1 Compressor running rules:

When indoor room temp. T1 is higher than setting value the compressor and outdoor fan will shut off.

1.1.11.2



1.1.11.3 Outdoor fan running rules:


The outdoor units have single fan speed. The outdoor fan will run following the compressor except when AC is in evaporator high temp. protection in heating mode , condenser high temp. protection in cooling mode ,defrosting mode and the current protection.

1.1.11.4 Indoor fan running rules:

JMF ON-OFF

When the compressor is on, the indoor fan can be set to high/med/low/auto. And the anti-cold wind function has the priority.

Auto fan action:



The indoor fan speed will adjust according to the value of T1-Ts.

1.1.11.5 Defrosting mode:

For VMF007/009/012/018

● **Condition of defrosting:**

1, AC will enter the defrosting mode if all of the following items are satisfied.

$\Delta T = T2 - T1$

$\Delta T' = \Delta T$, if the indoor fan=low speed.

$\Delta T' = \Delta T + 3$, if the indoor fan=medium speed.

$\Delta T' = \Delta T + 5$, if the indoor fan=high speed.

$\Delta T'_{max}$ is the maximum value of $\Delta T'$.

When fan speed changes (including anti-cold wind function), AC will detect ΔT after two minutes.

1.1 AC meets A1 or A2.

A1: The cumulative compressor running time is between 45~120 minutes. Meanwhile the value of ΔT is satisfied.

A2: The cumulative compressor running time is over 120 minutes. Meanwhile the value of ΔT is satisfied.

1.2 If the fan speed and the evaporator coil temp. T2 meet the conditions.

1.3 After the compressor keeps running 8 minutes, AC will detect the ΔT .

About the setting defrosting time:

	runtime (minute)	Defrosting time (minute)
Case 1	Runtime=45	10
Case 2	45 < runtime ≤ 60	7.5
Case 3	60 < runtime ≤ 90	8.5
Case 4	90 < runtime ≤ 120	10
Case 5	120 < runtime	12

Condition of ending defrosting:

If any one of the following items is satisfied, the defrosting will terminate and the machine will turn to normal heating mode.

- (1) The defrosting time is reached to the setting value.
- (2) The defrosting has been running for 3 minutes and $T2 \geq TCDE1^{\circ}C$.
- (3) The defrosting has been running for 2 minutes, check the value of T2. If $T2 - T2_{min} \geq TCDE2^{\circ}C$ during 4 minutes, the defrosting will terminate.

During the defrosting mode, the compressor keep running, indoor and outdoor motor will stop, defrost lamp of the indoor unit will be lighted .

For VMF024

● **Condition of defrosting:**

AC will enter defrosting mode if any of the following items is satisfied.

- (1) If $T3 < TC1$ and the compressor keeps running over 45 minutes. Meanwhile $T3 < TC3$ for 5 minutes.
- (2) After the last defrosting, the time that the outdoor fan is off but the compressor is on in high T2 protection cumulates up to 90 minutes.

● **Condition of ending defrosting:**


If any one of the following items is satisfied,

the defrosting will terminate and the machine will turn to normal heating mode.

- (1) T3 rises to be higher than TC2.
- (2) The machine has run for 10 minutes in defrosting.

During the defrosting mode, the compressor keep running, indoor and outdoor motor will stop, defrost lamp of the indoor unit will be lighted.


1.1.11.6 High evaporator coil temp.T2 protection:



1.1.12 Auto-mode

This mode can be chosen with remote controller.

In auto mode, the machine will choose cooling, heating or fan-only mode according to ΔT ($\Delta T = T1 - Ts$).



AC will run in auto mode in the below cases:

- (1) Pressing the forced auto button.
- (2) If AC is off, it will run in auto mode when the timer on function is active.
- (3) After setting the mode, AC will run in auto mode if the compressor keeps not running for certain time.

1.1.13 Drying mode

1.1.13.1 The compressor is cycled running with 10 minutes on and then 5 minutes off.

The indoor fan will keep running at low speed.

1.1.13.2 In drying mode, if room temperature is lower than 10°C, the compressor will stop and not resume until room temperature exceeds 13°C.

1.1.13.3 The evaporator anti-freezing protection is the same as that in cooling mode.

1.1.14 Forced operation function

Forced cooling mode:

The compressor and outdoor fan keep running and the indoor fan runs at low speed. After running for 30 minutes, AC will turn to auto mode with 24°C setting temperature.

Forced auto mode:

The action of forced auto mode is the same as normal auto mode with 24°C setting temperature.

When AC receives signals, such as switch on, switch off, timer on, timer off, mode setting, fan speed setting, sleeping mode setting, follow me setting, it will quit the forced operation.

1.1.15 Auto-Restart function

The indoor unit is equipped with auto-restart function, which is carried out through an auto-restart module. In case of a sudden power failure, the module memorizes the setting conditions before the power failure. The unit will resume the previous operation setting (not including swing function) automatically after 3 minutes when power returns.

If the memorization condition is forced cooling mode, the unit will run in cooling mode for 30 minutes and turn to auto mode as 24°C setting temp.

If AC is off before power off and AC is required to start up now, the compressor will JMF ON-OFF

have 1 minute delay when power on. Other conditions, the compressor will have 3 minutes delay when restarts.

1.1.16 Timer function

1.1.16.1 Timing range is 24 hours.

1.1.16.2 Timer on. The machine will turn on automatically when reaching the setting time.

1.1.16.3 Timer off. The machine will turn off automatically when reaching the setting time.

1.1.16.4 Timer on/off. The machine will turn on automatically when reaching the setting "on" time, and then turn off automatically when reaching the setting "off" time.

1.1.16.5 Timer off/on. The machine will turn off automatically when reaching the setting "off" time, and then turn on automatically when reaching the setting "on" time.

1.1.16.6 The timer function will not change the AC current operation mode. Suppose AC is off now, it will not start up firstly after setting the "timer off" function. And when reaching the setting time, the timer LED will be off and the AC running mode has not been changed.

1.1.16.7 The setting time is relative time.

1.1.17 Sleep function mode

1.1.17.1 Operation time in sleep mode is 7 hours. After 7 hours the AC quits this mode and turns off.

1.1.17.2 Operation process in sleep mode is as follow:

When cooling, the setting temperature rises 1°C (be lower than 30°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed as low speed.

When heating, the setting temperature decreases 1°C (be higher than 17°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed as low speed. (Anti-cold wind function has the priority)

1.1.17.3 Timer setting is available

1.1.18 Refrigerant Leakage Detection

With this new technology, the display area

will show “EC” when the outdoor unit detects refrigerant leakage. This function is only available in cooling mode.

When compressor is active, the value of the Coil temperature of evaporator T2 has no change or very little change.

1.1.19 8°C Heating(optional)

In heating operation, the preset temperature of the air conditioner can be as lower as 8°C, which keeps the room temperature steady at 8°C and prevents household things freezing when the house is unoccupied for a long time in severe cold weather.

1.1.20 Self clean(optional)

For heat pump models which are provided with this function, after running in cooling or drying mode, if the user press “Self Clean” button on remote controller, firstly, indoor unit runs in fan only mode for a while, then low heat operation and finally runs in fan only again. This function can keep the inside of indoor unit dry and prevent breeding of mold.

1.1.21 Follow me(I-feel)

1) If the indoor PCB receives the signal which

results from pressing the FOLLOW ME button on remote controller, the buzzer will emit a sound and this indicates the follow me function is initiated. But when the indoor PCB receives signal which sent from remote controller every 3 minutes, the buzzer will not respond. When the unit is running with follow me function, the PCB will control the unit according to the temperature from follow me signal, and the temperature collection function of room temperature sensor will be shielded, but the error detective function of room temperature sensor will be still valid.

2) When the follow me function is available, the PCB will control the unit according to the room temperature from the remote controller and the setting temperature.

3) The PCB will take action to the mode

change information from remote controller signal, but it will not affected by the setting temperature.

4) When the unit is running with follow me function, if the PCB doesn't receive any signal from remote controller for 7 minutes or pressing FOLLOW ME button again, the follow me function will be turned off automatically, and the temperature will control the unit according to the room temperature detected from its own room temperature sensor and setting temperature.

10. Troubleshooting

10.1 Indoor Unit Error Display

Operation lamp	Timer lamp	Display	LED STATUS
☆ 1 time	X	E1	EEPROM parameter error
☆ 2 times	X	E2	Zero-crossing signal detection error
☆ 3 times	X	E3	Indoor fan speed has been out of control
☆ 5 times	X	E5	Indoor room temperature sensor T1 open circuit or short circuit
☆ 6 times	X	E6	Evaporator coil temperature sensor T2 open circuit or short circuit
☆ 7 times	X	E7	Condenser coil temperature sensor T3 open circuit or short circuit(only for MS12F-24HRN1-QB8W, MS12F-28HRN1-QB8W)
☆ 2 times	O	EC	Refrigerant Leakage Detection
☆ 9 times	X	E9	Indoor / outdoor units communication error(only for MS12F-24HRN1-QB8W, MS12F-28HRN1-QB8W)

O (light)

X (off)


☆ (flash)

10.2 Diagnosis and Solution

1.1.22 EEPROM parameter error diagnosis and solution(E1)

Error Code	E1
Malfunction decision conditions	Indoor or outdoor PCB main chip does not receive feedback from EEPROM chip.
Supposed causes	<ul style="list-style-type: none"> ● Installation mistake ● PCB faulty

Trouble shooting:




EEPROM: a read-only memory whose contents can be erased and reprogrammed using a pulsed voltage.

1.1.23 Zero crossing detection error diagnosis and solution(E2)

Error Code	E2
Malfunction decision conditions	When PCB does not receive zero crossing signal feedback for 4 minutes or the zero crossing signal time interval is abnormal.
Supposed causes	<ul style="list-style-type: none"> ● Connection mistake ● PCB faulty


Trouble shooting:



1.1.24 Fan speed has been out of control diagnosis and solution(E3)

Error Code	E3
Malfunction decision conditions	When indoor fan speed keeps too low (300RPM) for certain time, the unit will stop and the LED will display the failure.
Supposed causes	<ul style="list-style-type: none"> ● Wiring mistake ● Fan ass'y faulty ● Fan motor faulty ● PCB faulty


Trouble shooting:



Index1:

1: Indoor AC Fan Motor



Power on and set the unit running in fan mode at high fan speed. After running for 15 seconds, measure the voltage of pin1 and pin2. If the value of the voltage is less than 100V(208~240V power supply)or 50V(115V power supply), the PCB must has problems and need to be replaced.



1.1.25 Open circuit or short circuit of temperature sensor diagnosis and solution(E5)

Error Code	E5/E6/ E7
Malfunction decision conditions	If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED will display the failure.
Supposed causes	<ul style="list-style-type: none"> ● Wiring mistake ● Sensor faulty


Trouble shooting:



1.1.26 Refrigerant Leakage Detection diagnosis and solution(EC)

Error Code	EC
Malfunction decision conditions	<p>Define the evaporator coil temp.T2 of the compressor just starts running as Tcool.</p> <p>In the beginning 5 minutes after the compressor starts up, if $T2 < T_{cool} - 2^{\circ}C$ does not keep continuous 4 seconds and this situation happens 3 times, the display area will show “EC” and AC will turn off.</p>
Supposed causes	<ul style="list-style-type: none"> ● T2 sensor faulty ● Indoor PCB faulty ● System problems, such as leakage or blocking.


Trouble shooting:



1.1.27 Indoor / outdoor unit's communication diagnosis and solution(E9)

Error Code	E9
Malfunction decision conditions	Indoor unit does not receive the feedback from outdoor unit during 120 seconds.
Supposed causes	<ul style="list-style-type: none"> Wiring mistake Indoor or outdoor PCB faulty


Trouble shooting:



Main parts check

1. Temperature sensor checking

Disconnect the temperature sensor from PCB, measure the resistance value with a tester.



Temperature Sensors.

Room temp.(T1) sensor,

Indoor coil temp.(T2) sensor,

Outdoor coil temp.(T3) sensor,

Outdoor ambient temp.(T4) sensor,

Compressor discharge temp.(T5) sensor.

Measure the resistance value of each winding by using the multi-meter.

Appendix 1 Temperature Sensor Resistance Value Table for T1,T2,T3,T4 (°C--K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	115.266	20	68	12.6431	60	140	2.35774	100	212	0.62973
-19	-2	108.146	21	70	12.0561	61	142	2.27249	101	214	0.61148
-18	0	101.517	22	72	11.5	62	144	2.19073	102	216	0.59386
-17	1	96.3423	23	73	10.9731	63	145	2.11241	103	217	0.57683
-16	3	89.5865	24	75	10.4736	64	147	2.03732	104	219	0.56038
-15	5	84.219	25	77	10	65	149	1.96532	105	221	0.54448
-14	7	79.311	26	79	9.55074	66	151	1.89627	106	223	0.52912
-13	9	74.536	27	81	9.12445	67	153	1.83003	107	225	0.51426
-12	10	70.1698	28	82	8.71983	68	154	1.76647	108	226	0.49989
-11	12	66.0898	29	84	8.33566	69	156	1.70547	109	228	0.486
-10	14	62.2756	30	86	7.97078	70	158	1.64691	110	230	0.47256
-9	16	58.7079	31	88	7.62411	71	160	1.59068	111	232	0.45957
-8	18	56.3694	32	90	7.29464	72	162	1.53668	112	234	0.44699
-7	19	52.2438	33	91	6.98142	73	163	1.48481	113	235	0.43482
-6	21	49.3161	34	93	6.68355	74	165	1.43498	114	237	0.42304
-5	23	46.5725	35	95	6.40021	75	167	1.38703	115	239	0.41164
-4	25	44	36	97	6.13059	76	169	1.34105	116	241	0.4006
-3	27	41.5878	37	99	5.87359	77	171	1.29078	117	243	0.38991
-2	28	39.8239	38	100	5.62961	78	172	1.25423	118	244	0.37956
-1	30	37.1988	39	102	5.39689	79	174	1.2133	119	246	0.36954
0	32	35.2024	40	104	5.17519	80	176	1.17393	120	248	0.35982
1	34	33.3269	41	106	4.96392	81	178	1.13604	121	250	0.35042
2	36	31.5635	42	108	4.76253	82	180	1.09958	122	252	0.3413
3	37	29.9058	43	109	4.5705	83	181	1.06448	123	253	0.33246
4	39	28.3459	44	111	4.38736	84	183	1.03069	124	255	0.3239
5	41	26.8778	45	113	4.21263	85	185	0.99815	125	257	0.31559
6	43	25.4954	46	115	4.04589	86	187	0.96681	126	259	0.30754
7	45	24.1932	47	117	3.88673	87	189	0.93662	127	261	0.29974
8	46	22.5662	48	118	3.73476	88	190	0.90753	128	262	0.29216
9	48	21.8094	49	120	3.58962	89	192	0.8795	129	264	0.28482
10	50	20.7184	50	122	3.45097	90	194	0.85248	130	266	0.2777
11	52	19.6891	51	124	3.31847	91	196	0.82643	131	268	0.27078
12	54	18.7177	52	126	3.19183	92	198	0.80132	132	270	0.26408
13	55	17.8005	53	127	3.07075	93	199	0.77709	133	271	0.25757
14	57	16.9341	54	129	2.95896	94	201	0.75373	134	273	0.25125
15	59	16.1156	55	131	2.84421	95	203	0.73119	135	275	0.24512
16	61	15.3418	56	133	2.73823	96	205	0.70944	136	277	0.23916
17	63	14.6181	57	135	2.63682	97	207	0.68844	137	279	0.23338
18	64	13.918	58	136	2.53973	98	208	0.66818	138	280	0.22776
19	66	13.2631	59	138	2.44677	99	210	0.64862	139	282	0.22231

EXPLODED VIEW AND SPARE PART LIST




Appendix 2 Temperature Sensor Resistance Value Table for T5 (°C --K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	542.7	20	68	68.66	60	140	13.59	100	212	3.702
-19	-2	511.9	21	70	65.62	61	142	13.11	101	214	3.595
-18	0	483	22	72	62.73	62	144	12.65	102	216	3.492
-17	1	455.9	23	73	59.98	63	145	12.21	103	217	3.392
-16	3	430.5	24	75	57.37	64	147	11.79	104	219	3.296
-15	5	406.7	25	77	54.89	65	149	11.38	105	221	3.203
-14	7	384.3	26	79	52.53	66	151	10.99	106	223	3.113
-13	9	363.3	27	81	50.28	67	153	10.61	107	225	3.025
-12	10	343.6	28	82	48.14	68	154	10.25	108	226	2.941
-11	12	325.1	29	84	46.11	69	156	9.902	109	228	2.86
-10	14	307.7	30	86	44.17	70	158	9.569	110	230	2.781
-9	16	291.3	31	88	42.33	71	160	9.248	111	232	2.704
-8	18	275.9	32	90	40.57	72	162	8.94	112	234	2.63
-7	19	261.4	33	91	38.89	73	163	8.643	113	235	2.559
-6	21	247.8	34	93	37.3	74	165	8.358	114	237	2.489
-5	23	234.9	35	95	35.78	75	167	8.084	115	239	2.422
-4	25	222.8	36	97	34.32	76	169	7.82	116	241	2.357
-3	27	211.4	37	99	32.94	77	171	7.566	117	243	2.294
-2	28	200.7	38	100	31.62	78	172	7.321	118	244	2.233
-1	30	190.5	39	102	30.36	79	174	7.086	119	246	2.174
0	32	180.9	40	104	29.15	80	176	6.859	120	248	2.117
1	34	171.9	41	106	28	81	178	6.641	121	250	2.061
2	36	163.3	42	108	26.9	82	180	6.43	122	252	2.007
3	37	155.2	43	109	25.86	83	181	6.228	123	253	1.955
4	39	147.6	44	111	24.85	84	183	6.033	124	255	1.905
5	41	140.4	45	113	23.89	85	185	5.844	125	257	1.856
6	43	133.5	46	115	22.89	86	187	5.663	126	259	1.808
7	45	127.1	47	117	22.1	87	189	5.488	127	261	1.762
8	46	121	48	118	21.26	88	190	5.32	128	262	1.717
9	48	115.2	49	120	20.46	89	192	5.157	129	264	1.674
10	50	109.8	50	122	19.69	90	194	5	130	266	1.632
11	52	104.6	51	124	18.96	91	196	4.849			
12	54	99.69	52	126	18.26	92	198	4.703			
13	55	95.05	53	127	17.58	93	199	4.562			
14	57	90.66	54	129	16.94	94	201	4.426			
15	59	86.49	55	131	16.32	95	203	4.294			
16	61	82.54	56	133	15.73	96	205	4.167			
17	63	78.79	57	135	15.16	97	207	4.045			
18	64	75.24	58	136	14.62	98	208	3.927			
19	66	71.86	59	138	14.09	99	210	3.812			

11. Exploded view and spare part list

11.1 ELSI-JMF009-N11




EXPLODED VIEW AND SPARE PART LIST



No.	BOM Code	Part Name	Quantity
1	12122000A01472	Panel assembly	1
2	12100204000673	Filter	2
3	17222000A00835	Structure Subassembly of Display Box	1
3.1	17122000A02292	VLED Display Module	1
4	12122000006694	E-Parts Cover Plate	1
5	12122000001883	frame assembly	1
5.1	12122000006272	Screw Cap	2
6	12100501000021	Drain Hose	1
7	15500406000010	Brass Nut	1
7	15500406000016	Brass Nut	1
8	12100303000008	Temperature Sensing Element Fixing clip	1
9	15822000000363	Evaporator assembly Gas valve assembly	1
10	12122000005431	Motor Bearing Cover	1
11	11002012002778	Single-phase Asynchronous Motor	1
12	12122000000350	Bearing sleeve	1
13	12622000000006	Bearing pedestal	1
14	12100102000036	Cross-flow window rotor	1
15	12122000005105	Wind Guide Assembly	1
16	12122000004172	Chassis Assembly	1
16.1	11002010000143	stepper motor	1
17	12122000000445	Pipe Pressing Board	1
18	12222000000024	Installation Plate	1
19	17222000009192	Electronic control box assembly	1
19.1	12122000007835	Electrical Control Box	1
19.2	12122000011004	Electronic control box II	1
19.3	17122000018554	Indoor Main Control Board Subassembly (Sticker)	1
19.4	11201007000088	Room Temperature Sensor	1
19.5	11201007000001	Temperature Sensor	1
19.6	17400401000094	Wire holder	1
19.7	11203103000014	Power Transformer	1
20	12122000004994	Electrical Control Box Cover	1
21	17317000A02580	Remote controller	1
22	12600701000039	Seal	1
23	12100509000061	Extend Water Pipe	1
24	12100204000685	Filter net of cold catalyst	1
53	12011600000015	Kit of Screw Accessories	1

11.2 ELSI-JMF012-N11




EXPLODED VIEW AND SPARE PART LIST



No.	BOM Code	Part Name	Quantity
1	12122000A01154	Panel assembly	1
3	17222000002800	Structure Subassembly of Display Box	1
3.1	17222000A00835	VLED Display Module	1
4	17122000A02292	E-Parts Cover Plate	1
5	12122000001749	frame assembly	1
5.1	12122000006272	Screw Cap	2
6	12100501000021	Drain Hose	1
7	15500406000010	Brass Nut	1
7	15500406000016	Brass Nut	1
8	12100303000008	Temperature Sensing Element Fixing clip	1
9	15822000003678	Evaporator assembly	1
10	12122000005431	Motor Bearing Cover	1
11	11002012003727	Single-phase Asynchronous Motor	1
12	12122000000350	Bearing sleeve	1
13	12622000000006	Bearing pedestal	1
14	12100102000022	Cross-flow Window Rotor.	1
15	12122000005123	Wind Guide Assembly	1
16	12122000004342	Chassis Assembly	1
16.1	11002010000143	stepper motor	1
17	12122000000445	Pipe Pressing Board	1
18	12222000000012	Installation Plate	1
19	17222000010050	Electronic control box assembly	1
19.1	12122000004586	Electrical Control Box	1
19.2	12122000004565	Electrical Control Box	1
19.3	17122000019631	Indoor Main Control Board Subassembly (Sticker)	1
19.4	11201007000221	Room Temperature Sensor	1
19.5	11201007000322	Temperature Sensor	1
19.6	17400401000094	Wire holder	1
19.7	11203103000014	Power Transformer	1
20	12122000004994	Electrical Control Box Cover	1
21	17317000A02580	Remote controller	1
22	12600701000039	Seal	1
23	12100509000061	Extend Water Pipe	1
24	12100204000685	Filter net of cold catalyst	1
25	12100204000633	Air filter	1
26	12100204000634	Right side of the filter	1
53	12011600000015	Kit of Screw Accessories	1


11.3 ELSI-JMF018-N11



EXPLODED VIEW AND SPARE PART LIST


No.	BOM Code	Part Name	Quantity
1	12122000A00653	Panel assembly	1
2	12100204000667	Filter	2
3	17222000A00835	Structure Subassembly of Display Box	1
3.1	17122000A02292	VLED Display Module	1
4	12122000006694	E-Parts Cover Plate	1
5	12122000001747	Panel frame assembly	1
5.1	12122000006272	Screw Cap	2
6	12100501000021	Drain Hose	1
7	15500406000016	Brass Nut	1
7	15500406000012	Brass Nut	1
8	12100303000008	Temperature Sensing Element Fixing clip	1
9	15822000004016	Evaporator assembly	1
10	12122000008147	Motor Bearing Cover	1
11	11002012000502	Single-phase Asynchronous Motor	1
12	12122000000350	Bearing sleeve	1
13	12622000000006	Bearing pedestal	1
14	12100102000072	Cross-flow window rotor	1
15	12122000006245	Wind Guide	1
16	12122000004388	Chassis Assembly	1
16.1	11002010000143	stepper motor	1
17	12122000000445	Pipe Pressing Board	1
18	12222000000011	Installation Plate	1
19	17222000010048	Electronic control box assembly	1
19.1	12122000004586	Electrical Control Box	1
19.2	12122000009440	Electrical Control Box	1
19.3	17122000019629	Indoor Main Control Board Subassembly (Sticker)	1
19.4	11201007000088	Room Temperature Sensor	1
19.5	11201007000322	Temperature Sensor	1
19.6	17400401000094	Wire holder	1
19.7	11203103000014	Power Transformer	1
20	12122000004994	Electrical Control Box Cover	1
21	17317000A02580	Remote controller	1
22	12600701000039	Seal	1
23	12100509000061	Extend Water Pipe	1
24	12100204000685	Filter net of cold catalyst	1
53	12011600000015	Kit of Screw Accessories	1

11.4 ELSI-JMF024-N11




EXPLODED VIEW AND SPARE PART LIST



No.	BOM Code	Part Name	Quantity
1	12122000A01256	Panel assembly	1
2	12100204000669	Air filter	1
3	12100204000658	Right side of the filter	1
4	17222000A00835	Structure Subassembly of Display Box	1
4.1	17122000A02292	VLED Display Module	1
5	12122000006693	E-Parts Cover Plate	1
6	12122000001907	frame assembly	1
6.1	12122000006272	Screw Cap	3
7	12122000008048	Wind Guide	1
8	12122000005591	Air Out Frame Assembly	1
8.1	11002010000015	stepper motor	1
9	12100501000021	Drain Hose	1
10	15500406000003	Brass Nut	1
10	15500406000010	Brass Nut	1
11	12100303000008	Temperature Sensing Element Fixing clip	1
12	15822000003901	Evaporator assembly Gas valve assembly	1
13	12122000005516	Motor Bearing Cover	1
14	12122000006772	Fixing board for motor	1
15	11002012000503	Single-phase Asynchronous Motor	1
16	12122000000350	Bearing sleeve	1
17	12622000000006	Bearing pedestal	1
18	12100102000002	Cross-flow window rotor	1
19	12122000007937	Chassis Assembly	1
20	12222000000054	Pipe Pressing Board	1
21	12222000000008	Installation Plate Subassembly	1
22	17222000010049	E-Parts Box assembly of Split Indoor Unit	1
22.1	12122000004598	Electrical Control Box	1
22.2	17122000019630	Indoor Main Control Board Subassembly (Sticker)	1
22.3	11203103000158	Power Transformer	1
22.4	11201007000003	Room Temperature Sensor	1
22.5	11201007000126	Temperature Sensor	1
22.6	17400401000028	Wire holder	1
23	12122000005046	Electrical Control Box Cover	1
24	17317000A02580	Remote controller	1
25	12600701000039	Seal	1
26	12100509000061	Extend Water Pipe	1
27	12100204000685	Filter net of cold catalyst	1

11.5 ELAU-VMF009-H11




EXPLODED VIEW AND SPARE PART LIST



No.	BOM Code	Part Name	Quantity
2	15822000003816	Condenser Assembly	1
4	12222000005064	Chassis assembly	1
5	12222000005065	Right clapboard	1
6	12100701000015	Big Handle.	1
7	12122000007150	Water Collecting Cover	1
8	12222000005067	Front panel assembly	1
8.1	12122000A03621	Air outlet grille	1
9	12222000005072	Top cover assembly	1
10	12100105000057	Axial fan	1
11	11002012008961	Single-phase Asynchronous Motor	1
12	12222000005068	Supporter assembly of fan motor	1
13	12222000005066	Left supporter	1
14	12222000005069	Partition board	1
15	12200203000019	Capacitor Clamp	1
16	17400103000011	Compressor Capacitor(Round)	1
17	17400401000057	Wire holder	1
18	12222000005070	Supporting board	1
19	17400101000082	Capacitor	1
20	15422000005094	Gas Valve Assembly	1
20.1	15500204000014	Low Pressure Valve	1
20.2	15500216000008	4-way Valve	1
21	15422000005095	High-Voltage valve Assembly	1
21.1	15500208000028	Liquid valve	1
21.2	12222000002571	Installing plate for valves	1
22	11103010001683	Fixed speed rotary compressor	1
24	15500406000016	Brass Nut	1
24	15500406000010	Brass Nut	1

11.6 ELAU-VMF012-H11




EXPLODED VIEW AND SPARE PART LIST



No.	BOM Code	Part Name	Quantity
2	15822000003860	Condenser assembly	1
4	12222000000632	Chassis Assembly	1
5	122220000003597	Parts fn Right Side Plate	1
6	12100701000015	Big Handle.	1
7	121220000007150	Water Collecting Cover	1
8	122220000004422	Front panel assembly	1
8.1	12122000A03621	Air outlet grille	1
9	122220000003598	Top cover assembly	1
10	121001050000057	Axial fan	1
11	11002012008961	Single-phase Asynchronous Motor	1
12	122220000004187	Supporter assembly of fan motor	1
13	122220000001232	Left Side Floor	1
14	122220000002235	Separation plate	1
15	122002030000018	Capacitor Clamp	1
16	174001030000055	Compressor Capacitor(Round)	1
17	174004010000080	Wire holder	1
18	122220000001591	Installation board for E-parts	1
19	174001010000083	Capacitor	1
20	154220000004773		1
20.1	155002040000262	Low Pressure Valve	1
20.2	15422000A00886	4-way Valve	1
20.3	122220000002571	Installing plate for valves	1
21	154220000005372	Liquid valve assembly	1
21.1	155002080000028	Liquid valve	1
22	111030100000467	Fixed speed rotary compressor	1
24	155004060000016	Brass Nut	1
24	155004060000010	Brass Nut	1

11.7 ELAU-VMF018-H11




EXPLODED VIEW AND SPARE PART LIST



No.	BOM Code	Part Name	Quantity
2	15822000003516	Condenser Assembly	1
4	12222000000632	Chassis Assembly	1
5	122220000003597	Parts fn Right Side Plate	1
6	12100701000015	Big Handle.	1
7	121220000007150	Water Collecting Cover	1
8	122220000004422	Front panel assembly	1
8.1	12122000A03621	Air outlet grille	1
9	122220000003598	Top cover assembly	1
10	12100105000004	Axial fan	1
11	11002012008761	Single-phase Asynchronous Motor	1
12	122220000004185	Supporter assembly of fan motor	1
13	122220000001232	Left Side Floor	1
14	122220000002235	Separation plate	1
15	122002030000018	Capacitor Clamp	1
16	174001030000010	Compressor Capacitor(Round)	1
17	174004010000080	Wire holder	1
18	122220000001591	Installation board for E-parts	1
19	174001010000084	Capacitor	1
20	154220000005113	4-way Valve assy.	1
20.1	155002040000058	Low Pressure Valve	1
20.2	155002160000003	4-way Valve	1
21	154220000005112	Liquid valve assembly	1
21.1	155002080000028	Liquid valve	1
22	11103010002529	Fixed Speed Rotary Compressor	1
24	155004060000016	Brass Nut	1
24	155004060000012	Brass Nut	1

11.8 ELAU-VMF024-H11



EXPLODED VIEW AND SPARE PART LIST



No.	BOM Code	Part Name	Quantity
2	12122000007150	Water Collecting Cover	1
3	15122000011523	4-way valve assembly	1
3.1	15500204000025	Low Pressure Valve	1
3.2	15500216000003	4-way Valve	1
4	12122000A03617	Air outlet grille	1
5	17222000009751	Electronic control box assembly	1
5.3	17122000002618	Subassembly of Outdoor Main Control Board	1
5.5	12200203000006	Capacitor Clamp	1
5.6	17400103000033	Compressor Capacitor(Round)	1
5.7	17400401000096	Wire holder	1
5.7	17400401000012	Wire holder	1
5.8	17400101000084	Capacitor	1
5.9	12222000005082	Electronic installing plate	1
5.10	11203502000095	AC contactor	1
6	12100701000015	Big Handle.	1
7	12222000004923	Supporter assembly of fan motor	1
8	11002012008460	Single-phase Asynchronous Motor	1
9	12222000004794	Left side plate assembly	1
11	11103010002609	Fixed Speed Rotary Compressor	1
12	12222000004795	Top cover assembly	1
13	15500406000003	Brass Nut	1
13	15500406000010	Brass Nut	1
14	12222000004784	Partition board assembly	1
15	15822000003636	Condenser Assembly	1
17	12222000004823	Chassis assembly	1
17.1	12222000004786	Chassis	1
17.2	12222000004788	Footing	2
19	15422000005152	Liquid valve assembly	1
19.1	15500208000023	Liquid valve	1
19.2	12222000002571	Installing plate for valves	1
20	12222000004822	Front panel	1
21	12222000004785	Right side plate	1
23	11201007000136	Temperature Sensor	1
24	12100105000181	Axial fan	1



SERVICE MANUAL

JMF ON-OFF Series