

HISTORY OF THE DOCUMENT

Reference **IOM RT 04-N**
 Oracle code **3990475**
 Designation **ROOFTAIR 40 / 110 (HFC410A)**

DATE	REVISION	DESCRIPTION	PAGE
03/12/2008	6	Modifying Electrical specifications Setting of thermal protections and contactor current Pre-heating time of compressors EC declaration, signature of Yann Mousset	8 15 20
24/12/2008	7	Modifying Electrical wiring diagram	XXIX
20/03/2009	8	Adding accessory weight Modifying setting Q3 S3 supply arrangement dimensions EC declaration, signature of Sébastien blard	7 15 XVI
27/04/2009	9	Modifying electric heater weight RT 60/70/80/100/110 capacity CH2 RT 60/70/80/100/110 S1 supply arrangement dimensions RT 60/70/80/100/110	7 8 XV
07/09/2009	10	Modifying crankcase heater S4 supply arrangement dimensions electrical wiring diagram SE3377	20 XVI XXII
24/03/2010		Modifying machine directive of EC declaration	
15/07/2010		Modifying EC declaration	
12/01/2011	11	Adding RT30 smoke detector maintenance Modifying position of centre of gravity electrical specifications cable entry dimensions RT 60/70/80 dimensions RT 100/110 S1 supply arrangement dimensions RT 30/40/50 S2 supply arrangement dimensions RT 30/40/50 S3 supply arrangement dimensions RT 30/40/50 S4 supply arrangement dimensions RT 30/40/50 R3 return arrangement dimensions electrical wiring diagram SE3377 electrical wiring diagram SE33781 electrical wiring diagram SE33782 electrical wiring diagram SE3563 electrical wiring diagram SE33791 electrical wiring diagram SE3559 electrical wiring diagram SE33793	23 7 8 17 IV V XV XV XVI XVI XVIII XXII XXIII XXIV XXVI XXVII XXIX XXX

01/03/2012	12	Modifying technical specifications weights electrical specifications economizer electric heater list of electrical wiring diagrams legend of electrical wiring diagrams Setting of thermal protections and contactor current cable entry RT100-110 air balancing S2 supply arrangement dimensions RT 80/100/110 R4 return arrangement dimensions refrigerant flow diagram electrical wiring diagram SE3563 electrical wiring diagram SE33791 Adding hot water coil dimensions	6 7 8 12 12 13 13 - 14 - 15 15 - 16 18 20 XV XVIII XX XXVI XXVII III - IV - V
03/07/2012	13	Modifying electrical wiring diagram SE3377 electrical wiring diagram SE33781 electrical wiring diagram SE33782	XXII XXIII XXIV
31/05/2013	14	Adding weight of extract fan Modifying compatibility between economizer and return configuration electrical wiring diagram SE3377 electrical wiring diagram SE33782 electrical wiring diagram SE3380 electrical wiring diagram SE33792	7 12 XXII XXIV XXV XXVIII
24/06/2013	15	Modifying dimensions supply air S3 RT 30 hot water	XVI