
WELLZONE 3V



Airwell Controller

- Components
- Accessories
- Diameters
- Control (Damper Actuator)




WELLZONE 4V




Airwell Controller


- Components
- Accessories
- Diameters
- Control (Damper Actuator)




WELLZONE 4V-5S




WELLZONE 5V


Airwell Controller
Components
Accessories
Diameters
Control (Damper Actuator)
SUPPLY AIR PLENUM 400 X 150
SUPPLY AIR GRILLE 400 X 150
Zone 1
Zone 2
Zone 3
Zone 4
Zone 5
DUCT REDUCER 250/200
Ø 200
Ø 250
SUPPLY AIR
DUCTED UNIT
RETURN AIR
Airwell
GRILLE 600x400 + RETURN AIR PLENUM 600x400 (Located in the hallway)

WELLZONE 5V-6S



WELLZONE 6V


Components
Accessories
Diameters
Control (Damper Actuator)
Airwell Controller
SUPPLY AIR PLENUM 400 X 150
SUPPLY AIR GRILLE 400 X 150
Zone 1
Zone 2
Zone 3
Zone 4
Zone 5
Zone 6
DUCT REDUCER 250/200
Ø 200
SUPPLY AIR
DUCTED UNIT
RETURN AIR
Airwell
Ø 250
GRILLE 600x400 + RETURN AIR PLENUM 600x400 (Located in the hallway)